

UMS Serialine

Unique serial numbers on every product – User Manual

Sep 30, 2026 · @Jarryd James

Welcome to Serialine

Serialine prints a unique serial number on every product on your line, straight from your Excel or CSV file. Each product that passes the sensor gets the next serial, in order, and every print is recorded.

What Serialine does for you:

- **One serial per product.** Printing is triggered by your line sensor, so a serial only goes on a product that is actually there.
- **No duplicates.** The printer checks the serial sequence itself and never prints the same serial twice.
- **Works from your own files.** Use the Excel or CSV list you already have. No database or special software needed.
- **Full traceability.** A print log records every serial with its date and time, ready for your batch records.
- **Safe restarts.** After a stop, a power cut or a closed window, Serialine continues from the first unprinted serial.
- **Controlled reprints.** A batch can be printed again only after an explicit confirmation, and the original log is kept.
- **Simple to use.** Double-click, choose the file, press ENTER. No installation and no technical knowledge needed.

How it works

Serialine sends your serials to the printer; your line sensor decides when each one is printed.

1. **Your serial file** – a list of unique serial numbers in Excel or CSV.
2. **Serialine** – reads the file and sends the serials to the printer over the network.
3. **Printer queue** – the printer holds up to 255 serials ready to print.
4. **Line sensor** – each product passing the sensor triggers one print.
5. **Printed product** – the product receives the next serial in the list.

6. **Print log** – Serialine records the printed serial with date and time, and tops up the queue.

When the last serial is printed, Serialine stops the printer automatically.

What you need

Your UMS technician sets up and tests all of this at installation.

Item	Requirement
Computer	Windows 10 or 11 laptop or PC, on the same network as the printer
Printer	Leibinger JET2neo, configured by UMS for Serialine
Line sensor	Photo-eye connected to the printer's print trigger input
Network	Ethernet connection between the computer and the printer
Serialine folder	<code>Serialine.exe</code> and <code>printer_settings.txt</code> , installed by UMS
Serial file	Excel (<code>.xlsx</code>) or CSV (<code>.csv</code>) file – see the next section

Computer settings: keep the computer plugged in and set to **never sleep** while plugged in. A computer that goes to sleep stops the batch.

Preparing your serial file

One file = one batch. Save it in the Serialine folder, with a name that identifies the batch, e.g. `Batch2026-041.xlsx`.

Rules:

1. Serials in **column A** of the **first sheet**, starting in cell **A1**.
2. **No heading row**. Anything in A1 is printed as the first serial.
3. One serial per row, printed top to bottom.
4. Every serial must be **unique**. Serialine refuses a file that contains a serial twice.
5. Serials must fit the print field set up on your printer (ask UMS for the maximum length).

6. Leading zeros are kept: 000123 prints as 000123 .

Example (Excel, first sheet):

	A
1	AV20260000001
2	AV20260000002
3	AV20260000003
4	AV20260000004

Empty rows are skipped.

Printing a batch

The daily procedure takes under a minute to start.

Before you start:

- ☐ Printer on, correct job loaded, jet running
- ☐ Printer printing **stopped** ("Ready for print start")
- ☐ Serial file saved in the Serialine folder

Start the batch:

1. Double-click **Serialine.exe** in the Serialine folder.
2. Serialine lists the files in the folder. Type the **number** of your batch file and press **ENTER**.
3. Check the line **Printing records 1..N**. **N must match the number of serials in your batch**.
4. Serialine loads the first serials into the printer and shows **Press ENTER to start printing**.
5. Press **ENTER**. The printer starts and waits for products.
6. Run the line. Each product gets the next serial; the screen shows **[PRINTED]** with the serial.
7. After the last serial, the printer stops automatically and the screen shows **[SUCCESS]**.
8. Press **ENTER** to close Serialine.

During printing: leave the Serialine window open and the computer on. Do not change the job on the printer while a batch is running.

Stops, restarts and reprints

Serialine always continues from the first unprinted serial. No serial is skipped or printed twice.

The printer stops during a batch (error, or Stop pressed):

1. The screen shows [STOPPED] Printing stopped after record X.
2. Fix the cause and acknowledge any message on the printer.
3. Check the last product: it should carry serial number X in your list.
4. When Serialine shows Press ENTER to start printing, press **ENTER**. Printing continues from serial X+1.

Serialine was closed, or the computer restarted:

1. Stop printing on the printer.
2. Start Serialine and choose the **same file**.
3. Serialine reads the print log and continues from the first unprinted serial.

Printing a completed batch again:

1. **Remove the products from the first print** that carry these serials, so no serial exists twice.
2. Start Serialine and choose the same file.
3. At This batch is already fully printed. Print it again? (y/N), type **y** and press ENTER.
4. Type **YES** in capitals and press ENTER to confirm.
5. The original log is kept and a new log is started.

Blank product at the end of a batch: a product that reaches the sensor right after the last serial, before the printer has stopped, receives a blank print. Remove it from the line.

Your print log

For every batch, Serialine writes a log in the Serialine folder named after the batch file:

Batch2026-041.xlsx → Batch2026-041_log.csv . It opens in Excel.

timestamp	record	serial
2026-10-06T08:14:02	1	AV2026000001
2026-10-06T08:14:03	2	AV2026000002
2026-10-06T08:14:03	3	AV2026000003

- **Keep every log** with the batch records. Serialine also uses it to continue after a stop.
- **Do not edit, rename or delete a log** while its batch is not finished.
- After a reprint, the earlier log is kept as
`<batch>_log_before_reprint_<date>_<time>.csv`.
- Back up the Serialine folder regularly, for example to a network drive.

Troubleshooting

Most messages are solved on the printer screen. If a problem remains, contact UMS support with a photo of the Serialine window.

Message or symptom	What it means	What to do
Printer is PRINTING - stop printing on the printer	Printing was already running	Stop printing on the printer. Serialine continues by itself
Printer reports error/message NNNN	A message is waiting on the printer	Read and acknowledge it on the printer screen
Printer state: ... - start the jet	The jet is not ready	Start the jet and wait until the printer is ready
[STOPPED] Printing stopped after record X	Printing stopped partway	See "Stops, restarts and reprints"
cannot connect or No reply	Computer cannot reach the printer	Check the network cable and that the printer is on. Then contact UMS
Dataset contains duplicate serials	A serial appears twice in the file	Correct the file, then start again
Serial ... contains a TAB or line break	A cell has hidden characters	Retype that serial in the file
... does not match the data file	The file changed after printing started, or a log from another batch has this name	Contact UMS before printing
Nothing left to print	The batch is already complete	Nothing to do. To print it again, see "Stops, restarts and reprints"

Message or symptom	What it means	What to do
First product shows a heading, not a serial	Heading in cell A1	Delete row 1 so A1 holds the first serial
Serial is cut off on the product	Serial longer than the print field	Contact UMS to adjust the print field
<code>Serialine.exe</code> is missing or blocked	Antivirus quarantined it	Ask your IT department to allow <code>Serialine.exe</code>

Support

UMS installs, tests and supports Serialine on your line. When you call, have the batch file name and a photo of the Serialine window ready.

Support phone	_____
Support email	_____
Your UMS technician	_____
Installed on	_____
Printer serial number	_____
Printer IP address	_____