



2.04 Tire Pressure Control System

1. Purpose

The purpose of the Standard Operating Procedure is to identify the hazards and define the steps for tire pressure control system .

2. Scope

This procedure is intended for use by all Silverpoint employees .

3. Hazard Identification

- Physical Stress .
- Bending and Stretching Strains .
- Personal Injury .
- Eye Injury .
- Pinch Points .
- Slips, Trips and Falls .
- Faulty Equipment
- Equipment Failure
- Discharging Air
- Dust
- Debris
- Lack of Knowledge

4. EHS Requirements

- Fire Retardant Coveralls .
- Steel Toed Boots .
- Safety Glasses .
- Gloves .
- Hard Hat .
- Hearing Protection .



- Bending and Lifting Techniques .
- Knowledge of the TPC Control Box and its Warning Signs .
- Knowledge of the TPC Controls for VT 124
- Full Knowledge of Equipment

5. References

- Silverpoint Corporate Codes of Practice
- Alberta OH&S
- Silverpoint Task List
- Silverpoint THA 2.04
- Tire Boss Manual Operations Manual

6. Procedure

6.1. Start-up.

- 6.1.1. The intended purpose of the tire boss system is to deflate tire pressure to lower the environmental impact while land spreading . To make the ride smoother and provide better traction in sand and soft ground .
- 6.1.2. Ensure all wheel valves are open by walking around the vacuum truck and opening each tire valve . When opening the valves , listen for air movement between the two tires , if a significant amount of air transfers between the tires it is indicating an air leak in one of the tires , monitor that set of tires for leakage .
- 6.1.3. Turn on control box in cab . VT 124 has a different TPC control box . This unit has a pressure display gauge and a valve for Inflating and Deflating . This system is preset to a certain psi (it may be anywhere from 30psi to 50psi) . This control box is on , as long as the truck is running .
- 6.1.4. When the control box is turned on the display will go through a start-up procedure and will then display the current pressure setting and description .

Example : Setting 5 Primary Empty 70 psi

6.2. Normal Operation .

- 6.2.1. After start-up , the screen will display the normal operation display showing the status (Inflating , Deflating or OK) and the PSI of the current setting and km speed traveled .
- 6.2.2. At pre-set intervals the setting number and description will flash on the screen .
- 6.2.3. Refer to 6.1.3 for VT 124 about operation .



6.3. Changing Settings .

- 6.3.1. Pushing the up arrow or down arrow button once will display the current setting number and description .
- 6.3.2. To change the setting , repeatedly push the up or down arrow to scroll through the settings . Stop at the desired setting number and the controller will automatically accept this setting . If you have to change settings pull over and do so. It's considered a distraction when driving .

6.4. Maintenance – Refer to Tire Boss Manual in the operations manual or call shop . Employees should have reviewed video upon hiring . Check for air leaks , damaged valves or fittings .

6.5. Safety Warnings .

- 6.5.1. Low Air Supply – If the supply air pressure drops below a safe level , the **LOW AIR SUPPLY WARNING** will sound and flash . The system will be inoperable until the air pressure builds to an acceptable level . On VT 124, solid red light, no alarm, beside pressure gauge , indicates tire pressure loss . Light goes out when pressuring up (around 60psi) .
- 6.5.2. Tire Pressure Loss – If a loss in tire pressure occurs and the system is not able to maintain pressures , the **TIRE PRESSURE LOSS** alarm will sound and flash indicating there is a specific tire pressure loss is occurring . In any case , stop the vehicle immediately and close all tire valves . Then find and fix the problem . If you have any questions don't hesitate to call the shop .
- 6.5.3. Over Speed Condition – If the vehicle exceeds the set point for a specific **PRESSURE SETTING** , an alarm will sound and flash . The operator must then slow down or change **PRESSURE SETTINGS** . If the alarm continues , the system will automatically change the **PRESSURE SETTING** to the next higher level .
- 6.5.4. Tire Chains - Please receive proper training on how to install tire chains properly with a TPC system and how to keep the tire chains tight , loose tire chains can tear off TPC lines . Tire chains **CAN** be used with the TPC systems .

6.6. Notes .

- 6.6.1. The whole system can take anywhere from 4 to 10 minutes to inflate the tires , so it is suggested to switch to the next setting prior to completing the previous setting . For example , when leaving the spread field empty and approaching a secondary gravel road , switch from setting 7 to setting 2 prior to your approach .
- 6.6.2. This is not necessary when deflating the tires as deflation will occur almost immediately .
- 6.6.3. If you are shutting the vacuum truck down , air the tires to highest setting and remember to **CLOSE TIRE BOSS VALVES** and shut off the control box in cab . One small leak can flatten all the tires if the valves are open . When starting truck back up make sure you walk around and open tire boss valves up . When traveling have your TPC system operating . Make sure that your tires are full with the Gallop systems as well .



- 6.6.4. TPC repair kits are supplied in all the trucks ; you will find extra lines , fittings and valves . If fittings are used , write in truck PMI or let your supervisor know, so they can be replaced .

Remember : if you are in doubt about what to do, call your Supervisor