



2.08 Pre/Post Inspection

1. Purpose

The purpose of a Pre/Post trip inspection is to identify systems or parts of a vacuum truck or well site trailer that are not working properly, have failed, or are missing parts so that they can be replaced or repaired before they cause harm. Regular inspections decrease downtime and associated costs. These costs include fines, towing, travel, and overtime of company mechanics, repair costs, and delays when using local garages.

2. Scope

This procedure is intended for use by all Silverpoint employees and Transportation Operators.

3. Hazard Assessment & Identification

- Slips, Trips and Falls
- Bending and Twisting
- Pushing and Pulling
- Pinch Points
- Mental Stress
- Physical Stress
- Wildlife
- Environmental
- Rocks and Holes
- Adverse Weather

4. EHS Requirement

- Fire retardant coveralls.
- Steel toed boots.
- Safety glasses.
- Gloves.
- Hardhat
- Hearing Protection



- Pre/Post Trip Book
- Logbook

5. References

- Silverpoint Corporate Codes of Practice
- Alberta OH&S
- National Safety Code
- Silverpoint Task List
- Silverpoint THA 2.08

6. Procedure

This procedure can be used for both a truck and trailer combination or a truck alone.

6.1. Chock block the wheels to keep the vehicle from moving.**6.2. Driver requirements**

- 6.2.1. Driver's license
- 6.2.2. Up to date logbook
- 6.2.3. 4 gas monitor, monitor kit, harness and lanyard (not in water trucks)
- 6.2.4. Fuel cards
- 6.2.5. Insurance, registration (up to date)
- 6.2.6. Original CVIP and up to date sticker
- 6.2.7. Operations binder

6.3. How to use the pre/post trip inspection book

- 6.3.1. Check off where the inspection occurred, use the "other" box if you are in the field and write in the land location you are at.
- 6.3.2. Check off pre/post trip inspection (which ever applies)
- 6.3.3. Fill in vehicle make (Kenworth, Freightliner, Western Star etc.)
- 6.3.4. Write in the start mileage for pre-trip and finish mileage for post trip.
- 6.3.5. Write in inspection date.



- 6.3.6. Write in inspection time.
- 6.3.7. Write in truck unit number.
- 6.3.8. Write in trailer unit number (if applicable).
- 6.3.9. Print your name on the inspector /driver's name line.
- 6.3.10. When a defect is found, find the appropriate check box and check that box. The checkboxes are very general so you will have to specify in writing what the defect is in the remarks section, be sure to mark the proper box in term of truck or trailer.
- 6.3.11. When working 12-hour shifts, have your cross shift sign off on your post trip inspection, during your crossover. Making him aware of any defects found on your post trip and route.

7. Pre/Post trip inspection general information

- 7.1. Always start at the same place when completing a pre/post trip inspection, this way you will develop a routine and will make the inspections consistent.
- 7.2. Be sure to take hold of things you are checking to confirm that they are secure.
- 7.3. Inspect overall unit for:
 - 7.3.1. Is the front of the truck sitting level or leaning to one side (this can indicate a front suspension problems)
 - 7.3.2. Look down the side of the truck, do the rear tires line up with each other (if not might indicate suspension problems)
 - 7.3.3. Is the cab sitting level (air ride cabs must be aired up to check this)
 - 7.3.4. Is there any visible body damage on the truck.
 - 7.3.5. Is the rear of the truck sitting level or leaning to one side (this can indicate a rear suspension problems)
 - 7.3.6. Is the trailer sitting level or leaning to one side (this can indicate a trailer suspension problems)
 - 7.3.7. Is there any visible body damage to the trailer.

8. Truck Inspection

- 8.1. Inspect under the hood of the truck to ensure that the following are in good working condition : before opening hood, check hood straps are in good condition .
 - 8.1.1. Engine oil level, look for leaks from the engine.
 - 8.1.2. Engine coolant level, look for leaks from the cooling system.
 - 8.1.3. Power steering fluid, look for leaks form the power steering system.
 - 8.1.4. Washer fluid level, look for leaks.



8.1.5. Steering wheel play and unions in good shape

8.1.6. Front tires, for wear and full of air

8.2. Tire Re-torque requirements (Refer to SOP 2.10 for further information)

8.2.1. All Silverpoint trucks are equipped with a tag system to notify the operator if any of the lug nuts on a truck need to be re-torqued .

8.2.2. There will be a notification tag attached to the dash or headliner of the truck instructing the operator on when the lug nuts need to be re-torqued .

8.3. Inspect the rest of the truck to ensure that the following are in good working condition :

8.3.1. Front bumper secure

8.3.2. Work light, regular lights, and reflective strips

8.3.3. Horns

8.3.4. Windshield for crack or chips

8.3.5. Wipers

8.3.6. Visible leaks on ground

8.3.7. Winter front or bug screen (proper one for conditions)

8.3.8. Over dimensional sign attached to front bumper (if towing a trailer)

8.3.9. Horns air/electric

8.3.10. Mirrors (adjusted and clean)

8.3.11. Turn on TPC control box.

8.3.12. Fuel tank position , straps tightness , fuel cap tightness

8.3.13. Cab steps

8.3.14. Fuel leaks

8.3.15. Exhaust mount

8.3.16. Handrail

8.3.17. Fire extinguisher and mount secure

8.3.18. Loose loads

8.3.19. Taillights

8.3.20. Brake lights



8.3.21 . Clearance lights

8.3.22 . Signal lights

8.3.23 . Valves are all capped .

8.3.24 . Vacuum hoses are properly secured on beaver tail.

8.3.25 . Vacuum hoses are not blocking tail and brake lights .

8.3.26 . Rear tires (bulges , wear and full of air), mud flaps good condition and secure , and rims for cracks

9. Trailer Inspection

9.1. Inspect the trailer :

9.1.1 . Insurance card

9.1.2 . Registration card

9.1.3 . Over dimensional permit

9.1.4 . Trailer CVIP (original)

9.1.5 . Pintle hitch is properly closed and locked .

9.1.6 . Safety chains secured properly .

9.1.7 . Master cylinder brake fluid is full (if not look for leaks in the brake system)

9.1.8 . Propane tank is turned off and properly secured .

9.1.9 . Generator is secure and doors closed (if it has one)

9.1.10 . Brake lights , clearance lights , and license plate lights

9.1.11 . Power cord is properly secured .

9.1.12 . Windows and doors closed and latched properly .

9.1.13 . Stairs are secure .

9.1.14 . Spare tire secure

9.1.15 . Stabilizer jacks are pinned (if equipped)

9.1.16 . Reflectors

9.1.17 . Entrance door is closed and secured .

9.1.18 . Mud flaps (properly mounted and in good shape)

9.1.19 . Inside and outside tire for bulges and cuts



9.1.20 . Tire tread for wear and full of air

9.1.21 . Lug nut indicators , lug nuts for tightness , missing lugs

9.1.22 . Rims for cracks

10. Brake Tug Tests

10.1.1. Release truck and Trailer Brakes

10.1.2 . Slowly move unit forward to approximately 5 MPH , be sure that unit rolls forward easily and check in the mirror to make sure that all the trailer tires are turning .

10.1.3 . Slowly apply trailer brakes using the trailer spike until you feel that the trailer brakes slow the unit down .

10.1.4 . Release brakes and resume 5 MPH .

10.1.5 . Apply truck brakes until you feel that they are slowing the unit down .

10.1.6 . Recheck that all the tires are turning , and that the unit does not seem to be dragging or low on power .

Remember : if you are in doubt about what to do, call your Supervisor