

**1. Purpose**

The purpose of the Standard Operating Procedure is to identify the hazards and define the steps for the use of a:

High Pressure Hot Water/Steam Wand System: "Steam"**2. Responsibilities**

This procedure is intended for use by all Silverpoint employees for the safe operation of using a:

- High Pressure Hot Water/Steam Wand System .
- All employees using the Pressure Washer must be trained and certified in the safe operation of the equipment and familiar with all controls .
- Untrained personnel are not permitted to operate this equipment .

3. Hazard Identification

- Equipment Damage and Failure;
- Personal Injury;
- Physical Stress;
- Mental Stress;
- Restricted Visibility;
- Pinch Points;
- Diesel Fumes;
- Slips, Trips and Falls;
- Burns;
- Hot Pipe Surfaces;
- Extreme Noise.

4. EHS Requirements

- Fire Retardant Coveralls;
- Steel Toed Boots;
- Safety Glasses;
- Gloves;
- Hard Hat;
- Hearing Protection;
- Proper Labeling of Valves.

5. References

- Silverpoint Corporate Codes of Practice;
- Alberta OH&S;
- Silverpoint Task List.

6. Procedure:**Steam**

The steam nozzle is used for 250-degree F Wet Steam operation. This nozzle is sized for operation with the unloader and steam valve (where applicable) to provide high pressure wet steam. Replacement of this nozzle with an improperly sized nozzle may cause operational problems with the machine.



- 1) Install steam nozzle into lance assembly.
- 2) Follow “Hot Water Operation” start-up procedures.
- 3) Turn steam valve completely counterclockwise to achieve maximum outlet temperature (250 F)

NOTE: Upon initial start-up, water will begin turning hot in approximately 20 seconds and will reach maximum temperature Within 2-1/2 minutes providing that the trigger gun remains open. The burner will not fire when the trigger is released.

• **ADJUSTABLE THERMOSTAT:**

Regulates the maximum discharge temperature. Turn the dial to the desired maximum discharge temperature. This may cause the burner to fire intermittently.

• **BALL VALVE (Auxiliary Tank)**

- 1) Connect hose from the auxiliary tank to open port on the 3-way ball valve;
- 2) Use the selector lever on the ball valve to allow water to flow from the auxiliary tank to the pump;
- 3) The water level in the auxiliary tank must always be higher than the pump inlet. This will ensure gravity feed of water to the pump. Failure to keep the water level above the pump inlet will result in the pump running dry and damage to the wet end of the pump.

Remember : If you are in doubt about what to do, call your supervisor