1 glow plugs relay	27	5V	53	throttle pos	79	nc
2 <mark>nc</mark>	28	nc	54	nc	80	glow plugs lamp
3 (sck)	29	nc	55	+12V / ATT	81	nc
4 (sda)	30	nc	56	nc	82	nc
5 (a0)	31	turbo pressure	57	oil temp	83	3.3V
6 (cpu reset)	32	H window button	58	coolant temp	84	nc
7 (cs)	33	nc	59	nc	85	nc
8 (3.3v)	34	misc 1	60	nc	86	nc
9 <mark>nc</mark>	35	EGR	61	nc	87	nc
10 <mark>nc</mark>	36	nc	62	nc	88	nc
11 nc	37	nc	63	air temp	89	nc
12 heater hi	38	nc		nc	90	
13 heater lo	39	DPF start	65	nc	91	
14 EGT	40	nc	66	DPF lamp	92	+12V / ignition
15	41	misc 2	67	nc	93	nc
16	42	turbo solenoid	68	FAN	94	nc
17 heated window	43	nc	69	idle solenoid	95	nc
18	44	nc	70		96	
19 heated window	45	nc	71	+12V / ignition	97	+12V / ignition
20 <mark>nc</mark>	46		72	nc	98	nc
21 hall sign	47	nc	73	nc	99	nc
22 hall gnd	48	nc	74	nc	100	
23 <mark>nc</mark>	49	SDA	75	nc	101	nc
24 <mark>nc</mark>	50	SCL	76	gnd	102	nc
25 gnd	51	gnd	77	gnd	103	gnd
26 <mark>nc</mark>	52	nc	78	nc	104	nc