

openvaf-r / OSDI Nuances and Gotchas

Non-obvious behaviors at the Verilog-A / OSDI to ngspice-netlist boundary

Ngspice + OpenVAF Enhancements project

July 2026

Contents

openvaf-r / OSDI nuances and gotchas	2
1. Unconnected trailing terminals are <i>optional</i> , not an error	3
2. Vector/bus ports flatten to <i>positional</i> terminals	4
3. Array/bus node names contain literal brackets	5
4. There is no "current between two nodes"	6
Scope	7

openvaf-r / OSDI nuances and gotchas

A running list of non-obvious behaviors at the boundary between a Verilog-A model (compiled by **openvaf-r** to a **.osdi** library) and the ngspice netlist. None of these are bugs — they are consequences of how Verilog-A / OSDI semantics map onto a SPICE netlist — but each can surprise you, so they are collected here.

Companion reading: the [built-in natures and disciplines](#) reference and the [compiler internals](#) guide.

1. Unconnected trailing terminals are *optional*, not an error

A Verilog-A model port can be left unconnected on the instance line; the trailing terminal then becomes an internal node and the model sees it as open. This is the standard `$port_connected` mechanism (also how Spectre behaves), used e.g. for an optional self-heating dt port:

```
if ($port_connected(dt)) /* thermal node wired */ ;
else                     /* run isothermal */ ;
```

In ngspice's OSDI layer (`osdi/osdisetup.c`), each unconnected terminal is marked with a `-1` sentinel; `connected_terminals` is the index of the first `-1`, and everything from there on is allocated as an internal node and reported as *not connected* to `setup_instance` (so `$port_connected` returns false):

```
uint32_t connected_terminals = descr->num_terminals;
for (uint32_t i = 0; i < descr->num_terminals; i++)
    if (terminals[i] == -1) { connected_terminals = i; break; }
```

The consequence — an asymmetric, silent lower bound. For a device with N terminals:

nodes on the instance line	result
exactly N	runs normally
fewer than N (trailing)	runs silently — the missing trailing terminals become internal nodes; <code>\$port_connected</code> is false for them. <i>No warning</i> .
more than N	hard error: too many nodes connected to instance

So a genuine netlist typo that drops a trailing node looks identical to a deliberately-open optional port — it is accepted without a diagnostic. Classic SPICE primitives (R, C, a 4-terminal MOSFET) reject a short node list; OSDI trades that check for the optional-port feature. There is no per-port "optional" flag in Verilog-A (any port may be left open, that is what `$port_connected` is for), so a simulator cannot tell an intended open port from an accidental one. Mind your trailing terminal counts — the too-many case is caught for you, the too-few case is not.

2. Vector/bus ports flatten to *positional* terminals

A Verilog-A vector (bus) port ([Enhancement-3 / E-89](#)) such as output `out[0:3]`; compiles to *four separate positional terminals* in the .osdi device. The netlist connects them by position, one node per bit:

```
module tapbuf(in, out); output out[0:3]; ... // 5 terminals: in, out[0..3]
```

```
N1 in o0 o1 o2 o3 tmod ; in -> in, o0..o3 -> out[0..3]
```

There is no bus object in the netlist — only a flat, ordered node list. The array/bus node-range syntax ([Enhancement-221](#)) `a[0:3]` is a *pre-parse textual unroll* (`inp_expand_buses` in `frontend/inpcom.c`): it rewrites the single token `a[0:3]` into the four tokens `a[0]` `a[1]` `a[2]` `a[3]` wherever it appears, with no binding to any particular port. So it composes with a bus port naturally —

```
N1 in a[0:3] tmod ; -> N1 in a[0] a[1] a[2] a[3] tmod
```

— but the range carries no semantics: `N1 a[0:3] in tmod` is equally accepted and unrolls positionally to a *different* (here electrically singular) connection. The range is a typing shorthand; getting the positions right is on you (see also nuance 1 for the terminal-count behaviour). Confirmed example: with `tapbuf` above and $V_{in} = 2$ V , $v(a[k]) = 0.25 \cdot (k+1) \cdot 2 = 0.5 \cdot (k+1) \rightarrow 0.5, 1.0, 1.5, 2.0$.

3. Array/bus node names contain literal brackets

Because the range unroll produces node *names* with literal brackets, the node is called `a[0]` — the `[` and `]` are part of the name. In ngspice's interactive expression parser (`print` / `plot` / `let`), `[...]` is the vector-index operator, so `a[0]` naturally parses as “*element 0 of a vector a*”. [Enhancement-224](#) adds a literal-node fallback so `print a[0]` and `print v(a[0])` resolve the *node* when no vector `a` exists; ordinary vector indexing (`realvec[3]`) is unaffected. Good to know:

- `vec_get` / `vec_fromplot` (`frontend/vectors.c`) look names up literally (`findvec`) — they do *not* parse brackets; the index parsing is purely in the expression grammar.
- `vec_fromplot` also strips the `v(node)` / `i(node)` wrappers: `v(x)` → node `x`, and `i(x)` → `x#branch`.

4. There is no "current between two nodes"

ngspice has no `I(node1, node2)` branch-current syntax (that is Verilog-A / Spectre form). Branch current is read as a device parameter `@device[i]` or, for a voltage source, `i(Vsrc)`. For a two-terminal element written as a bus, e.g. a resistor `R1 a[0:1]` ($\rightarrow$ `R1 a[0] a[1]`), its current is `@r1[i]`, not `I(a[0], a[1])`. `i()` in an expression takes a *source name*, not a node pair.

Scope

These are integration nuances of running openvaf-r-compiled .osdi models in ngspice; they involve no bug and no pending fix. Verilog-A *language* coverage is tracked separately (the coverage audit), and the analog-only boundary — no wreal/digital nets — is covered there.