

FIBRE ROUTER QUICK GUIDE

The lights on the front of the router

POWER, green: the router is on.

PON, green and steady: the router is synchronised with the fibre network. PON blinking: the router is trying to synchronise. Wait two minutes.

LOS, red: loss of signal. The router receives no light from the fibre. Check that the green fibre cable is plugged in and not bent. If LOS stays red, call technical support: the fault is in the line, not in your home.

INTERNET, green: the router has an internet connection.

WI-FI, off: normal in bridge mode, when another router or a mesh system makes the wifi.

Restarting the router

When the internet drops, restart the fibre router first. Switch it off, wait 30 seconds and switch it on. Wait until PON and INTERNET are steady green, which takes about two minutes. Only then restart your own router or the main node of your mesh system.

Factory reset

With the router on, hold the RESET pin at the back for 10 seconds with a paper clip, until all the lights blink. The router starts again with the settings of the label on its base: the wifi name, the wifi password and the admin password.

A factory reset removes bridge mode. Set bridge mode again in the admin page, in Advanced, WAN, Mode.