

Command/Response		0	1	2	3	4	5	6	7
		ID				Value			
Request Data Frames:	0x108040FE **	0x00	0x00	0x00	0x00	0x00	0x00	0x00	0x00
Receive Data:	0x1081407F ***	0x01	0x0E	0x00	0x00	0x00	0x00	0x00	0x0A
		0x01	0x70	0x00	0x00	Input Power			
		0x01	0x71	0x00	0x00	Input Frequency			
		0x01	0x72	0x00	0x00	Input Current			
		0x01	0x73	0x00	0x00	Output Power			
		0x01	0x74	0x00	0x00	Efficiency			
		0x01	0x75	0x00	0x00	Output Voltage			
		0x01	0x76	0x00	0x00	Output Current Max			
		0x01	0x78	0x00	0x00	Input Voltage			
		0x01	0x7F	0x00	0x00	Output Temperature			
		0x01	0x81	0x00	0x00	Output Current			
		0x01	0x82	0x00	0x00	Output Current			
		0x01	0x83	0x00	0x10	Unknown- normally zero			

Value Divisor

/1024

/1024

/1024

/1024

/1024

/1024

/20

/1024

/1024

/1024

/1024

Not sure what this is?

Unknown frame

/15 if Pin 9 and Pin 10 are connected (to release 75A max current)

		0	1	2	3	4	5	6	7
		ID				Value			
Set Data:	0x108180FE*	0x01	0x00	0x00	0x00	On-line Output Voltage			
		0x01	0x01	0x00	0x00	Off-line/Default Output Voltage			
		0x01	0x02	0x00	0x00	Overvoltage Protection? (Untested)			
		0x01	0x03	0x00	0x00	On-line Current Limit			
		0x01	0x04	0x00	0x00	Off-line/Default Output Current Limit			
		0x01	0x07	0x00	0x00	Current limit??			
		0x01	0x32	0x00	0xXX	0x00	0x00	0x00	0x00
		0x01	0x34	0x00	0xXX	0x00	0x00	0x00	0x00
		0x01	0x35	0x00	0xXX	0x00	0x00	0x00	0x00

Value Multiplier

V * 102

V * 102

V * 102

A * 2

A * 2

A * 1.157

-

Acceptable range 41.5 to 58.5V in 0.1V steps. Example: 460 (46.0V) * 102 = 00 00 B7 48

Acceptable range 48 to 58.5V in 0.1V steps

Acceptable range 56.5 to 60.5V (as per datasheet)

Acceptable range 0 to 90.5A in 0.1A steps. Example: 500 (50.0 A) * 1.38 = 00 00 02 B2

Acceptable range 0 to 90.5A in 0.1A steps

Not tested...

XX: 01 - disable Huawei (standby mode), 00 - enable Huawei

XX: 01 -Turn on the fans at full power, 00 - automatic fan speed control (On-line)

XX: 01 -Turn on the fans at full power, 00 - automatic fan speed control (Off-line)

*1.5 if in full power mode

*1.5 if in full power mode

The rectifier can operate in two states:
Off-line is when there is no CAN communication (i.e. standalone operation). This occurs on power-up or if CAN communication has timed-out (Orange LED slowly blinking).
On-line values are only valid when CAN communication is present (Orange LED not blinking). These values are volatile and reset to default on loss of CAN comms.
CAN communication time-out is approximately 60 seconds. i.e. if you stop sending valid CAN messages to the rectifier, the rectifier will switch to Off-line/Default values in approximately 60 seconds.
*0x108180FE for first Huawei, 0x108280FE for second Huawei, etc. 0x108080FE for all units in the system
** 0x108040FE to request status messages from all recitfiers, when more than one Rectifier is on the CAN BUS you can use 0x108140FE to request status from rectifier 1; 0x108240FE to request from No.2 rectifier etc
***0x1081407F is the ID that reports for the first rectifier (true also when only one is on the BUS); 0x1082407F is the ID for status messages from No.2 rectifier etc.