PDP-11/05 SCL Connector

(as viewed from the back of system)

UL	J SS	PP	MM	KK	HH	EE	CC	AA	Υ	W	U	S	Р	M	K	Н	E	С	Α
39	37	35	33	31	29	27	25	23	21	19	17	15	13	11	09	07	05	03	01
V	TT	RR	NN	LL	JJ	FF	DD	BB	Z	Х	V	Т	R	N	L	J	F	D	В
40	38	36	34	32	30	28	26	24	22	20	18	16	14	12	10	08	06	04	02

SCL Connector Signals

Signal	SCL Connector Pin						
GND	A/01, B/02, UU/39, VV/40						
-15V	BB/24						
SERIAL OUT + (20mA)	V/18						
CLK IN (TTL)	T/16						
SERIAL IN - (20mA)	DD/26						
READER RUN - (20mA)	R/14						
CLK DISAB (TTL)	N/12						
SERIAL OUT - (20mA)	L/10						
+5V	C/03						
SERIAL OUT (TTL)	D/04						
READER RUN + (20mA)	F/06						
SERIAL IN (TTL) *	RR/36						
20ma INTERLOCK **	NN/34						
SERIAL IN + (20ma)	LL/32						

Notes

- * **SERIAL IN (TTL)** [RR/36] expects the input signal to be inverted as compared to a traditional TTL serial line--i.e. 0V represents a serial MARK and +5V represents a SPACE.
- ** To enable the 20ma interface, **20ma INTERLOCK** [NN/34] must be connected to **SERIAL IN (TTL)** [RR/36].