



मध्य रेल
मुंबई मंडल
टी आर ओ विभाग

e-SIGNAL LOCATION BOOK

Importance

The Signal Location Book is an essential safety document for train operations. It provides detailed information about:

- Signals
- Signals located on gradients and curves
- Neutral sections
- Permanent speed restrictions
- Yard signal layouts
- Other important sectional features

Mandatory Requirement

The Signal Location Book is compulsory for all Loco Pilots and Assistant Loco Pilots while working trains.

Purpose

- To identify the correct location of signals.
- To maintain awareness of signal locations and aspects.
- To ensure safe and efficient train operation
- To comply with sectional permanent speed restrictions and caution orders
- To prevent Signal Passing at Danger (SPAD) and other unsafe situations

Responsibility

Loco Pilots and Assistant Loco Pilots must:

- Carry the latest updated Signal Location Book
- Study the section before working the train
- Refer to the Signal Location Book whenever required during duty

Main Features of e-Signal Location Book

- ♦ Signal book prepared as per Crew Beat
- ♦ Signals located on Right hand side shown in **Red font color**.
- ♦ Signals provided with diversions given along with its description.
- ♦ Signals located on curvature indicated by left or right curvature sign.
- ♦ Signals located on UP/Down gradient indicated by UP/DN arrow.
- ♦ Location of Neutral Sections.
- ♦ Section wise list of signals located on right hand side.
- ♦ Yard lines diagrams along with signals.

Signal Location Book Prepared as per Crew Beat

Suburban

CSMT Suburban Main Line Beat

CSMT Suburban Harbour Line Beat

KYN Suburban Beat

PNVL Suburban Beat



Main Line (Coaching)

CSMT Main Line IGP–PUNE Beat

CSMT Main Line KR Beat

CSMT Main Line MMR–SNSI–JL Beat



Main Line (Goods)


KYN Lobby Goods Beat

PNVL Lobby Goods Beat



Signal Located on Right Hand side shown in **Red Font** color

UP & Down Gradient shown by UP/Down arrows



Left & Right curvature shown by left or right arc signs



PNVL-ROHA DOWN LINE					
SIGNAL NO.	LOCATION	DESCRIPTION	SIGNAL NO.	LOCATION	DESCRIPTION
PEN S-9	103/12	UDGL-2 STR	NGTN S-5		UDGL-1 STR
PEN S-11	104/10	ADV STR	NGTN S-6	UDL DN STR	RHS
DIST (P)	106/44	GATE DIST	NGTN S-7		UDGL-2 STR
SW-2 (G)	107/38	GATE-22	NGTN S-8	131/12	ADV STR
PSR >	95 KMPH	108/12-109/6	500 M BOARD	131/44	N
DIST (P)	110/6	GATE DIST	250 M BOARD	132/8	
SW-2 (G)	111/6	GATE-26	DJ OPEN	132/14	
DIST (P)	115/22	KASU DIST	N/S	132/20	
KASU S-2	116/20	DN L/L ADV	TUNNEL 134/18-135/16		
KASU (KASU) 117.38 KM			DIST (P)	136/12	IBS DIST
KASU S-3	117/28	DN M/L STR	S-9 (IB)	137/26	NGTN IBS