

BrewMaster Pro 3000

User Manual — 12-Cup Programmable Coffee Maker, Model BM-3000

1. Safety Information

Read all instructions before using the BrewMaster Pro 3000 for the first time. Keep this manual for future reference.

***WARNING:** To reduce risk of fire, electric shock, or injury, do not immerse the power cord, plug, or base unit in water or any other liquid.*

- Do not operate the appliance with a damaged cord or plug.
- Do not touch hot surfaces; use handles and knobs.
- Unplug from the outlet when not in use and before cleaning.
- Do not use outdoors.
- This appliance is not intended for use by children.

2. Parts Overview

The BrewMaster Pro 3000 includes the following components: water reservoir (1.8L capacity), removable filter basket, glass carafe with heat-resistant handle, warming plate, control panel with LCD display, and a permanent gold-tone filter.

The control panel features four buttons: POWER, BREW STRENGTH, PROGRAM, and CLOCK. The LCD display shows the current time, brew strength setting, and a cup icon that flashes during brewing.

3. Setup and First Use

Before first use, wash the carafe, filter basket, and permanent filter in warm, soapy water. Rinse thoroughly. Run one full brew cycle with water only (no coffee grounds) to clean the internal components.

To set up your BrewMaster Pro 3000:

- Place the unit on a flat, dry, heat-resistant surface away from the edge of the counter.
- Open the reservoir lid and fill with cold water to the desired line (4 to 12 cups).
- Insert the permanent filter into the filter basket and close the lid.
- Plug the power cord into a grounded outlet.
- Press and hold the CLOCK button for 3 seconds, then use the arrow buttons to set the current time.

4. Brewing Instructions

Add ground coffee to the filter basket — use approximately 1 tablespoon of ground coffee per cup for standard strength. Close the lid and place the carafe on the warming plate, making sure it is centered correctly.

Press BREW STRENGTH to toggle between Regular and Bold. Press the POWER button once to begin brewing. The cup icon on the display will flash throughout the brew cycle. A full 12-cup pot takes approximately 8 to 10 minutes to brew.

The warming plate keeps coffee hot for up to 2 hours after brewing completes, after which the unit will automatically power off to conserve energy.

5. Programming a Delayed Brew

To brew coffee automatically at a future time, press PROGRAM and use the arrow buttons to set your desired brew start time, then press PROGRAM again to confirm. The PROGRAM indicator light will remain lit until the scheduled brew begins.

6. Cleaning and Maintenance

Allow the unit to cool completely before cleaning. Wipe the exterior with a damp cloth. The carafe, filter basket, and permanent filter are dishwasher safe on the top rack.

Descale the unit every 2 to 3 months, or sooner in hard water areas. Fill the reservoir with a 50/50 mixture of white vinegar and water, run a full brew cycle without coffee grounds, then run two additional cycles with clean water to rinse.

7. Troubleshooting

Problem	Possible Cause	Solution
Coffee maker will not turn on	Not plugged in properly	Check the power cord connection and outlet
Brewing is slow or incomplete	Mineral buildup	Descale the unit (see Section 6)
Coffee is weak	Incorrect coffee-to-water ratio	Use 1 tbsp ground coffee per cup, or select Bold strength
Overflow at filter basket	Filter basket not seated correctly	Remove and reinsert the filter basket firmly
Display is unresponsive	Unit needs a reset	Unplug the unit for 30 seconds, then plug it back in to reset the control panel

8. Specifications

Specification	Value
Capacity	12 cups (1.8 L)
Power	900W, 120V, 60Hz
Dimensions	9.5 in x 7.2 in x 12.8 in
Weight	3.4 lbs
Warranty	2 years limited