

EcoTemp Smart Thermostat

User Manual — WiFi-Enabled Smart Thermostat, Model ET-200

1. Safety and Compatibility

The EcoTemp Smart Thermostat is compatible with most 24V heating and cooling systems, including forced air, heat pump, and radiant systems. It is not compatible with 110V/120V line voltage systems (common in baseboard heaters).

***WARNING:** Turn off power to your HVAC system at the circuit breaker before installing or removing the thermostat. Installation involves working with low-voltage wiring; if you are unsure about compatibility, consult a licensed HVAC technician.*

2. What's in the Box

- EcoTemp Smart Thermostat display unit
- Wall mounting plate and screws
- Wire labels
- Trim plate (for covering old thermostat marks on the wall)
- Quick start guide

3. Installation

Turn off power to your HVAC system before beginning. Remove your old thermostat from the wall and take a photo of the wiring before disconnecting anything. Label each wire according to its terminal (R, C, W, Y, G) using the included labels.

Attach the mounting plate to the wall using the included screws, ensuring it is level. Connect each labeled wire to the matching terminal on the mounting plate. A C-wire (common wire) is required for continuous WiFi connectivity; if your system does not have a C-wire, a C-wire adapter is available separately.

Snap the display unit onto the mounting plate and restore power at the breaker. The thermostat will power on and guide you through initial setup on-screen.

4. WiFi and App Pairing

Download the EcoTemp app (available for iOS and Android) and create an account. On the thermostat, go to Settings > WiFi and select your home network, then enter your WiFi password using the dial. Once connected, open the app and select 'Add Device' to pair your thermostat.

5. Basic Operation

Rotate the outer dial to adjust the target temperature. Press the dial once to access the menu, where you can switch between Heat, Cool, Auto, and Off modes.

To create a schedule, open the app and go to Schedule, then set target temperatures for Morning, Day, Evening, and Night periods. The thermostat will also learn your manual adjustments over time and suggest schedule changes (Smart Learning mode), which can be enabled or disabled in Settings.

Eco Mode automatically adjusts the temperature when the app detects nobody is home, based on your phone's location. This can be disabled under Settings > Eco Mode.

6. Troubleshooting

Problem	Possible Cause	Solution
Blank display	No power reaching the unit	Check the breaker; confirm the C-wire is connected or use a C-wire adapter
Thermostat won't connect to WiFi	Incorrect password or weak signal	Re-enter the WiFi password; move your router closer or use a WiFi extender
HVAC system not responding to changes	Wiring mismatch	Confirm wire labels match the terminal diagram in Section 3
App shows 'Offline'	Thermostat lost WiFi connection	Check your home WiFi is working; the thermostat will auto-reconnect
Thermostat unresponsive on screen	Software needs a reset	Press and hold the dial for 10 seconds until the screen goes blank

7. Specifications

Specification	Value
Temperature Range	45°F to 90°F (7°C to 32°C)
Compatible Voltage	24V systems only
Connectivity	802.11 b/g/n WiFi, 2.4GHz only
Display	3.5 in color touch-sensitive dial
Warranty	3 years limited