Flashing STM32 motor controller card for STM32F407VET6 C30D version.

Important: Use **FlyMcu V0.2188** version for C30D 2.0 or 2.1 boards.

Do and Don't

1. Do not put the board on the anti-static bag when you are programming or flashing the board. The anti-static bag is for storage use only.

2. At all times, hold the board by the edge, avoid touching any metal pins or solder to avoid static shock on the ICs. Store it in an anti-static bag.

3. Put the board on an insulated surface like acrylic panel or laminated tabletop.

4. Disconnect the 12V supply to the card and switch off the main switch during flashing of the program.

5. Disconnect the supply to Raspberry Pi card if it is connected.

6. Connect the USB Type C cable to port 1 of the board.

Port 1 is the port that is nearest to the potentiometer.

7. Reflash the board as per procedures in section 1.

8. After flashing, disconnect USB cable from port1.

9. Connect and turn on the power (12 V).

10. Touch the plastic of the CPU chip and the IMU chip if it is very hot, check your program. Please note that do not touch the chip's pins.

11. If the chips are not overheating, proceed to test your program.