

JUMA PA-100D

Operating Manual

Firmware v5.01 (DL4JC) · October 2026

Based on the operating manual for firmware v4.00a by Adrian Ryan, 5B4AIY (revision 15-DEC-2021). Original firmware by Juha Niinikoski, OH2NLT, and Matti Hohtola, OH7SV.

Not an official JUMA release. You use this firmware at your own risk. Test every new firmware with a dummy load and low power first. You can return to the original v4.01a at any time without losing the calibration (see section 10).

Contents

1 Introduction	4
1.1 Version numbers	4
1.2 What is new compared with v4.01a	4
2 Front panel controls	5
2.1 PWR	5
2.2 UP / DOWN	5
2.3 DISPLAY/CONFIG	5
2.4 OPER	6
2.5 AUTO	6
2.6 BAND+ / BAND-	6
2.7 Normal display	6
3 Getting started	7
4 User configuration	8
4.1 Auto Band Detect	8
4.2 Serial Speed	8
4.3 Serial Port	8
4.4 Polling Interval	9
4.5 LCD Display – Backlight	9
4.6 LCD Display – Contrast	9
4.7 SWR Trip	9
4.8 Fan Control	9
4.9 Temperature	9
4.10 Overtemp	9
4.11 Fan Cut-In Temp	9
4.12 Band Display	10
4.13 Graphical Limits	10
4.14 Graphic Display	10
4.15 RF Power Meter	10
4.16 Start-Up Display	10
4.17 F-Sense QSK	10
4.18 About	11
5 Saving settings	12
6 Band selection and filter protection	13
6.1 Protection on a band change	13
6.2 F-Sense	13
7 Service and calibration mode	14
7.1 Voltmeter	14
7.2 Ammeter	15
7.3 RF power (high power)	15

7.4 RF power (low power).....	15
7.5 Beep Len	15
7.6 Beep Tone.....	15
7.7 Power Averaging	15
7.8 Voltage alarms	15
7.9 Frequency meter.....	16
7.10 Splash Screen.....	16
8 Serial port	17
8.1 Serial test suite	17
8.2 Cables and levels	17
8.3 KX2/KX3 and other ASCII transceivers	17
8.4 Xiegu band voltages	18
8.5 HR50 mode.....	18
8.6 Remote control	19
9 Alarms	21
10 Firmware update and going back	22
11 Quick reference.....	23
12 Settings record.....	24
13 Credits.....	26

1 Introduction

The PA-100D is a 100 W all-band (160–10 m) linear amplifier, designed as a companion to the JUMA TRX-2 but usable with almost any low-power transceiver (Elecraft KX2/KX3, Yaesu FT-817/818, Xiegu, Icom IC-705 and others). This manual describes operation and setup with **firmware v5.01**. It runs on the JUMA PA-100D and on the RS-928 clone.

1.1 Version numbers

Some dealers list the original firmware **v4.01a** as "**4.1a**". That is the original firmware, not a newer version. This firmware continues from v4.01a Build 3 (5B4AIY) and starts at **v5.00** so that the two cannot be confused. The version is shown on the start-up screen and on the *About* page of the user configuration.

1.2 What is new compared with v4.01a

Protection

- All TX protection runs in the 1 ms interrupt: RF off 2 ms after KEY is released, SWR trip, over-current, filter mismatch, active alarms, and a main-loop watchdog (2 s). In v4.01a the protection stopped whenever the main loop waited (button held, save prompt, serial test).
- The filter relays are never switched under power. On a band change RF is turned off first, the relays switch 20 ms after RF off, and TX is held off for another 20 ms while they settle.
- The input frequency is compared with the selected low-pass filter every millisecond. Above the filter for 2 ms → RF off until the band is correct. This cures the **O/C alarm** of v4.01a on the first transmission after a band change in F-Sense mode.
- The gain (attenuator) relays no longer switch while transmitting.
- RF is turned off in the user configuration, on a processor fault and before power-off.

Band selection

- F-Sense works reliably with two-tone, noise and SSB, and never selects a filter below the transmitted frequency (section 6.2).
- New switch **F-Sense QSK** (section 4.17).
- New band select modes **Xiegu** (band voltages, section 8.4) and **HR50** (Hardrock-50 serial protocol, section 8.5).
- KX2/KX3: frequencies above 30 MHz no longer wrap to a low band; incomplete or corrupted FA messages are ignored.

Operation

- **OPER held** saves the settings without switching off (section 5).
- New user configuration page **About** with version and credits; the start-up screen shows only the model and firmware version.
- Service menu **Beep Tone** for the RS-928 buzzer (section 7.6).
- Serial receive overrun at high baud rates fixed; status reply sent in one piece.

The calibration and configuration in the EEPROM are kept when you load this firmware.

2 Front panel controls

The PA-100D has eight buttons: **PWR**, **UP**, **DOWN**, **DISPLAY/CONFIG**, **OPER**, **AUTO**, **BAND+** and **BAND-**. "Brief press" means less than approx. 0.5 s, "hold" means approx. 0.7 s or longer. The quick reference in section 11 summarises all functions.

2.1 PWR

- **Power on:** briefly press PWR. The start-up screen appears (if *Splash Screen* is on):



JUMA PA-100D

Firmware v5.01

The amplifier always starts in **Standby**.

- **Power off:** hold PWR. If you have changed a gain, the band (manual mode) or Auto/Manual since the last save, the save prompt appears first (section 5). RF is turned off before the fans.
- **Cancel alarms:** a brief press clears the most urgent active alarm. If an alarm cannot be cleared, hold PWR for an emergency shutdown; nothing is saved.
- **Previous page:** in the normal display a brief press steps back to the previous measurement page (e.g. quickly between power and SWR). In the user configuration and the service menu it steps back one page; held, the pages step back automatically.
- **No** in every save prompt.

2.2 UP / DOWN

In the normal display UP/DOWN change the **gain** of the current band (G1–G4). G1 is the lowest gain; each step is approx. 2 dB. The "gain" is in fact an input attenuator (G1 = –6 dB ... G4 = 0 dB). Each of the nine bands has its own gain setting.

A gain change while transmitting is applied **after** the transmission, so that the attenuator relays never switch under drive power.

In the menus UP/DOWN change the value of the current page. Held, they repeat; the repeat speed depends on the parameter.

2.3 DISPLAY/CONFIG

- **Brief press** in the normal display: next measurement page – output power, SWR, supply voltage, current, heat-sink temperature, and in F-Sense mode an additional page with the input frequency (1 kHz resolution) and output power.
- **Hold:** enters the **user configuration** (section 4). In the user configuration a brief press goes to the next page; held, the pages advance automatically.
- **Held while switching on:** RS-232 loop-back test. Characters received from a terminal are echoed and shown on the display. Brief PWR ends the test.

2.4 OPER

- **Brief press** in the normal display: toggles **Operate / Standby**. The change happens when the button is released.
- **Hold** (approx. 0.7 s, not while transmitting): **save prompt** for the current settings, without switching off (section 5).
- In the user configuration and the service menu: **save & exit** prompt.
- **Held while switching on**: starts the boot loader (flash writer) for a firmware update (section 10).

In **Standby** the signal path goes straight through, without filters or attenuator; the transceiver works directly into the antenna. The meters still show power and SWR. In **Operate** the amplifier is active.

2.5 AUTO


Toggles between **automatic** (A on the lower display line) and **manual** (M) band selection. In manual mode BAND+/BAND– select the band (160 m ... 10 m). Pressing BAND+ or BAND– while in AUTO also switches to manual. Not available in the band select mode *Manual*.

With a serial band select mode (Yaesu CAT, KX2/KX3, Juma-TRX2), every manual band change and every change between A and M sends a frequency query to the transceiver, and a valid answer overrides the manual band. This prevents an inadvertently wrong filter.

2.6 BAND+ / BAND–

- Select the next higher / lower band in manual mode; held, the band repeats. Not possible while transmitting.
- **BAND+** is **Yes** in every save prompt.
- **BAND+ held while switching on**: reload the factory defaults (prompt: BAND+ = Yes, PWR = No).
- **BAND– held while switching on**: the serial message time-out of the HR50 mode becomes 5 s instead of 200 ms, for tests with a terminal program (display: *Serial Time-Out / Set to: 5 Secs*). Until the next power-on. The KX2/KX3 mode no longer needs this: it works with a terminal at any typing speed.

2.7 Normal display



Upper line: bar graph and the selected measurement. Lower line: gain (G1–G4), state, A/M and band.

State	Meaning
STBY	Standby
OPER	Operate, receiving
TX	Operate, transmitting
Err	KEY active, but the band is unknown or out of band – TX inhibited
SWR, 0/C, TEMP, Hi–V, Lo–V, Batt	Alarm (flashing, section 9)

Band ? = band unknown (e.g. no answer to a poll), ?! = out of band. Both inhibit TX.

3 Getting started

1. Connect the transceiver to the RF input, the antenna (or dummy load) to the output, and the PTT (KEY) line to the T/R socket. Use a fused power lead.
2. Switch on, enter the user configuration (DISPLAY held) and choose the **Auto Band Detect** mode that suits your transceiver (section 4.1). Without a CAT/band data connection use **F-Sense**.
3. Leave with OPER and save (BAND+).
4. Start with gain G1 and low drive (1–2 W), check power and SWR, then increase.

4 User configuration

Hold **DISPLAY/CONFIG** until a long beep sounds and *User Configuration* appears. Release the button; the last used page is shown. Next page: **DISPLAY** brief (or held to scroll). Previous page: **PWR** brief (or held). Change the value with **UP/DOWN**. A long beep and a longer delay mark page 0. TX is off as long as the menu is open.

To leave, briefly press **OPER** and answer the save prompt: **BAND+** saves, **PWR** discards the changes and restores the previous settings.

Pages that do not apply to the current mode are skipped (see notes on each page).

4.1 Auto Band Detect

Default: **F-Sense**

Mode	Band source	Notes
Yaesu CAT	Yaesu 5-byte binary CAT protocol (e.g. FT-817/818 with CT-62 level converter)	Polling is set to 2 s when selected
KX2/KX3	ASCII FA frequency (Elecraft, Kenwood, newer Yaesu, any radio that answers FA;)	Polling set to 2 s when selected; section 8.3
HR50	The PA answers the Hardrock-50 serial commands; band from the host	Section 8.5
Juma-TRX2	Band messages of the JUMA TRX-2	Polling not needed, disabled when selected
F-Sense	Frequency of the RF drive signal	Only RF and PTT needed; section 6.2
FT817/818	Band voltage on the BAND socket (FT-817/818)	
Xiegu	Band voltage of the Xiegu ACC port (230 mV steps), also Brick2/3, SquareSDR	Section 8.4
Manual	Only BAND+/BAND-	No protection at all – a wrong band can destroy the filters or transistors. Use only as a last resort.

The menu order is: Yaesu CAT → KX2/KX3 → HR50 → Juma-TRX2 → F-Sense → FT817/818 → Xiegu → Manual.

4.2 Serial Speed

Default: **9600 Baud** · Range: 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200 Baud · 8 data bits, 1 stop bit, no parity.

4.3 Serial Port

Default: **Off** · Off / Remote / Test

- **Remote:** remote control and status (section 8.6).
- **Test:** serial test suite (section 8.1).

Only shown in the modes F-Sense, FT817/818, Xiegu and Manual – in the other modes the serial port carries the band data.

4.4 Polling Interval

Default: **2 s** · Range: 0 (off) – 10 s

- Yaesu CAT, KX2/KX3, Juma-TRX2: the transceiver is asked for its frequency at this interval. If no answer arrives within one interval, the band becomes unknown (?) and TX is inhibited until the next valid answer.
- Remote mode: the amplifier sends a status message at this interval (section 8.6).

Only shown in Yaesu CAT, KX2/KX3, Juma-TRX2, or with *Serial Port = Remote*. Not shown in HR50 mode (the host sends the band).

4.5 LCD Display – Backlight

Default: **300** · Range: 50 – 1000

4.6 LCD Display – Contrast

Default: **2000** · Range: 0 – 3000

4.7 SWR Trip

Default: **3.0** · Range: 1.0 – 9.0

The SWR alarm only trips in **Operate**. 1.0 is useful for testing the alarm with a dummy load.

4.8 Fan Control

Default: **Normal**

Setting	Fan
Normal	Controlled only by the heat-sink temperature
Low	Always at least low speed; higher speeds by temperature
Medium	Always at least medium speed; high speed by temperature
High	Always high speed

4.9 Temperature

Default: **Celsius** · Celsius / Fahrenheit. Changing the scale resets the over-temperature limit and fan cut-in temperature to their defaults in the new scale.

4.10 Overtemp

Default: **70 °C / 158 °F** · Range: 50 – 100 °C / 120 – 212 °F

4.11 Fan Cut-In Temp

Default: **40 °C / 104 °F** · Range: 0 °C (32 °F) up to the over-temperature limit – 20 °C (– 40 °F)

At the cut-in temperature the fan starts at low speed, 5 °C (10 °F) higher at medium, 10 °C (20 °F) higher at high speed. It stops 2 °C (4 °F) below the cut-in temperature. A low setting (e.g. 0 °C) is a quick test of the fan.

4.12 Band Display

Default: **MHz** · MHz / Metres

4.13 Graphical Limits

Default: **Off**

- **Off**: the bar graph shows the output power; full scale is set in the service menu (40–160 W).
- **On**: the bar graph shows the selected measurement relative to its limit: current to the 24 A hardware trip, temperature to the over-temperature limit, SWR from 1:1 to the trip limit, voltage from the under-voltage to the over-voltage trip. Recommended with the dBm power meter.

4.14 Graphic Display

Default: **Original** · Original / Large / Small scale markers.

4.15 RF Power Meter

Default: **Watts** · Watts / dBm (1 W = +30 dBm, 10 W = +40 dBm, 100 W = +50 dBm).

4.16 Start-Up Display

Default: **O/P Power** · O/P Power / SWR / Voltage / Current / Temperature – the measurement page shown after power-on.

4.17 F-Sense QSK

Default: **Off** · Off / On · Only shown in F-Sense mode.

	Off (default)	On
TX enabled	only once F-Sense has measured the frequency in this transmission – until then the signal passes at transceiver power through the bypass	at once, with the last measured band
First transmission after a change to a higher band (e.g. 40 → 20 m)	PA never amplifies through a wrong filter	RF off after 2 ms until the band is measured
First transmission after a change to a lower band (e.g. 20 → 80 m)	PA never amplifies through a wrong filter	RF off after 3 ms until the band is measured; a few ms of poorly suppressed harmonics
Delay at the start of each transmission	approx. 20–40 ms without PA (longer with SSB if the speech starts quietly)	none
Suitable for	SSB, digital modes, CW without full QSK	CW with full break-in

Rule of thumb: leave it **Off** unless you use CW with full break-in. With **On**, after a change to a lower band, key briefly at low power first.

4.18 About

The last page. Firmware version and credits; UP/DOWN scrolls:

Line	
Firmware v5.01	Installed firmware version
0H2NLT Original	Juha Niinikoski – original firmware
0H7SV JUMA	Matti Hohtola – JUMA
5B4AIY to 4.01a	Adrian Ryan – extensions and maintenance up to v4.01a
DL4JC from 4.03	Modifications from v4.03 on

Nothing on this page is stored.

5 Saving settings

The gains of all bands, the band, Auto/Manual and all user configuration pages are stored together in the EEPROM. There are three ways to save them; all show the same prompt:

Save Settings?
PWR:No BAND+:Yes

Where	Opened by	BAND+ (Yes)	PWR (No)
Normal display	OPER held (approx. 0.7 s, not while transmitting)	saves	settings stay active, unsaved
Leaving the user configuration	OPER brief	saves	restores the previous settings
Power off	PWR held, only if gain, band or Auto/Manual were changed	saves, then off	off without saving

Saved! or Cancelled! confirms the choice.

6 Band selection and filter protection

6.1 Protection on a band change

- The filter relays are never switched under power. If the band changes while transmitting, RF is turned off first; the relays switch 20 ms after RF off, and TX stays off for 20 ms more.
- Every millisecond the input frequency is compared with the selected low-pass filter, in every band select mode. If it is above the filter for 2 ms, RF goes off until the band is correct.
- F-Sense mode, first 200 ms of a transmission: if the frequency is below the selected filter for 3 ms (poor harmonic suppression, e.g. 80 m through the 20 m filter), RF goes off until the band has been measured.
- An invalid or unknown band (?, ?!) always inhibits TX.

6.2 F-Sense

The RF drive signal is counted (1 ms gate) and the band is selected from 20 samples. Drive with **100 mW – 10 W**. For a reliable first measurement on a new band, key **TUNE** or CW briefly.

- A **higher** band is selected from any signal at once – the safe direction for the amplifier.
- A **lower** band is selected from a **clean carrier** (TUNE, CW: all samples within approx. 3 %).
- Modulated signals (two-tone, noise, SSB) are counted too low by the input shaper (two-tone approx. 85 % of the real frequency). From such a signal a lower band is only selected at the start of a transmission and only if even the highest sample + 20 % is below the current filter. The band is then the **highest amateur band** between the highest sample and + 20 %: e.g. 14 MHz two-tone (counted as 11.9 MHz) selects 20 m, not 30 m, and 3.7 MHz SSB selects 80 m, not 40 m. If the real frequency is still higher, the filter test of 6.1 turns RF off at once and the next measurement corrects the band.
- Once the band has been measured in a transmission, it is only increased, never lowered – SSB speech cannot switch the filter down in mid-transmission.
- If the new frequency is only just below the current filter (e.g. 10.1 MHz noise from the 20 m filter), the amplifier stays on the higher filter; set the band once with TUNE.

The frequency page (DISPLAY, F-Sense only) shows the counted frequency; with modulated signals it reads too low.

7 Service and calibration mode

From the off state, hold **PWR** until a beep sounds and

Calibration
Mode v5.01

appears. Release **PWR**. Pages: **DISPLAY** brief/held forward, **PWR** brief/held back. Values: UP/DOWN. **OPER** opens the save prompt (**BAND+** saves, **PWR** restores the previous calibration).

Connect a dummy load. In this mode the amplifier starts in Operate with the minimum gain (G1, 5 W drive gives approx. 40–50 W) – the band gains are restored on exit. It can only be keyed on the ammeter and RF power pages, which also show A/M and the selected filter. A 20 m signal is recommended. Before entering, select **AUTO** (filter by F-Sense) or **MANUAL** (10 m filter) in the normal mode and save. Any alarm ends the service mode.

Page	Setting	Default	Range
0	Supply (voltmeter factor)	5250	4750 – 5750
1	Ammeter factor	2520	1500 – 4000
2	RF power factor (high power)	1062	750 – 1500
3	RF power offset (low power)	120	0 – 150
4	Beep Len	50 ms	0 (off) – 100 ms
5	Beep Tone	JUMA	JUMA / RS-928
6	Power Averaging	1 (off)	1 – 16
7	Overvoltage alarm	On	On / Off
8	Overvoltage Trip	14.50 V	14.0 – 15.0 V
9	Low Voltage alarm	On	On / Off
10	Low Voltage Trip	11.00 V	10.5 – 11.5 V
11	Pre-Limit Trip	11.20 V	Low Voltage Trip + 0.1 ... + 0.8 V
12	Full-Scale Power (bar graph)	100 W	40 – 160 W
13	Frequency meter factor	999985	999625 – 1000345
14	Splash Screen	On	On / Off

Pages 8, 10 and 11 are skipped when the corresponding alarm is off.

7.1 Voltmeter

Measure the supply at the amplifier's power connector with an accurate 4-digit multimeter and adjust the factor until the display agrees (± 1 digit). The display here is not averaged (in normal operation it is a 50-sample average), which helps to find the most stable setting.

7.2 Ammeter

Drive to approx. 30–80 W CW, wait for the reading to settle, and adjust to a reference (clip-on DC ammeter, shunt, or an accurate power supply meter). Expect approx. ± 0.2 A at full power (shunt contact resistance and heating). In normal operation the ammeter is a peak-hold meter (approx. 1 s).

7.3 RF power (high power)

Drive to 50–100 W CW into a dummy load and adjust to an accurate power meter (or a directional coupler and oscilloscope). SWR meters with a power scale are usually not accurate enough. Without reference equipment keep the default.

7.4 RF power (low power)

At approx. 4–5 W output on 20 m adjust the offset. Switch between pages 2 and 3 (PWR brief) with the corresponding drive levels until both agree. If you end up near a limit, reset to approx. 1060 / 120 and start again. Expect approx. ± 10 %; the lowest displayed power is approx. 0.4 W.

7.5 Beep Len

0 switches the beeper off; important acknowledgements (e.g. entering the menus) still beep.

7.6 Beep Tone

Setting	Tones
JUMA (default)	unchanged: 601, 784, 934, 1397 Hz, alarm 2000 Hz
RS-928	2300, 2450, 2600, 2750 Hz, alarm 2700 Hz

The RS-928 buzzer only sounds clean between approx. 2300 and 2800 Hz. A changed setting is played at once.

7.7 Power Averaging

Averages the power and SWR measurement over 1–16 samples (approx. 4 ms each). The SWR protection in the interrupt averages over at least 8 ms and starts 20 ms after the beginning of a transmission, so normal relay switching does not cause false trips. Leave at **1** unless an external linear or separate RX/TX antennas cause transient SWR alarms; more than 6–10 samples point to a problem elsewhere.

7.8 Voltage alarms

- **Overvoltage:** for mobile use; alternator spikes or poor connections can trigger it.
- **Low Voltage:** final limit, e.g. for lead-acid batteries (do not discharge below 10.5 V).
- **Pre-Limit:** an early warning above the Low Voltage Trip. If the Low Voltage Trip is changed, the pre-limit follows by the same amount.

7.9 Frequency meter

Feed 100 mW – 5 W of a CW signal on an exact kHz frequency in the 10 m band (e.g. 28.850 MHz). Step the factor up until the display just reads one kHz less without jitter, note it; step down until it just reads one kHz more, note it. The mean of both (integer) is the factor.

7.10 Splash Screen

Off: the start-up screen is skipped and the amplifier starts almost at once.

8 Serial port

8.1 Serial test suite

Serial Port = Test (modes F-Sense, FT817/818, Xiegu, Manual), terminal 8N1 at the set speed.

Key	Function
H, ?	Help
A	A-D channel dump (current, voltage, band voltage, reverse/forward power, temperature)
B	Alarm test (0 = all off, 1 O/C, 2 SWR, 3 temperature, 4 over-voltage, 5 pre-limit, 6 low voltage, 7 all on)
C	LCD bar graph and character test
D	Clear the factory-default reset counter
E	Dump calibration and user settings – keep a copy before a firmware update
F	EEPROM dump
G	F-Sense test on/off: each sample set with bins, lowest/highest sample, c lean/mod/far
I	Input attenuator (gain) of each band
J	Temperature sensor calibration (fast display, any key ends)
K	Buzzer sound test (frequency and duration)
L / M	Write ASCII / hex to the LCD
Z	Divide-by-zero trap test (RF off, fan on)

Temperature sensor: the BD139 (Q3) on the heat sink is both the sensor and the bias reference. Let the amplifier reach room temperature, measure the heat sink with an accurate thermometer, and adjust the potentiometer on the control board using J.

8.2 Cables and levels

Signal (PC, DB-9)	Pin	3.5 mm plug on the PA-100D
RX data (from the PA)	2	Ring
TX data (to the PA)	3	Tip
Ground	5	Sleeve

On the **RS-928 tip and ring are swapped** on the serial and the PTT socket. The Elecraft KX3 ACC1 uses 0 V / +12 V instead of true RS-232 levels; the PA accepts them, some USB adapters do not.

8.3 KX2/KX3 and other ASCII transceivers

The PA uses the FA frequency answer, e.g. FA00014175000; (11 digits, Hz – Elecraft/Kenwood) or FA014175000; (9 digits – Yaesu FT-991, FTDX10) or FA14175000; (8 digits – Yaesu FT-450/950/2000, FTDX1200/3000/5000). Other lengths and corrupted messages are ignored; a new message always starts with F.

KX3 setup:

1. KX3 RF output → PA RF input.
2. KX3 **ACC2** → PA **T/R**: the keying transistor is on the ring of the 2.5 mm plug and goes to the tip of the 3.5 mm plug; sleeve to sleeve. **Do not connect the tip of the 2.5 mm plug.**
3. KX3 **ACC1** → PA **RS-232** with a tip/ring crossed cable (or set the PA's internal jumpers to the update position and use a straight cable).
4. PA: *Auto Band Detect* = KX2/KX3, *Serial Speed* as on the KX3 (KX3 default 4800).
5. Either KX3 menu **AUTOINF** = **ANT CTRL** (the KX3 sends FA on every change; polling may be off), or leave polling on (2 s; 1 s responds faster).

With polling off, switch on the KX3 first and then the PA: the PA sends one FA; query at power-on (the KX3 sends nothing on its own when switched on). Any manual band change or A/M change also sends a query.

KX2: same, through the TRRS ACC socket (keyline and serial data; e.g. Elecraft KX2ACBL breakout).

Test without a radio: connect a terminal and type e.g. FA007000000; (9 digits) – the 40 m filter is selected.

8.4 Xiegu band voltages

Input as for the FT-817 band voltage. Thresholds midway between the levels, ±115 mV tolerance:

Band	160 m	80 m	60 m*	40 m	30 m	20 m	17 m	15 m	12 m	10 m
Voltage	0.23 V	0.46 V	0.69 V	0.92 V	1.15 V	1.38 V	1.61 V	1.84 V	2.07 V	2.30 V

* 60 m uses the 40 m filter. Below 115 mV = out of band, above 2.415 V = unknown; both inhibit TX. Brick2/3 and SquareSDR deliver the same XPA125 levels.

FT-817/818 band voltages (mode FT817/818): 0.33 V 160 m, 0.67 V 80 m, 1.00 V 40 m, 1.33 V 30 m, 1.67 V 20 m, 2.00 V 17 m, 2.33 V 15 m, 2.67 V 12 m, 3.00 V 10 m.

8.5 HR50 mode

Auto Band Detect = HR50: the PA behaves like a HobbyPCB Hardrock-50 on the serial port. Programs and transceivers with HR50 support can select the band, switch Operate/Standby and read the status. The port then speaks only HR50: remote control, serial test and polling are off. Set *Serial Speed* to the host (the HR50 USB port defaults to 19200).

Command	Function
FAxxxxxxxxxx;	Frequency in Hz, selects the band. Kenwood IF...; data is handled the same way.
HRBNn; / HRBN;	Set / read band: 0 = 6 m, 1 = 10 m, 2 = 12 m, 3 = 15 m, 4 = 17 m, 5 = 20 m, 6 = 30 m, 7 = 40 m, 8 = 60 m, 9 = 80 m, 10 = 160 m, 99 = unknown
HRMDn; / HRMD;	1 = PTT (Operate), 0 = OFF (Standby). 2 (COR) and 3 (QRP) select Standby.
HRRX;	Status, e.g. RX, PTT, 20M, 27C, 13.8V;
H RTP; / HRVT;	Temperature H RTP27C; / supply voltage HRVT13.8V;
HRAT; / HRKX; / HRBR;	HRAT0; (no ATU) / HRKX0; / serial speed 0–3 (4800–38400); below 4800 the answer is 0, above 38400 (57600, 115200) it is 3 – the HR50 protocol knows no higher speeds
HRTM...;	ATU pass-through, answer HRTM; as an HR50 without ATU

Commands end with ;, upper or lower case; answers end with ;\r\n. SET commands are not answered. The band is kept until the host sends a new one. 6 m and "unknown" inhibit TX. HRBR, HRTP and HRKX are read-only; set speed and temperature scale in the menu.

8.6 Remote control

Serial Port = Remote (modes F-Sense, FT817/818, Xiegu, Manual). Command format: =<letter>[digit] followed by CR.

Command	Function
=A	Automatic band selection
=Bn	Manual band, n = 1 (160 m) ... 9 (10 m)
=C	Clear alarm
=Gn	Gain n = 1 ... 4 (applied after the transmission if sent during TX)
=O	Operate
=Pn	Power off; n = 1 saves the current settings, n = 0 or no digit does not save. RF is turned off first.
=R	Request status
=S	Standby

Status reply, e.g. 0:A:T:C: 5:1:1.0:14.09: 8.1: 27.2: 26:0: 0 followed by LF CR. Fields:

#	Value	Meaning
1	O / S	Operate / Standby
2	A / M	Automatic / manual band selection
3	T / R	Transmit / receive
4	C / F	Temperature scale
5	nn	Band 1 (160 m) ... 9 (10 m), 10 = unknown
6	n	Gain 1 – 4 (G1 = –6 dB ... G4 = 0 dB)
7	n.n	SWR
8	nn.nn	Supply voltage, V
9	nn.n	Current, A
10	nnn.n	Output power, W
11	nnn	Temperature
12	n	Fan 0 = off, 1 = low, 2 = medium, 3 = high
13	HH	Alarms, hexadecimal: bit 0 SWR, 1 over-current, 2 temperature, 3 over-voltage, 4 pre-limit, 5 low voltage

The reply is formatted completely and sent in one piece.

Remote time-out: with polling off, a remotely commanded Operate returns to Standby if no command arrives for 5 s – poll at least every few seconds (1 s recommended). With polling on, the amplifier sends a status message at every interval and never times out; a failed remote host is then not detected (as in v4.01a). Operate selected at the front panel does not time out.

USB-serial adapters split lines according to their latency timer (FTDI: 16 ms). Programs should assemble lines up to LF CR. Under Windows the latency timer can be set to 1 ms (Device Manager → COM port → Advanced).

Cautions: always **fuse the power leads**. Remote power-off does not disconnect the PA module from the supply; only the fuse protects against a shorted transistor. Jumper **J4** on the control board makes the PA switch on as soon as power is applied (for fully remote operation with a remotely switched power supply – use with great care). Request the status periodically.

9 Alarms

Alarm	Display	Cause	Effect
High SWR	SWR	SWR above the trip limit, Operate only	RF off, Standby
Over-current	O/C	Hardware trip of the MAX4373 at 24 A (latched)	RF off at once (also read directly in the 1 ms interrupt), Standby
Over-temperature	TEMP	Heat sink above the limit	RF off, Standby; fan at full speed
Over-voltage	Hi-V	Supply above the trip (if enabled)	RF off, Standby
Low voltage	Lo-V	Supply below the final limit (if enabled)	RF off, Standby
Pre-limit	Batt	Supply below the pre-limit (if Low Voltage is enabled)	Warning: no Standby, but TX stays off until acknowledged with PWR. Occurs once per power-on.

The alarm flashes and a loud beep sounds. A brief **PWR** clears the most urgent alarm first, then the next. DISPLAY, OPER, AUTO and BAND± are inactive while an alarm is shown, and TX stays off. If an over-current alarm cannot be cleared, switch off at once and look for the fault. The low voltage alarm can only be cleared once the voltage has risen again. Recharge batteries as soon as possible – a discharged lead-acid battery sulphates.

Test the alarms with the serial test (B) or, for SWR, with *SWR Trip* = 1.0 into a dummy load.

10 Firmware update and going back

The PA-100D has the **Ingenia boot loader**. A firmware file is loaded over the serial port with the Ingenia loader (Windows) or with `tools/juma-flash.py` (Windows, macOS, Linux). Full instructions: README in the repository (github.com/jcmerg/juma-pa100d-firmware).

1. Check the serial connection first: *Serial Speed* 115200, *Serial Port* Test, type H and F several times – the output must be error-free. Save the E dump.
2. Switch off. **Hold OPER and press PWR**: the boot loader starts.
3. Load `firmware/Juma PA-100D v5.01.hex` – program flash only, **never** the data EEPROM or the configuration registers. With `juma-flash.py`:

```
python3 tools/juma-flash.py --port COM3 "firmware/Juma PA-100D v5.01.hex"
```
4. Disconnect the power supply (PWR does not work in the boot loader), then switch on normally.

EEPROM: the original configuration and calibration blocks are unchanged – no checksum error, the calibration is kept. New settings (F-Sense QSK, Beep Tone, Xiegu/HR50) are in a separate extension block.

Going back: load `firmware/Juma PA-100D v4.01a Build 3 (original).hex` the same way. The calibration and all original settings are kept; Xiegu becomes F-Sense, HR50 becomes KX2/KX3, F-Sense QSK is ignored.

RS-928: delivered without the boot loader. It must be programmed once with a PICKit through header J19 (keep PWR pressed during programming), see the README.

11 Quick reference

Button	Brief press	Hold
PWR	Power on · cancel alarm · previous page · No in prompts	Power off (with save prompt) · from off: service mode · in menus: pages back
UP / DOWN	Gain (normal) · value (menus)	Repeat
DISPLAY/ CONFIG	Next measurement page · next menu page	User configuration · in menus: pages forward · from off (with PWR): RS-232 loop-back test
OPER	Operate/Standby (on release) · save & exit in menus	Save prompt (normal display, not in TX) · from off (with PWR): boot loader
AUTO	Auto / Manual band selection	–
BAND+	Higher band · Yes in prompts	Repeat · from off (with PWR): factory defaults
BAND–	Lower band	Repeat · from off (with PWR): HR50 message time-out 5 s

12 Settings record

User configuration

Setting	Default	Your setting
Auto Band Detect	F-Sense	
Serial Speed	9600 Baud	
Serial Port	Off	
Polling Interval	2 s	
Backlight	300	
Contrast	2000	
SWR Trip	3.0	
Fan Control	Normal	
Temperature	Celsius	
Overtmp	70 °C	
Fan Cut-In Temp	40 °C	
Band Display	MHz	
Graphical Limits	Off	
Graphic Display	Original	
RF Power Meter	Watts	
Start-Up Display	O/P Power	
F-Sense QSK	Off	
Band select / band / gain	Manual, 10 m, G1 on all bands	

Calibration

Setting	Default	Your setting
Voltmeter	5250	
Ammeter	2520	
RF power factor	1062	
RF power offset	120	
Beep Len	50 ms	
Beep Tone	JUMA	
Power Averaging	1	
Overvoltage / Trip	On / 14.50 V	
Low Voltage / Trip	On / 11.00 V	

Setting	Default	Your setting
Pre-Limit	11.20 V	
Full-Scale Power	100 W	
Frequency meter	999985	
Splash Screen	On	

13 Credits

- Original firmware: **Juha Niinikoski, OH2NLT**, and **Matti Hohtola, OH7SV** (JUMA)
- Extensions, maintenance and the v4.00a manual: **Adrian Ryan, 5B4AIY**
- Modifications from v4.03 and this manual: **DL4JC**
- Ingenia dsPIC boot loader: Ingenia-CAT S.L., adapted by OH2NLT