

API Protocol: Auth



Domotica | Audio | Video

Duotecno	Showroom:	T +3250 200560
Astridlaan 170A	Ten Briele 18.1	F +3250 200561
8310 Assebroek	8200 Sint-Michiels	
Belgium	Belgium	email: info@duotecno.be

API AUTHORIZATION

Version 1.05

Info: <http://www.duotecno.be>

Overview Authorization API	3
Supported nodes:	3
Create client credentials.....	4
Overview:	4
Request:.....	4
Response:	4
Example postman:.....	5
Refresh client access token	6
Overview:	6
Request:.....	6
Response:	6
Example postman:.....	6
Authorization error codes:	8
How to use in the configuration API.	8
Example Postman: API configuration request.....	8

Overview Authorization API

The base url for this API is: **https://[IP-Address]:8081/**

Protocol: https.

[IP-Address]: The IP-Address of the Duotecno node.

The port is always 8081.

Possibilities:

- Create client.
- Refresh client token.

The number of client login credentials is limited.

A client must only create the first time his login credentials. He must store these credentials and reuse them. When the access token is expired he must ask a new token via the refresh request.

To reduce the number of clients in the server a client **MUST** first always try to refresh his access token. **Only when this is not possible he must create a new client id.** This can happen when the client is not used for a long time.

When the server holds many clients and needs space for newer client ids it will remove the oldest clients first.

The client id and access tokens should be used in the configuration API.

A client id will only be stored by the server when it uses the configuration API.

Supported nodes:

Node	Minimum firmware version
Touchscreen	V66.05.08
TCP/IP Homeserver	V66.05.08
Universal audio interface	V66.05.08

Create client credentials

First a client must be created.

The response holds the client id and access tokens to use in the HTTP header of the configuration API functions.

Once a client is created he must use the access & refresh tokens.

Overview:

http method	GET
Endpoint	/auth/create
Response	Status code 200 (or error 400/401)

Request:

The HTTP header must hold Base64 client & password values.

The client id should be a dummy value.

Syntax: Base64 { dummyClientId:password }

Client id and password must be separated by a ':'

A ':' cannot be used in the client & password.

Response:

When successful the HTTP status code will be 200 and the json body holds the credentials to use.

When an error occurs the response will be HTTP status code 400/401. (See authorization errors).

keys	Value
"access_token"	String: The access token. This value should be used in the http header of the configuration API. Syntax Base64 { clientid:accesstoken } This value changes when a new access token is requested.
"client_id"	String: The client id. This value should be used in the http header of the configuration API. Syntax Base64 { clientid:accesstoken } This value never changes and must be used in the header with every call.
"expiry_time"	Integer value: The time in seconds the accesstoken is valid. After this time the client can ask a new accesstoken using the refresh_token.
"refresh_token"	String: The refresh token. This value should be used in the auth/refresh request. Syntax Base64 { clientid:refreshToken } This value changes when a new access token is requested.
"token_type"	String: value is always "Bearer".

Example postman:

Request:

<https://192.168.0.239:8081/auth/create>

dummy client: ADly5NVtjsZVmQIc

paswoord: duotecno

Base 64 Authorization string is: QURseTVOVnRqc1pWbVFJYzpkdW90ZWNUbw==

GET	https://192.168.0.239:8081/auth/create
Params	Authorization ● Headers (9) Body Pre-request Script Tests Settings
☒ Host ⓘ	<calculated when request is sent>
☒ User-Agent ⓘ	PostmanRuntime/7.28.1
☒ Accept ⓘ	*/*
☒ Accept-Encoding ⓘ	gzip, deflate, br
☒ Connection ⓘ	keep-alive
☒ Authorization	Basic QURseTVOVnRqc1pWbVFJYzpkdW90ZWNUbw==
Key	Value

Response:

```
{
  "access_token": "xBErAnB6C3Fqu41l",
  "client_id": "aR8NtDjryC3jjWOY",
  "expiry_time": 2400,
  "refresh_token": "9lvnH7xFilwzN8AE",
  "token_type": "Bearer"
}
```

Refresh client access token

After the expiry time the client access token can no longer be used. The client must call this request function to get a new access token.

The response holds the client id and new access token.

After this call the old access and refresh tokens can no longer be used.

In the configuration API:

When the client receives a http response error status code 401 "expired_token" it must use this request function to refresh his token. After refreshing the token he must use the new access token in the configuration API calls.

Overview:

http method	GET
Endpoint	/auth/refresh
Response	Status code 200 (or error 400/401)

Request:

The HTTP header must hold Base64 client & refresh access token.

Syntax: Base64 { clientid:refreshToken }

Client id and the refresh token must be separated by a ':'

Response:

When successful the HTTP status code will be 200 and the json body holds the new access and refresh tokens.

When an error occurs the response will be HTTP status code 400/401. (See authorization errors).

The same parameters are used as in the create response.

Both the "access_token" and "refresh_token" are new values.

Example postman:

Request:

https://192.168.0.239:8081/auth/refresh

client: aR8NtDjryC3jjWOY

refresh token: 9lvnH7xFllwzN8AE

Base 64 Authorization string is: YVI4TnREanJ5QzNqaldPWT05bHZuSDd4Rklsd3pOOEFF

GET

⌵

https://192.168.0.239:8081/auth/refresh

Params

Authorization

Headers (8)

Body

Pre-request Script

Tests

Settings

☒

Host ⓘ

<calculated when request is sent>

☒

User-Agent ⓘ

PostmanRuntime/7.28.1

☒

Accept ⓘ

/

☒

Accept-Encoding ⓘ

gzip, deflate, br

☒

Connection ⓘ

keep-alive

☒

Authorization

Basic YVI4TnREanJ5QzNqaldPWTo5bHZuSDd4Rklsd3pOOEFF

Key

Value

Response:

```
{
  "access_token": "byiD9NrK95oELNjz",
  "client_id": "aR8NtDjryC3jjWOY",
  "expiry_time": 2400,
  "refresh_token": "jVn1K1zwEBJvCkPc",
  "token_type": "Bearer"
}
```

