Chapter A2 **Programmers' Model**

This chapter introduces the ARM® Programmers' Model. It contains the following sections:

- Data types on page A2-2
- *Processor modes* on page A2-3
- Registers on page A2-4
- General-purpose registers on page A2-6
- Program status registers on page A2-11
- Exceptions on page A2-16
- Endian support on page A2-30
- Unaligned access support on page A2-38
- Synchronization primitives on page A2-44
- The Jazelle Extension on page A2-53
- Saturated integer arithmetic on page A2-69.

A2.1 Data types

ARM processors support the following data types:

Byte 8 bits
Halfword 16 bits
Word 32 bits

- _____Note _____
- Support for halfwords was introduced in version 4.
- ARMv6 has introduced unaligned data support for words and halfwords. See *Unaligned access support* on page A2-38 for more information.
- When any of these types is described as *unsigned*, the N-bit data value represents a non-negative integer in the range 0 to $+2^{N}-1$, using normal binary format.
- When any of these types is described as *signed*, the N-bit data value represents an integer in the range -2^{N-1} to $+2^{N-1}-1$, using two's complement format.
- Most data operations, for example ADD, are performed on word quantities. Long multiplies support
 64-bit results with or without accumulation. ARMv5TE introduced some halfword multiply
 operations. ARMv6 introduced a variety of Single Instruction Multiple Data (SIMD) instructions
 operating on two halfwords or four bytes in parallel.
- Load and store operations can transfer bytes, halfwords, or words to and from memory, automatically
 zero-extending or sign-extending bytes or halfwords as they are loaded. Load and store operations
 that transfer two or more words to and from memory are also provided.
- ARM instructions are exactly one word and are aligned on a four-byte boundary. Thumb[®] instructions
 are exactly one halfword and are aligned on a two-byte boundary. Jazelle[®] opcodes are a variable
 number of bytes in length and can appear at any byte alignment.

A2.2 Processor modes

The ARM architecture supports the seven processor modes shown in Table A2-1.

can read from		\rightarrow		Table A2-1 ARM processor modes		
	Processor mod		Mode number	Description		
	User	usr	0b10000	Normal program execution mode		
for our	FIQ	fiq	0b10001	Supports a high-speed data transfer or channel process		
timer interrupt	IRQ	irq	0b10010	Used for general-purpose interrupt handling		
(& other)	Supervisor	svo	0b10011	A protected mode for the operating system		
	Abort	abt	0b10111	Implements virtual memory and/or memory protection		
	Undefined	und	0b11011	Supports software emulation of hardware coprocessors		
	System	sys	0b11111	Runs privileged operating system tasks (ARMv4 and above)		

Mode changes can be made under software control, or can be caused by external interrupts or exception processing.

Most application programs execute in User mode. When the processor is in User mode, the program being executed is unable to access some protected system resources or to change mode, other than by causing an exception to occur (see *Exceptions* on page A2-16). This allows a suitably-written operating system to control the use of system resources.

The modes other than User mode are known as *privileged modes*. They have full access to system resources and can change mode freely. Five of them are known as *exception modes*:

- FIQ
- IRQ
- Supervisor
- Abort
- Undefined.

These are entered when specific exceptions occur. Each of them has some additional registers to avoid corrupting User mode state when the exception occurs (see *Registers* on page A2-4 for details).


The remaining mode is System mode, which is not entered by any exception and has exactly the same registers available as User mode. However, it is a privileged mode and is therefore not subject to the User mode restrictions. It is intended for use by operating system tasks that need access to system resources, but wish to avoid using the additional registers associated with the exception modes. Avoiding such use ensures that the task state is not corrupted by the occurrence of any exception.

A2.3 Registers

The ARM processor has a total of 37 registers:

- Thirty-one general-purpose registers, including a program counter. These registers are 32 bits wide and are described in *General-purpose registers* on page A2-6.
- Six status registers. These registers are also 32 bits wide, but only some of the 32 bits are allocated or need to be implemented. The subset depends on the architecture variant supported. These are described in *Program status registers* on page A2-11.

Registers are arranged in partially overlapping banks, with the current processor mode controlling which bank is available, as shown in Figure A2-1 on page A2-5. At any time, 15 general-purpose registers (R0 to R14), one or two status registers, and the program counter are visible. Each column of Figure A2-1 on page A2-5 shows which general-purpose and status registers are visible in the indicated processor mode.



r13 = stack pointer sp

r14 = link register lr

we currently

will do user

soon-ish.

mode,-

r15 = program counter

r0-r3 = argument registers, caller-saved

Figure A2-1 Register organization

A2.4 General-purpose registers

The general-purpose registers R0 to R15 can be split into three groups. These groups differ in the way they are banked and in their special-purpose uses:

- The unbanked registers, R0 to R7
- The banked registers, R8 to R14
- Register 15, the PC, is described in *Register 15 and the program counter* on page A2-9.

A2.4.1 The unbanked registers, R0 to R7

Registers R0 to R7 are *unbanked registers*. This means that each of them refers to the same 32-bit physical register in all processor modes. They are completely general-purpose registers, with no special uses implied by the architecture, and can be used wherever an instruction allows a general-purpose register to be specified.

A2.4.2 The banked registers, R8 to R14 r8-r12 only banked by FIQ

Registers R8 to R14 are *banked registers*. The physical register referred to by each of them depends on the current processor mode. Where a particular physical register is intended, without depending on the current processor mode, a more specific name (as described below) is used. Almost all instructions allow the banked registers to be used wherever a general-purpose register is allowed.

—— Note ———
There are a few exceptions to this rule for processors pre-ARMv6, and they are noted in the individual
instruction descriptions. Where a restriction exists on the use of banked registers, it always applies to all of
R8 to R14. For example, R8 to R12 are subject to such restrictions even in systems in which FIQ mode is
never used and so only one physical version of the register is ever in use.

Registers R8 to R12 have two banked physical registers each. One is used in all processor modes other than FIQ mode, and the other is used in FIQ mode. Where it is necessary to be specific about which version is being referred to, the first group of physical registers are referred to as R8_usr to R12_usr and the second group as R8_fiq to R12_fiq.

Registers R8 to R12 do not have any dedicated special purposes in the architecture. However, for interrupts that are simple enough to be processed using registers R8 to R14 only, the existence of separate FIQ mode versions of these registers allows very fast interrupt processing.

Registers R13 and R14 have six banked physical registers each. One is used in User and System modes, and each of the remaining five is used in one of the five exception modes. Where it is necessary to be specific about which version is being referred to, you use names of the form:

R13_<mode>

where <mode> is the appropriate one of usr, svc (for Supervisor mode), abt, und, irq and fiq.

Register R13 is normally used as a stack pointer and is also known as the SP. The SRS instruction, introduced in ARMv6, is the only ARM instruction that uses R13 in a special-case manner. There are other such instructions in the Thumb instruction set, as described in Chapter A6 *The Thumb Instruction Set*.

Each exception mode has its own banked version of R13. Suitable uses for these banked versions of R13 depend on the architecture version:

• In architecture versions earlier than ARMv6, each banked version of R13 will normally be initialized to point to a stack dedicated to that exception mode. On entry, the exception handler typically stores the values of other registers that it wants to use on this stack. By reloading these values into the register when it returns, the exception handler can ensure that it does not corrupt the state of the program that was being executed when the exception occurred.

If fewer exception-handling stacks are desired in a system than this implies, it is possible instead to initialize the banked version of R13 for an exception mode to point to a small area of memory that is used for temporary storage while transferring to another exception mode and its stack. For example, suppose that there is a requirement for an IRQ handler to use the Supervisor mode stack to store SPSR_irq, R0 to R3, R12, R14_irq, and then to execute in Supervisor mode with IRQs enabled. This can be achieved by initializing R13_irq to point to a four-word temporary storage area, and using the following code sequence on entry to the handler:

"store multiple, increment after

! means write

back to reg

```
→STMIA R13, (R0-R3)
                        ; Put RO-R3 into temporary storage
 MRS
        RØ, SPSR
                         Move banked SPSR and R12-R14 into
 MOV
        R1, R12
                        ; unbanked registers
        R2, R13
 MOV
 MOV
        R3, R14
 MRS
        R12, CPSR
                        ; Use read/modify/write sequence
                                                                        CPSR_c = only write
 BIC
        R12, R12, #0x1F; on CPSR to switch to Supervisor
 ORR
        R12, R12, #0x13; mode
                                                                        control bits
 MSR
        CPSR_c R12
       R13!, (R1,R3)
                       ; Push original {R12, R14_irg}, then
 STMFD
        R0, [R13,#-20]!; SPSR_irq with a gap for R0-R3
 STR
                         Reload R0-R3 from temporary storage
 LDMIA
       R2, {R0-R3}
                         Modify and write CPSR again to
 BIC
        R12, R12, #0x80;
 MSR
        CPSR_c, R12
                         re-enable IRQs
 STMIB
      R13, {R0-R3}
                         Store RO-R3 in the gap left on the
                        ; stack for them
```

• In ARMv6 and above, it is recommended that the OS designer should decide how many exception-handling stacks are required in the system, and select a suitable processor mode in which to handle the exceptions that use each stack. For example, one exception-handling stack might be required to be locked into real memory and be used for aborts and high-priority interrupts, while another could use virtual memory and be used for SWIs, Undefined instructions and low-priority interrupts. Suitable processor modes in this example might be Abort mode and Supervisor mode respectively.

The banked version of R13 for each of the selected modes is then initialized to point to the corresponding stack, and the other banked versions of R13 are normally not used. Each exception handler starts with an SRS instruction to store the exception return information to the appropriate stack, followed (if necessary) by a CPS instruction to switch to the appropriate mode and possibly

re-enable interrupts, after which other registers can be saved on that stack. So in the above example, an Undefined Instruction handler that wants to re-enable interrupts immediately would start with the following two instructions:

SRSFD #svc_mode!
CPSIE i, #svc_mode

The handler can then operate entirely in Supervisor mode, using the virtual memory stack pointed to by R13_svc.

Register R14 (also known as the Link Register or LR) has two special functions in the architecture:

- In each mode, the mode's own version of R14 is used to hold subroutine return addresses. When a subroutine call is performed by a BL or BLX instruction, R14 is set to the subroutine return address. The subroutine return is performed by copying R14 back to the program counter. This is typically done in one of the two following ways:
 - Execute a BX LR instruction.



An MOV PC,LR instruction will perform the same function as BX LR if the code to which it returns uses the current instruction set, but will not return correctly from an ARM subroutine called by Thumb code, or from a Thumb subroutine called by ARM code. The use of MOV PC,LR instructions for subroutine return is therefore deprecated.

- On subroutine entry, store R14 to the stack with an instruction of the form:
 STMFD SP!, {<registers>,LR}
 and use a matching instruction to return:
 LDMFD SP!, {<registers>,PC}
- When an exception occurs, the appropriate exception mode's version of R14 is set to the exception return address (offset by a small constant for some exceptions). The exception return is performed in a similar way to a subroutine return, but using slightly different instructions to ensure full restoration of the state of the program that was being executed when the exception occurred. See *Exceptions* on page A2-16 for more details.

Register R14 can be treated as a general-purpose register at all other times.

Note	
11016	

When nested exceptions are possible, the two special-purpose uses might conflict. For example, if an IRQ interrupt occurs when a program is being executed in User mode, none of the User mode registers are necessarily corrupted. But if an interrupt handler running in IRQ mode re-enables IRQ interrupts and a nested IRQ interrupt occurs, any value the outer interrupt handler is holding in R14_irq at the time is overwritten by the return address of the nested interrupt.

System programmers need to be careful about such interactions. The usual way to deal with them is to ensure that the appropriate version of R14 does not hold anything significant at times when nested exceptions can occur. When this is hard to do in a straightforward way, it is usually best to change to another

processor mode during entry to the exception handler, before re-enabling interrupts or otherwise allowing nested exceptions to occur. (In ARMv4 and above, System mode is often the best mode to use for this purpose.)

A2.4.3 Register 15 and the program counter

Register R15 (R15) is often used in place of the other general-purpose registers to produce various special-case effects. These are instruction-specific and so are described in the individual instruction descriptions.

There are also many instruction-specific restrictions on the use of R15. these are also noted in the individual instruction descriptions. Usually, the instruction is UNPREDICTABLE if R15 is used in a manner that breaks these restrictions.

If an instruction description neither describes a special-case effect when R15 is used nor places restrictions on its use, R15 is used to read or write the *Program Counter* (PC), as described in:

- Reading the program counter
- Writing the program counter on page A2-10.

Reading the program counter

When an instruction reads the PC, the value read depends on which instruction set it comes from:

- For an ARM instruction, the value read is the address of the instruction plus 8 bytes. Bits [1:0] of this
 value are always zero, because ARM instructions are always word-aligned.
- For a Thumb instruction, the value read is the address of the instruction plus 4 bytes. Bit [0] of this value is always zero, because Thumb instructions are always halfword-aligned.

This way of reading the PC is primarily used for quick, position-independent addressing of nearby instructions and data, including position-independent branching within a program.

An exception to the above rule occurs when an ARM STR or STM instruction stores R15. Such instructions can store either the address of the instruction plus 8 bytes, like other instructions that read R15, or the address of the instruction plus 12 bytes. Whether the offset of 8 or the offset of 12 is used is IMPLEMENTATION DEFINED. An implementation must use the same offset for all ARM STR and STM instructions that store R15. It cannot use 8 for some of them and 12 for others.

Because of this exception, it is usually best to avoid the use of STR and STM instructions that store R15. If this is difficult, use a suitable instruction sequence in the program to ascertain which offset the implementation uses. For example, if R0 points to an available word of memory, then the following instructions put the offset of the implementation in R0:

```
SUB R1, PC, #4 ; R1 = address of following STR instruction
STR PC, [R0] ; Store address of STR instruction + offset,
LDR R0, [R0] ; then reload it
SUB R0, R0, R1 ; Calculate the offset as the difference
```

The rules about how R15 is read apply only to reads by instructions. In particular, they do not necessarily describe the values placed on a hardware address bus during instruction fetches. Like all other details of hardware interfaces, such values are IMPLEMENTATION DEFINED.

Writing the program counter

When an instruction writes the PC, the normal result is that the value written to the PC is treated as an instruction address and a branch occurs to that address.

Since ARM instructions are required to be word-aligned, values they write to the PC are normally expected to have bits [1:0] == 0b00. Similarly, Thumb instructions are required to be halfword-aligned and so values they write to the PC are normally expected to have bit [0] == 0.


The precise rules depend on the current instruction set state and the architecture version:

- In T variants of ARMv4 and above, including all variants of ARMv6 and above, bit[0] of a value
 written to R15 in Thumb state is ignored unless the instruction description says otherwise. If bit[0]
 of the PC is implemented (which depends on whether and how the Jazelle Extension is implemented),
 then zero must be written to it regardless of the value written to bit[0] of R15.
- In ARMv6 and above, bits[1:0] of a value written to R15 in ARM state are ignored unless the instruction description says otherwise. Bit[1] of the PC must be written as zero regardless of the value written to bit[1] of R15. If bit[0] of the PC is implemented (which depends on how the Jazelle Extension is implemented), then zero must be written to it.
- In all variants of ARMv4 and ARMv5, bits[1:0] of a value written to R15 in ARM state must be 0b00. If they are not, the results are UNPREDICTABLE.

Several instructions have their own rules for interpreting values written to R15. For example, BX and other instructions designed to transfer between ARM and Thumb states use bit[0] of the value to select whether to execute the code at the destination address in ARM state or Thumb state. Special rules of this type are described on the individual instruction pages, and override the general rules in this section.

A2.5 **Program status registers**

The Current Program Status Register (CPSR) is accessible in all processor modes. It contains condition code flags, interrupt disable bits, the current processor mode, and other status and control information. Each exception mode also has a Saved Program Status Register (SPSR), that is used to preserve the value of the CPSR when the associated exception occurs.



User mode and System mode do not have an SPSR, because they are not exception modes. All instructions that read or write the SPSR are UNPREDICTABLE when executed in User mode or System mode.

l=1, int's The format of the CPSR and the SPSRs is shown below. disabled 31 30 29 28 27 26 25 24 23 20 19 16 15 C V E F T Q J RESERVED GE[3:0] M[4:0] Res RESERVED

A2.5.1 Types of PSR bits

table a2-1

PSR bits fall into four categories, depending on the way in which they can be updated:

Reserved bits Reserved for future expansion. Implementations must read these bits as 0 and ignore

> writes to them. For maximum compatibility with future extensions to the architecture, they must be written with values read from the same bits.

User-writable bits Can be written from any mode. The N, Z, C, V, Q, GE[3:0], and E bits are

user-writable.

Can be written from any privileged mode. Writes to privileged bits in User mode are Privileged bits

ignored. The A, I, F, and M[4:0] bits are privileged.

Can be written from any privileged mode. Writes to execution state bits in User **Execution state bits**

mode are ignored. The J and T bits are execution state bits, and are always zero in ISSUE

ARM state.

Privileged MSR instructions that write to the CPSR execution state bits must write zeros to them, in order to avoid changing them. If ones are written to either or both of them, the resulting behavior is UNPREDICTABLE. This restriction applies only to the CPSR execution state bits, not the SPSR execution state bits.

A2.5.2 The condition code flags

The N, Z, C, and V (Negative, Zero, Carry and oVerflow) bits are collectively known as the condition code flags, often referred to as flags. The condition code flags in the CPSR can be tested by most instructions to determine whether the instruction is to be executed.

The condition code flags are usually modified by:

- Execution of a comparison instruction (CMN, CMP, TEQ or TST).
- Execution of some other arithmetic, logical or move instruction, where the destination register of the
 instruction is not R15. Most of these instructions have both a flag-preserving and a flag-setting
 variant, with the latter being selected by adding an S qualifier to the instruction mnemonic. Some of
 these instructions only have a flag-preserving version. This is noted in the individual instruction
 descriptions.

In either case, the new condition code flags (after the instruction has been executed) usually mean:

- N Is set to bit 31 of the result of the instruction. If this result is regarded as a two's complement signed integer, then N = 1 if the result is negative and N = 0 if it is positive or zero.
- **Z** Is set to 1 if the result of the instruction is zero (this often indicates an *equal* result from a comparison), and to 0 otherwise.
- **C** Is set in one of four ways:
 - For an addition, including the comparison instruction CMN, C is set to 1 if the addition produced a carry (that is, an unsigned overflow), and to 0 otherwise.
 - For a subtraction, including the comparison instruction CMP, C is set to 0 if the subtraction produced a borrow (that is, an unsigned underflow), and to 1 otherwise.
 - For non-addition/subtractions that incorporate a shift operation, C is set to the last bit shifted out of the value by the shifter.
 - For other non-addition/subtractions, C is normally left unchanged (but see the individual instruction descriptions for any special cases).
- V Is set in one of two ways:
 - For an addition or subtraction, V is set to 1 if signed overflow occurred, regarding the
 operands and result as two's complement signed integers.
 - For non-addition/subtractions, V is normally left unchanged (but see the individual instruction descriptions for any special cases).

The flags can be modified in these additional ways:

- Execution of an MSR instruction, as part of its function of writing a new value to the CPSR or SPSR.
- Execution of MRC instructions with destination register R15. The purpose of such instructions is to transfer coprocessor-generated condition code flag values to the ARM processor.
- Execution of some variants of the LDM instruction. These variants copy the SPSR to the CPSR, and their main intended use is for returning from exceptions.
- Execution of an RFE instruction in a privileged mode that loads a new value into the CPSR from memory.
- Execution of flag-setting variants of arithmetic and logical instructions whose destination register is R15. These also copy the SPSR to the CPSR, and are intended for returning from exceptions.

A2.5.3 The Q flag

In E variants of ARMv5 and above, bit[27] of the CPSR is known as the Q flag and is used to indicate whether overflow and/or saturation has occurred in some DSP-oriented instructions. Similarly, bit[27] of each SPSR is a Q flag, and is used to preserve and restore the CPSR Q flag if an exception occurs. See *Saturated integer arithmetic* on page A2-69 for more information.

In architecture versions prior to ARMv5, and in non-E variants of ARMv5, bit[27] of the CPSR and SPSRs must be treated as a reserved bit, as described in *Types of PSR bits* on page A2-11.

A2.5.4 The GE[3:0] bits

In ARMv6, the SIMD instructions use bits[19:16] as *Greater than or Equal* (GE) flags for individual bytes or halfwords of the result. You can use these flags to control a later SEL instruction, see *SEL* on page A4-127 for more details.

Instructions that operate on halfwords:

- set or clear GE[3:2] together, based on the result of the top halfword calculation
- set or clear GE[1:0] together, based on the result of the bottom halfword calculation.

Instructions that operate on bytes:

- set or clear GE[3] according to the result of the top byte calculation
- set or clear GE[2] according to the result of the second byte calculation
- set or clear GE[1] according to the result of the third byte calculation
- set or clear GE[0] according to the result of the bottom byte calculation.

Each bit is set (otherwise cleared) if the results of the corresponding calculation are as follows:

- for unsigned byte addition, if the result is greater than or equal to 28
- for unsigned halfword addition, if the result is greater than or equal to 2^{16}
- for unsigned subtraction, if the result is greater than or equal to zero
- for signed arithmetic, if the result is greater than or equal to zero.

In architecture versions prior to ARMv6, bits[19:16] of the CPSR and SPSRs must be treated as a reserved bit, as described in *Types of PSR bits* on page A2-11.

A2.5.5 The E bit

From ARMv6, bit[9] controls load and store endianness for data handling. See *Instructions to change CPSR E bit* on page A2-36. This bit is ignored by instruction fetches.

In architecture versions prior to ARMv6, bit[9] of the CPSR and SPSRs must be treated as a reserved bit, as described in *Types of PSR bits* on page A2-11.

A2.5.6 The interrupt disable bits

A, I, and F are the interrupt disable bits:

A bit Disables imprecise data aborts when it is set. This is available only in ARMv6 and above. In earlier versions, bit[8] of CPSR and SPSRs must be treated as a reserved bit, as described in *Types of PSR bits* on page A2-11.

I bit Disables IRQ interrupts when it is set.

F bit Disables FIQ interrupts when it is set.

A2.5.7 The mode bits

M[4:0] are the mode bits. These determine the mode in which the processor operates. Their interpretation is shown in Table A2-2.

Table A2-2 The mode bits

M[4:0]	Mode	Accessible registers
0ь10000	User	PC, R14 to R0, CPSR
0b10001	FIQ	PC, R14_fiq to R8_fiq, R7 to R0, CPSR, SPSR_fiq
0b10010	IRQ	PC, R14_irq, R13_irq, R12 to R0, CPSR, SPSR_irq
0b10011	Supervisor	PC, R14_svc, R13_svc, R12 to R0, CPSR, SPSR_svc
0b10111	Abort	PC, R14_abt, R13_abt, R12 to R0, CPSR, SPSR_abt
0b11011	Undefined	PC, R14_und, R13_und, R12 to R0, CPSR, SPSR_und
0b11111	System	PC, R14 to R0, CPSR (ARMv4 and above)

Not all combinations of the mode bits define a valid processor mode. Only those combinations explicitly described can be used. If any other value is programmed into the mode bits M[4:0], the result is UNPREDICTABLE.

r15

A2.5.8 The T and J bits

The T and J bits select the current instruction set, as shown in Table A2-3.

Table A2-3 The T and J bits

J	Т	Instruction set
0	0	ARM
0	1	Thumb
1	0	Jazelle
1	1	RESERVED

we don't use

The T bit exists on t variants of ARMv4, and en all variants of ARMv5 and above. on non-T variants of ARMv4, the T bit must be treated as a reserved by as described in *Types of PSR bits* on page A2-11.

The Thumb instruction set is implemented on T variants of ARMv4 and ARMv5, and on all variants of ARMv6 and above. instructions that switch between ARM and Thumb state execution can be used freely on implementation of these architectures.

The Thumb instruction set is not implemented on non-T variants of ARMv5. If the Thumb instruction set is selected by setting T ==1 on these architecture variants, the next instruction executed will cause an Undefined Instruction exception (see *Undefined Instruction exception* on page A2-19). Instructions that switch between ARM and Thumb state execution can be used on implementation of these architecture variants, but only function correctly as long as the program remains in ARM state. If the program attempts to switch to Thumb state, the first instruction executed after that switch causes an Undefined Instruction exception. Entry into that exception then switches back to ARM state. The exception handler can detect that this was the cause of the exception from the fact that the T bit of SPSR_und is set.

The J bit exists on ARMv5TEJ and on all variants of ARMv6 and above. On variants of ARMv4 and ARMv5, other than ARMv5TEJ, the J bit must be treated as a reserved bit, as described in *Types of PSR bits* on page A2-11.

Hardware acceleration for Jazelle opcode execution can be implemented on ARMv5TEJ and on ARMv6 and above. On these architecture variants, the BXJ instruction is used to switch from ARM state into Jazelle state when the hardware accelerator is present and enabled. If the hardware accelerator is disabled, or not present, the BXJ instruction behaves as a BX instruction, and the J bit remains clear. For more details, see *The Jazelle Extension* on page A2-53.

A2.5.9 Other bits



Other bits in the program status registers are reserved for future expansion. In general, programmers must take care to write code in such a way that these bits are never modified. Failure to do this might result in code that has unexpected side effects on future versions of the architecture. See *Types of PSR bits* on page A2-11, and the usage notes for the MSR instruction on page A4-76 for more details.

Exceptions A2.6

Exceptions are generated by internal and external sources to cause the processor to handle an event, such as an externally generated interrupt or an attempt to execute an Undefined instruction. The processor state just before handling the exception is normally preserved so that the original program can be resumed when the exception routine has completed. More than one exception can arise at the same time.

The ARM architecture supports seven types of exception. Table A2-4 lists the types of exception and the processor mode that is used to process each type. When an exception occurs, execution is forced from a fixed memory address corresponding to the type of exception. These fixed addresses are called the *exception* vectors.

Note	
The normal vector at address 0x000000 expansion.	014 and the high vector at address 0xFFFF0014 are reserved for future
	no gap, implication?

Table A2-4 Exception processing modes

Exception type	Mode	VE	a Normal address	High vector address
Reset	Supervisor		0x00000000	0xFFFF0000
Undefined instructions	Undefined		0x00000004	0xFFFF0004
Software interrupt (SWI)	Supervisor		0x00000008	0xFFFF0008
Prefetch Abort (instruction fetch memory abort)	Abort		0x0000000C	0xFFFF000C
Data Abort (data access memory abort)	Abort		0x00000010	0xFFFF0010
IRQ (interrupt)	IRQ	0	0x00000018	0xFFFF0018
,		1	IMPLEMENTAT	ION DEFINED
FIQ (fast interrupt)	FIQ	0	0x0000001C	0xFFFF001C
		1	IMPLEMENTAT	ION DEFINED

a. VE = vectored interrupt enable (CP15 control); RAZ when not implemented.

When an exception occurs, the banked versions of R14 and the SPSR for the exception mode are used to save state as follows:

```
old state so we can use
R14_<exception_mode> = return link
SPSR_<exception_mode> = CPSR
CPSR[4.0] = exception mode number
CPSR[5] = 0
                                      /* Execute in ARM state */
if <exception_mode> == Reset or FIQ then
                                      /* Disable fast interrupts */
    CPSR[6] = 1
/* else CPSR[6] is unchanged */
                                      /* Disable normal interrupts */
CPSR[7] = 1
if <exception_mode> != UNDEF or SWI then
    CPSR[8] = 1
                                      /* Disable imprecise aborts (v6 only) */
/* else CPSR[8] is unchanged */
CPSR[9] = CP15_reg1_EEbit
                                      /* Endianness on exception entry */
PC = exception vector address
```

To return after handling the exception, the SPSR is moved into the CPSR, and R14 is moved to the PC. This can be done atomically in two ways:

- using a data-processing instruction with the S bit set, and the PC as the destination
- using the Load Multiple with Restore CPSR instruction, as described in *LDM* (3) on page A4-40.

In addition, in ARMv6, the RFE instruction (see *RFE* on page A4-113) can be used to load the CPSR and PC from memory, so atomically returning from an exception to a PC and CPSR that was previously saved in memory.

Collectively these mechanisms define all of the mechanisms which perform a return from exception.

The following sections show what happens automatically when the exception occurs, and also show the recommended data-processing instruction to use to return from each exception. This instruction is always a MOVS or SUBS instruction with the PC as its destination.

— Note —

When the recommended data-processing instruction is a SUBS and a Load Multiple with Restore CPSR instruction is used to return from the exception handler, the subtraction must still be performed. This is usually done at the start of the exception handler, before the return link is stored to memory.

For example, an interrupt handler that wishes to store its return link on the stack might use instructions of the following form at its entry point:

```
SUB R14, R14, #4
STMFD SP!, {<other_registers>, R14}
and return using the instruction:

LDMFD SP!, {<other_registers>, PC}^
```

A2.6.1 ARMv6 extensions to the exception model

In ARMv6 and above, the exception model is extended as follows:

- An imprecise data abort mechanism that allows some types of data abort to be treated asynchronously. The resulting exceptions behave like interrupts, except that they use Abort mode and its banked registers. This mechanism includes a mask bit (the A bit) in the PSRs, in order to ensure that imprecise data aborts do not occur while another abort is being handled. The mechanism is described in *Imprecise data aborts* on page A2-23.
- Support for vectored interrupts controlled by the VE bit in the system control coprocessor (see *Vectored interrupt support* on page A2-26). It is IMPLEMENTATION DEFINED whether support for this mechanism is included in earlier versions of the architecture.
- Support for a low interrupt latency configuration controlled by the FI bit in the system control
 coprocessor (see *Low interrupt latency configuration* on page A2-27). It is IMPLEMENTATION
 DEFINED whether support for this mechanism is included in earlier versions of the architecture.
- Three new instructions (CPS, SRS, RFE) to improve nested stack handling of different exceptions in a common mode. CPS can also be used to efficiently enable or disable the interrupt and imprecise abort masks, either within a mode, or while transitioning from a privileged mode to any other mode. See New instructions to improve exception handling on page A2-28 for a brief description.

A2.6.2 Reset

When the Reset input is asserted on the processor, the ARM processor immediately stops execution of the current instruction. When Reset is de-asserted, the following actions are performed:

```
R14_svc = UNPREDICTABLE value
SPSR_svc = UNPREDICTABLE value
CPSR[4:0] = 0b10011
                                 /* Enter Supervisor mode */
CPSR[5] = 0
                                 /* Execute in ARM state */
CPSR[6]
         = 1
                                 /* Disable fast interrupts */
                                 /* Disable normal interrupts */
CPSR[7]
          = 1
CPSR[8]
          = 1
                                 /* Disable Imprecise Aborts (v6 only) */
CPSR[9]
          = CP15_reg1_EEbit
                                 /* Endianness on exception entry */
if high vectors configured then
    PC
          = 0xFFFF0000
else
    PC
          = 0 \times 000000000
```

After Reset, the ARM processor begins execution at address 0x00000000 or 0xFFFF0000 in Supervisor mode with interrupts disabled.

Note			
There is no architecturally	defined way o	f returning f	rom a Reset.

A2.6.3 Undefined Instruction exception

If the ARM processor executes a coprocessor instruction, it waits for any external coprocessor to acknowledge that it can execute the instruction. If no coprocessor responds, an Undefined Instruction exception occurs.

If an attempt is made to execute an instruction that is UNDEFINED, an Undefined Instruction exception occurs (see *Extending the instruction set* on page A3-32).

The Undefined Instruction exception can be used for software emulation of a coprocessor in a system that does not have the physical coprocessor (hardware), or for general-purpose instruction set extension by software emulation.

When an Undefined Instruction exception occurs, the following actions are performed:

```
R14 und
         = address of next instruction after the Undefined instruction
SPSR\_und = CPSR
CPSR[4:0] = 0b11011
                                 /* Enter Undefined Instruction mode */
CPSR[5] = 0
                                 /* Execute in ARM state */
                                 /* CPSR[6] is unchanged */
CPSR[7] = 1
                                 /* Disable normal interrupts */
                                 /* CPSR[8] is unchanged */
CPSR[9]
         = CP15_reg1_EEbit
                                 /* Endianness on exception entry */
if high vectors configured then
   PC
         = 0xFFFF0004
else
    PC
         = 0 \times 000000004
```

To return after emulating the Undefined instruction use:

```
MOVS PC, R14
```

This restores the PC (from R14_und) and CPSR (from SPSR_und) and returns to the instruction following the Undefined instruction.

In some coprocessor designs, an internal exceptional condition caused by one coprocessor instruction is signaled *imprecisely* by refusing to respond to a later coprocessor instruction. In these circumstances, the Undefined Instruction handler takes whatever action is necessary to clear the exceptional condition, then returns to the second coprocessor instruction. To do this use:

SUBS PC,R14,#4

A2.6.4 Software Interrupt exception

The Software Interrupt instruction (SWI) enters Supervisor mode to request a particular supervisor (operating system) function. When a SWI is executed, the following actions are performed:

```
R14_svc = address of next instruction after the SWI instruction
SPSR\_svc = CPSR
CPSR[4:0] = 0b10011
                                 /* Enter Supervisor mode */
CPSR[5] = 0
                                 /* Execute in ARM state */
                                 /* CPSR[6] is unchanged */
CPSR[7]
          = 1
                                 /* Disable normal interrupts */
                                 /* CPSR[8] is unchanged */
CPSR[9]
          = CP15_reg1_EEbit
                                 /* Endianness on exception entry */
if high vectors configured then
    PC
          = 0xFFFF0008
else
    PC
          = 0 \times 000000008
```

To return after performing the SWI operation, use the following instruction to restore the PC (from R14_svc) and CPSR (from SPSR_svc) and return to the instruction following the SWI:

MOVS PC, R14

A2.6.5 Prefetch Abort (instruction fetch memory abort)

A memory abort is signaled by the memory system. Activating an abort in response to an instruction fetch marks the fetched instruction as invalid. A Prefetch Abort exception is generated if the processor tries to execute the invalid instruction. If the instruction is not executed (for example, as a result of a branch being taken while it is in the pipeline), no Prefetch Abort occurs.

In ARMv5 and above, a Prefetch Abort exception can also be generated as the result of executing a BKPT instruction. For details, see *BKPT* on page A4-14 (ARM instruction) and *BKPT* on page A7-24 (Thumb instruction).

When an attempt is made to execute an aborted instruction, the following actions are performed:

```
R14_abt = address of the aborted instruction + 4
SPSR_abt = CPSR
CPSR[4:0] = 0b10111
                                 /* Enter Abort mode */
                                 /* Execute in ARM state */
CPSR[5] = 0
                                 /* CPSR[6] is unchanged */
CPSR[7]
         = 1
                                 /* Disable normal interrupts */
                                 /* Disable Imprecise Data Aborts (v6 only) */
CPSR[8]
          = 1
CPSR[9]
          = CP15_reg1_EEbit
                                 /* Endianness on exception entry */
if high vectors configured then
         = 0xFFFF000C
    PC
else
    PC
          = 0x0000000C
```