



POWERFACTORY

PowerFactory 2026

Python Function Reference

POWER SYSTEM SOLUTIONS
MADE IN GERMANY

P2026

Publisher:

DlgSILENT GmbH
Heinrich-Hertz-Straße 9
72810 Gomaringen / Germany
Tel.: +49 (0) 7072-9168-0
Fax: +49 (0) 7072-9168-88
info@digsilent.de

Please visit our homepage at:

<https://www.digsilent.de>

Copyright DlgSILENT GmbH

All rights reserved. No part of this publication may be reproduced or distributed in any form without written permission of DlgSILENT GmbH.

July 7, 2026

r133669

Contents

1	General Description	1
2	PowerFactory Module	2
3	Application Methods	4
3.1	File System	46
3.2	Date/Time	48
3.3	Dialogue Boxes	48
3.4	Environment	51
3.5	Mathematics	55
3.6	Output Window	61
4	Output Window	64
5	Object Methods	66
5.1	General Methods	66
5.2	Network Elements	97
5.2.1	ElmArea	97
5.2.2	ElmAsm	99
5.2.3	ElmAsmsc	103
5.2.4	ElmBattery	104
5.2.5	ElmBbone	105
5.2.6	ElmBmu	107
5.2.7	ElmBoundary	108
5.2.8	ElmBranch	110
5.2.9	ElmCabsys	111
5.2.10	ElmComp	112
5.2.11	ElmCoup	112
5.2.12	ElmDcu	114
5.2.13	ElmDsl	115
5.2.14	ElmFeeder	116
5.2.15	ElmFile	118

5.2.16	ElmFilter	119
5.2.17	ElmFsrc	120
5.2.18	ElmGenstat	121
5.2.19	ElmGndswt	124
5.2.20	ElmLne	125
5.2.21	ElmLnesec	131
5.2.22	ElmMdl	131
5.2.23	ElmNec	133
5.2.24	ElmNet	133
5.2.25	ElmPvsys	136
5.2.26	ElmRecmono	139
5.2.27	ElmRelay	139
5.2.28	ElmRes	145
5.2.29	ElmShnt	161
5.2.30	ElmStactrl	161
5.2.31	ElmSubstat	163
5.2.32	ElmSvs	167
5.2.33	ElmSym	168
5.2.34	ElmTerm	171
5.2.35	ElmTow	179
5.2.36	ElmTr2	180
5.2.37	ElmTr3	184
5.2.38	ElmTr4	188
5.2.39	ElmTrain	193
5.2.40	ElmTrb	193
5.2.41	ElmTrfstat	194
5.2.42	ElmTrmult	197
5.2.43	ElmVac	200
5.2.44	ElmVltreg	201
5.2.45	ElmVscmono	202
5.2.46	ElmXnet	203
5.2.47	ElmZone	205
5.3	Station Elements	208
5.3.1	StaCombi	208
5.3.2	StaCt	208
5.3.3	StaCubic	209
5.3.4	StaExtbrkmea	212
5.3.5	StaExtcmdmea	217
5.3.6	StaExtdatmea	222
5.3.7	StaExtfmea	227

5.3.8	StaExtfuelmea	232
5.3.9	StaExtimea	237
5.3.10	StaExtpfmea	242
5.3.11	StaExtpmea	247
5.3.12	StaExtqmea	253
5.3.13	StaExtsmea	258
5.3.14	StaExttapmea	263
5.3.15	StaExtv3mea	269
5.3.16	StaExtvmea	274
5.3.17	StaSwitch	279
5.3.18	StaVt	281
5.4	Commands	281
5.4.1	ComAddlabel	282
5.4.2	ComAddon	282
5.4.3	ComAmpacity	294
5.4.4	ComArcreport	294
5.4.5	ComAuditlog	296
5.4.6	ComBoundary	296
5.4.7	ComCapo	297
5.4.8	ComCheck	298
5.4.9	ComCimdbexp	300
5.4.10	ComCimdbimp	301
5.4.11	ComCimtogrid	302
5.4.12	ComCimvalidate	305
5.4.13	ComConreq	311
5.4.14	ComContingency	311
5.4.15	ComCoordreport	318
5.4.16	ComCosim	334
5.4.17	ComDiffoutage	335
5.4.18	ComDllmanager	336
5.4.19	ComDpl	336
5.4.20	ComFlickermeter	342
5.4.21	ComGenrelinc	342
5.4.22	ComGridtocim	343
5.4.23	ComHostcap	348
5.4.24	ComImport	349
5.4.25	ComInc	350
5.4.26	ComLdf	352
5.4.27	ComLink	354
5.4.28	ComMerge	356

5.4.29 ComMot	362
5.4.30 ComNmink	363
5.4.31 ComOmr	364
5.4.32 ComOpc	365
5.4.33 ComOutage	366
5.4.34 ComPfdimport	368
5.4.35 ComPrjconnector	369
5.4.36 ComProtgraphic	369
5.4.37 ComPvcurves	369
5.4.38 ComPython	370
5.4.39 ComRed	373
5.4.40 ComRel3	374
5.4.41 ComRelpost	376
5.4.42 ComRelreport	377
5.4.43 ComReltabreport	377
5.4.44 ComReport	378
5.4.45 ComRes	379
5.4.46 ComShc	380
5.4.47 ComShctrace	382
5.4.48 ComSim	386
5.4.49 ComSimoutage	388
5.4.50 ComStationware	393
5.4.51 ComSvgexport	394
5.4.52 ComSvgimport	395
5.4.53 ComTablereport	396
5.4.54 ComTasks	437
5.4.55 ComTececo	445
5.4.56 ComTececocmp	445
5.4.57 ComTransfer	447
5.4.58 ComUcte	448
5.4.59 ComUcteexp	449
5.4.60 ComWr	452
5.5 Settings	453
5.5.1 SetCluster	453
5.5.2 SetColscheme	454
5.5.3 SetDatabase	461
5.5.4 SetDataext	461
5.5.5 SetDeskpage	463
5.5.6 SetDesktop	464
5.5.7 SetDistrstate	473

5.5.8	SetFilt	474
5.5.9	SetLevelvis	474
5.5.10	SetLvscale	477
5.5.11	SetParalman	477
5.5.12	SetPath	478
5.5.13	SetPrj	483
5.5.14	SetScenario	485
5.5.15	SetSelect	486
5.5.16	SetTabgroup	489
5.5.17	SetTboxconfig	495
5.5.18	SetTime	496
5.5.19	SetUser	497
5.5.20	SetVipage	498
5.6	Others	502
5.6.1	BlkDef	502
5.6.2	BlkSig	505
5.6.3	ChaVecfile	505
5.6.4	CimArchive	506
5.6.5	CimModel	506
5.6.6	CimObject	513
5.6.7	GrpPage	522
5.6.8	IntAddonvars	528
5.6.9	IntCase	534
5.6.10	IntComtrade	536
5.6.11	IntComtradeset	543
5.6.12	IntDataset	549
5.6.13	IntDocument	550
5.6.14	IntDplmap	551
5.6.15	IntDplvec	554
5.6.16	IntEvt	556
5.6.17	IntExtaccess	557
5.6.18	IntGate	558
5.6.19	IntGrf	558
5.6.20	IntGrfgroup	559
5.6.21	IntGrflayer	560
5.6.22	IntGrfnet	569
5.6.23	IntIcon	572
5.6.24	IntLibrary	573
5.6.25	IntMat	573
5.6.26	IntMon	580

5.6.27 IntNdata	582
5.6.28 IntNnet	582
5.6.29 IntOutage	583
5.6.30 IntPlannedout	585
5.6.31 IntPrj	586
5.6.32 IntPrjfolder	598
5.6.33 IntQlim	600
5.6.34 IntRas	601
5.6.35 IntReport	602
5.6.36 IntRunarrange	614
5.6.37 IntScenario	614
5.6.38 IntScensched	618
5.6.39 IntScheme	620
5.6.40 IntSscheduler	622
5.6.41 IntSstage	623
5.6.42 IntSubset	626
5.6.43 IntSym	627
5.6.44 IntTemplate	628
5.6.45 IntThrating	629
5.6.46 IntUrl	630
5.6.47 IntUser	631
5.6.48 IntUserman	632
5.6.49 IntVec	633
5.6.50 IntVecobj	636
5.6.51 IntVersion	637
5.6.52 IntViewbookmark	639
5.6.53 PltAxis	639
5.6.54 PltBiasdiff	640
5.6.55 PltComplexdata	641
5.6.56 PltDataseries	642
5.6.57 PltImpedancex	644
5.6.58 PltLegend	645
5.6.59 PltLinebarplot	646
5.6.60 PltNetgraphic	651
5.6.61 PltOvercurrent	651
5.6.62 PltPowerpq	653
5.6.63 PltShcsweep	654
5.6.64 PltTimedistance	654
5.6.65 PltTitle	655
5.6.66 PltVectorplot	656

5.6.67 RelChar	659
5.6.68 RelFuse	659
5.6.69 RelLogdip	661
5.6.70 RelLogic	661
5.6.71 RelToc	662
5.6.72 RelZpol	662
5.6.73 ScnFreq	663
5.6.74 ScnFrt	665
5.6.75 ScnSpeed	667
5.6.76 ScnSync	669
5.6.77 ScnVar	671
5.6.78 ScnVolt	673
5.6.79 StoMaint	675
5.6.80 TriCont	676
5.6.81 TriDisc	676
5.6.82 TriFile	676
5.6.83 TriVal	677
5.6.84 TypAsmo	677
5.6.85 TypCtcore	678
5.6.86 TypLne	679
5.6.87 TypMdl	679
5.6.88 TypQdsl	681
5.6.89 TypTr2	683
5.6.90 VisPath	683
5.6.91 VisPcompdiffplt	685
5.6.92 VisPlottz	687
5.6.93 VisValue	688
6 Callback functions	689
Index	690

1 General Description

This reference manual describes the syntax of all available functions and methods provided by the **PowerFactory** module. The used Python interface version is 2 (new in **PowerFactory** 2016). For syntax of the Python interface version 1 (**PowerFactory** 15.x) please use the [DPL reference](#) with the extended return values.

Note: function calls with named arguments are not yet supported.

Please refer to the **PowerFactory User Manual** for general information about Python as scripting language and its usage.

2 **PowerFactory** Module

Overview

[__version__](#)
[GetApplication](#)
[GetApplicationExt](#)

__version__

Holds the version of **PowerFactory** e.g. "25.0.9" for **PowerFactory** 2025 SP7.

```
powerfactory.__version__
```

GetApplication

This function is deprecated, because **PowerFactory** will not be closed regularly (so the log file will not be closed). Please use [GetApplicationExt\(\)](#).

Creates a powerfactory.Application object and returns it. When the Python script is started from external **PowerFactory** will be started. Please hold the created application object as long as you use **PowerFactory** from Python and do not call this function twice.

```
Application powerfactory.GetApplication([str username = None,]  
                                       [str password = None,]  
                                       [str commandLineArguments = None])
```

ARGUMENTS

username (optional)

Name of the user to log in to **PowerFactory** (default None). None enforces the default behaviour as if PowerFactory was started via shortcut.

password (optional)

The password for the user which should be logged in (default None). None omits the password.

commandLineArguments (optional)

Additional command line options (default None). These need to be specified in the same way as if **PowerFactory** was started via a command shell. None omits the command line arguments.

RETURNS

Application object on success, otherwise None.

SEE ALSO

[GetApplicationExt\(\)](#)

GetApplicationExt

Same as `powerfactory.GetApplication()` but throwing an exception with an error code when **PowerFactory** was not able to start. Furthermore if **PowerFactory** exits due to an error, `powerfactory.ExitError` can be caught in an Python script for doing clean-up. A detailed description of all error codes can be found in the [Error Codes](#) documentation.

When **PowerFactory** was started by a Python script from external and the application object is deleted then **PowerFactory** is terminated but the current process keeps running. In this situation it is not possible to start **PowerFactory** again in the same process.

```
Application powerfactory.GetApplicationExt([str username = None,]  
                                           [str password = None,]  
                                           [str commandLineArguments = None])
```

RETURNS

Application object on success. In the error case an exception with a detailed error code is thrown.

EXAMPLE

The following example starts **PowerFactory** from external and handles initialisation errors:

```
import sys;  
sys.path.append(r"C:\Program Files\DIgSILENT\PowerFactory 2026\python\3.14")  
  
import powerfactory  
  
try:  
    app = powerfactory.GetApplicationExt()  
    # ... some calculations ...  
except powerfactory.ExitError as error:  
    print(error)  
    print('error.code = %d' % error.code)
```

SEE ALSO

[GetApplication\(\)](#)

3 Application Methods

Overview

ActivateProject
ClearRecycleBin
CommitTransaction
ConvertGeometryStringToMDL
CreateFaultCase
CreateProject
DecodeColour
DefineTransferAttributes
DeleteUntouchedObjects
EncodeColour
ExecuteCmd
GetActiveCalculationStr
GetActiveNetworkVariations
GetActiveProject
GetActiveScenario
GetActiveScenarioScheduler
GetActiveStages
GetActiveStudyCase
GetAllUsers
GetAttributeDescription
GetAttributeUnit
GetAvailableAttributes
GetAvailableAttributesAsJson
GetBorderCubicles
GetBrowserSelection
GetCalcRelevantObjects
GetCalculationBalancedMode
GetCalculationDescription
GetCalculations
GetCalculationsAsJson
GetClassDescription
GetClassId
GetCurrentDiagram
GetCurrentScript
GetCurrentSelection
GetCurrentUser
GetCurrentZoomScaleLevel
GetDataFolder
GetDesktop
GetDiagramSelection
GetFlowOrientation
GetFromStudyCase

GetGlobalLibrary
GetInterfaceVersion
GetLanguage
GetLocalLibrary
GetMem
GetObjectByDbObjectKey
GetProjectFolder
GetRecordingStage
GetSettings
GetSummaryGrid
GetTouchedObjects
GetTouchingExpansionStages
GetTouchingStageObjects
GetTouchingVariations
GetUnitPrefixFactor
GetUserManager
GetUserSettings
Hide
ImportDz
ImportSnapshot
IsAttributeModelInternal
IsLdfValid
IsNAN
IsRmsValid
IsScenarioAttribute
IsShcValid
IsSimValid
IsWriteCacheEnabled
LicenceHasModule
LoadProfile
MarkInGraphics
MigrateAllProjects
OutputFlexibleData
PostCommand
PrepForUntouchedDelete
Rebuild
ReloadProfile
ResetCalculation
ResGetData
ResGetDescription
ResGetFirstValidObject
ResGetFirstValidObjectVariable
ResGetFirstValidVariable
ResGetIndex
ResGetMax
ResGetMin
ResGetNextValidObject
ResGetNextValidObjectVariable
ResGetNextValidVariable
ResGetObject
ResGetUnit
ResGetValueCount
ResGetVariable
ResGetVariableCount
ResLoadData
ResReleaseData

ResSortToVariable
SaveAsScenario
SearchObjectByForeignKey
SearchObjectsByCimId
SelectToolbox
SetAttributeInRootAndStageObjects
SetAttributeModelInternal
SetInterfaceVersion
SetShowAllUsers
SetVariationRecordingMode
SetWriteCacheEnabled
Show
SplitLine
StatFileGetXrange
StatFileResetXrange
StatFileSetXrange
WriteChangesToDb

ActivateProject

Activates a project with its name.

```
int Application.ActivateProject(str name)
```

ARGUMENTS

<i>name</i>	Name ("Project"), full qualified name ("Project.IntPrj") or full qualified path ("User\Project.IntPrj") of a project.
-------------	---

RETURNS

0 on success and 1 if project can not be found or activated.

ClearRecycleBin

Clears the recycle bin of currently logged in user.

```
None Application.ClearRecycleBin()
```

CommitTransaction

Writes pending changes to database.

While a script is running none of the changes are written to the database unless the script terminates. **PowerFactory** can be forced to write all pending changes to the database using this function.

```
None Application.CommitTransaction()
```

ConvertGeometryStringToMDL

Conversion of string geometry used in PowerFactory versions < 23.

```
str Application.ConvertGeometryStringToMDL(str orgString,  
                                           DataObject intGrfOrLayer)
```

ARGUMENTS

orgString String to be converted.

intGrfOrLayer
IntGrf or IntGrflayer which contains the text.

RETURNS

The converted MDL-string.

CreateFaultCase

Create fault cases from the given elements.

```
int Application.CreateFaultCase(set elms,
                               int mode,
                               [int createEvt = 0],
                               [DataObject folder = None]
                               )
```

ARGUMENTS

elms Selected elements to create fault cases.

mode How the fault cases are created:

- 0** Single fault case containing all elements.
- 1** n-1 (multiple cases).
- 2** n-2 (multiple cases).
- 3** Collecting coupling elements and create fault cases for line couplings.

createEvt (optional)

Switch event:

- 0** Do NOT create switch events (default).
- 1** Create switch events.

folder (optional)

Folder in which the fault case is stored.

RETURNS

- 0** On success.
- 1** On error.

CreateProject

Creates a new Project inside the parent object. The default project stored in the Configuration/Default folder will be copied and if it contains any Study Cases the first will be used instead of creating a new one. If desired, a new grid can also be created. Returns the newly created project.

```
DataObject Application.CreateProject(str projectName,
                                     str gridName,
                                     [DataObject parent = None])
DataObject Application.CreateProject(str projectName,
                                     [DataObject parent = None])
```


ARGUMENTS

projectName

Name of the new project. Leave empty to open up the IntPrj dialog and let the user enter a name.

gridName

Name of the grid that's created for the new project. Use an empty string to open up the ElmNet dialog and let the user enter a name.
Leave out this argument completely to not create a grid.

parent

The parent for the new project. Can be omitted to use the currently logged on user as default.

DecodeColour

Decodes a colour value stored in PowerFactory's internal colour representation, and splits it into its RGBA components.

```
[int red,  
int green,  
int blue,  
int alpha] Application.DecodeColour(int encodedColour)
```

ARGUMENTS

encodedColour

Colour value given in PowerFactory's internal colour representation, as read from any colour attribute.

red (out) Red colour channel. Range [0,255].

green (out) Green colour channel. Range [0,255].

blue (out) Blue colour channel. Range [0,255].

alpha (out) Colour transparency. Range [0,255], with 0 being fully transparent and 255 being fully opaque.

DefineTransferAttributes

Defines for a given classname the attributes for blockwise access via [DataObject.GetAttributes\(\)](#) and [DataObject.SetAttributes\(\)](#).

```
None Application.DefineTransferAttributes(str classname,  
                                         str attributes  
                                         )
```

ARGUMENTS

classname

Name of a class.

attributes Comma separated names of attributes.

SEE ALSO

[DataObject.GetAttributes\(\)](#), [DataObject.SetAttributes\(\)](#)

DeleteUntouchedObjects

Delete all objects stored in the grid (or stored in set) which are not modified. Requires call of [PrepForUntouchedDelete\(\)](#) first, see [Application.PrepForUntouchedDelete\(\)](#). Hint: function should only be used when a variation is active. For details please contact support.

```
int Application.DeleteUntouchedObjects(DataObject grid)
int Application.DeleteUntouchedObjects(list grids)
```

EncodeColour

Encodes an RGBA colour value into PowerFactory's internal colour representation. The returned value is meant to be assigned to a colour attribute.

```
int Application.EncodeColour(int red,
                             int green,
                             int blue,
                             [int alpha = 255])
```

ARGUMENTS

- red* Red colour channel. Must be in the range [0,255].
- green* Green colour channel. Must be in the range [0,255].
- blue* Blue colour channel. Must be in the range [0,255].
- alpha(optional)*
Colour transparency. Must be in the range [0,255], with 0 being fully transparent and 255 being fully opaque.

RETURNS

The encoded colour value. This value can be assigned to any colour attribute.

ExecuteCmd

Executes given command string as it would be executed if typed directly into the Input Window. Current script will continue after the command has been executed. This function is mainly intended for testing purpose and should be used by experienced users only.

```
None Application.ExecuteCmd(str command)
```

ARGUMENTS

- command*
The command string

GetActiveCalculationStr

Gets the “string ID” of the currently valid calculation.

```
str Application.GetActiveCalculationStr()
```

RETURNS

String ID of the currently valid calculation, see [Application.GetCalculations\(\)](#).

SEE ALSO

[Application.GetCalculations\(\)](#), [Application.GetCalculationDescription\(\)](#),
[Application.GetCalculationBalancedMode\(\)](#), [Application.GetCalculationsAsJson\(\)](#) (not available in DPL)

GetActiveNetworkVariations

Returns all active variations for the 'Network Data' folder.

```
list Application.GetActiveNetworkVariations()
```

RETURNS

Returns currently active *IntScheme* objects. Set is empty in case of no scheme being currently active.

GetActiveProject

This function returns the currently active project.

```
DataObject Application.GetActiveProject()
```

RETURNS

Returns currently active *IntPrj* object or None in case of no project being currently active.

GetActiveScenario

Returns the currently active scenario. None is returned if there is no active scenario.

```
DataObject Application.GetActiveScenario()
```

RETURNS

Returns currently active *IntScenario* object or None in case of no scenario being currently active.

GetActiveScenarioScheduler

Returns currently active scenario scheduler.

```
DataObject Application.GetActiveScenarioScheduler()
```

RETURNS

Returns currently active *IntScensched* object or None in case of no scheduler being currently active.

GetActiveStages

Returns all active stages currently active for a given folder, e.g. 'Network Data' folder.

```
list Application.GetActiveStages([DataObject variedFolder = None])
```

ARGUMENTS

variedFolder (optional)

Folder for which all active stages will be returned; by default, the project folder 'Network Data' is taken.

RETURNS

Returns currently active *IntSstage* objects. Set is empty in case of no stages being currently active.

GetActiveStudyCase

Returns the active Study Case. None is returned if there is no active study case.

```
DataObject Application.GetActiveStudyCase()
```

RETURNS

The active study case (*IntCase* object) or None.

RETURNS

Returns currently active *IntCase* object or None in case of no study case being currently active.

GetAllUsers

Returns all known users, regardless of any Data Manager filters.

```
list Application.GetAllUsers([int forceReload = 0])
```

ARGUMENTS

forceReload

- 0** Default, returns the cached state if function was called before.
- 1** Forces the cache to be cleared, may impact performance.

RETURNS

Returns a container with all known users.

GetAttributeDescription

Returns the description of an attribute.

```
str Application.GetAttributeDescription(str classname,
                                       str name,
                                       int short = 0)
```

ARGUMENTS

<i>classname</i>		Name of a class.
<i>name</i>		Name of an attribute.
<i>short</i>	0	Return long attribute description (default).
	1	Return short attribute description.

RETURNS

None	For an invalid class or attribute name.
str	Long or short attribute description.

SEE ALSO

[Application.GetAttributeUnit\(\)](#)

GetAttributeUnit

Returns the unit of an attribute e.g. km, MW....

```
str Application.GetAttributeUnit(str classname,  
                                str name  
                                )
```

ARGUMENTS

<i>classname</i>	Name of a class.
<i>name</i>	Name of an attribute.

RETURNS

None	For an invalid class or attribute name.
str	Attribute unit.

SEE ALSO

[Application.GetAttributeDescription\(\)](#)

GetAvailableAttributes

Gets all variables available for a class.

```
str Application.GetAvailableAttributes(str className,  
                                      [str calculation,]  
                                      [int balanced,]  
                                      [str nameSpace])
```

ARGUMENTS

<i>className</i>	Name of a PowerFactory class
<i>calculation (optional)</i>	Calculation page value, see Application.GetCalculations()
Empty	Attributes for all calculations (default)

Set Only attributes for given calculation. Please note that for "basic" you will get all calculation results that are available for all calculations (namespace 'b'). In case you want to get the input attributes, please use the namespace filter 'e'.

balanced (optional)

Calculation type (only considered if calculation is set).

0 Unbalanced calculation
1 Balanced calculation (default)

nameSpace (optional)

Attribute namespace

Empty Attributes for all namespaces (default)
Set Only attributes of given namespace.

Namespace	Attribute group
e	Input data (built-in)
p	Input data (data extensions)
b	Calculation quantities (independent of calculation)
c	Calculation quantities (results)
m	Calculation quantities (results per connection)
n	Calculation quantities (results per bus)
s	Calculation quantities (signals and states)
x	Calculation quantities (user-defined)

RETURNS

List of attribute names with one attribute name per line.

GetAvailableAttributesAsJson

Gets attributes available for a class with additional information as string in JSON format.

JSON schema:

```
{
  "$schema": "http://json-schema.org/draft/2019-09/schema",
  "title": "Attributes",
  "type": "object",
  "required": ["class", "attributes"],
  "properties": {
    "class": {
      "type": "string"
    },
    "attributes": {
      "type": ["array", "null"],
      "items": {
        "type": "object"
      },
      "required": ["namespace", "name", "instances"],
      "properties": {
        "namespace": {
          "type": "string"
        }
      }
    }
  }
}
```

```
"name": {
  "type": "string"
},
"busses": {
  "type": "array",
  "items": {
    "type": "string"
  }
},
"instances": {
  "type": "array",
  "items": {
    "type": "object"
  },
  "properties": {
    "description": {
      "type": "string"
    },
    "unit": {
      "type": "string"
    },
    "data_type": {
      "type": "string"
    },
    "subindex_dimension": {
      "type": "integer"
    },
    "phases": {
      "type": "array",
      "items": {
        "type": "string"
      }
    },
    "functions": {
      "type": "array",
      "items": {
        "type": "string"
      }
    },
    "statistics": {
      "type": "array",
      "items": {
        "type": "string"
      }
    },
    "signal_type": {
      "type": "string"
    },
    "calculations_balanced": {
      "type": "array of strings"
    },
    "calculations_unbalanced": {
      "type": "array of strings"
    }
  }
}
```

```

    }
  }
}

```

The resulting JSON could look like (attribute list is elided):

```

{
  "class": "ElmLne",
  "attributes": [
    {
      "namespace": "e",
      "name": "loc_name",
      "instances": [
        {
          "description": "Name",
          "unit": null,
          "data_type": "string",
        },
      ],
    },
    {
      "namespace": "m",
      "name": "uinet",
      "busses": ["bus1", "bus2"],
      "instances": [
        {
          "description":
            "Phase Voltage, Imaginary Part, referred to network",
          "unit": "p.u.",
          "data_type": "double",
          "phases": ["A", "B", "C"],
          "calculations_balanced": [],
          "calculations_unbalanced": ["ldf"],
          "model": "BasMon_ldf_rst"
        },
        {
          "description":
            "Phase Voltage, Imaginary Part, referred to network",
          "unit": "p.u.",
          "data_type": "double",
          "calculations_balanced":
            ["ldf", "dcldf", "dccontopf", "optcapo"],
          "calculations_unbalanced": [],
          "model": "BasMon_ldf_sym"
        },
      ],
    },
    {
      "namespace": "s",
      "name": "iL1",
      "instances": [
        {
          "description": "Line-Current (bus1)",
          "unit": "",

```



```

        "data_type": "double",
        "functions": ["dt"],
        "signal_type": "STATE, continuous",
        "calculations_balanced": [],
        "calculations_unbalanced": ["emt"],
        "model": "CalLnedcshc_ins_rst"
    }
}
},
...
]
}

```

```

str Application.GetAvailableAttributesAsJson(str className,
                                           [str calculation,]
                                           [int balanced,]
                                           [str nameSpace,]
                                           [str properties])

```

ARGUMENTS

className

Name of a **PowerFactory** class

calculation (optional)

Calculation page value, see [Application.GetCalculations\(\)](#)

Empty Attributes for all calculations (default)

Set Only attributes for given calculation. Please note that for "basic" you will get all calculation results that are available for all calculations (namespace 'b'). In case you want to get the input attributes, please use the namespace filter 'e'.

balanced (optional)

Calculation type (only considered if calculation is set).

0 Unbalanced calculation

1 Balanced calculation (default)

nameSpace (optional)

Attribute namespace, see [Application.GetAvailableAttributes\(\)](#)

Empty Attributes for all namespaces (default)

Set Only attributes of given namespace

properties (optional)

Comma separated list of JSON attribute instance property keys to be serialized, see JSON schema above.

Empty All available properties (default)

Set Only given properties

RETURNS

Attribute information in JSON format.

EXAMPLE

The following script gets all calculation bus results ("m:") available for the class `ElmLne` in balanced load flow and includes only the properties description and unit in the resulting JSON:

```
import powerfactory
app = powerfactory.GetApplicationExt()
attributes = app.GetAvailableAttributesAsJson("ElmLne", "ldf", 1, "m",
                                             "description,unit");
```

SEE ALSO

[Application.GetAvailableAttributes\(\)](#) [Application.GetCalculations\(\)](#)

GetBorderCubicles

This function returns the border cubicles of the parent station of passed element topologically reachable from that element.

A cubicle (*StnCubic*) is considered to be a border cubicle if it resides inside the station

- and points to an element that sits outside the station
- or to a branch element that is connected to a terminal outside the station.

```
list Application.GetBorderCubicles(DataObject element)
```

ARGUMENTS

element Element from which the search for border cubicles starts

RETURNS

A set, containing border cubicles *StnCubic*. If the element does not reside in any substation or no border cubicles exist, the set is empty.

GetBrowserSelection

Returns all objects marked in the “on top” Data Manager (Browser, right side). In comparison to [Application.GetCurrentSelection\(\)](#) this is independently of how the script is executed.

```
list Application.GetBrowserSelection()
```

RETURNS

Objects marked in the “on top” Data Manager (Browser, right side).

SEE ALSO

[Application.GetCurrentSelection\(\)](#), [Application.GetDiagramSelection\(\)](#)

GetCalcRelevantObjects

Returns all currently calculation relevant objects, i.e. the objects which are used by the calculations.

The set of objects depends on active study case, active grid(s) and variation(s).

In contrast to [DataObject.IsCalcRelevant\(\)](#) it does not return objects of the active study case e.g. simulation events (Evt*).

```
list Application.GetCalcRelevantObjects([str nameFilter = "**.*",]
                                         [int includeOutOfService = 1,]
                                         [int topoElementsOnly = 0,]
                                         [int bAcSchemes = 0])
```

ARGUMENTS

nameFilter (optional)

(Class) name filter. Wildcards are supported. Multiple filters to be separated by comma ','. Must not contain a backslash '\.

If omitted, all objects are returned (corresponds to '*.*').

Examples for valid filter strings:

- 'ElmTerm'
- 'A*.ElmTerm'
- '**.ElmLod,*.ElmSym'

includeOutOfService (optional)

Flag whether to include out of service objects. Default is 1 (=included).

topoElementsOnly (optional)

Flag to filter for topology relevant objects only. Default is 0 (=all objects).

bAcSchemes (optional)

Flag to include hidden objects in active schemes. Default is 0 (=not included).

RETURNS

The currently calculation relevant objects, according to the given arguments. The order of the set is undefined.

SEE ALSO

[DataObject.IsCalcRelevant\(\)](#)

GetCalculationBalancedMode

Gets balanced/unbalanced mode for a calculation.

```
int Application.GetCalculationBalancedMode(str calculationId)
```

ARGUMENTS

calculationId

Calculation string ID, see [Application.GetCalculations\(\)](#).

RETURNS

- 0** Calculation is available as balanced and unbalanced
- 1** Calculation is only available as balanced
- 2** Calculation is only available as unbalanced

SEE ALSO

[Application.GetCalculations\(\)](#), [Application.GetActiveCalculationStr\(\)](#),
[Application.GetCalculationDescription\(\)](#), [Application.GetCalculationsAsJson\(\)](#) (not available
in DPL)

GetCalculationDescription

Gets the description text for a calculation as displayed on the pages of the object dialogs.

```
str Application.GetCalculationDescription(str calculationId)
```

ARGUMENTS

calculationId

Calculation string ID, see [Application.GetCalculations\(\)](#).

RETURNS

Description text.

SEE ALSO

[Application.GetCalculations\(\)](#), [Application.GetActiveCalculationStr\(\)](#),
[Application.GetCalculationBalancedMode\(\)](#), [Application.GetCalculationsAsJson\(\)](#) (not avail-
able in DPL)

GetCalculations

Gets “string IDs” of all calculations available.

String ID	Dialog Page Name	balanced	unbalanced
basic	Basic Data	X	
ldf	Load Flow AC	X	X
dcldf	Load Flow DC	X	
lvldf	Low Voltage Load Flow	X	X
acsens	AC Load Flow Sensitivities	X	X
dcsens	DC Load Flow Sensitivities	X	
shc	Short-Circuit VDE/IEC	X	X
shcfull	Short-Circuit Complete	X	X
shcansi	Short-Circuit ANSI	X	X
shc61363	Short-Circuit IEC61363	X	
shcdc	Short-Circuit DC	X	
acct	Contingency Analysis AC	X	
dccont	Contingency Analysis DC	X	
acldfsweep	Quasi-dynamic Simulation AC	X	X
dcldfsweep	Quasi-dynamic Simulation DC	X	
rms	RMS-Simulation	X	X
emt	EMT-Simulation		X
modal	Modal/Eigenvalue Analysis	X	
prot	Protection	X	X
arcflash	Arc Flash Calculation	X	X
cabsiz	Cable Sizing: International Standard	X	X
cabsizerf	Cable Sizing: User Defined	X	X

cabsizervf	Cable Sizing: Verification	X	X
cabamp	Cable Ampacity	X	X
harm	Power Quality/Harmonics	X	X
fsweep	Frequency Sweep	X	X
dachcz	Connection Request D-A-CH-CZ	X	
bdew	Connection Request BDEW	X	
vde4100	Connection Request VDE 4100/4105	X	
vde4110	Connection Request VDE 4110	X	
topo	Tie Open Point Opt.	X	X
mvplan	Voltage Profile Optimisation	X	
balance	Phase Balance Optimisation		X
optcapo	Optimal Capacitor Placement	X	X
backbone	Backbone Calculation	X	
rel	Reliability	X	
omr	Optimal Manual Restoration	X	
optrcs	Optimal RCS Placement	X	
genrel	Generation Adequacy	X	
cntrest	Contingency Restoration Analysis	X	
hostcap	Hosting Capacity Analysis	X	
powpark	Power Park Energy Analysis	X	
acsto	Probabilistic Load Flow AC	X	X
dcsto	Probabilistic Load Flow DC	X	
acopfsto	Probabilistic OPF AC	X	
dcopfsto	Probabilistic OPF DC	X	
dcopfctsto	Probabilistic OPF with Contingencies DC	X	
opf	Optimal Power Flow AC	X	
dcopf	Optimal Power Flow DC	X	
dccontopf	OPF with Contingencies DC	X	
acuc	Unit Commitment AC	X	
dcuc	Unit Commitment DC	X	
placeopt	Optimal Equipment Placement	X	
est	State Estimation	X	X
motstart	Motor Starting Calculation	X	X
usercalc	User defined calculation	X	
tececo	Techno-Economic Calculation	X	

```
str Application.GetCalculations()
```

RETURNS

List of calculation string IDs with one ID per line.

SEE ALSO

[Application.GetActiveCalculationStr\(\)](#), [Application.GetCalculationDescription\(\)](#), [Application.GetCalculationBalancedMode\(\)](#), [Application.GetCalculationsAsJson\(\)](#) (not available in DPL)

GetCalculationsAsJson

Gets all calculations available including additional information in JSON format.

JSON schema:

```
{
  "$schema": "http://json-schema.org/draft/2019-09/schema",
  "title": "Calculation Pages",
  "type": "object",
  "required": ["calculation_pages"],
  "properties":
  {
    "calculation_pages":
    {
      "type": "array",
      "items":
      {
        "type": "object"
      },
      "required":
        ["id", "description", "balanced", "unbalanced", "group"],
      "properties":
      {
        "id":
        {
          "type": "string"
        },
        "description":
        {
          "type": "string"
        },
        "balanced":
        {
          "type": "boolean"
        },
        "unbalanced":
        {
          "type": "boolean"
        },
        "group":
        {
          "type": "string"
        }
      }
    }
  }
}
```

```
str Application.GetCalculationsAsJson()
```

RETURNS

Calculation information in JSON format.

SEE ALSO

[Application.GetCalculations\(\)](#), [Application.GetActiveCalculationStr\(\)](#),
[Application.GetCalculationDescription\(\)](#), [Application.GetCalculationBalancedMode\(\)](#)

GetClassDescription

Returns a description for a **PowerFactory** class.

```
str Application.GetClassDescription(str name)
```

ARGUMENTS

name Name of a **PowerFactory** class

RETURNS

Returns the description of a valid **PowerFactory** class, otherwise an empty string.

GetClassId

Returns a class identifier number.

Each class name corresponds to one unique number. The mapping of class name might be different for different build numbers of **PowerFactory**, but it is guaranteed that it will not be changed while an Api instance exists. (Do not keep these numbers static, get them dynamically in your code using this method).

```
int Application.GetClassId(str className)
```

ARGUMENTS

className
Class name e.g. "ElmTerm".

0 Class name invalid.

>0 Class id of valid class name.

GetCurrentDiagram

This function offers access to the current diagram object (*IntGrfnet*).

```
DataObject Application.GetCurrentDiagram()
```

GetCurrentScript

Returns the current script (ComPython).

```
DataObject Application.GetCurrentScript()
```

RETURNS

The current script (ComPython) or None if started from external.

GetCurrentSelection

Returns all objects marked in the “on top” Data Manager (Browser, right side) or diagram when the script is executed via the right-click menu entry 'Execute Script'. When the script is executed e.g via the edit dialog or via a toolbar button then it always returns an empty selection.

```
list Application.GetCurrentSelection()
```

RETURNS

Objects marked in the “on top” Data Manager (Browser, right side) or diagram.

SEE ALSO

[Application.GetBrowserSelection\(\)](#), [Application.GetDiagramSelection\(\)](#)

GetCurrentUser

Returns the PowerFactory user of current session.

```
DataObject Application.GetCurrentUser()
```

RETURNS

Returns an *IntUser* object, never None.

GetCurrentZoomScaleLevel

Returns the zoom or scale level of the currently active diagram. If the active diagram is geographic, then the scale level is returned, otherwise the zoom level is returned.

```
int Application.GetCurrentZoomScale()
```

RETURNS

Zoom or scale level of the active diagram as integer.

- For geographic diagrams the scale level is returned. E.g. returns 50000 if 1:50000 is in the zoom/ratio combo box
- For all other diagrams the zoom level is returned. E.g. returns 150 if 150

A value of -1 is returned in case of no open diagram.

GetDataFolder

This function returns the folder in which the network data for the given class are stored.

```
DataObject Application.GetDataFolder(str classname,  
                                     [int iCreate = 0])
```

ARGUMENTS

classname

Classname of the elements:

ElmBmu
ElmArea
ElmZone

ElmRoute
ElmOwner
ElmOperator
ElmFeeder
ElmCircuit
ElmBoundary
IntScales

iCreate (optional)

- | | |
|----------|---|
| 0 | The folder is searched and returned if found. If the folder does not exist, None is returned (default). |
| 1 | The folder is created if it does not exist. The found or created folder is returned. |

RETURNS

The network data folder, which is found or created.

SEE ALSO

[DataObject.IsNetworkDataFolder\(\)](#)

GetDesktop

Returns the currently active Desktop.

```
DataObject Application.GetDesktop()
```

RETURNS

The desktop object

GetDiagramSelection

Returns all objects marked in the “on top” diagram. In comparison to [Application.GetCurrentSelection\(\)](#) this is independently of how the script is executed.

```
list Application.GetDiagramSelection()
```

RETURNS

Objects marked in the “on top” diagram.

SEE ALSO

[Application.GetCurrentSelection\(\)](#), [Application.GetBrowserSelection\(\)](#)

GetFlowOrientation

This function returns the flow orientation setting of the active project.

```
int Application.GetFlowOrientation()
```

RETURNS

- 1** No project is active
- 0** Flow orientation of active project is "MIXED MODE"
- 1** Flow orientation of active project is "LOAD ORIENTED"
- 2** Flow orientation of active project is "GENERATOR ORIENTED"

GetFromStudyCase

Returns the first found object of class "className" from the currently active study case. The object is created when no object of the given name and/or class was found.

For commands the returned instance corresponds to the one that is used if opened via the main menu load-flow, short-circuit, transient simulation, etc.,

```
DataObject Application.GetFromStudyCase(str className)
```

ARGUMENTS

className

Class name of the object ("Class"), optionally preceded by an object name without wildcards and a dot ("Name.Class").

RETURNS

The found or created object.

GetGlobalLibrary

Returns the global library for object-types of class "ClassName". ClassName may be omitted, in which case the complete global library folder is returned.

```
DataObject Application.GetGlobalLibrary([str ClassName = ""])
```

ARGUMENTS

ClassName (optional)

The classname of the objects for which the library folder is sought

RETURNS

The library folder

SEE ALSO

[Application.GetLocalLibrary\(\)](#)

GetInterfaceVersion

Returns the currently set interface version.

It holds the value set with SetInterfaceVersion() or the interface version from the current script (parameter 'interfaceVersion') if the python script is executed from within PowerFactory.

Have a look into the PowerFactor user manual to get more informations about the interface version of a script.

```
int Application.GetInterfaceVersion()
```

RETURNS

The currently set interface version or 0 if PowerFactory is started from external and SetInterfaceVersion() is not called.

GetLanguage

Returns a string for the current program language setting.

```
str Application.GetLanguage()
```

RETURNS

en	English
de	German
es	Spanish
fr	French
ru	Russian
cn	Simplified Chinese
tr	Turkish

GetLocalLibrary

Returns the local library for object-types of class "ClassName". ClassName may be omitted, in which case the complete local library folder is returned.

```
DataObject Application.GetLocalLibrary([str ClassName = ""])
```

ARGUMENTS

ClassName (optional)

The classname of the objects for which the library folder is sought

RETURNS

The library folder

SEE ALSO

[Application.GetGlobalLibrary\(\)](#)

GetMem

Allows to trace memory consumption (current working set size).

```
int Application.GetMem([int calculateDelta=0],
                      [int inMegaByte=0]
                      )
```

ARGUMENTS

calculateDelta (optional)

Measure absolute memory consumption if 0, measure the delta since the last time it was called if 1 (default: 0).

inMegaByte (optional)

Returns consumption in byte if 0, in megabyte if 1 (default: 0).

RETURNS

The current working set size or the delta since the last call.

GetObjectByDbObjectKey

Returns the object for an Object Key.

```
DataObject Application.GetObjectByDbObjectKey(DataObject projectOrLibrary,
                                              str dbObjectKey)
```

ARGUMENTS

projectOrLibrary
Project or library

dbObjectKey
The Object Key in the database

RETURNS

DataObject The object in the project/library with that Object Key if existing.
None Otherwise.

SEE ALSO

[DataObject.GetDbObjectKey\(\)](#)

GetProjectFolder

Returns the project folder of a given type of active project. There is at most one folder per type (except 'Generic').

```
DataObject Application.GetProjectFolder(str type,
                                         [int create = 1])
```

ARGUMENTS

type Type of the corresponding project folder. See [IntPrjFolder.GetProjectFolderType\(\)](#) for a list of possible values.

create (optional)
Determines whether the project folder shall be created if it does not exist:

0 The project folder is not created if it does not exist.
1 The project folder is created if it does not exist (default).

RETURNS

An *IntPrjFolder* object or None. None is returned if there is no currently active project, or if there is no project folder of this type and 'create' is given as 0.

GetRecordingStage

Returns the currently active recording scheme stage.

```
DataObject Application.GetRecordingStage()
```

RETURNS

An *IntSstage* object; None if there is no recording stage.

GetSettings

Offers read-only access to some selected **PowerFactory** settings.

```
str Application.GetSettings(str key)
```

ARGUMENTS

key

Key	Return type	Description
username	string	Name of logged-in user
installationdir	string	Fully qualified path of installation directory
workingdir	string	Fully qualified path of working directory
tempdir	string	Fully qualified path of temporary directory
sessionid	integer	ID of current session
db_driver	string	Name of used database driver
logfile	string	Path of current log file

RETURNS

Value of settings as string

GetSummaryGrid

Returns the summary grid in the currently active Study Case. The summary grid is the combination of all active grids in the study case.

```
DataObject Application.GetSummaryGrid()
```

RETURNS

A *ElmNet* object, or None when no grids are active

GetTouchedObjects

Gets all root objects added, modified or deleted in the given variations and expansion stages.

```
list Application.GetTouchedObjects(object varOrStage)
list Application.GetTouchedObjects(list varsAndStages)
```

ARGUMENTS

varOrStage

Variation or expansion stage.

varsAndStages

Variations and expansion stages.

RETURNS

Matching root objects.

GetTouchingExpansionStages

Gets all expansion stages in which at least one of the given objects is added, modified or deleted.

```
list Application.GetTouchingExpansionStages(object rootObject)
list Application.GetTouchingExpansionStages(list rootObjects)
```

ARGUMENTS

rootObject
Root object.

rootObjects
Root objects.

RETURNS

Matching expansion stages.

GetTouchingStageObjects

Gets all stage objects adding, modifying or deleting one of the given objects.

```
list Application.GetTouchingStageObjects(object rootObject)
list Application.GetTouchingStageObjects(list rootObjects)
```

ARGUMENTS

rootObject
Root object.

rootObjects
Root objects.

RETURNS

Matching expansion stages.

GetTouchingVariations

Gets all variations in which at least one of the given objects is added, modified or deleted.

```
list Application.GetTouchingVariations(object rootObject)
list Application.GetTouchingVariations(list rootObjects)
```

ARGUMENTS

rootObject
Root objects.

rootObjects
Root objects.

RETURNS

Matching variations.

GetUnitPrefixFactor

Get the factor for the given unit prefix, e.g. "k" or "M".

```
double Application.GetUnitPrefixFactor(str unitPrefix)
```

ARGUMENTS

unitPrefix The unit prefix:

Symbol	a	f	p	n	u	m	-
Name	atto	femto	pico	nano	micro	milli	
Factor	10^{-18}	10^{-15}	10^{-12}	10^{-9}	10^{-6}	10^{-3}	1

Symbol	k	M	G	T	P	E
Name	kilo	mega	giga	tera	peta	exa
Factor	10^3	10^6	10^9	10^{12}	10^{15}	10^{18}

RETURNS

The factor for the given unit prefix or 0 for not supported unit prefixes.

SEE ALSO

[DataObject.GetAttributeUnitPrefix\(\)](#), [DataObject.GetAttributeUnitPrefixFactor\(\)](#)

GetUserManager

Offers access to the user manager object (IntUserman) stored in the configuration folder.

```
DataObject Application.GetUserManager()
```

RETURNS

The user manager object

GetUserSettings

Convenient routine to get the settings object (SetUser) of a user.

```
object Application.GetUserSettings([object user = None])
```

ARGUMENTS

user (optional)

If current user that executes the function is Administrator, passing a user object (IntUser) will return the corresponding setting object for that user.

Note: For normal users, the argument is ignored and always the setting object of current user is returned.

RETURNS

Returns the settings object (SetUser) for a user.

Hide

Hides the **PowerFactory** application window.

```
None Application.Hide()
```

SEE ALSO

[Application.Show\(\)](#)

ImportDz

Imports a DZ file. Overwrites data if it already exists.

```
[int errorCode,  
list importedObjects] Application.ImportDz(DataObject target,  
                                           str dzFilePath)
```

ARGUMENTS

target Target object for imported data.

dzFilePath
Path to the DZ file that should be imported.

importedObjects (out)
Collection of top-level objects imported.

RETURNS

0 Success
-1 Wrong file extension
nonzero Import failed

ImportSnapshot

Imports a Snapshot DZS file.

```
[int errorCode,  
list importedObjects ] Application.ImportSnapshot(str dzsFilePath)
```

ARGUMENTS

dzsFilePath
Path to the DZ file that should be imported.

importedObjects (out)
Collection of top-level objects imported.

RETURNS

0 Success
-1 Wrong file extension
nonzero Import failed

IsAttributeModelInternal

Returns whether the attribute values are accessed as internally stored.

```
int Application.IsAttributeModelInternal()
```


RETURNS

- 0** Attribute values accessed as displayed in **PowerFactory** (unit conversion applied).
- 1** Attribute values accessed as internally stored.

SEE ALSO

[Application.SetAttributeModelInternal\(\)](#)

IsLdfValid

Checks to see if the last load-flow results are still valid and available.

```
int Application.IsLdfValid()
```

RETURNS

0 if no load-flow results are available

IsNAN

Checks whether a double value is NAN (not a number).

```
int Application.IsNAN(float value)
```

ARGUMENTS

value Double value to check.

RETURNS

Returns 1, if value is NAN, 0 otherwise.

IsRmsValid

Checks to see if the last RMS simulation results are still valid and available.

```
int Application.IsRmsValid()
```

RETURNS

0 if no RMS simulation results are available

IsScenarioAttribute

Checks if a given attribute of a given class is recorded in scenario. It does not check whether a concrete instance is recorded at all. The check is just performed against the scenario configuration and is independent of a concrete scenario.

```
int Application.IsScenarioAttribute(str classname, str attributename)
```

ARGUMENTS

classname
Name of a **PowerFactory** class.

attributename
Name of an attribute of given class.

RETURNS

- 1** If attribute is scenario relevant according to current scenario configuration.
- 0** If attribute is not scenario relevant.

IsShcValid

Checks to see if the last short-circuit results are still valid and available.

```
int Application.IsShcValid()
```

RETURNS

- 0 if no short-circuit results are available

IsSimValid

Checks to see if the last simulation results are still valid and available.

```
int Application.IsSimValid()
```

RETURNS

- 0 if no simulation results are available

IsWriteCacheEnabled

Returns whether or not the cache method for optimizing performances is enabled. For more informations, see [Application.SetWriteCacheEnabled\(\)](#).

```
int Application.IsWriteCacheEnabled()
```

RETURNS

- 0** Write cache is disabled.
- 1** Write cache is enabled.

SEE ALSO

[Application.SetWriteCacheEnabled\(\)](#), [Application.WriteChangesToDb\(\)](#)

LicenceHasModule

Checks whether the current licence contains a module.

The following licence module abbreviations can be used:

- ai - Artificial Intelligence
- anaredefas - ANAREDE/ANAFAS Export
- arcflash - Arc-Flash Analysis
- c37 - C37 Simulation Interface
- cabOpt - Cable Analysis
- cimEentso - CIM Import/Export (ENTSO-E Profile)

- cimEentsoCorp - CIM Import/Export (ENTSO-E Profile) - corp.
- cimlentso - CIM Import (ENTSO-E Profile)
- conrequest - Connection Request Assessment
- contingency - Contingency Analysis
- cosim - Co-Simulation Interface
- crypt - DPL/DSL/QDSL Encryption
- dist - Distance Protection
- distr - Distribution Network Tools
- econom - Economic Analysis Tools
- fmuexp - FMU Model Export
- harm - Power Quality and Harmonic Analysis
- integral - Integral Export
- masterstation - PFM Master Station
- motstart - Motor Starting Functions
- muld - Multi-User Database
- netred - Network Reduction
- opc - OPC Interface
- opfact - OPF (Economic Dispatch)
- opfreact - OPF (Reactive Power Optimisation)
- paramid - System Parameter Identification
- probAnalysis - Probabilistic Analysis
- prot - Time-Overcurrent Protection
- psse - PSS/E Export
- qdynsim - Quasi - Dynamic Simulation
- reli - Reliability and Restoration Analysis
- script - Scripting and Automation
- smallsig - Small Signal Stability Analysis
- stab - Stability Analysis Functions (RMS)
- stabemt - Electromagnetic Transients (EMT)
- staest - State Estimation
- transmission - Transmission Network Tools
- unitcomm - Unit Commitment and Dispatch Optimisation

```
int Application.LicenceHasModule(str module)
```

ARGUMENTS

module Abbreviated name of the licence module, e.g. "prot". See list above.

RETURNS

- 1** Module is contained in the current licence. Corresponding functionality can be used.
- 0** Module is not contained in the current licence.

LoadProfile

Activates a profile for current user. This corresponds to the select profile action via main menu "TOOLS-Profiles".

```
int Application.LoadProfile(str profileName)
```

ARGUMENTS

profileName
Name of profile to be loaded.

RETURNS

- 0** On error, e.g. profile with given name not found.
- 1** On success.

SEE ALSO

[Application.ReloadProfile\(\)](#)

MarkInGraphics

This function is not supported in GUI-less mode.

Marks all objects in the diagram in which the elements are found by hatch crossing them.

```
None Application.MarkInGraphics(list objects,  
                                [int searchOpenedDiagramsOnly = 0])
```

ARGUMENTS

objects Objects to be marked.

searchOpenedDiagramsOnly (optional)

Search can be restricted to currently shown diagrams on the desktop, instead of all diagrams.

- 0** Searching all diagrams, not only the ones which are currently shown on the desktop. If there is more than one occurrence the user will be prompted which diagrams shall be opened (default).
- 1** Only search in currently opened diagrams and open the first diagram in which the elements were found.

MigrateAllProjects

Migrates all projects in the database to the current PowerFactory version. In multi-user databases this function can be run only as Administrator user.

```
int Application.MigrateAllProjects()
```

RETURNS

- 0** On success.
- 1** On error.

OutputFlexibleData

Outputs the Flexible Data of the given objects to the output window.

Has identical functionality to that implemented in the Object Filter dialogue, whereby the user can right-click on a single row or multiple rows in a Flexible Data page and select Output ... Flexible Data. The OutputFlexibleData() function assumes that the user has already defined a Flexible Data page for the objects in the set. Upon execution of this function, all Flexible Data defined for the objects in the set is output to the **PowerFactory** output window in a tabular format.

```
None Application.OutputFlexibleData(list objects,
                                   [str flexibleDataPage = ''])
```

ARGUMENTS

objects Objects to output the Flexible Data for.

flexibleDataPage (optional)

Name of the Flexible Data page to be outputted. If multiple Flexible Data pages are defined and no or an empty string is given then a dialog to select a Flexible Data page is shown.

PostCommand

Adds a command as string to the command pipe of the "input window". The posted command string will be executed after the currently running script has finished.

```
None Application.PostCommand(str commandString)
None Application.PostCommand(DataObject command)
```

ARGUMENTS

commandString

A command as string e.g 'exit' for ComExit.

command

A command. Internally the command is converted to a command string including all its properties.

PrepForUntouchedDelete

Mark (as not modified) all objects stored in the grid (or stored in set). Required for function [Application.DeleteUntouchedObjects\(\)](#).

```
None Application.PrepForUntouchedDelete(DataObject grid)
None Application.PrepForUntouchedDelete(list grids)
```

Rebuild

Rebuilds the currently visible single line diagram or plot.

```
None Application.Rebuild([int iMode = 1])
```

ARGUMENTS

iMode (optional)

- | | |
|---|---|
| 0 | Draws graphic objects only |
| 1 | (default) Reads graphic objects (IntGrf) from database and draws |
| 2 | For single line diagrams: Reads graphic objects (IntGrf) from database, re-calculates intersections and draws.
For plot pages: Adjust view to page format and re-create plots. |

ReloadProfile

Reloads currently selected user profile. (See main menu "TOOLS-Profiles")

```
None Application.ReloadProfile()
```

SEE ALSO

[Application.LoadProfile\(\)](#)

ResetCalculation

Resets all calculations and deletes all calculation results.

Results that have been written to result objects (for display in graphs) will not be destroyed. All results that are visible in the single line diagrams, however, will be destroyed.

```
None Application.ResetCalculation()
```

SEE ALSO

[Application.IsAutomaticCalculationResetEnabled\(\)](#),
[Application.SetAutomaticCalculationResetEnabled\(\)](#)

ResGetData

This function is deprecated. Please use [ElmRes.GetValue\(\)](#) or [IntComtrade.GetValue\(\)](#) instead.

```
[int error,
float d ] Application.ResGetData(DataObject resultObject,
                                int ix,
                                [int col])
```

ResGetDescription

This function is deprecated. Please use [ElmRes.GetDescription\(\)](#) or [IntComtrade.GetDescription\(\)](#) instead.

```

str Application.ResGetDescription(DataObject resultObject,
                                int col,
                                [int ishort])

```

ResGetFirstValidObject

This function is deprecated. Please use [ElmRes.GetFirstValidObject\(\)](#) instead.

```

int Application.ResGetFirstValidObject(DataObject resultFile,
                                       int row,
                                       [str classNames,]
                                       [str variableName,]
                                       [float limit,]
                                       [int limitOperator,]
                                       [float limit2,]
                                       [int limitOperator2])
int Application.ResGetFirstValidObject([DataObject resultFile,]
                                       [int row,]
                                       [list objects])

```

ResGetFirstValidObjectVariable

This function is deprecated. Please use [ElmRes.GetFirstValidObjectVariable\(\)](#) instead.

```

int Application.ResGetFirstValidObjectVariable(DataObject resultFile,
                                              [str variableNames])

```

ResGetFirstValidVariable

This function is deprecated. Please use [ElmRes.GetFirstValidVariable\(\)](#) instead.

```

int Application.ResGetFirstValidVariable(DataObject resultFile,
                                         int row,
                                         [str variableNames])

```

ResGetIndex

This function is deprecated. Please use [ElmRes.FindColumn\(\)](#) or [IntComtrade.FindColumn\(\)](#) instead.

```

int Application.ResGetIndex(DataObject resultFile,
                           DataObject obj,
                           [str varName])
int Application.ResGetIndex(DataObject resultFile,
                           DataObject obj,
                           [int colIndex])
int Application.ResGetIndex(DataObject resultFile,
                           [str varName,]
                           [int colIndex])

```

ResGetMax

This function is deprecated. Please use [ElmRes.FindMaxInColumn\(\)](#) or [IntComtrade.FindMaxInColumn\(\)](#) instead.

```
[int row,
float value] Application.ResGetMax(DataObject resultFile,
                                int col)
```

ResGetMin

This function is deprecated. Please use [ElmRes.FindMinInColumn\(\)](#) or [IntComtrade.FindMinInColumn\(\)](#) instead.

```
[int row,
float value] Application.ResGetMin(DataObject resultFile,
                                int col)
```

ResGetNextValidObject

This function is deprecated. Please use [ElmRes.GetNextValidObject\(\)](#) instead.

```
int Application.ResGetNextValidObject(DataObject resultFile,
                                     [str classNames,]
                                     [str variableName,]
                                     [float limit,]
                                     [int limitOperator,]
                                     [float limit2,]
                                     [int limitOperator2])
int Application.ResGetNextValidObject(DataObject resultFile,
                                     list objects)
```

ResGetNextValidObjectVariable

This function is deprecated. Please use [ElmRes.GetNextValidObjectVariable\(\)](#) instead.

```
int Application.ResGetNextValidObjectVariable(DataObject resultFile,
                                             [str variableNames])
```

ResGetNextValidVariable

This function is deprecated. Please use [ElmRes.GetNextValidVariable\(\)](#) instead.

```
int Application.ResGetNextValidVariable(DataObject resultFile,
                                       [str variableNames])
```

ResGetObject

This function is deprecated. Please use [ElmRes.GetObject\(\)](#) instead.

```
DataObject Application.ResGetObj(DataObject resultObject,
                                int col)
```


ResGetUnit

This function is deprecated. Please use [ElmRes.GetUnit\(\)](#) or [IntComtrade.GetUnit\(\)](#) instead.

```
str Application.ResGetUnit(DataObject resultObject,  
                           int col)
```

ResGetValueCount

This function is deprecated. Please use [ElmRes.GetNumberOfRows\(\)](#) or [IntComtrade.GetNumberOfRows\(\)](#) instead.

```
int Application.ResGetValueCount(DataObject resultObject,  
                                [int col])
```

ResGetVariable

This function is deprecated. Please use [ElmRes.GetVariable\(\)](#) or [IntComtrade.GetVariable\(\)](#) instead.

```
str Application.ResGetVariable(DataObject resultObject,  
                              int col)
```

ResGetVariableCount

This function is deprecated. Please use [ElmRes.GetNumberOfColumns\(\)](#) or [IntComtrade.GetNumberOfColumns\(\)](#) instead.

```
int Application.ResGetVariableCount(DataObject resultObject)
```

ResLoadData

This function is deprecated. Please use [ElmRes.Load\(\)](#) or [IntComtrade.Load\(\)](#) instead.

```
None Application.ResLoadData(DataObject resultObject)
```

ResReleaseData

This function is deprecated. Please use [ElmRes.Release\(\)](#) or [IntComtrade.Release\(\)](#) instead.

```
None Application.ResReleaseData(DataObject resultObject)
```

ResSortToVariable

This function is deprecated. Please use [ElmRes.SortAccordingToColumn\(\)](#) or [IntComtrade.SortAccordingToColumn\(\)](#) instead.

```
int Application.ResSortToVariable(DataObject resultObject,  
                                 int col)
```

SaveAsScenario

Saves the operational data or relevant network elements as a new scenario.

```
DataObject Application.SaveAsScenario(str pName,
                                     int iSetActive)
```

ARGUMENTS

pName Name of the new scenario.

iSetActive

1 Activate the new scenario afterwards.

0 Do not activate the new scenario.

RETURNS

Returns newly created *IntScenario* object. None is returned in case of creation of a new scenario was not allowed (e.g. no active project).

SearchObjectByForeignKey

Searches for an object by foreign key within an active project.

```
DataObject Application.SearchObjectByForeignKey(str foreignKey)
```

ARGUMENTS

foreignKey

 Foreign key

RETURNS

Object if found, otherwise None.

SearchObjectsByCimId

Searches for objects by CIM RDF ID within an active project.

```
list Application.SearchObjectsByCimId(str cimId)
```

ARGUMENTS

cimId CIM RDF ID

RETURNS

Matching objects.

EXAMPLE

The following example shows how to search for objects by CIM RDF ID:

```
import powerfactory
app = powerfactory.GetApplicationExt()

objects = app.SearchObjectsByCimId("_17086487-56ba-4979-b8de-064025a6b4da")
for object in objects:
    app.PrintInfo(object)
```

SelectToolbox

Sets tool box to be displayed at a switchable tool box group.

```
int Application.SelectToolbox(int toolbar,
                             str groupName,
                             str toolboxName)
```

ARGUMENTS

toolbar **1** Main tool bar
 2 Drawing tool bar (SGL)

groupName
 Name of tool box group.

toolboxName
 Name of tool box to be selected.

RETURNS

0 On error, e.g. no matching tool box found.
1 On success.

SetAttributeInRootAndStageObjects

Sets an attribute value in all occurrences of an object, i.e. in the root object and all stage objects referring to that root object.

```
int Application.SetAttributeInRootAndStageObjects(DataObject obj,
                                                  str attributeName,
                                                  str value)
int Application.SetAttributeInRootAndStageObjects(list objs,
                                                  str attributeName,
                                                  str value)
```

ARGUMENTS

obj Object to be modified.

objs Objects to be modified.

attributeName
 Name of attribute to be modified, including prefix and subindices.

value New attribute value.

RETURNS

0 OK
1 Error

SetAttributeModelInternal

Changes the way how attribute values are accessed.

```
None Application.SetAttributeModeInternal(int internalMode)
```

ARGUMENTS

<i>internalMode</i>	0	Access attribute values as displayed in PowerFactory (unit conversion applied).
	1	Access attribute values as internally stored.

SEE ALSO

[Application.IsAttributeModelInternal\(\)](#)

SetInterfaceVersion

Sets the current interface version. Only values which can be set to the python script parameter 'interfaceVersion' are allowed. Setting the interface version does not affect the parameter 'interfaceVersion' of the current script.

Have a look into the PowerFactor user manual to get more informations about the interface version of a script.

```
int Application.SetInterfaceVersion(int version)
```

ARGUMENTS

version interface version to be set

RETURNS

0 if the version is successfully set, otherwise 1.

SetShowAllUsers

Enables or disables the filtering of all available users in data manager. All users are only visualised in data manager when enabled.

```
int Application.SetShowAllUsers(int enabled)
```

ARGUMENTS

<i>enabled</i>	0	Disabled, only Demo, Public Area Users and current user are shown
	1	Enabled, all available users are listed

RETURNS

Returns previous setting.

1	If enabled before.
0	If disabled before.

SetVariationRecordingMode

Sets the variation recording mode.

```
None Application.SetVariationRecordingMode(int mode)
```

ARGUMENTS

<i>mode</i>	0	Standard recording mode, recording into the active recording expansion stage
	1	All modifications and the base grid are adapted (independent of active variations)
	2	Only the last modification is adapted, in case there is no modification yet, the base grid is adapted

SetWriteCacheEnabled

This function intends to optimize performances or disable the value consistency check of attributes. In order to modify objects in **PowerFactory**, those must be set in a special edit mode before any value can be changed. Switching back and forth between edit mode and stored mode is time consuming; enabling the write cache flag will set objects in edit mode and they will not be switched back until [Application.WriteChangesToDb\(\)](#) is called.

Another purpose of this function is to disable the value consistency check executed whenever an attribute is set. Note: Enabling the write cache delays the value consistency check until [Application.WriteChangesToDb\(\)](#) is called or the write cache is disabled. This might be required when dependent attributes are set where the object is temporarily left in an invalid state until all attributes are set. In DPL please use [SetConsistencyCheck\(\)](#) for the same purpose.

```
None Application.SetWriteCacheEnabled(int enabled)
```

ARGUMENTS

<i>enabled</i>	0	Disables the write cache.
	1	Enables the write cache.

SEE ALSO

[Application.IsWriteCacheEnabled\(\)](#), [Application.WriteChangesToDb\(\)](#)

Show

Shows the **PowerFactory** application window (only possible with a full license, not supported for engine licenses).

```
None Application.Show()
```

SEE ALSO

[Application.Hide\(\)](#)

SplitLine

Splits the passed line or ElmBranch-object at a given position and inserts a new terminal. With the optional parameters for specifying the bay end terminals of a substation it is possible to set the new connection nodes within an already existing substation.

```
DataObject Application.SplitLine(DataObject Line,
                                [float percent = 50,]
                                [int createSwitchSide0 = 0,]
                                [int createSwitchSide1 = 0,]
                                [int graphicSplit = 0,])
```

```
[DataObject bayEndTerm1 = None, ]
[DataObject bayEndTerm2 = None])
```

ARGUMENTS

double percent (optional)

Position in percent from the first connection side where line shall be split.

int createSwitchSide0 (optional - will be ignored if a substation is inserted)

0 (default) Do not create switch on first connection side. Will be ignored if a 'bayEndTerm1' or 'bayEndTerm2' is set.

1 Create switch on first connection side.

int createSwitchSide1 (optional - will be ignored if a substation is inserted)

0 (default) Do not create switch on second connection side. Will be ignored if a 'bayEndTerm1' or 'bayEndTerm2' is set.

1 Create switch on second connection side.

int graphicSplit (optional)

0 (default) Do not perform line split graphically.

1 Split line also graphically.

object bayEndTerm1 (optional - only needed when connecting into an existing substation)

First (bay end) terminal inside substation.

object bayEndTerm2 (optional - only needed when connecting into an existing substation)

Second (bay end) terminal inside substation.

RETURNS

Inserted terminal or None on error.

StatFileGetXrange

Gets the x-range for the statistic result file.

```
[int error,
float min,
float max] Application.StatFileGetXrange()
```

ARGUMENTS

min (out) First point in time considered in statistics.

max (out) Last point in time considered in statistics.

RETURNS

0 If time range of statistic result file was found.

1 On errors (There is no statistic result file).

StatFileResetXrange

Reset the user defined x-range of the statistic result file. The complete x-range will be considered in the statistic results after calling this function.

```
None Application.StatFileResetXrange()
```

StatFileSetXrange

Sets the user defined x-range of the statistic result file. The statistic results consider only the given time range.

```
None Application.StatFileSetXrange(float min,
                                   float max)
```

ARGUMENTS

min First point in time to be considered in statistics.
max Last point in time to be considered in statistics.

WriteChangesToDb

This function combined with [Application.SetWriteCacheEnabled\(\)](#) is meant to optimize performances. If the write cache flag is enabled all objects remain in edit mode until `WriteChangesToDb()` is called and all the modifications made to the objects are saved into the database.

```
None Application.WriteChangesToDb()
```

SEE ALSO

[Application.SetWriteCacheEnabled\(\)](#), [Application.IsWriteCacheEnabled\(\)](#)

3.1 File System

Overview

[GetAbsolutePath](#)
[GetInstallationDirectory](#)
[GetTemporaryDirectory](#)
[GetWorkspaceDirectory](#)

GetAbsolutePath

Returns an absolute file path.

This will expand paths starting relative to the application working directory and will replace placeholders like `$(WorkspaceDir)`, `$(ProjectDir)` or `$(InstallationDir)`. The project directory will either be determined by the reference object that is passed or by taking the project directory of the active project if nothing is passed. The special path segment `".."` will not be replaced as this is typically handled by the operating system.

```
str Application.GetAbsolutePath(str pathToTransform, [object referenceObject])
```

ARGUMENTS

pathToTransform
The path that should be transformed
referenceObject
A reference object to choose the correct project

RETURNS

An absolute path equivalent to the relative path passed to the function.

GetInstallationDirectory

Returns the installation directory of **PowerFactory** .

```
str Application.GetInstallationDirectory()
```

RETURNS

Full path to installation directory of current **PowerFactory** .

DEPRECATED NAMES

GetInstallDir

SEE ALSO

[Application.GetTemporaryDirectory\(\)](#), [Application.GetWorkspaceDirectory\(\)](#)

GetTemporaryDirectory

Returns the temporary directory of used by **PowerFactory** .

```
str Application.GetTemporaryDirectory()
```

RETURNS

Full path to a directory where temporary data can be stored. This directory is also used by **PowerFactory** to store temporary data.

DEPRECATED NAMES

GetTempDir

SEE ALSO

[Application.GetWorkspaceDirectory\(\)](#), [Application.GetInstallationDirectory\(\)](#)

GetWorkspaceDirectory

Returns the workspace directory of **PowerFactory** .

```
str Application.GetWorkspaceDirectory()
```

RETURNS

Full path to the directory where currently used workspace is stored.

DEPRECATED NAMES

GetWorkingDir

SEE ALSO

[Application.GetTemporaryDirectory\(\)](#), [Application.GetInstallationDirectory\(\)](#)

3.2 Date/Time

Overview

[GetStudyTimeObject](#)

GetStudyTimeObject

Returns the date and time object (SetTime) from the study case. This is the object being used by the characteristics, scenarios, ...

RETURNS

SetTime or None.

3.3 Dialogue Boxes

Overview

[CloseTableReports](#)
[GetTableReports](#)
[ShowModalBrowser](#)
[ShowModalSelectBrowser](#)
[ShowModelessBrowser](#)
[UpdateTableReports](#)

CloseTableReports

This function is not supported in GUI-less mode.

Closes all open table reports.

Please note: Table reports currently running one of their scripts are not closed.

```
None Application.CloseTableReports()
```

GetTableReports

This function is not supported in GUI-less mode.

Returns all open table reports.

```
list Application.GetTableReports()
```

ShowModalBrowser

This function is not supported in GUI-less mode.

Opens a modal browser window and lists all given objects.

```
None Application.ShowModalBrowser(list objects,
                                   [int detailMode = 0,]
                                   [str title = '',]
                                   [str page = ''])
```

ARGUMENTS

objects Objects to be listed. The listing is in detailed mode, if only one kind of objects (e.g. only ElmTerm) is contained.

detailMode (optional)

- 0** Show browser in normal mode (default).
- 1** Show browser in detail mode.

title (optional)

String for user defined window title. The default window title is shown when no or an empty string is given.

page (optional)

Name of page to be shown in browser e.g. 'Flexible Data' (only in detailed mode). The default page is shown when no or an empty string is given.

ShowModalSelectBrowser

This function is not supported in GUI-less mode.

Opens a modal browser window and lists all given objects. The user can make a selection from the list.

```
list Application.ShowModalSelectBrowser(list objects,
                                         [str title,]
                                         [str classFilter,]
                                         [str page = ''])
```

ARGUMENTS

objects Objects to be listed. The listing is in detailed mode, if only one kind of objects (e.g. only ElmTerm) is contained.

title (optional)

String for user defined window title. The default window title is shown when no or an empty string is given.

classFilter (optional)

Class name filter. If set, only objects matching that filter will be listed in the dialog e.g. 'Elm*', 'ElmTr?' or 'ElmTr2,ElmTr3'.

page (optional)

Name of page to be shown in browser e.g. 'Flexible Data' (only in detailed mode). The default page is shown when no or an empty string is given.

RETURNS

Set of selected objects. The set is empty if “cancel” is pressed.

ShowModelessBrowser

This function is not supported in GUI-less mode.

Opens a modeless browser window and lists all given objects.

```
None Application.ShowModelessBrowser(list objects,  
                                     [int detailMode = 0,]  
                                     [str title = '',]  
                                     [str page = ''])
```

ARGUMENTS

objects Objects to be listed. The listing is in detailed mode, if only one kind of objects (e.g. only ElmTerm) is contained.

detailMode (optional)

- 0** Show browser in normal mode (default).
- 1** Show browser in detail mode.

title (optional)

String for user defined window title. The default window title is shown when no or an empty string is given.

page (optional)

Name of page to be shown in browser e.g. 'Flexible Data' (only in detailed mode). The default page is shown when no or an empty string is given.

UpdateTableReports

This function is not supported in GUI-less mode.

Updates all open table reports.

```
None Application.UpdateTableReports()
```

3.4 Environment

Overview

[EchoOff](#)
[EchoOn](#)
[GetApplicationColourScheme](#)
[IsAutomaticCalculationResetEnabled](#)
[IsFinalEchoOnEnabled](#)
[IsUserBreakPressed](#)
[SetAutomaticCalculationResetEnabled](#)
[SetFinalEchoOnEnabled](#)
[SetGraphicUpdate](#)
[SetGuiUpdateEnabled](#)
[SetProgressBarUpdatesEnabled](#)
[SetUserBreakEnabled](#)

EchoOff

Freezes (de-activates) the user-interface. For each `EchoOff()`, an `EchoOn()` should be called. An `EchoOn()` is automatically executed at the end of the execution of a `ComDpl` or `ComPython`. This could be changed with [Application.SetFinalEchoOnEnabled\(\)](#).

```
None Application.EchoOff()
```

SEE ALSO

[Application.EchoOn\(\)](#),
[Application.IsFinalEchoOnEnabled\(\)](#),
[Application.SetFinalEchoOnEnabled\(\)](#)

EchoOn

Re-activates the user interface. For more informations see [Application.EchoOff\(\)](#).

```
None Application.EchoOn()
```

SEE ALSO

[Application.EchoOff\(\)](#),
[Application.IsFinalEchoOnEnabled\(\)](#),
[Application.SetFinalEchoOnEnabled\(\)](#)

GetApplicationColourScheme

Returns the colour scheme used by the application.

```
int Application.GetApplicationColourScheme()
```

RETURNS

- 1 Light mode
- 2 Dark mode

IsAutomaticCalculationResetEnabled

Returns whether the automatic calculation reset while setting attributes is enabled. See [Application.SetAutomaticCalculationResetEnabled\(\)](#) for more informations.

```
int Application.IsAutomaticCalculationResetEnabled()
```

RETURNS

Returns 1 when the automatic calculation reset is enabled and 0 otherwise.

SEE ALSO

[Application.SetAutomaticCalculationResetEnabled\(\)](#), [Application.ResetCalculation\(\)](#)

IsFinalEchoOnEnabled

Returns whether the automatic [Application.EchoOn\(\)](#) at the end of each *ComDpl* or *ComPython* is enabled.

```
int Application.IsFinalEchoOnEnabled()
```

RETURNS

- 1** Final [Application.EchoOn\(\)](#) is enabled.
- 0** Final [Application.EchoOn\(\)](#) is disabled.

SEE ALSO

[Application.SetFinalEchoOnEnabled\(\)](#), [Application.EchoOn\(\)](#), [Application.EchoOff\(\)](#)

IsUserBreakPressed

API only: returns whether the user pressed the “Break” button on the main tool bar.

Remark, this method is only available for API and not for Python. In **Python**, please use the callback [_PowerFactory_OnUserInterrupt\(\)](#) instead.

A typical use-case for calling this function is as follows: A ComDpl/ComPython command is started and loads the **PowerFactory** API, which starts a long-running task. In this situation, the **PowerFactory** API can now regularly call `IsUserBreakPressed()` to terminate the task as soon as the user presses the “Break” button.

```
int Application.IsUserBreakPressed()
```

RETURNS

Returns 1 when the user pressed the “Break” button and 0 otherwise.

SEE ALSO

[_PowerFactory_OnUserInterrupt\(\)](#)
[Application.SetUserBreakEnabled\(\)](#)

SetAutomaticCalculationResetEnabled

Enables or disables the automatic calculation reset while setting attributes.

In Python/API the automatic calculation reset is by default enabled. Thus changing an object attribute could lead to a calculation reset, e.g. changing the scaling factor of a load, but do not have to, e.g. renaming an object.

Even if the automatic calculation reset is disabled, changing the "outserv" attribute of an arbitrary network element or the "on_off" attribute of a switch device resets automatically the current calculation.

When the calculation is reset the load-flow will be calculated with a flat start. Thus switching the automatic calculation reset off can be helpful e.g. when calculating a load-flow without a flat start. On the other side it could lead to wrong results e.g. doing short-circuit calculations after changing the short-circuit-location of a branch without calling [Application.ResetCalculation\(\)](#).

```
None Application.SetAutomaticCalculationResetEnabled(int enabled)
```

SEE ALSO

[Application.IsAutomaticCalculationResetEnabled\(\)](#), [Application.ResetCalculation\(\)](#)

SetFinalEchoOnEnabled

Enables or disables the automatic [Application.EchoOn\(\)](#) at the end of each *ComDpl* or *ComPython*.

```
None Application.SetFinalEchoOnEnabled(int enabled)
```

ARGUMENTS

enabled

- | | |
|---|---|
| 1 | Enables the final Application.EchoOn() . |
| 0 | Disables the final Application.EchoOn() . |

SEE ALSO

[Application.IsFinalEchoOnEnabled\(\)](#), [Application.EchoOn\(\)](#), [Application.EchoOff\(\)](#)

SetGraphicUpdate

Enables or disables the updates of the single line graphics.

```
None Application.SetGraphicUpdate(int enabled)
```

ARGUMENTS

enabled

- | | |
|---|--|
| 0 | disabled (graphic will not be updated automatically) |
| 1 | enabled |

SetGuiUpdateEnabled

Enables or disables updates of the graphical user interface (e.g. application window) while the script is running.

This can be useful to get maximum execution performance. However, the user interface might look frozen and becomes not responsive.

Please note that the progress bar, which is located in the status bar of the application window, is not affected by this. Updates of the progress bar can be enabled or disabled separately by invoking [Application.SetProgressBarUpdatesEnabled\(\)](#).

The updates will automatically be re-enabled after termination of the script. In case of sub-scripts, the restore is done at termination of main script.

```
int Application.SetGuiUpdateEnabled(int enabled)
```

ARGUMENTS

enabled

- | | |
|----------|-----------------------|
| 0 | Disables GUI updates. |
| 1 | Enables GUI updates. |

RETURNS

Previous state before the function was called

- | | |
|----------|-----------------------------------|
| 0 | GUI updates were disabled before. |
| 1 | GUI updates were enabled before. |

DEPRECATED NAMES

SetRescheduleFlag

SEE ALSO

[Application.SetProgressBarUpdatesEnabled\(\)](#), [Application.SetGraphicUpdate\(\)](#)

SetProgressBarUpdatesEnabled

Enables or disables updates of the progress bar (located in the status bar of the application window) while the script is running. Other components of the status bar are not affected.

If a script executes a high number of small, fast commands that report progress (noticeable by the progress bar repeatedly and quickly filling up), disabling progress bar updates can provide an immense performance boost.

The updates will automatically be re-enabled after termination of the script. In case of sub-scripts, the restore is done at termination of main script.

```
int Application.SetProgressBarUpdatesEnabled(int enabled)
```

ARGUMENTS

enabled

- | | |
|----------|--------------------------------|
| 0 | Disables progress bar updates. |
| 1 | Enables progress bar updates. |

RETURNS

Previous state before the function was called

- | | |
|----------|--|
| 0 | Progress bar updates were disabled before. |
| 1 | Progress bar updates were enabled before. |

SEE ALSO

[Application.SetGuiUpdateEnabled\(\)](#), [Application.SetGraphicUpdate\(\)](#)

SetUserBreakEnabled

Enables or disables the “Break” button of the main tool bar. After script execution it is disabled automatically.

Disabling the “Break” button before executing a lot of Python code e.g a large loop can provide an immense performance boost. Disabling the “Break” button does not lead to a further performance improvement when the GUI updates are already disabled (see [Application.SetGuiUpdateEnabled\(\)](#)).

```
None Application.SetUserBreakEnabled(int enabled)
```

ARGUMENTS

enabled

0	Disables “Break” button.
1	Enable “Break” button.

DEPRECATED NAMES

SetEnableUserBreak

SEE ALSO

[_PowerFactory_OnUserInterrupt\(\)](#)
[Application.IsUserBreakPressed\(\)](#)

3.5 Mathematics

Overview

[GetRandomNumber](#)
[GetRandomNumberEx](#)
[InvertMatrix](#)
[RndExp](#)
[RndGetMethod](#)
[RndGetSeed](#)
[RndNormal](#)
[RndSetup](#)
[RndUnifInt](#)
[RndUnifReal](#)
[RndWeibull](#)
[SetRandomSeed](#)

GetRandomNumber

This function is marked as deprecated since PowerFactory 2017. Please use [Application.RndUnifReal\(\)](#) instead.

Draws a uniformly distributed random number. Uses the 'global random number generator'. If x_1 and x_2 are omitted, the distribution will be uniform in the interval $[0, 1]$. If only x_1 is given, the distribution is uniform in $[0, x_1]$ and with both x_1 and x_2 , the distribution is uniform in $[x_1, x_2]$.

```
float Application.GetRandomNumber([float x1,]
                                  [float x2])
```

ARGUMENTS

x1 (optional)
 x_2 not given: maximum; x_1 and x_2 given: minimum

x2 (optional)
 maximum

RETURNS

A uniformly distributed random number

GetRandomNumberEx

This function is marked as deprecated since PowerFactory 2017. Please use [Application.RndUnifReal\(\)](#), [Application.RndNormal\(\)](#) or [Application.RndWeibull\(\)](#) instead.

Draws a random number according to a specific probability distribution. Uses the 'global random number generator'.

```
float Application.GetRandomNumberEx(int distribution,
                                    [float p1,]
                                    [float p2])
```

ARGUMENTS

distribution

0	uniform distribution
1	normal distribution
2	weibull distribution
else	returns 0.0

p1 (optional)

distribution = 0 (uniform), argument p2 is also given: min
distribution = 0 (uniform), argument p2 is not given: max (min is assumed to be 0).
distribution = 1 (normal) : mean
distribution = 2 (weibull) : scale

p2 (optional)

distribution = 0 (uniform) : max
distribution = 1 (normal) : stddev
distribution = 2 (weibull) : weibull

RETURNS

- double** Newly drawn random number from the specified distribution.
- 0.0** On failure e.g. non-supported mode.

InvertMatrix

This routine calculates the inverse matrix by the Gauss-Jordan method. It uses scaled partial pivoting preceded by column equilibration of the input matrix. The routine can be called in two different versions:

- **Real Inversion:** Only one matrix, *realPart*, is provided as an input to the function. Then, *realPart* is inverted and the result, $realPart^{-1}$, is stored into the input matrix *realPart* on success.
- **Complex Inversion:** Two matrices, *realPart* and *imaginaryPart*, are provided as inputs to this function. Then, a complex matrix *C* is formed, with entries

$$C(i,j) = A(i,j) + j \cdot imaginaryPart(i,j).$$

The complex matrix *C* is inverted and, on success, the resulting real part of C^{-1} is written to *realPart* whereas the resulting imaginary part of C^{-1} is written to *imaginaryPart*. Please note that *realPart* and *imaginaryPart* must have the same dimensions.

```
int Application.InvertMatrix(DataObject realPart,
                             [DataObject imaginaryPart])
```

ARGUMENTS

realPart If *imaginaryPart* is not set, *realPart* is the matrix to invert on input. In case of success, it will be overwritten by the inverted input matrix. If *imaginaryPart* is set, it holds the real part of the complex matrix to invert on input and is overwritten by the real part of the inverted complex matrix on output.

imaginaryPart

If this is set, it should hold the imaginary part of the matrix to invert on input and is overwritten by the imaginary part of the inverted matrix on output.

RETURNS

- 1** Matrix inversion failed. The provided input matrix is singular.
- 0** Matrix inversion was successful. Resulting inverted matrix returned in input matrix/matrices.

RndExp

Returns a random number distributed according to exponential distribution with given rate. See the example given in the DPL description of [Application.RndSetup\(\)](#).

```
float Application.RndExp(float rate, [int rngNum])
```

ARGUMENTS

rate Rate of exponential distribution.

rngNum (optional)

Number of the random number generator.

0 (default) 'Global random number generator'.

1, 2, ... Other random number generators accessible via this number.

RETURNS

double Random number

RndGetMethod

Returns the used method of a random number generator. See the example given in the DPL description of [Application.RndSetup\(\)](#).

```
str Application.RndGetMethod([int rngNum])
```

ARGUMENTS

rngNum (optional)

Number of the random number generator of which the method type is returned.

0 (default) 'Global random number generator'.

1, 2, ... Other random number generators accessible via this number.

RETURNS

string Name of the used method

RndGetSeed

Returns the used seed of a random number generator. See the example given in the DPL description of [Application.RndSetup\(\)](#).

```
int Application.RndGetSeed([int rngNum])
```

ARGUMENTS

rngNum (optional)

Number of the random number generator.

0 (default) 'Global random number generator'.

1, 2, ... Other random number generators accessible via this number.

RETURNS

int Used seed

RndNormal

Returns a random number distributed according to normal distribution with given mean and standard deviation. See the example given in the DPL description of [Application.RndSetup\(\)](#).

```
float Application.RndNormal(float mean, float stddev, [int rngNum])
```

ARGUMENTS

mean Mean of normal distribution.

stddev Standard deviation of normal distribution.

rngNum (optional)

Number of the random number generator.

0 (default) 'Global random number generator'.

1, 2, ... Other random number generators accessible via this number.

RETURNS

double Random number

RndSetup

Initializes a random number generator. Allows to choose:

1. Whether to seed automatically or not.
2. The seed, if not automatically seeded.
3. The type of random number generator.
4. The random number generator to use.

Supported types of random number generators:

1. Mersenne Twister,
2. Linear Congruential,
3. Additive Lagged Fibonacci.

Internally a vector of random number generators is used. These can be accessed via the number passed as last argument. Number 0 corresponds to the 'global random number generator', updated also in ComInc and ComGenreInc. Numbers 1,2,... will access different random number generators, which can be setup individually.

```
None Application.RndSetup(int seedAutomatic,
                          [int seed],
                          [int rngType],
                          [int rngNum])
```

ARGUMENTS

seedAutomatic

Seed the random number generator automatically

- | | |
|----------|----------------------------|
| 0 | Do not seed automatically. |
| 1 | Seed automatically. |

seed (optional)

Seed for the random number generator. (default: 0) Note, that for the Additive Lagged Fibonacci generator, only the seeds 0,...,9 are supported.

rngType (optional)

Type of random number generator

- | | |
|----------|---|
| 0 | Mersenne Twister (recommended) (default). |
| 1 | Linear Congruential. |
| 2 | Additive Lagged Fibonacci. |

rngNum (optional)

Number of random number generator to be used

- | | |
|--------------------|--|
| 0 (default) | 'Global random number generator'. |
| 1, 2, ... | Other random number generators accessible via this number. |

RndUnifInt

Returns a random number distributed according to uniform distribution on the set of numbers $\{min, \dots, max\}$. See the example given in the DPL description of [Application.RndSetup\(\)](#).

```
int Application.RndUnifInt(int min, int max, [int rngNum])
```

ARGUMENTS

min Smallest possible number

max Largest possible number

rngNum (*optional*)
Number of the random number generator.

0 (default) 'Global random number generator'.

1, 2, ... Other random number generators accessible via this number.

RETURNS

int Random number

RndUnifReal

Returns a random number distributed according to uniform distribution on the interval $[min, max]$. See the example given in the DPL description of [Application.RndSetup\(\)](#).

```
float Application.RndUnifReal(float min, float max, [int rngNum])
```

ARGUMENTS

min Lower endpoint of interval $[min, max]$

max Upper endpoint of interval $[min, max]$

rngNum (*optional*)
Number of the random number generator.

0 (default) 'Global random number generator'.

1, 2, ... Other random number generators accessible via this number.

RETURNS

double Random number

RndWeibull

Returns a random number distributed according to Weibull distribution with given shape and scale parameters. See the example given in the DPL description of [Application.RndSetup\(\)](#).

```
float Application.RndWeibull(float shape, float scale, [int rngNum])
```

ARGUMENTS

shape Shape parameter of Weibull distribution.

scale Scale parameter of Weibull distribution.

rngNum (*optional*)
Number of the random number generator.

0 (default) 'Global random number generator'.

1, 2, ... Other random number generators accessible via this number.

RETURNS

double Random number

SetRandomSeed

This function is marked as deprecated since PowerFactory 2017. Please use [Application.RndSetup\(\)](#) instead.

Initializes the 'global random number generator' as Additive Lagged Fibonacci random number generator. Sets the seed for the random number generator. One out of 10 predefined initialization seeds can be selected.

```
None Application.SetRandomSeed(int seed)
```

ARGUMENTS

seed seed 0..9

3.6 Output Window

Overview

[ClearOutputWindow](#)
[FlushOutputWindow](#)
[GetOutputWindow](#)
[PrintError](#)
[PrintInfo](#)
[PrintPlain](#)
[PrintWarn](#)
[SetOutputWindowState](#)

ClearOutputWindow

Clears the output window.

```
None Application.ClearOutputWindow()
```

FlushOutputWindow

Calling this function ensures that all previously printed and potentially buffered messages are visible in the output window.

```
None Application.FlushOutputWindow()
```

EXAMPLE

```
import powerfactory
app = powerfactory.GetApplicationExt()
app.PrintInfo('It is not guaranteed that this message is \
shown immediately in the output window as it could be buffered.')
# After this call all previously printed messages
# are guaranteed to be visible in the output window.
app.FlushOutputWindow()
```

GetOutputWindow

Returns the **PowerFactory** Output Window.

```
OutputWindow Application.GetOutputWindow()
```

RETURNS

An instance of the class `OutputWindow`.

EXAMPLE

```
import powerfactory
app = powerfactory.GetApplicationExt()
outputWindow = app.GetOutputWindow()
outputWindow.Print(powerfactory.OutputWindow.MessageType.Plain,
                  "Hello World!")
```

PrintError

Prints a message as error into the **PowerFactory** Output Window. See [OutputWindow.Print\(\)](#) for more informations.

```
None Application.PrintError(str message)
```

PrintInfo

Prints a message as information into the **PowerFactory** Output Window. See [OutputWindow.Print\(\)](#) for more informations.

```
None Application.PrintInfo(str message)
```

PrintPlain

Prints a message as normal text into the **PowerFactory** Output Window. See [OutputWindow.Print\(\)](#) for more informations.

```
None Application.PrintPlain(str message)
```

PrintWarn

Prints a message as warning into the **PowerFactory** Output Window. See [OutputWindow.Print\(\)](#) for more informations.

```
None Application.PrintWarn(str message)
```

SetOutputWindowState

Changes the display state of the output window.

```
None Application.SetOutputWindowState(int newState)
```

ARGUMENTS

newState

- | | |
|-----------|--------------------------|
| 0 | Minimized output window. |
| 1 | Maximized output window. |
| -1 | Restore previous state. |

4 Output Window

Overview

[Clear](#)
[Flush](#)
[GetContent](#)
[Print](#)
[Save](#)
[SetState](#)

Clear

Clears the output window.

```
None OutputWindow.Clear()
```

Flush

Calling this function ensures that all previously printed and potentially buffered messages are visible in the output window.

```
None OutputWindow.Flush()
```

GetContent

Returns the content (unfiltered or filtered) of the output window.

```
[str] OutputWindow.GetContent()  
[str] OutputWindow.GetContent(MessageType filter)
```

ARGUMENTS

filter (optional)

If given, then only text from messages of this type will be returned.

RETURNS

List of texts of output window messages (unfiltered or filtered).

SEE ALSO

[OutputWindow.Print\(\)](#)

Print

Prints a message as normal text, as information, as warning or as error into the **PowerFactory** Output Window.

```
None OutputWindow.Print(str message)
None OutputWindow.Print(MessageType type, str message)
```

ARGUMENTS

type Type of message to print:

OutputWindow.MessageType.Plain Normal text.

OutputWindow.MessageType.Info Information.

OutputWindow.MessageType.Warn Warning.

OutputWindow.MessageType.Error Error.

The message is printed as normal text if no message type is given.

message Message to print.

EXAMPLE

```
import powerfactory
app = powerfactory.GetApplicationExt()
outputWindow = app.GetOutputWindow()
outputWindow.Print(powerfactory.OutputWindow.MessageType.Plain,
                   "Hello World!")
```

Save

Saves the content of current output window to a file.

```
None OutputWindow.Save(str filePath)
```

ARGUMENTS

filePath Full file name with path e.g. d:\data\output.txt. Possible file formats are html, txt and out.

SetState

Changes the display state of the output window.

```
None OutputWindow.SetState(int newState)
```

ARGUMENTS

newState

- 0** Minimized output window.
- 1** Maximized output window.
- 1** Restore previous state.

5 Object Methods

5.1 General Methods

Overview

AddCopy
CopyData
CreateObject
Delete
Energize
GetAttribute
GetAttributeDescription
GetAttributeDisplayed
GetAttributeLength
GetAttributes
GetAttributeShape
GetAttributeType
GetAttributeUnit
GetAttributeUnitPrefix
GetAttributeUnitPrefixFactor
GetChildren
GetClassName
GetCombinedProjectSource
GetConnectedElements
GetConnectionCount
GetContents
GetControlledNode
GetCubicle
GetDbObjectId
GetDbObjectKey
GetDbProjectId
GetFullPath
GetImpedance
GetInom
GetNode
GetOperator
GetOwner
GetParent
GetReferences
GetRegion
GetShortPath
GetSupplyingSubstations
GetSupplyingTransformers
GetSupplyingTrfstations

[GetSystemGrounding](#)
[GetUnom](#)
[GetZeroImpedance](#)
[HasAttribute](#)
[HasReferences](#)
[HasResults](#)
[IsCalcRelevant](#)
[IsDeleted](#)
[IsEarthed](#)
[IsEnergized](#)
[IsHidden](#)
[IsInFeeder](#)
[IsNetworkDataFolder](#)
[IsNode](#)
[IsObjectActive](#)
[IsObjectModifiedByVariation](#)
[Isolate](#)
[IsOutOfService](#)
[IsReducible](#)
[IsShortCircuited](#)
[MarkInGraphics](#)
[Move](#)
[PasteCopy](#)
[PurgeUnusedObjects](#)
[ReportUnusedObjects](#)
[SearchObject](#)
[SetAttribute](#)
[SetAttributeInRootAndStageObjects](#)
[SetAttributeLength](#)
[SetAttributes](#)
[SetAttributeShape](#)
[ShowEditDialog](#)
[ShowModalSelectTree](#)
[SwitchOff](#)
[SwitchOn](#)
[WriteChangesToDb](#)

AddCopy

Adds a copy of a single object or a set of objects to this object (= target object).

When copying a single object it is possible to give the new name. The new name will be concatenated by the given name parts.

The target object must be able to receive a copy of the objects.

Copying a set of objects will respect all internal references between those objects. Copying a set of lines and their types, for example, will result in a set of copied lines and line types, where the copied lines will use the copied line types.

When source object(s) and target object are inside different projects the method [DataObject.PasteCopy\(\)](#) has to be used instead, since it adapts all references automatically.

```

DataObject DataObject.AddCopy(DataObject objectToCopy,
                               [int|str partOfName0,]
                               [...])
DataObject DataObject.AddCopy(list objectsToCopy)

```

ARGUMENTS

objectToCopy

Object to copy.

objectNameParts (optional)

Specifies one or more segments to be concatenated to form the name of the new copy. Usually, this parameter is set to the desired name of the copied object, but providing multiple segments can be useful for adding indices or other identifiers to the object name.

objectsToCopy

Set of objects to copy.

RETURNS

Returns the copy that has been created on success or None, when copying a single object.

SEE ALSO

[DataObject.PasteCopy\(\)](#), [DataObject.Move\(\)](#), [Application.Delete\(\)](#)

EXAMPLE

The following example creates three copies of an object received as script input argument. The resulting copies will be named 'Copied Object 0', 'Copied Object 1', 'Copied Object 2':

```
import powerfactory
app = powerfactory.GetApplicationExt()
script = app.GetCurrentScript()
targetFolder = script.targetFolder
sourceObject = script.sourceObject
for i in range(3):
    copy = targetFolder.AddCopy(sourceObject, "Copied Object ", i)
    app.PrintInfo(f"Copied {str(sourceObject)} to {str(copy)}")
```

CopyData

Copies all parameters except for loc_name and containers from one object to another.

[None](#) [DataObject.CopyData\(DataObject source\)](#)

ARGUMENTS

source Object from which parameters are to be copied

RETURNS

0	ok
1	error

CreateObject

Creates a new object of given class and name in the target object. The object name will be concatenated by the given object name parts. The target object must be able to store an object of the given class in its content otherwise the currently running script will stop with an error.

```
DataObject DataObject.CreateObject(str className,
                                   [int|str objectNamePart0,]
                                   [...])
)
```

ARGUMENTS

className

The class name of the object to create.

objectNameParts (optional)

Parts of the name of the object to create (without classname) which will be concatenated to the object name.

RETURNS

object Newly created object.

None When no object was created.

Delete

Deletes the object from the database. The object is not destroyed but moved to the recycle bin.

```
int DataObject.Delete()
```

RETURNS

0 Object successfully deleted.

≠ 0 Deletion failed e.g. not allowed.

SEE ALSO

[DataObject.CreateObject\(\)](#)

Energize

Performs an “energize” action on the network element. This corresponds to removing earthings from current region (if any) followed by a “switch on” action on the element. The action is identical to that in the context menu.

```
[int error,
list changedSwitches] DataObject.Energize([int resetRA])
```

ARGUMENTS

changedSwitches (optional, out)

All switches whose switching state was changed by the action are filled into this set.

resetRA (optional)

Determines whether an active running arrangement that would prevent switching action should be deactivated or not.

- | | |
|----------|--|
| 1 | All running arrangements that cause blocking of relevant switches are applied and reset automatically before the switching is performed. |
| 0 | (default) Active running arrangements are not reset. Blocked switches will cause the switching action to fail. |

RETURNS

Information about the success of the action:

- | | |
|----------|------------------------|
| 0 | Action was successful. |
| 1 | Action failed. |

SEE ALSO

[DataObject.SwitchOn\(\)](#), [DataObject.SwitchOff\(\)](#), [DataObject.Isolate\(\)](#)

GetAttribute

Returns the value of an attribute.

```
int|float|str|DataObject|list DataObject.GetAttribute(str name,
                                                    [str unitPrefix])
```

ARGUMENTS

- | | |
|-------------------|-----------------------------------|
| <i>name</i> | Name of the attribute. |
| <i>unitPrefix</i> | The unit prefix, e.g. "k" or "M". |

RETURNS

Value of the attribute either in its current unit (like in the edit dialog seen) or in its given unit. An exception is thrown for invalid attribute names.

SEE ALSO

[DataObject.SetAttribute\(\)](#), [DataObject.GetAttributeType\(\)](#)

GetAttributeDescription

Returns the description of an attribute.

```
str DataObject.GetAttributeDescription(str name,
                                       int short = 0)
```

ARGUMENTS

- | | | | | | |
|--------------|--|----------|--|----------|-------------------------------------|
| <i>name</i> | Name of an attribute. | | | | |
| <i>short</i> | <table border="0"> <tr> <td style="vertical-align: top; padding-right: 20px;">0</td> <td>Return long attribute description (default).</td> </tr> <tr> <td style="vertical-align: top; padding-right: 20px;">1</td> <td>Return short attribute description.</td> </tr> </table> | 0 | Return long attribute description (default). | 1 | Return short attribute description. |
| 0 | Return long attribute description (default). | | | | |
| 1 | Return short attribute description. | | | | |

RETURNS

- | | |
|-------------|--------------------------------------|
| None | For an invalid attribute name. |
| str | Long or short attribute description. |

SEE ALSO

[DataObject.GetAttributeType\(\)](#), [DataObject.GetAttributeUnit\(\)](#)

GetAttributeDisplayed

Returns the displayed value of an attribute as string.

```
str DataObject.GetAttributeDisplayed(str name)
```

ARGUMENTS

name Name of the attribute.

RETURNS

Displayed value of the attribute as string in its current unit (like in the edit dialog seen). An exception is thrown for invalid attribute names.

SEE ALSO

[DataObject.GetAttribute\(\)](#), [DataObject.SetAttribute\(\)](#)

GetAttributeLength

Returns the length of a vector or matrix attribute. The length of a matrix attribute is the number of rows.

```
int DataObject.GetAttributeLength(str name)
```

ARGUMENTS

name Name of an attribute.

RETURNS

- > 0 Length of a valid vector or matrix attribute.
- 0 All other valid attributes.
- 1 For invalid attribute names.

SEE ALSO

[DataObject.GetAttributeShape\(\)](#), [DataObject.SetAttributeLength\(\)](#),
[DataObject.GetAttributeType\(\)](#)

GetAttributes

Gets the values of the transfer attributes defined via [Application.DefineTransferAttributes\(\)](#).

```
list DataObject.GetAttributes()
```

RETURNS

List of values for the defined transfer attributes. An exception is thrown for invalid attribute names.

SEE ALSO

[DataObject.SetAttributes\(\)](#), [Application.DefineTransferAttributes\(\)](#)

GetAttributeShape

Returns the shape of an attribute. The shape is a list of the form [number of rows, number of columns].

```
[int rows,
int columns ] DataObject.GetAttributeShape(str name)
```

ARGUMENTS

name Name of an attribute.

RETURNS

[≥ 0 , ≥ 0] Shape of a valid vector or matrix attribute.
 [0, 0] All other valid attributes.
 [-1, 0] For invalid attribute names.

SEE ALSO

[DataObject.GetAttributeLength\(\)](#), [DataObject.SetAttributeShape\(\)](#),
[DataObject.GetAttributeType\(\)](#)

GetAttributeType

Returns the type of an attribute.

The following attribute types exist:

<i>AttributeType.INVALID</i>	Attribute does not exist.
<i>AttributeType.INTEGER</i>	Integer attribute.
<i>AttributeType.INTEGER_VEC</i>	Integer vector attribute.
<i>AttributeType.DOUBLE</i>	Double attribute.
<i>AttributeType.DOUBLE_VEC</i>	Double vector attribute.
<i>AttributeType.DOUBLE_MAT</i>	Double matrix attribute.
<i>AttributeType.OBJECT</i>	Data object attribute.
<i>AttributeType.OBJECT_VEC</i>	Data object vector attribute.
<i>AttributeType.STRING</i>	String attribute.
<i>AttributeType.STRING_VEC</i>	String vector attribute.
<i>AttributeType.INTEGER64</i>	64-bit integer attribute.
<i>AttributeType.INTEGER64_VEC</i>	64-bit integer vector attribute.

```
AttributeType DataObject.GetAttributeType(str name)
```

ARGUMENTS

name Name of an attribute.

RETURNS

The type of an attribute or *AttributeType.INVALID* for an invalid attribute name.

SEE ALSO

[DataObject.GetAttribute\(\)](#), [DataObject.SetAttribute\(\)](#)

GetAttributeUnit

Returns the unit of an attribute e.g. km, MW....

```
str DataObject.GetAttributeUnit(str name)
```

ARGUMENTS

name Name of an attribute.

RETURNS

None For an invalid attribute name.

str Attribute unit.

SEE ALSO

[DataObject.GetAttributeType\(\)](#), [DataObject.GetAttributeDescription\(\)](#)

GetAttributeUnitPrefix

This function returns the unit prefix (e.g. "k" or "M") of the given attribute.

```
str DataObject.GetAttributeUnitPrefix(str name,
                                     [int type = 0])
```

ARGUMENTS

name The name of the attribute.

type (optional)

The type of the attribute unit.

0 The unit prefix of the displayed unit (Default).

1 The unit prefix of the internal unit.

RETURNS

The unit prefix (e.g. "k" or "M") of the given attribute. See the unit prefix table for more information.

SEE ALSO

[Application.GetUnitPrefixFactor\(\)](#), [DataObject.GetAttributeUnitPrefixFactor\(\)](#)

GetAttributeUnitPrefixFactor

This function returns the unit prefix factor (e.g. 1000) of the given attribute.

```
double DataObject.GetAttributeUnitPrefixFactor(str name,
                                              [int type = 0])
double DataObject.GetAttributeUnitPrefixFactor(str name,
                                              str relativeToPrefix,
                                              [int type = 0])
```

ARGUMENTS

name The name of the attribute.

relativeToPrefix (optional)

The unit prefix relative to, e.g. "k" or "M".

type (optional)

The type of the attribute unit.

0 The unit prefix factor of the displayed unit (Default).

1 The unit prefix factor of the internal unit.

2 The unit prefix factor of the displayed unit divided by the unit prefix factor of the internal unit (not allowed when relativeToPrefix is given).

RETURNS

The unit prefix factor (e.g. 1000) of the given attribute or 0 on error. See the unit prefix table for more information.

SEE ALSO

[Application.GetUnitPrefixFactor\(\)](#), [DataObject.GetAttributeUnitPrefix\(\)](#)

GetChildren

This function returns the objects that are stored within the object the function was called on. In contrast to [DataObject.GetContents\(\)](#) this function gives access to objects that are currently hidden due to scheme management.

```
list DataObject.GetChildren(int hiddenMode,
                           [str filter,]
                           [int subfolders])
```

ARGUMENTS

hiddenMode

Determines how hidden objects are handled.

- 0** Hidden objects are ignored. Only nonhidden objects are returned.
- 1** Hidden objects and nonhidden objects are returned.
- 2** Only hidden objects are returned. Nonhidden objects are ignored.

filter (optional)

Name filter, possibly containing '*' and '?' characters.

subfolder (optional)

Determines if children of subfolders are returned.

- 0** Only direct children are returned, children of subfolders are ignored (Default).
- 1** Also children of subfolders are returned.

RETURNS

Objects that are stored in the called object.

SEE ALSO

[DataObject.GetContents\(\)](#)

GetClassName

Returns the class name of the object.

```
str DataObject.GetClassName()
```

RETURNS

The class name of the object.

GetCombinedProjectSource

For an object in a combined project return the intermediate folder where the object is contained, indicating the original source project.

```
DataObject DataObject.GetCombinedProjectSource()
```

RETURNS

The intermediate folder for that object or nothing when not applicable.

GetConnectedElements

Returns the set of connected elements. Only electrically connected elements are returned when the conditions of all switches are regarded. Possible connections will also be returned when rBrk and/or rDis is zero, in the case of open breakers and/or disconnectors. The default values are (0,0,0).

```
list DataObject.GetConnectedElements([int rBrk],  
                                     [int rDis],  
                                     [int rOut])
```

ARGUMENTS

rBrk (optional)

if 1, regards position of breakers

rDis (optional)

if 1, regards position of disconnectors

rOut (optional)

if 1, regards in-service or out-of-service status

RETURNS

The set of connected elements.

GetConnectionCount

Returns the number of electrical connections.

ARGUMENTS

includeNeutral (optional)

1, also separate neutral conductor connections are taken into account.

```
int DataObject.GetConnectionCount([int includeNeutral=0])
```

RETURNS

The number of electrical connections.

GetContents

Returns the objects that are stored in the object and whose name matches the argument name. No object is returned if the object's container is empty, or if the object is not capable of storing objects. The argument name may contain the complete name and classname, or parts of the name with wildcard and class name.

```
list DataObject.GetContents([str Name,]
                             [int recursive,]
                             [int skipInactiveProjectContent])
```

ARGUMENTS

Name (optional)

loc name.class name, name possibly contains wildcards: '*' and '?' characters

recursive (optional)

- 1** All contained objects will be added recursively.
- 0** (default) Only direct children of current object will be collected.

skipInactiveProjectContent (optional)

- 1** Do not search in inactive projects.
- 0** (default) Search in inactive projects also.

RETURNS

Objects that are stored in the object.

GetControlledNode

Returns the target terminal and the resulting target voltage for generators and other voltage regulating units.

```
[DataObject node,
float targetVoltage] DataObject.GetControlledNode(int bus,
                                                  [int check])
```

ARGUMENTS

bus)

- 1** currently controlled bus
- 0** HV bus
- 1** MV/ LV bus
- 2** LV bus

targetVoltage (out)

The target voltage of the voltage regulating unit in pu.

check (optional)

- 0** (default) Do not check if the control mode is set to voltage control.
- 1** Only return the controlled node if the control mode is set to voltage control.

RETURNS

Controlled node, None if no controlled terminal exists (or not voltage controlled if check=1)

GetCubicle

Returns the cubicle of an object at the connection with index n, or None if there is no cubicle inside the object.

```
DataObject DataObject.GetCubicle(int side)
```

ARGUMENTS

side The connection number.

RETURNS

The cubicle object or None.

GetDbObjectId

Returns the Id for an object (depends to the current database).

```
int DataObject.GetDbObjectId([int asString])
str DataObject.GetDbObjectId([int asString])
```

ARGUMENTS

asString Set the return type:

- 0** Return the id as int (default). If Id is greater than 2^{31} (out of integer range) then returns a negative number.
- 1** Return the id as string (required if Id greater than 2^{31}).

RETURNS

The Object Id in the current database.

DEPRECATED NAMES

GetObjectId_

SEE ALSO

[DataObject.GetDbObjectKey\(\)](#), [DataObject.GetDbProjectId\(\)](#)

GetDbObjectKey

Returns the Object Key for an object. The Object Key is a unique identifier which remains constant during the lifetime of an object. Even after export and re-import (in same or another database), an object keeps its key.

Alternatively, the key can also be accessed via the attribute "objectKey".

```
str DataObject.GetDbObjectKey()
```

RETURNS

The Object Key e.g. "T4108k/RnUyenmjUh7iR0w".

SEE ALSO

[Application.GetObjectByDbObjectKey\(\)](#), [DataObject.GetDbObjectId\(\)](#),
[DataObject.GetDbProjectId\(\)](#)

GetDbProjectId

Returns the project Id for an object (depends to the current database).

```
int DataObject.GetDbProjectId([int asString])
str DataObject.GetDbProjectId([int asString])
```

ARGUMENTS

asString Set the return type:

- 0** Return the id as int (default). If Id is greater than 2^{31} (out of integer range) then returns a negative number.
- 1** Return the id as string (required if Id greater than 2^{31}).

RETURNS

The Project Id of the object in the current database.

DEPRECATED NAMES

GetObjectPid_

SEE ALSO

[DataObject.GetDbObjectId\(\)](#), [DataObject.GetDbObjectKey\(\)](#)

GetFullPath

Returns the full path (complete database path including the name and class name) or a short path with fixed length of the object as a string. See [DataObject.GetShortPath\(\)](#) for more details on the short path.

```
str DataObject.GetFullPath([int fixedLength])
```

ARGUMENTS

type(optional)

Is used to format the returned path:

not given

No special formatting. The full path is returned. It does not become a clickable link if printed to the output window.

= 0

The short path in single quotation marks instead of the full path is returned. It becomes a clickable link if printed to the output window.

> 0 (but less or equal to 190)

The short path in single quotation marks formatted exactly to this length is returned. It becomes a clickable link if printed to the output window.

RETURNS

The full path or the short path with fixed length of the object.

DEPRECATED NAMES

GetFullName

SEE ALSO

[DataObject.GetShortPath\(\)](#)**GetImpedance**

Returns the positive sequence impedance of an element referred to a given voltage.

```
[int error,
float real,
float imag] DataObject.GetImpedance(float refVoltage,
                                   [int i3Trf])
```

ARGUMENTS

real (out) Real part of the impedance in Ohm.*imag (out)*
Imaginary part of the impedance in Ohm.*refVoltage*
Reference voltage for the impedance in kV.*i3Trf (optional)*
When used with an *ElmTr3*

- 0** Return the HV-MV impedance.
- 1** Return the HV-LV impedance.
- 2** Return the MV-LV impedance.

RETURNS

- 1** An error occurred.
- 0** Otherwise.

SEE ALSO

[object.GetZeroImpedance\(\)](#)**GetInom**

Returns the nominal current of the object at given bus index.

```
float DataObject.GetInom([int busIndex = 0],
                        [int inclChar = 0])
```

ARGUMENTS

busIndex (optional)
Bus index, default value is 0.*inclChar (optional)*
option to consider thermal rating objects and values modified by characteristics on the (de-)rating factor.

- 0** Not considering thermal rating objects or values modified by characteristics on the (de-)rating factor (default).

- 1 Considering thermal rating objects and values modified by characteristics on the (de-)rating factor.
- 2 Considering thermal rating objects but not values modified by characteristics on the (de-)rating factor.

RETURNS

The nominal current at bus index.

SEE ALSO

[DataObject.GetUnom\(\)](#)

GetNode

Returns the node connected to the object at specified bus index.

```
DataObject DataObject.GetNode(int busIndex,
                               [int considerSwitches = 0])
```

ARGUMENTS

busIndex Bus index.

considerSwitches (optional)

- 0 Ignore the status of the switches (default).
- 1 Consider the status of the switches.

RETURNS

- object** Connected node object at specified bus index.
None If no node at bus index is found.

GetOperator

Returns the element's operator (*ElmOperator*).

```
DataObject DataObject.GetOperator()
```

RETURNS

Object of class *ElmOperator* determined according to following rules

- If operator is set in current object instance (attribute "pOperator") this operator object is returned.
- Else the operator inherited from its parent is used (recursively applied).
- None if none of its parents have an operator set.

GetOwner

Returns the element's owner (*ElmOwner*).

```
DataObject DataObject.GetOwner()
```

RETURNS

Object of class *ElmOwner* determined according to following rules

- If owner is set in current object instance (attribute “pOwner”) this owner object is returned.
- Else the owner inherited from its parent is used (recursively applied).
- None if none of its parents have an operator set.

GetParent

Returns the parent folder object (same as parameter 'fold_id').

```
DataObject DataObject.GetParent()
```

RETURNS

DataObject The parent folder object.

None On the root database folder e.g. parent of a user.

SEE ALSO

[DataObject.GetContents\(\)](#)

GetReferences

Returns a set containing all objects with references to the object the method was called on. By default, references from IntSubset objects or hidden objects are ignored.

```
list DataObject.GetReferences([str filter = '*',]
                             [int includeSubsets = 0,]
                             [int includeHiddenObjects = 0,]
                             [int includeDataExtensions = 0])
```

ARGUMENTS

filter (optional)

Object filter to get only objects whose name matches this filter string, e.g. '*.ElmLne'. (default: '*')

includeSubsets (optional)

Forces references from IntSubset objects to be evaluated. These are normally not included for performance reasons. (default: 0)

includeHiddenObjects (optional)

Include also hidden objects. By default they are not included. In contrast hidden objects are always included in the 'Reference List' output of the data browser. (default: 0)

includeDataExtensions (optional)

References from Data Extension parameters are also included. These are normally not included for performance reasons. (default: 0)

RETURNS

Set of objects with references to the object the method was called on.

SEE ALSO

[DataObject.GetReferences\(\)](#)

GetRegion

All network components are internally associated with an artificial region. A region consists of topologically connected elements. This means, two elements *elm1* and *elm2* are topologically connected $\Leftrightarrow$ `elm1.GetRegion() == elm2.GetRegion()`.

A region is simply identified by a number that can be access via this function.

```
int DataObject.GetRegion()
```

RETURNS

Region index >0 . A value of `'-1'` means status is unknown for that element (normally for not topology relevant elements).

GetShortPath

Returns the short path of an object together with its name and class name.

The short path is the path relative to the network data folder or the project folder of the currently activated project. If the object is not part of the currently activated project then its full path is returned, instead. It does not become a clickable link if printed to the output window.

```
str DataObject.GetShortPath()
```

RETURNS

The short path of the object (including its name and class name) as string.

SEE ALSO

[DataObject.GetFullPath\(\)](#)

GetSupplyingSubstations

Returns the closest supplying substation(s) for a network component.

“Closest” means that there is no other supplying element of same type in topological path between network component and the supplying component(s) returned by this function.

```
list DataObject.GetSupplyingSubstations()
```

RETURNS

List of substations (objects of class `ElmSubstat`). Can be empty.

SEE ALSO

[ElmTr2.GetSuppliedElements\(\)](#), [ElmTr3.GetSuppliedElements\(\)](#),
[ElmSubstat.GetSuppliedElements\(\)](#), [ElmTrfstat.GetSuppliedElements\(\)](#),
[DataObject.GetSupplyingTransformers\(\)](#), [DataObject.GetSupplyingTrfstations\(\)](#)

GetSupplyingTransformers

Returns the closest supplying transformer(s) for a network component. “Closest” means that there is no other supplying element of same type in topological path between network component and the supplying component(s) returned by this function.

```
list DataObject.GetSupplyingTransformers()
```

RETURNS

List of transformers (objects of class *ElmTr2* or *ElmTr3*). Can be empty.

SEE ALSO

[ElmTr2.GetSuppliedElements\(\)](#), [ElmTr3.GetSuppliedElements\(\)](#),
[ElmSubstat.GetSuppliedElements\(\)](#), [ElmTrfstat.GetSuppliedElements\(\)](#),
[DataObject.GetSupplyingSubstations\(\)](#), [DataObject.GetSupplyingTrfstations\(\)](#)

GetSupplyingTrfstations

Returns the closest supplying transformer station(s) for a network component. “Closest” means that there is no other supplying element of same type in topological path between network component and the supplying component(s) returned by this function.

```
list DataObject.GetSupplyingTrfstations()
```

RETURNS

List of transformer stations (objects of class *ElmTrfstat*). Can be empty.

SEE ALSO

[ElmTr2.GetSuppliedElements\(\)](#), [ElmTr3.GetSuppliedElements\(\)](#),
[ElmSubstat.GetSuppliedElements\(\)](#), [ElmTrfstat.GetSuppliedElements\(\)](#),
[DataObject.GetSupplyingTransformers\(\)](#), [DataObject.GetSupplyingSubstations\(\)](#)

GetSystemGrounding

Returns the grounding type employed in the grounding area of the grid the object belongs to. The grounding area is defined by network components separating the zero sequence system (e.g. star-delta transformers).

```
int DataObject.GetSystemGrounding()
```

RETURNS

- | | |
|-----------|--------------------------------------|
| -1 | grounding type can not be determined |
| 0 | system is solidly grounded |
| 1 | system is compensated |
| 2 | system is isolated |

GetUnom

Returns the nominal voltage of the object.

```
float DataObject.GetUnom([int busIndex = 0])
```

ARGUMENTS

busIndex (optional)

Bus index, default value is 0.

RETURNS

The nominal voltage at bus index.

SEE ALSO

[DataObject.GetInom\(\)](#)**GetZeroImpedance**

Returns the zero sequence impedance of an element referred to a given voltage.

```
[int error,
float real,
float imag] DataObject.GetZeroImpedance(float refVoltage,
                                         [int i3Trf])
```

ARGUMENTS

real (out) Real part of the impedance in Ohm.*imag* (out)

Imaginary part of the impedance in Ohm.

refVoltage

Reference voltage for the impedance in kV.

i3Trf (optional)When used with an *ElmTr3*

- | | |
|----------|-----------------------------|
| 0 | Return the HV-MV impedance. |
| 1 | Return the HV-LV impedance. |
| 2 | Return the MV-LV impedance. |

RETURNS

- | | |
|----------|--------------------|
| 1 | An error occurred. |
| 0 | Otherwise. |

SEE ALSO

[object.GetImpedance\(\)](#)**HasAttribute**

Returns whether the given name is a currently valid attribute name.

```
int DataObject.HasAttribute(str name)
```

ARGUMENTS

name Name of an attribute.

RETURNS

- | | |
|----------|---|
| 0 | Given name is not a currently valid attribute name. |
| 1 | Given name is a currently valid attribute name. |

SEE ALSO

[DataObject.GetAttribute\(\)](#), [DataObject.SetAttribute\(\)](#)

HasReferences

Find out whether there are objects with references to the object the method was called on.

```
int DataObject.HasReferences()
```

RETURNS

- 0** There are no such objects
- 1** There is one or more such objects

SEE ALSO

[DataObject.GetReferences\(\)](#)

HasResults

Checks if the object has calculated result parameters.

```
int DataObject.HasResults([int ibus])
```

ARGUMENTS

ibus (optional)

Bus index

- 1(default)** Checks if "c:" quantities exist
- >= 0** Checks if 'm:xxxx:bus ' quantities exist for bus index=ibus
- 2** Hidden objects are returned

RETURNS

- 0** no results available
- 1** results exist

IsCalcRelevant

Returns whether the object is relevant for calculation.

In contrast to [Application.GetCalcRelevantObjects\(\)](#) it also returns 1 for objects in the active study case e.g. simulation events (Evt*).

```
int DataObject.IsCalcRelevant()
```

RETURNS

- 0** When the object is not used for calculations.
- 1** When the object is currently used for calculations.

SEE ALSO

[Application.GetCalcRelevantObjects\(\)](#)

IsDeleted

Returns 1 if the object is deleted.

```
int DataObject.IsDeleted()
```

RETURNS

- | | |
|----------|----------------------------|
| 1 | Object is already deleted. |
| 0 | Object is not deleted. |

IsEarthed

Checks if a network component is topologically connected to any earthed component. Earthing components are terminals / busbars (*ElmTerm*) with attribute 'iEarth' = 1 and all closed grounding switches (*ElmGndswt*). An energized component is never considered to be earthed.

```
int DataObject.IsEarthed()
```

RETURNS

- | | |
|----------|---|
| 1 | Component is earthed (connected to an earthing component) |
| 0 | Component is not earthed |

IsEnergized

Checks if a network component is energized. A component is considered to be energized, if it is topologically connected to a generator. All other elements are considered to be deenergized.

```
int DataObject.IsEnergized()
```

RETURNS

- | | |
|-----------|---|
| 1 | Component is energized |
| 0 | Component is deenergized |
| -1 | Component has no energizing status (status unknown) |

IsHidden

Checks whether an object is hidden with respect to currently activated variation. An object is hidden if it is

- *deleted* in currently active variation or
- *added* in a variation that is currently not active

```
int DataObject.IsHidden()
```

RETURNS

- | | |
|----------|--------------------------------|
| 0 | not hidden, currently 'active' |
| 1 | hidden, currently 'inactive' |

IsInFeeder

Checks if the object is part of the given feeder. A network element is considered being part of a feeder if a topological path from the feeder definition to the element exists.

This function is based on load flow calculation results. Therefore, it can only be used after such a calculation has been successfully executed and as long as the results are available.

```
int DataObject.IsInFeeder(DataObject Feeder,
                          [int OptNested=0])
```

ARGUMENTS

Feeder The Feeder definition object *ElmFeeder*

OptNested (optional)

0 Nested feeders are not considered.

1 Nested feeders are considered.

RETURNS

1 If “Feeder” is a feeder definition and the object is part of that feeder.

0 Otherwise

SEE ALSO

[ElmFeeder.GetAll\(\)](#)

IsNetworkDataFolder

Checks whether given object is a special folder within a project that stores specific data elements. Each project can not have more than one instance per folder type.

The following folder types are distinguished (**PowerFactory** class names):

IntArea stores *ElmArea* objects

IntBbone stores *ElmBbone* and *SetBbone* objects

IntBmu stores *ElmBmu* objects

IntBoundary stores *ElmBoundary* objects

IntCircuit stores *ElmCircuit* objects

IntFeeder stores *ElmFeeder* objects

IntMeteostat stores *ElmMeteostat* objects

IntOperator stores *ElmOperator* objects

IntOwner stores *ElmOwner* objects

IntPath stores *SetPath* objects

IntRoute stores *ElmRoute* objects

IntScales stores *Tri** objects

```
int DataObject.IsNetworkDataFolder()
```


RETURNS

- 0** false, object is not a network data folder
- 1** true, object is a network data folder

SEE ALSO

[Application.GetDataFolder\(\)](#)

IsNode

Indicates whether an object is a node (terminal or busbar).

```
int DataObject.IsNode()
```

RETURNS

- 1** Object is a node.
- 0** Otherwise.

IsObjectActive

Check if an object is active for specific time.

```
int DataObject.IsObjectActive(int time)
```

ARGUMENTS

time Time in seconds since 01.01.1970 00:00:00.

RETURNS

- 0** Object is not active (hidden or deleted).
- 1** Object is active.

IsObjectModifiedByVariation

Check if an object is active for specific time.

```
int DataObject.IsObjectModifiedByVariation(int considerADD,
                                           int considerDEL,
                                           int considerDELTA)
```

ARGUMENTS

considerADD

checks if an ADD-object exists

- 0** ignore ADD-objects
- 1** consider ADD-objects

considerDEL

check if a DELETE-Object exists or exist for the parent objects

- 0** ignore DELETE-objects
- 1** consider DELETE-objects

considerDELTA

check if a DELTA-Object exists

- 0** ignore DELTA-objects
- 1** consider DELTA-objects

RETURNS

- 0** Object is not modified by an active variation
- 1** Object is modified by an active variation

Isolate

Performs an “isolate” action on the network element. This corresponds to performing a “switch off” action followed by an additional earthing of switched off region. The action is identical to that in the context menu.

```
[int error,
list changedSwitches] DataObject.Isolate([int resetRA,]
                                           [int isolateCBs])
```

ARGUMENTS

changedSwitches (optional, out)

All switches whose switching state was changed by the action are filled into this set

resetRA (optional)

Determines whether an active running arrangement that would prevent switching action should be deactivated or not.

- 1** All running arrangements that cause blocking of relevant switches are applied and reset automatically before the switching is performed.
- 0** (default) Active running arrangements are not reset. Blocked switches will cause the switching action to fail

isolateCBs (optional)

Determines if, in addition, circuit breakers should be isolated by opening its adjacent disconnectors (if not given, default will be taken from project settings)

- 0** No additional opening of disconnectors
- 1** Also open disconnectors adjacent to switched circuit breakers)

RETURNS

Information about the success of the action:

- 0** Action was successful
- 1** Action failed

SEE ALSO

[DataObject.SwitchOn\(\)](#), [DataObject.SwitchOff\(\)](#), [DataObject.Energize\(\)](#)

IsOutOfService

Indicates whether or not the object is currently out of service.

```
int DataObject.IsOutOfService()
```

RETURNS

- 0** When the object is in service.
- 1** When the object is out of service.

IsReducible

Checks if object can be reduced during network reduction.

```
int DataObject.IsReducible()
```

RETURNS

- 0** object can never be reduced.
- 1** object can be reduced (e.g. switch, zero-length lines)
- 2** in principle the object can be reduced, but not now (e.g. switch that is set to be detailed)

IsShortCircuited

Returns whether an element is short-circuited or not.

```
int DataObject.IsShortCircuited()
```

RETURNS

- 0** No short-circuit found.
- 1** Element is short-circuited.

MarkInGraphics

This function is not supported in GUI-less mode.

Marks the object in the diagram in which the element is found by hatch crossing it. By default all the currently opened diagrams are searched for the element to mark beginning with the diagram shown. The first diagram in which the element is found will be opened and the element is marked.

Alternatively the search can be extended to all existing diagrams by passing 1 as parameter. If the element exists in more than one diagram the user can select from a list of diagrams which diagram shall be opened.

```
None DataObject.MarkInGraphics([int searchAllDiagramsAndSelect = 0])
```

ARGUMENTS

searchAllDiagramsAndSelect (optional)

Search can be extended to all diagrams, not only the ones which are currently shown on the desktop.

- 0** Only search in currently opened diagrams and open the first diagram in which the element was found. (default)
- 1** Searching all diagrams, not only the ones which are currently shown on the desktop. If there is more than one occurrence the user will be prompted which diagrams shall be opened.

RETURNS

A diagram in which the element is drawn is opened and the element is marked.

Move

Moves an object or a set of objects to this folder.

```
int DataObject.Move(DataObject objectToMove)
int DataObject.Move(list objectsToMove)
```

ARGUMENTS

objectToMove
Object to move.

objectsToMove
Set of objects to move.

RETURNS

0 On success.
1 On error.

SEE ALSO

[DataObject.AddCopy\(\)](#), [DataObject.PasteCopy\(\)](#), [Application.Delete\(\)](#)

PasteCopy

Pastes a copy of a single object or a set of objects to this object (= target object) using the merge tool when source object(s) and target object are inside different projects (equivalent to a manual copy&paste operation).

```
[int error,
DataObject newObject] DataObject.PasteCopy(DataObject objectToCopy,
                                             [int resetMissingReferences = 0])
int DataObject.PasteCopy(list objectsToCopy)
```

ARGUMENTS

objectToCopy
Object to be copied.

objectsToCopy
Set of objects to copy.

newObject (out)
The new object copy of objectToCopy is assigned on success.

resetMissingReferences (optional)
Determines how to handle missing references.

0 No action is taken, the operation is cancelled with an error (default).
1 Missing references are automatically reset.

RETURNS

0 Object(s) successfully copied.
1 Error.

SEE ALSO

[DataObject.AddCopy\(\)](#), [DataObject.Move\(\)](#), [Application.Delete\(\)](#)

PurgeUnusedObjects

The function deletes the following child objects:

1. All 'hidden' objects without corresponding "Add" object. These objects are only deleted, if the condition is fulfilled for all child objects (hidden without corresponding 'Add' object).
2. All internal expansion stage objects with invalid target object (target object reference is missing).

It's crucial that there is no study case active when executing the function.

```
None DataObject.PurgeUnusedObjects()
```

SEE ALSO

[DataObject.ReportUnusedObjects\(\)](#)

ReportUnusedObjects

Prints a report in the PowerFactory output window, which object will be deleted when function [DataObject.PurgeUnusedObjects\(\)](#) is called. It's crucial that there is no study case active when executing the function.

```
None DataObject.ReportUnusedObjects()
```

SEE ALSO

[DataObject.PurgeUnusedObjects\(\)](#)

SearchObject

Searches for an object with a full path, such as 'rootfolder.class\subfolder.class\...\locname.class '.

```
DataObject DataObject.SearchObject(str name)
```

ARGUMENTS

name string to search

RETURNS

Returns the searched object.

SEE ALSO

[DataObject.GetFullPath\(\)](#)

SetAttribute

Sets the value of an attribute.

```
None DataObject.SetAttribute(str name,
                             int|float|str|DataObject|list value,
                             [str unitPrefix])
```

ARGUMENTS

- name* Name of an attribute.
- value* Value to be set in its current/given unit (like in the edit dialog seen). An exception is thrown for invalid attribute names.
- unitPrefix* The unit prefix, e.g. "k" or "M".

SEE ALSO

[DataObject.GetAttribute\(\)](#), [DataObject.GetAttributeType\(\)](#)

SetAttributeInRootAndStageObjects

Sets an attribute value in all occurrences of an object, i.e. in the root object and all stage objects referring to that root object.

```
int DataObject.SetAttributeInRootAndStageObjects(str attributeName,
                                                  str value)
```

ARGUMENTS

- attributeName* Name of attribute to be modified, including prefix and subindices.
- value* New attribute value.

RETURNS

- 0 OK
- 1 Error

SetAttributeLength

Sets the length of a vector or matrix attribute. The length of a matrix attribute is the number of rows.

```
int DataObject.SetAttributeLength(str name, int length)
```

ARGUMENTS

- name* Name of an attribute.
- length* New length of the attribute.

RETURNS

- 0 On success.
- 1 On error.

SEE ALSO

[DataObject.SetAttributeShape\(\)](#), [DataObject.GetAttributeLength\(\)](#),
[DataObject.GetAttributeType\(\)](#)

SetAttributes

Sets the values of the transfer attributes defined via [Application.DefineTransferAttributes\(\)](#).

```
None DataObject.SetAttributes(list values)
```

ARGUMENTS

values Values to be set in its current unit (like in the edit dialog seen). The internal unit can be used with [Application.SetAttributeModelInternal\(\)](#). An exception is thrown for invalid attribute names or values.

SEE ALSO

[Application.DefineTransferAttributes\(\)](#), [DataObject.GetAttributes\(\)](#)

SetAttributeShape

Sets the shape of a matrix or vector attribute. The shape is a list of the form [number of rows, number of columns]. Number of columns has to be 0 for vectors.

```
int DataObject.SetAttributeShape(str name, list shape)
```

ARGUMENTS

name Name of an attribute.

shape New shape of the attribute.

RETURNS

0 On success.

1 On error.

SEE ALSO

[DataObject.SetAttributeLength\(\)](#), [DataObject.GetAttributeShape\(\)](#),
[DataObject.GetAttributeType\(\)](#)

ShowEditDialog

This function is not supported in GUI-less mode.

Opens the edit dialogue of the object. Command objects (such as *ComLdf*) will have their “Execute” button disabled. The execution of the running script will be halted until the edit dialogue is closed again.

Editing of command objects (*ComDPL*, *ComPython*) is not supported.

```
int DataObject.ShowEditDialog()
```

RETURNS

- 1** Edit dialogue was cancelled by the user.
- 0** Otherwise.

ShowModalSelectTree

This function is not supported in GUI-less mode.

Shows a modal window with the database object tree of the object on which the function is called on.

```
DataObject DataObject.ShowModalSelectTree([str title,]
                                           [str filter])
```

ARGUMENTS

title (optional)

Title of the dialog. If omitted, a default title will be used.

filter (optional)

Classname filter e.g. 'ElmLne' or 'Com*'. If set, a selection is only accepted if the classname of the selected object matches that filter.

RETURNS

- DataObject** Selected object.
- None** No object selected e.g. 'Cancel' clicked.

SwitchOff

Performs a “switch off” action on the network element. This action is identical to that in the context menu.

```
[int error,
list changedSwitches] DataObject.SwitchOff([int resetRA,]
                                           [int simulateOnly])
```

ARGUMENTS

changedSwitches (optional, out)

All switches whose switching state was changed by the action are filled into this set

resetRA (optional)

Determines whether an active running arrangement that would prevent switching action should be deactivated or not.

- 1** All running arrangements that cause blocking of relevant switches are applied and reset automatically before the switching is performed.
- 0** (default) Active running arrangements are not reset. Blocked switches will cause the switching action to fail

simulateOnly (optional)

Can be used to get the switches that would be changed. No switching is performed if set to '1'. (default is '0')

RETURNS

Information about the success of the action:

- 0** Action was successful
- 1** Action failed

SEE ALSO

[DataObject.SwitchOn\(\)](#), [DataObject.Isolate\(\)](#), [DataObject.Energize\(\)](#)

SwitchOn

Performs a “switch on” action on the network element. This action is identical to that in the context menu.

```
[int error,
list changedSwitches] DataObject.SwitchOn([int resetRA,]
                                           [int simulateOnly])
```

ARGUMENTS

changedSwitches (optional, out)

All switches whose switching state was changed by the action are filled into this set

resetRA (optional)

Determines whether an active running arrangement that would prevent switching action should be deactivated or not.

- 1** All running arrangements that cause blocking of relevant switches are applied and reset automatically before the switching is performed.
- 0** (default) Active running arrangements are not reset. Blocked switches will cause the switching action to fail

simulateOnly (optional)

Can be used to get the switches that would be changed. No switching is performed if set to '1'. (default is '0')

RETURNS

Information about the success of the action:

- 0** Action was successful
- 1** Action failed

SEE ALSO

[DataObject.SwitchOff\(\)](#), [DataObject.Isolate\(\)](#), [DataObject.Energize\(\)](#)

WriteChangesToDb

See [Application.WriteChangesToDb\(\)](#) for a detailed description.

```
None DataObject.WriteChangesToDb()
```

5.2 Network Elements

5.2.1 ElmArea

Overview

[CalculateInterchangeTo](#)
[CalculateVoltageLevel](#)
[CalculateVoltInterVolt](#)
[DefineBoundary](#)
[GetAll](#)
[GetBranches](#)
[GetBuses](#)
[GetObjs](#)

CalculateInterchangeTo

Calculates interchange power to the given area (calculated quantities are: Pinter, Qinter, Pexport, Qexport, Pimport, Qimport). Prior the calculation the valid load flow calculation is required.

```
int ElmArea.CalculateInterchangeTo(DataObject area)
```

ARGUMENTS

area Area to which the interchange is calculated

RETURNS

< 0 Calculation error (i.e. no valid load flow, empty area...)
0 No interchange power to the given area
1 Interchange power calculated

CalculateVoltageLevel

Internal function to calculate per voltage level the corresponding summary results. The values are stored in current area (values from the previous load flow calculation are overwritten):

```
int ElmArea.CalculateVoltageLevel(double U)
```

ARGUMENTS

U for voltage level (in kV)

RETURNS

< 0 error
= 0 voltage level not exists in the area
> 0 ok

CalculateVoltInterVolt

This function calculates the power flow from voltage level to voltage level. The values are stored in current area in the following attributes (values from the previous load flow calculation are overwritten):

- Pinter: Active Power Flow
- Qinter: Reactive Power Flow
- ExportP: Export Active Power Flow
- ExportQ: Export Reactive Power Flow
- ImportP: Import Active Power Flow
- ImportQ: Import Reactive Power Flow

```
int ElmArea.CalculateVoltInterVolt(double Ufrom,
                                   double Uto)
```

ARGUMENTS

Ufrom from voltage level (in kV)

Uto to voltage level (in kV)

RETURNS

- < 0 error
- = 0 voltage levels not exists in the area, no interchange exists
- > 0 ok

DefineBoundary

Defines boundary with this area as interior part. Resulting cubicles of boundary are busbar-oriented towards the area.

```
DataObject ElmArea.DefineBoundary(int shift)
```

ARGUMENTS

shift Elements outside the area that are within a distance of shift many elements to a boundary cubicle of the area are added to the interior part of the resulting boundary

RETURNS

The defined boundary is returned in case of success. Otherwise None, if an error appeared in the definition of the boundary.

GetAll

Returns all objects which belong to this area.

```
list ElmArea.GetAll()
```

RETURNS

The set of contained objects.

GetBranches

Returns all branches which belong to this area.

```
list ElmArea.GetBranches()
```

RETURNS

The set of branch objects.

GetBuses

Returns all buses which belong to this area.

```
list ElmArea.GetBuses()
```

RETURNS

The set of objects.

GetObjs

Returns all objects of the given class which belong to this area.

```
list ElmArea.GetObjs(str classname)
```

ARGUMENTS

classname

Name of the class (i.e. "ElmTr2").

RETURNS

The set of objects.

5.2.2 ElmAsm

Overview

[CalcEfficiency](#)
[GetAvailableGenPower](#)
[GetElecTorque](#)
[GetGroundingImpedance](#)
[GetMechTorque](#)
[GetMotorStartingFlag](#)
[GetStepupTransformer](#)
[IsPQ](#)

CalcEfficiency

Calculate efficiency for connected storage model at given active power value.

```
float ElmAsm.CalcEfficiency(float activePowerMW)
```

ARGUMENTS

activePowerMW

Active power value to calculate efficiency for.

RETURNS

Returns the resulting efficiency in p.u.

GetAvailableGenPower

Returns the available power that can be dispatched from the generator, for the particular study time.

For the case of conventional generators (no wind generation selected), the available power is equal to the nominal power specified.

For wind generators, the available power will depend on the wind model specified:

- No Wind Model: No available power.
- Stochastic Wind Model: Given the specified mean wind speed, the available power is calculated from the Power Curve. If the units of the Power Curve are in MW, the returned value is directly the available power. In the other hand, if the units are in PU, the returned value is multiplied by the nominal power of the generator to return the available power.
- Time Series Characteristics of Active Power Contribution: The available power is the average of the power values (in MW) obtained from all the specified time characteristics for the current study time.
- Time Series Characteristics of Wind Speed: The available power is calculated with the average of the power values (in MW) calculated for all the specified time characteristics. A power value for any time characteristic is calculated by obtaining the wind speed for the current study time, and then calculating the power from the specified Power Curve. If the units of the Power Curve are in MW, the returned value is directly the power value. In the other hand, if the units are in PU, the returned value is multiplied by the nominal power of the generator to return the power value.

For motors, the available power is zero.

```
float ElmAsm.GetAvailableGenPower()
```

RETURNS

Available generation power

GetElecTorque

Calculates the electrical torque for a given speed and voltage.

```
float ElmAsm.GetElecTorque(float speed,
                           float uReal,
                           [float addZReal,]
                           [float addZImag]
                           )
```

ARGUMENTS

- speed* speed value in p.u.
- uReal* voltage value (real part) in p.u.
- addZReal (optional)*
 additional impedance (real part) in p.u.
- addZImag (optional)*
 additional impedance (imaginary part) in p.u.

RETURNS

Returns the calculated electrical torque.

GetGroundingImpedance

Returns the impedance of the internal grounding.

```
[int valid,
float resistance,
float reactance ] ElmAsm.GetGroundingImpedance(int busIdx)
```

ARGUMENTS

- busIdx* Bus index where the grounding should be determined.
- resistance (out)*
 Real part of the grounding impedance in Ohm.
- reactance (out)*
 Imaginary part of the grounding impedance in Ohm.

RETURNS

- 0** The values are invalid (e.g. because there is no internal grounding)
- 1** The values are valid.

GetMechTorque

Calculates the electrical torque for a given speed and voltage.

```
float ElmAsm.GetMechTorque(float speed,
                           float uReal
                           )
```

ARGUMENTS

- speed* speed value in p.u.
- uReal* voltage value (real part) in p.u.

RETURNS

Returns the calculated mechanical torque.

GetMotorStartingFlag

Returns the starting motor condition.

```
int ElmAsm.GetMotorStartingFlag()
```

RETURNS

Returns the motor starting condition. Possible values are:

- 1** in the process of being calculated
- 0** not calculated
- 1** successful start
- 2** unsuccessful start

GetStepupTransformer

Performs a topological search to find the step-up transformer of the asynchronous machine.

```
DataObject ElmAsm.GetStepupTransformer(float Voltage,  
                                         int swStatus  
                                         )
```

ARGUMENTS

hvVoltage
voltage level at which the search will stop

ignSwStatus
consideration of switch status. Possible values are:

- 0** consider all switch status
- 1** ignore breaker status
- 2** ignore all switch status

RETURNS

Returns the first collected step-up transformer object. It is empty if not found (e.g. start terminal already at hvVoltage).

IsPQ

Informs whether or not it is a "PQ" machine (constant Q control mode).

```
int ElmAsm.IsPQ()
```

RETURNS

Returns 1 if it is a "PQ" machine.

5.2.3 ElmAsmSc

Overview

[GetAvailableGenPower](#)
[GetGroundingImpedance](#)
[GetStepupTransformer](#)

GetAvailableGenPower

Returns the available power that can be dispatched from the generator, for the particular study time.

For the case of conventional generators (no wind generation selected), the available power is equal to the nominal power specified.

For wind generators, the available power will depend on the wind model specified:

- No Wind Model: No available power.
- Stochastic Wind Model: Given the specified mean wind speed, the available power is calculated from the Power Curve. If the units of the Power Curve are in MW, the returned value is directly the available power. In the other hand, if the units are in PU, the returned value is multiplied by the nominal power of the generator to return the available power.
- Time Series Characteristics of Active Power Contribution: The available power is the average of the power values (in MW) obtained from all the specified time characteristics for the current study time.
- Time Series Characteristics of Wind Speed: The available power is calculated with the average of the power values (in MW) calculated for all the specified time characteristics. A power value for any time characteristic is calculated by obtaining the wind speed for the current study time, and then calculating the power from the specified Power Curve. If the units of the Power Curve are in MW, the returned value is directly the power value. In the other hand, if the units are in PU, the returned value is multiplied by the nominal power of the generator to return the power value.

For motors, the available power is zero.

```
float ElmAsmSc.GetAvailableGenPower()
```

RETURNS

Available generation power

GetGroundingImpedance

Returns the impedance of the internal grounding.

```
[int valid,  
float resistance,  
float reactance ] ElmAsmSc.GetGroundingImpedance(int busIdx)
```

ARGUMENTS

busIdx Bus index where the grounding should be determined.

resistance (out)
Real part of the grounding impedance in Ohm.

reactance (out)

Imaginary part of the grounding impedance in Ohm.

RETURNS

- 0** The values are invalid (e.g. because there is no internal grounding)
- 1** The values are valid.

GetStepupTransformer

Performs a topological search to find the step-up transformer of the asynchronous machine.

```
DataObject ElmAsmSc.GetStepupTransformer(float Voltage,
                                           int swStatus
                                           )
```

ARGUMENTS

hvVoltage

voltage level at which the search will stop

ignSwStatus

consideration of switch status. Possible values are:

- 0** consider all switch status
- 1** ignore breaker status
- 2** ignore all switch status

RETURNS

Returns the first collected step-up transformer object. It is empty if not found (e.g. start terminal already at hvVoltage).

5.2.4 ElmBattery

Overview

[GetGroundingImpedance](#)

GetGroundingImpedance

Returns the impedance of the internal grounding. Voltage source with a setpoint of zero are considered as grounding devices themselves; i.e. the Ri paramter is used.

```
[int valid,
float resistance,
float reactance ] ElmBattery.GetGroundingImpedance(int busIdx)
```

ARGUMENTS

busIdx Bus index where the grounding should be determined.

resistance (out)

Real part of the grounding impedance in Ohm.

reactance (out)

Imaginary part of the grounding impedance in Ohm.

RETURNS

- 0** The values are invalid (e.g. because there is no internal grounding)
- 1** The values are valid.

5.2.5 ElmBbone

Overview

[CheckBbPath](#)
[GetBbOrder](#)
[GetCompleteBbPath](#)
[GetFOR](#)
[GetMeanCs](#)
[GetMinCs](#)
[GetTieOpenPoint](#)
[GetTotLength](#)
[HasGnrlMod](#)

CheckBbPath

Check whether the backbone object is still valid. This means:

- a** Terminals determining backbone path are still directly connected.
- b** One switch is open on the path of an inter-feeder backbone.
- c** Contents of backbone match specified starting-feeder (and end feeder).
- d** Start and end of feeder are calculation-relevant.
- e** Path is unique via the defined terminals (no parallel elements (only warning!)).

```
int ElmBbone.CheckBbPath(int outputMsg)
```

ARGUMENTS

outputMsg

- 1** Output resulting messages of check function.
- 0** Only check, no output of messages.

RETURNS

- 0** Backbone is valid.
- 1** Backbone is invalid because of one or more of the above listed reasons.

GetBbOrder

Get order of backbone object, determined by backbone calculation according to the selected criterion.

```
int ElmBbone.GetBbOrder()
```

RETURNS

The order of the backbone object. The smaller the returned value, the better the backbone according to chosen criterion. The order 1 is returned for the best backbone.

GetCompleteBbPath

Get the complete (ordered) path containing all terminals and connecting elements of the backbone.

```
list ElmBbone.GetCompleteBbPath(int iReverse,
                                [int iStopAtTieOpen = 0])
```

ARGUMENTS

AllElmsOnBb (out)

Ordered path containing all terminals and connecting elements of the backbone.

iReverse

- | | |
|---|---|
| 0 | Return ordered path from start feeder to end feeder |
| 1 | Return ordered path from end feeder to start feeder |

iStopAtTieOpen

- | | |
|---|--|
| 0 | return complete path |
| 1 | only return part of path in start feeder (iReverse=0) / in end feeder (iReverse=1) |

GetFOR

Get aggregated forced outage rate (FOR) of all elements on the path of the backbone.

```
float ElmBbone.GetFOR()
```

RETURNS

The aggregated forced outage rate (FOR) of all elements on the path of the backbone [in 1/a].

GetMeanCs

Get mean cross section value of all elements on the path of the backbone. Every cross section value is weighted with the relative length corresponding to the total length of the backbone.

```
float ElmBbone.GetMeanCs()
```

RETURNS

The mean cross section of the elements on the backbone path [in mm²].

GetMinCs

Get minimum cross section value of all elements on the path of the backbone. Optional: a set with all elements on the backbone path featuring this cross section may be returned.

```
[float minCs,
set ElmsMinCs] ElmBbone.ElmBoundary.IsSplitting()
```

ARGUMENTS

ElmsMinCs

Elements on the backbone path featuring minimum cross section value.

RETURNS

The minimum cross section of all elements on the backbone path [in mm²].

GetTieOpenPoint

Search and obtain the first open switching device (ElmCoup, StaSwitch) on the backbone path (starting from the infeeding point of the starting feeder).

```
DataObject ElmBbone.GetTieOpenPoint()
```

RETURNS

The switching device (ElmCoup or StaSwitch) or None if backbone is invalid.

GetTotLength

Get total length of all elements on the path of the backbone.

```
float ElmBbone.GetTotLength()
```

RETURNS

The total length of the backbone path [in km].

HasGnrlMod

Check whether backbone object ElmBbone has a valid CalBbone where corresponding results are stored. This is only the case after a backbone calculation by scoring method (until the calculation is reset).

```
int ElmBbone.HasGnrlMod()
```

RETURNS

- 1** ElmBbone has a calculation model,
- 0** no calculation model available.

5.2.6 ElmBmu**Overview**

[Apply](#)
[Update](#)

Apply

Applies the power dispatch. Depending on the selected 'Distribution Mode ' this is done by a built-in algorithm based on 'Merit Order' or by a user-defined DPL script that is stored in the contents of the virtual power plant object.

```
int ElmBmu.Apply()
```

RETURNS

- 0** on success, no error occurred
- 1** error during dispatch by virtual power plant. Please note, a value of 1 is also returned in case the power plant is current set out-of-service.

Update

Updates the list of machines in the tables: 'Dispatchable Machines' and 'Non-dispatchable (fixed) Machines'.

```
None ElmBmu.Update()
```

5.2.7 ElmBoundary

Overview

[AddCubicle](#)
[CalcShiftedReversedBoundary](#)
[Clear](#)
[GetInterior](#)
[IsSplitting](#)
[Resize](#)
[Update](#)

AddCubicle

Adds a given cubicle with given orientation to an existing boundary. The cubicle is added only if it is not already contained within the boundary.

```
int ElmBoundary.AddCubicle(DataObject cubicle,
                           int orientation
                           )
```

RETURNS

- 0** cubicle was successfully added
- 1** cubicle was not added because it is already contained (including given orientation)

CalcShiftedReversedBoundary

Defines boundary where exterior and interior part of this boundary are exchanged. Resulting boundary cubicles are branch-oriented.

```
[int error,
DataObject boundary] ElmBoundary.CalcShiftedReversedBoundary(float shift)
```

ARGUMENTS

shift Elements that are within a distance of *shift* many elements to a boundary cubicle of this boundary are added to the exterior part of the resulting boundary.

boundary (out)
Defined boundary.

RETURNS

- 0** Successful call, boundary defined.
- 1** Error during determination of boundary cubicles.

Clear

Removes all boundary cubicles from an existing boundary.

```
None ElmBoundary.Clear()
```

GetInterior

Returns a set of all elements that are contained in the interior region of the boundary.

```
list ElmBoundary.GetInterior()
```

RETURNS

Returns the set of interior elements.

IsSplitting

Checks if the boundary splits the network into two regions. A boundary is called splitting, if and only if, for each boundary cubicle, the adjacent terminal and the adjacent branch component belong to different sides of the boundary.

```
[int isSplitting,  
list notSplittingCubicles] ElmBoundary.IsSplitting()
```

ARGUMENTS

notSplittingCubicles (optional, out)
All cubicles that prevent the boundary from being splitting are filled into this set.

RETURNS

- 0** not splitting boundary
- 1** splitting boundary

Resize

Resizes the boundary cubicle vector and the cubicle orientation vector.

```
None ElmBoundary.Resize(float size)
```

ARGUMENTS

size size of the referenced vector (number of cubicles)

RETURNS

If the resize is unsuccessful the error message shall be issued.

Update

Updates cached information (such as topological interior). Required when boundary definition was changed via DPL or Python.

```
None ElmBoundary.Update()
```

5.2.8 ElmBranch**Overview**

[InsertTemplate](#)
[Update](#)

InsertTemplate

Inserts graphic templates from both project library and global libraries into the specified target folder.

```
None ElmBranch.InsertTemplate(DataObject targetFolder,
                              [DataObject conNode1],
                              [DataObject conNode2],
                              [DataObject diagram],
                              [float posX],
                              [float posY])
```

ARGUMENTS

targetFolder

Target folder of new elements.

None Default target folder of diagram is used.

conNode1

Relevant if template shall be connected. Any terminal or cubicle.

conNode2

Relevant if template shall be connected. Any terminal or cubicle.

diagram

Target diagram if template shall also be inserted graphically.

posX

x-postion in mm. Only relevant if target diagram is specified and a centered default position is not desired.

posY

y-postion in mm. Only relevant if target diagram is specified and a centered default position is not desired.

Update

Updates connection points and contained elements of the branch. If the branch element externally modified by the user, then the update shall refresh all connections in the correct manner. Behaves same as the update button within the ElmBranch.

```
None ElmBranch.Update()
```

5.2.9 ElmCabsys

Overview

[FitParams](#)
[GetLineCable](#)
[Update](#)

FitParams

Calculates distributed parameters for cable system elements. Whether this function calculates constant parameters or frequency dependent parameters depends on the user setting of the parameter 'i_model' in the ElmCabsys dialog. The settings are as follows: i_model=0: constant parameters; i_model=1: frequency dependent parameters.

```
int ElmCabsys.FitParams()
```

RETURNS

0	on success
1	on error

GetLineCable

Gets cable type for the corresponding line, within the cable system.

```
DataObject ElmCabsys.GetLineCable(int line)
```

ARGUMENTS

<i>line</i>	Index of line.
-------------	----------------

RETURNS

cable type	On success.
None	On error.

Update

Updates cable system element depending on configuration of the associated cable system type.

```
int ElmCabsys.Update()
```


RETURNS

- 1** Cable system was updated.
- 0** Update was not required.

5.2.10 ElmComp

Overview

[SlotUpdate](#)

SlotUpdate

Performs a slot update for the composite model, to try to reassign each model found in the composite model contents to the corresponding slot.

```
None ElmComp.SlotUpdate()
```

DEPRECATED NAMES

Slotupd

5.2.11 ElmCoup

Overview

[Close](#)
[GetRemoteBreakers](#)
[IsBreaker](#)
[IsClosed](#)
[IsOpen](#)
[Open](#)

Close

Closes the switch by changing its status to 'close'. This action will fail if the status is currently determined by an active running arrangement.

```
int ElmCoup.Close()
```

RETURNS

- 0** On success
- ≠ 0** On error

SEE ALSO

[ElmCoup.Open\(\)](#)

GetRemoteBreakers

Returns the remote circuit breakers or connected bus bars.

This information is determined by a topological search that starts at given breaker in all directions, generally stopping at

- switches of type circuit breaker
- switches that are open
- busbars (ElmTerm::iUsage == 0)

If the search reaches a busbar while only reducible components have been passed (see [DataObject.IsReducible\(\)](#)) it stops and returns the connected busbar (no breaker found). In case of non-reducible components have been passed, the search continues until next circuit breaker is found. Only breakers with given breaker state are returned.

```
[list remoteBreakers,
list foundBreakers,
list foundBusbars ] ElmCoup.GetRemoteBreakers(int desiredBreakerState)
```

ARGUMENTS

desiredBreakerState

Only breakers with given status are collected.

- 1** Return all remote circuit breakers
- 1** Return all closed remotod circuit breakers
- 0** Return all opened remotod circuit breakers

foundBreakers (out)

The list of the remote circuit breakers

foundBusbars (optional, out)

The list of the local bus bars

IsBreaker

Checks if type of current switch is 'circuit-breaker'.

```
int ElmCoup.IsBreaker()
```

RETURNS

- 1** Switch is a circuit-breaker.
- 0** Switch is not a circuit-breaker.

IsClosed

Returns information about current switch state.

```
int ElmCoup.IsClosed()
```

RETURNS

- 1** switch is closed
- 0** switch is open

SEE ALSO

[ElmCoup.IsOpen\(\)](#)

IsOpen

Returns information about current switch state.

```
int ElmCoup.IsOpen()
```

RETURNS

1	switch is open
0	switch is closed

SEE ALSO

[ElmCoup.IsClosed\(\)](#)

Open

Opens the switch by changing its status to 'open'. This action will fail if the status is currently determined by an active running arrangement.

```
int ElmCoup.Open()
```

RETURNS

0	On success
≠ 0	On error

SEE ALSO

[ElmCoup.Close\(\)](#)

5.2.12 ElmDcu

Overview

[GetGroundingImpedance](#)

GetGroundingImpedance

Returns the impedance of the internal grounding. Voltage source with a setpoint of zero are considered as grounding devices themselves; i.e. the Ri paramter is used.

```
[int valid,  
float resistance,  
float reactance ] ElmDcu.GetGroundingImpedance(int busIdx)
```

ARGUMENTS

busIdx Bus index where the grounding should be determined.

resistance (out)
Real part of the grounding impedance in Ohm.

reactance (out)

Imaginary part of the grounding impedance in Ohm.

RETURNS

- 0** The values are invalid (e.g. because there is no internal grounding)
- 1** The values are valid.

5.2.13 ElmDsl

Overview

[ExportToClipboard](#)
[ExportToFile](#)
[InterfaceUpdate](#)

ExportToClipboard

Export the parameter list to clipboard.

```
None ElmDsl.ExportToClipboard([str colSeparator],
                               [int useLocalHeader]
                               )
```

ARGUMENTS

colSeparator (optional)

Separator between the columns (default: tab character).

useLocalHeader (optional)

Use the localised version of the header. Possible values are:

- 1** Yes (default).
- 0** No (use English language header).

ExportToFile

Export the parameter list to CSV file(s).

```
None ElmDsl.ExportToFile(str filePath,
                          [str colSeparator],
                          [int useLocalHeader]
                          )
```

ARGUMENTS

filePath Path of the CSV target file. In case of array and matrix parameters (names: “array_NAME” and “matrix_NAME”), additional CSV files are created in the same location with names obtained by appending “_array_NAME” and “_matrix_NAME” to the target file name.

colSeparator (optional)

Separator between the columns (default: “;”).

useLocalHeader (optional)

Use the localised version of the header. Possible values are:

- 1** Yes (default).
- 0** No (use English language header).

InterfaceUpdate

Updates the interface signal connection of the ElmDsl (see 'Advanced 3' page of 'Basic Data').

5.2.14 ElmFeeder

Overview

[CalcAggrVarsInRadFeed](#)
[GetAll](#)
[GetBranches](#)
[GetBuses](#)
[GetNodesBranches](#)
[GetObjs](#)

CalcAggrVarsInRadFeed

Computes all the aggregated variables in radial feeders.

```
int ElmFeeder.CalcAggrVarsInRadFeed([int lookForRoot,]
                                     [int considerNested])
```

ARGUMENTS

lookForRoot (optional)

Calculates the variables from the deepest root. Possible values are:

- 0** Start from this feeder
- 1** (default) Find the deepest root.

considerNested (optional)

Calculates the variables also for any nested subfeeders. Possible values are:

- 0** Ignore any nested feeders
- 1** (default) Consider nested feeders.

RETURNS

Returns whether or not the aggregated variables were calculated. Possible values are:

- 0** error during calculation
- 1** calculated correctly

GetAll

Returns a set with all objects belonging to this feeder.

```
list ElmFeeder.GetAll([int iNested])
```

ARGUMENTS

iNested (optional)

Affects the collection of objects in case of nested feeders:

- | | |
|----------|--|
| 0 | Only the objects of this feeder will be returned. |
| 1 | (default) All elements including those of nested feeders will be returned. |

RETURNS

The set of network elements belonging to this feeder. Can be empty.

SEE ALSO

[DataObject.IsInFeeder\(\)](#)**GetBranches**

Returns a set with all branch elements belonging to this feeder.

```
list ElmFeeder.GetBranches([int iNested])
```

ARGUMENTS

iNested (optional)

Affects the collection of objects in case of nested feeders:

- | | |
|----------|--|
| 0 | Only the objects of this feeder will be returned. |
| 1 | (default) All elements including those of nested feeders will be returned. |

RETURNS

The set of bus and branch elements in feeder.

GetBuses

Returns a set with all buses belonging to this feeder.

```
list ElmFeeder.GetBuses([int iNested])
```

ARGUMENTS

iNested (optional)

Affects the collection of objects in case of nested feeders:

- | | |
|----------|--|
| 0 | Only the objects of this feeder will be returned. |
| 1 | (default) All elements including those of nested feeders will be returned. |

RETURNS

The set of bus elements in feeder.

GetNodesBranches

Returns a set with all buses and branches belonging to this feeder.

```
list ElmFeeder.GetNodesBranches([int iNested])
```

ARGUMENTS

iNested (optional)

Affects the collection of objects in case of nested feeders:

- 0** Only the objects of this feeder will be returned.
- 1** (default) All elements including those of nested feeders will be returned.

RETURNS

The set of bus and branch elements in feeder.

GetObjs

Returns a set with all objects of class 'ClassName' which belong to this feeder.

```
list ElmFeeder.GetObjs(str ClassName,
                       [int iNested])
```

ARGUMENTS

iNested (optional)

Affects the collection of objects in case of nested feeders:

- 0** Only the objects of this feeder will be returned.
- 1** (default) All elements including those of nested feeders will be returned.

RETURNS

The set of feeder objects.

5.2.15 ElmFile**Overview**

[LoadFile](#)
[SaveFile](#)

LoadFile

(Re)Loads the file into a buffer.

```
int ElmFile.LoadFile([int loadComplete = 1])
```

ARGUMENTS

loadComplete (optional)

- 0** Removes all points in the future simulation time and adds all points from the file (including the current interpolated value).
- 1** Clears the buffer and reloads the complete file (default).

RETURNS

- 0 On success.
- $\neq 0$ On error.

SaveFile

Saves the buffer and overwrites the file.

```
int ElmFile.SaveFile()
```

RETURNS

- 0 On success.
- $\neq 0$ On error.

5.2.16 ElmFilter**Overview**

[GetGroundingImpedance](#)

GetGroundingImpedance

Returns the impedance of the internal grounding. Single phase filters connected to neutral are considered as grounding devices themselves; i.e. instead of the dedicated grounding parameters, the filters parameters are used.

```
[int valid,
float resistance,
float reactance ] ElmFilter.GetGroundingImpedance(int busIdx)
```

ARGUMENTS

- busIdx* Bus index where the grounding should be determined.
- resistance (out)*
Real part of the grounding impedance in Ohm.
- reactance (out)*
Imaginary part of the grounding impedance in Ohm.

RETURNS

- 0 The values are invalid (e.g. because there is no internal grounding)
- 1 The values are valid.

5.2.17 ElmFsrc

Overview

[Init](#)
[SetAmpl](#)
[SetPhase](#)

Init

Resizes the amplitude and phase vectors to a given size and initial all values to zero.

```
None ElmFsrc.Init(float arg0)
```

ARGUMENTS

arg0 New size of the amplitude and phase vector.

SetAmpl

Set amplitude value for the corresponding row index.

```
None ElmFsrc.SetAmpl(float arg0,  
                     float arg1  
                     )
```

ARGUMENTS

arg0 amplitude value

arg1 row index (1 based). The first row has index 1. Invalid index (*leq0*) leads to scripting error.

SetPhase

Set phase value (in deg) for the corresponding row index.

```
None ElmFsrc.SetPhase(float arg0,  
                     float arg1  
                     )
```

ARGUMENTS

arg0 phase value

arg1 row index (1 based). The first row has index 1. Invalid index (*leq0*) leads to scripting error.

5.2.18 ElmGenstat

Overview

[CalcEfficiency](#)
[Derate](#)
[Disconnect](#)
[GetAvailableGenPower](#)
[GetGroundingImpedance](#)
[GetStepupTransformer](#)
[IsConnected](#)
[Reconnect](#)
[ResetDerating](#)

CalcEfficiency

Calculate efficiency for connected storage model at given active power value.

```
float ElmGenstat.CalcEfficiency(float activePowerMW)
```

ARGUMENTS

activePowerMW
Active power value to calculate efficiency for.

RETURNS

Returns the resulting efficiency in p.u.

Derate

Derates the value of the Max. Active Power Rating according to the specified value given in MW.

The following formula is used: $P_{max_uc} = P_{max_uc} - "Deratingvalue"$.

```
None ElmGenstat.Derate(float deratingP)
```

ARGUMENTS

deratingP Derating value

Disconnect

Disconnects a static generator by opening the first circuit breaker. The topological search performed to find such a breaker, stops at any busbar.

```
int ElmGenstat.Disconnect()
```

RETURNS

0 breaker already open or successfully opened
1 an error occurred (no breaker found, open action not possible (earthing / RA))

GetAvailableGenPower

Returns the available power that can be dispatched from the generator, for the particular study time.

For the case of conventional generators (no wind generation selected), the available power is equal to the nominal power specified.

For wind generators, the available power will depend on the wind model specified:

- No Wind Model: No available power.
- Stochastic Wind Model: Given the specified mean wind speed, the available power is calculated from the Power Curve. If the units of the Power Curve are in MW, the returned value is directly the available power. In the other hand, if the units are in PU, the returned value is multiplied by the nominal power of the generator to return the available power.
- Time Series Characteristics of Active Power Contribution: The available power is the average of the power values (in MW) obtained from all the specified time characteristics for the current study time.
- Time Series Characteristics of Wind Speed: The available power is calculated with the average of the power values (in MW) calculated for all the specified time characteristics. A power value for any time characteristic is calculated by obtaining the wind speed for the current study time, and then calculating the power from the specified Power Curve. If the units of the Power Curve are in MW, the returned value is directly the power value. In the other hand, if the units are in PU, the returned value is multiplied by the nominal power of the generator to return the power value.

For motors, the available power is zero.

```
float ElmGenstat.GetAvailableGenPower()
```

RETURNS

Available generation power

GetGroundingImpedance

Returns the impedance of the internal grounding.

```
[int valid,  
float resistance,  
float reactance ] ElmGenstat.GetGroundingImpedance(int busIdx)
```

ARGUMENTS

busIdx Bus index where the grounding should be determined.

resistance (out)
Real part of the grounding impedance in Ohm.

reactance (out)
Imaginary part of the grounding impedance in Ohm.

RETURNS

- 0** The values are invalid (e.g. because there is no internal grounding)
- 1** The values are valid.

GetStepupTransformer

Performs a topological search to find the step-up transformer of the static generator.

```
DataObject ElmGenstat.GetStepupTransformer(float voltage,
                                           int swStatus
                                           )
```

ARGUMENTS

voltage voltage level at which the search will stop

swStatus consideration of switch status. Possible values are:

- 0** consider all switch status
- 1** ignore breaker status
- 2** ignore all switch status

RETURNS

Returns the first collected step-up transformer object. It is empty if not found (e.g. start terminal already at hvVoltage).

IsConnected

Checks if generator is topologically connected to any busbar.

```
int ElmGenstat.IsConnected()
```

RETURNS

- 0** false, not connected to a busbar
- 1** true, generator is connected to a busbar

Reconnect

Connects a static generator by closing all switches (breakers and isolators) up to the first breaker on the HV side of a transformer. The topological search to find all the switches, stops at any busbar.

```
int ElmGenstat.Reconnect()
```

RETURNS

- 0** the machine was successfully closed
- 1** a error occurred and the machine could not be connected to any busbar

ResetDerating

Resets the derating value, setting the Max. Active Power Rating according to the rating factor. The following formula is used: $P_{max_uc} = p_{maxratf} * P_n * n_{gnum}$.

```
None ElmGenstat.ResetDerating()
```

5.2.19 ElmGndswt

Overview

[Close](#)
[GetGroundingImpedance](#)
[IsClosed](#)
[IsOpen](#)
[Open](#)

Close

Closes the switch by changing its status to 'close'. If closed, the connected node will be considered as being earthed.

```
int ElmGndswt.Close()
```

RETURNS

1, always

SEE ALSO

[ElmGndswt.Open\(\)](#)

GetGroundingImpedance

Returns the impedance of the internal grounding. ElmGndswt is only considered to have an internal grounding if it is single phase and connected to neutral or DC.

```
[int valid,  
float resistance,  
float reactance ] ElmGndswt.GetGroundingImpedance(int busIdx)
```

ARGUMENTS

busIdx Bus index where the grounding should be determined.

resistance (out)
Real part of the grounding impedance in Ohm.

reactance (out)
Imaginary part of the grounding impedance in Ohm.

RETURNS

- 0** The values are invalid (e.g. because there is no internal grounding)
- 1** The values are valid.

IsClosed

Returns information about current switch state.

```
int ElmGndswt.IsClosed()
```

RETURNS

- 1** switch is closed
- 0** switch is open

SEE ALSO

[ElmGndswt.IsOpen\(\)](#)

IsOpen

Returns information about current switch state.

```
int ElmGndswt.IsOpen()
```

RETURNS

- 1** switch is open
- 0** switch is closed

SEE ALSO

[ElmGndswt.IsClosed\(\)](#)

Open

Opens the switch by changing its status to 'open'.

```
int ElmGndswt.Open()
```

RETURNS

- 0, always

SEE ALSO

[ElmGndswt.Close\(\)](#)

5.2.20 ElmLne

Overview

[AreDistParamsPossible](#)
[CreateFeederWithRoutes](#)
[FitParams](#)
[GetIthr](#)
[GetType](#)
[GetY0m](#)
[GetY1m](#)
[GetZ0m](#)
[GetZ1m](#)
[GetZmatDist](#)
[HasRoutes](#)
[HasRoutesOrSec](#)
[IsCable](#)
[IsNetCoupling](#)

MeasureLength
SetDetailed

AreDistParamsPossible

Check if the line fulfils conditions for the calculation of distributed parameters:

ElmLne No routes, no sections

TypTow only 1 circuit x 3 phases

TypGeo only 1 circuit x 3 phases

TypLne AC system, 3 phases and 0 neutral

TypCabsys only 1 circuit x 3 phases

```
int ElmLne.AreDistParamsPossible()
```

RETURNS

The returned value are:

- 0** All conditions fulfilled
- 1** Line contains routes
- 2** Line contains sections
- 3** Line has no type
- 4** TypTow/TypCabsys does not fulfil conditions for distributed paramters
- 5** TypLne does not fulfil conditions for distributed parameters
- 6** Short-circuit flag is set (EMT or RMS simulations)
- 7** TypLne/TypTow: B0 and B1 = 0
- 8** Error, no condition state could be determined

CreateFeederWithRoutes

Creates a new feeder in the line by splitting the line into 2 routes and inserting a terminal.

```
int ElmLne.CreateFeederWithRoutes(float dis,
                                   float rem,
                                   DataObject O)
int ElmLne.CreateFeederWithRoutes(float dis,
                                   float rem,
                                   DataObject O,
                                   [int sw0,]
                                   [int sw1])
```

ARGUMENTS

- dis* Inserting operation occurs after this distance
- rem* Remaining distance, percentage of distance 'dis'
- O* Branch object that is to be connected at the inserted terminal
- sw0* If set to (1), switch is inserted on the first side
- sw1* If set to (1), switch is inserted on the second side

RETURNS

- 0** Success, feeders created
- 1** Error

FitParams

Calculates distributed parameters of the line element. Whether this function calculates constant parameters or frequency dependent parameters depends on the user setting of the parameter 'i_model' in the ElmLne dialogue. The settings are as follows: i_model=0: constant parameters; i_model=1: frequency dependent parameters.

```
int ElmLne.FitParams([int isRMSModel = 0,]
                    [int modify = 1])
```

ARGUMENTS

isRMSModel

modify

RETURNS

- 0** Success
- 1** Error

GetIthr

Returns the rated short-time current of the line element.

```
float ElmLne.GetIthr()
```

RETURNS

Returns rated short-time current value

GetType

Returns the line type object.

```
DataObject ElmLne.GetType()
```

RETURNS

The TypLne object if exists or None

GetY0m

The function returns the zero-sequence mutual coupling admittance (G0m, B0m) in uS of the line and input argument line (object Lne2). When Lne2 = line, the function returns the zero-sequence self admittance.

```
[int error,
float G0m,
float B0m ] ElmLne.GetY0m(DataObject Lne2)
```


ARGUMENTS

Lne2 Line element

G0m (out)
Resulting G0m value

B0m (out)
Resulting B0m value

RETURNS

0 Success, data obtained

1 Error, e.g. no coupling objects defined

GetY1m

The function returns the positive-sequence mutual coupling admittance (G1m, B1m) in uS of the line and input argument line (object Lne2). When Lne2 = line, the function returns the positive-sequence self admittance.

```
[int error,
float G1m,
float B1m ] ElmLne.GetY1m (DataObject Lne2)
```

ARGUMENTS

Lne2 Line element

G1m (out)
Resulting G1m value

B1m (out)
Resulting B1m value

RETURNS

0 Success, data obtained

1 Error, e.g. no coupling objects defined

GetZ0m

Gets the zero-sequence mutual coupling impedance (R0m, X0m) in Ohm of the line and input argument line (object otherLine). When otherLine = line, the function returns the zero-sequence self impedance.

```
[int error,
float R0m,
float X0m ] ElmLne.GetZ0m(DataObject otherLine)
```

ARGUMENTS

otherLine Line element

R0m (out)
To be obtained R0m value

X0m (out)
To be obtained X0m value

RETURNS

- 0** Success, data obtained
- 1** Error, e.g. no coupling objects defined

GetZ1m

The function returns the positive-sequence mutual coupling impedance (R1m, X1m) in Ohm of the line and input argument line (object Lne2). When Lne2 = line, the function returns the positive-sequence self impedance.

```
[int error,
float R1m,
float X1m ] ElmLne.GetZ1m(DataObject Lne2)
```

ARGUMENTS

- Lne2* Line element
- R1m (out)*
Resulting R1m value
- X1m (out)*
Resulting X1m value

RETURNS

- 0** Success, data obtained
- 1** Error, e.g. no coupling objects defined

GetZmatDist

The function gets impedance matrix in phase domain (only amplitudes), for a line with distributed parameters, short-circuit ended.

```
int ElmLne.GetZmatDist(float frequency,
int exact,
DataObject matrix)
```

ARGUMENTS

- frequency*
Frequency for which the calculation is carried out
- exact* 0: Approximated solution, 1: Exact solution for 'frequency'
- matrix* Impedance matrix to be filled with the impedance amplitudes

RETURNS

The returned value reports if the impedance matrix acquired:

- 1** Error, no matrix acquired
- 0** Success, matrix acquired

HasRoutes

Checks if the line is subdivided into routes.

```
int ElmLne.HasRoutes()
```

RETURNS

- 0 When the line is a single line
- 1 When the line is subdivided into routes

HasRoutesOrSec

Checks if the line is subdivided into routes or sections.

```
int ElmLne.HasRoutesOrSec()
```

RETURNS

- 0 When the line is a single line
- 1 When the line is subdivided into routes
- 2 When the line is subdivided into sections

IsCable

Checks if this line is a cable.

```
int ElmLne.IsCable()
```

RETURNS

- 2 when line contains cable and overhead line sections
- 1 Line is a cable
- 0 Line is not a cable

IsNetCoupling

Checks if the line connects two grids.

```
int ElmLne.IsNetCoupling()
```

RETURNS

The returned value reports if the line is a coupler:

- 1 The line is a coupler (connects two grids)
- 0 The line is not a coupler

MeasureLength

Measures the length of this line using the active diagram. For graphical measurement the active diagram needs to have a scaling factor. Geographic diagrams by default have a scaling factor. If `iUseGraphic = 1`, the line length is determined directly from the positions given in (latitude/longitude) considering the earth as a perfect sphere. In this case no graphic needs to be open.

```
float ElmLne.MeasureLength([int iUseGraphic])
```

ARGUMENTS

iUseGraphic (optional)

Use SGL diagram for calculation or not.

- | | |
|----------|---|
| 1 | Use displayed diagram for calculation (default) |
| 0 | Calculate distance without diagram |

RETURNS

- | | |
|----------|--|
| ≥ 0 | Returns the graphical length of this line in its current unit |
| < 0 | Error: E.g. when line is not represented in the active diagram and iUseGraphic=1 |

SetDetailed

The function can be used to prevent the automatically reduction of a line e.g. if the line is a line dropper (length = 0). The function should be called when no calculation method is valid (before first load flow). The internal flag is automatically reset after the first calculation is executed.

```
int ElmLine.SetDetailed()
```

5.2.21 ElmLnsec**Overview**

[IsCable](#)

IsCable

Checks if this line section is a cable.

```
int ElmLnsec.IsCable()
```

RETURNS

- | | |
|-----------|-----------------------------|
| 1 | Line section is a cable |
| 0 | Line section is not a cable |
| -1 | Error |

5.2.22 ElmMdl**Overview**

[Check](#)
[ExportToClipboard](#)
[ExportToFile](#)

Check

Checks the Modelica Model.

```
int ElmMdl.Check()
```

RETURNS

- 0** Modelica Model is correct.
- 1** Error found.

ExportToClipboard

Export the parameter list to clipboard.

```
None ElmMdl.ExportToClipboard([str colSeparator],
                               [int useLocalHeader]
                               )
```

ARGUMENTS

colSeparator (optional)

Separator between the columns (default: tab character).

useLocalHeader (optional)

Use the localised version of the header. Possible values are:

- 1** Yes (default).
- 0** No (use English language header).

ExportToFile

Export the parameter list to CSV file(s).

```
None ElmMdl.ExportToFile(str filePath,
                          [str colSeparator],
                          [int useLocalHeader]
                          )
```

ARGUMENTS

filePath Path of the CSV target file. In case of array and matrix parameters (names: “array_NAME” and “matrix_NAME”), additional CSV files are created in the same location with names obtained by appending “_array_NAME” and “_matrix_NAME” to the target file name.

colSeparator (optional)

Separator between the columns (default: “;”).

useLocalHeader (optional)

Use the localised version of the header. Possible values are:

- 1** Yes (default).
- 0** No (use English language header).

5.2.23 ElmNec

Overview

[GetGroundingImpedance](#)

GetGroundingImpedance

Returns the impedance of the internal grounding.

```
[int valid,
float resistance,
float reactance ] ElmNec.GetGroundingImpedance(int busIdx)
```

ARGUMENTS

busIdx Bus index where the grounding should be determined.

resistance (out)
Real part of the grounding impedance in Ohm.

reactance (out)
Imaginary part of the grounding impedance in Ohm.

RETURNS

0 The values are invalid (e.g. because there is no internal grounding)
1 The values are valid.

5.2.24 ElmNet

Overview

[Activate](#)
[CalculateInterchangeTo](#)
[CalculateVoltageLevel](#)
[CalculateVoltInterVolt](#)
[Deactivate](#)
[DefineBoundary](#)

Activate

Adds a grid to the active study case. Can only be applied if there are is no currently active calculation (i.e. running contingency analysis).

```
int ElmNet.Activate()
```

RETURNS

0 on success
1 on error

CalculateInterchangeTo

This function calculates the power flow from current grid to a connected grid. The values are stored in current grid in the following attributes (values from the previous load flow calculation are overwritten):

- Pinter: Active Power Flow
- Qinter: Reactive Power Flow
- ExportP: Export Active Power Flow
- ExportQ: Export Reactive Power Flow
- ImportP: Import Active Power Flow
- ImportQ: Import Reactive Power Flow

```
int ElmNet.CalculateInterchangeTo(DataObject net)
```

ARGUMENTS

net Connected grid

RETURNS

- < 0 error
- = 0 grids are not connected, no interchange exists
- > 0 ok

CalculateVoltageLevel

Internal function to calculate per voltage level the corresponding summary results. The values are stored in current grid (values from the previous load flow calculation are overwritten):

```
int ElmNet.CalculateVoltageLevel(double U)
```

ARGUMENTS

U for voltage level (in kV)

RETURNS

- < 0 error
- = 0 voltage level not exists in the grid
- > 0 ok

CalculateVollnterVoll

This function calculates the power flow from voltage level to voltage level. The values are stored in current grid in the following attributes (values from the previous load flow calculation are overwritten):

- Pinter: Active Power Flow
- Qinter: Reactive Power Flow
- ExportP: Export Active Power Flow

- ExportQ: Export Reactive Power Flow
- ImportP: Import Active Power Flow
- ImportQ: Import Reactive Power Flow

```
int ElmNet.CalculateVoltInterVolt(double Ufrom,
                                   double Uto)
```

ARGUMENTS

Ufrom from voltage level (in kV)
Uto to voltage level (in kV)

RETURNS

< 0 error
 = 0 voltage levels not exists in the grid, no interchange exists
 > 0 ok

Deactivate

Removes a grid from the active study case. Can only be applied if there are is no currently active calculation.

```
int ElmNet.Deactivate()
```

RETURNS

0 on success
 1 on error

DefineBoundary

Defines boundary with this grid as interior part. Resulting cubicles of boundary are busbar-oriented towards the grid.

```
DataObject ElmNet.DefineBoundary(int shift)
```

ARGUMENTS

shift Elements outside the grid that are within a distance of shift many elements to a boundary cubicle of the grid are added to the interior part of the resulting boundary

RETURNS

The defined boundary is returned in case of success. Otherwise None, if an error appeared in the definition of the boundary.

5.2.25 ElmPvsys

Overview

[CalcEfficiency](#)
[Derate](#)
[Disconnect](#)
[GetAvailableGenPower](#)
[GetGroundingImpedance](#)
[GetStepupTransformer](#)
[IsConnected](#)
[Reconnect](#)
[ResetDerating](#)

CalcEfficiency

Calculate efficiency for connected storage model at given active power value.

```
float ElmPvsys.CalcEfficiency(float activePowerMW)
```

ARGUMENTS

activePowerMW
Active power value to calculate efficiency for.

RETURNS

Returns the resulting efficiency in p.u.

Derate

Derates the value of the Max. Active Power Rating according to the specified value given in MW.

The following formula is used: $P_{max_uc} = P_{max_uc} - "Deratingvalue"$.

```
None ElmPvsys.Derate(float deratingP)
```

ARGUMENTS

deratingP Derating value

Disconnect

Disconnects a PV system by opening the first circuit breaker. The topological search performed to find such a breaker, stops at any busbar.

```
int ElmPvsys.Disconnect()
```

RETURNS

0 breaker already open or successfully opened
1 an error occurred (no breaker found, open action not possible (earthing / RA))

GetAvailableGenPower

Returns the available power that can be dispatched from the generator, for the particular study time.

For the case of conventional generators (no wind generation selected), the available power is equal to the nominal power specified.

For wind generators, the available power will depend on the wind model specified:

- No Wind Model: No available power.
- Stochastic Wind Model: Given the specified mean wind speed, the available power is calculated from the Power Curve. If the units of the Power Curve are in MW, the returned value is directly the available power. In the other hand, if the units are in PU, the returned value is multiplied by the nominal power of the generator to return the available power.
- Time Series Characteristics of Active Power Contribution: The available power is the average of the power values (in MW) obtained from all the specified time characteristics for the current study time.
- Time Series Characteristics of Wind Speed: The available power is calculated with the average of the power values (in MW) calculated for all the specified time characteristics. A power value for any time characteristic is calculated by obtaining the wind speed for the current study time, and then calculating the power from the specified Power Curve. If the units of the Power Curve are in MW, the returned value is directly the power value. In the other hand, if the units are in PU, the returned value is multiplied by the nominal power of the generator to return the power value.

For motors, the available power is zero.

```
float ElmPvsys.GetAvailableGenPower()
```

RETURNS

Available generation power

GetGroundingImpedance

Returns the impedance of the internal grounding.

```
[int valid,  
float resistance,  
float reactance ] ElmPvsys.GetGroundingImpedance(int busIdx)
```

ARGUMENTS

busIdx Bus index where the grounding should be determined.

resistance (out)
Real part of the grounding impedance in Ohm.

reactance (out)
Imaginary part of the grounding impedance in Ohm.

RETURNS

- 0** The values are invalid (e.g. because there is no internal grounding)
- 1** The values are valid.

GetStepupTransformer

Performs a topological search to find the step-up transformer of the PV system.

```
DataObject ElmPvsys.GetStepupTransformer(float voltage,
                                           int swStatus
                                           )
```

ARGUMENTS

voltage voltage level at which the search will stop

swStatus consideration of switch status. Possible values are:

- 0** consider all switch status
- 1** ignore breaker status
- 2** ignore all switch status

RETURNS

Returns the first collected step-up transformer object. It is empty if not found (e.g. start terminal already at hvVoltage).

IsConnected

Checks if a PV system is already connected to any busbar.

```
int ElmPvsys.IsConnected()
```

RETURNS

- 0** false, not connected to a busbar
- 1** true, generator is connected to a busbar

Reconnect

Connects a PV system by closing all switches (breakers and isolators) up to the first breaker on the HV side of a transformer. The topological search to find all the switches, stops at any busbar.

```
int ElmPvsys.Reconnect()
```

RETURNS

- 0** the machine was successfully closed
- 1** a error occurred and the machine could not be connected to any busbar

ResetDerating

Resets the derating value, setting the Max. Active Power Rating according to the rating factor. The following formula is used: $P_{max_uc} = p_{maxratf} * P_n * n_{gnum}$.

```
None ElmPvsys.ResetDerating()
```

5.2.26 ElmRecmono

Overview

[GetGroundingImpedance](#)

GetGroundingImpedance

Returns the impedance of the internal grounding. Only the DC side is considered to be grounded.

```
[int valid,
float resistance,
float reactance ] ElmRecmono.GetGroundingImpedance(int busIdx)
```

ARGUMENTS

busIdx Bus index where the grounding should be determined.

resistance (out)
Real part of the grounding impedance in Ohm.

reactance (out)
Imaginary part of the grounding impedance in Ohm.

RETURNS

- 0** The values are invalid (e.g. because there is no internal grounding)
- 1** The values are valid.

5.2.27 ElmRelay

Overview

[CalculateMaxFaultCurrents](#)
[CheckRanges](#)
[GetCalcRX](#)
[GetMaxFdetectCalcI](#)
[GetOperatedSwitches](#)
[GetSlot](#)
[GetUnom](#)
[IsStarted](#)
[SetImpedance](#)
[SetMaxI](#)
[SetMaxIearth](#)
[SetMinI](#)
[SetMinIearth](#)
[SetOutOfService](#)
[SetTime](#)
[SlotUpdate](#)

CalculateMaxFaultCurrents

Calculates and stores the “Max. phase fault current” and the “Max. earth fault current”.

```
None ElmRelay.CalculateMaxFaultCurrents()
```

CheckRanges

Checks the settings of all elements in the relay for range violations.

```
int ElmRelay.CheckRanges()
```

RETURNS

- 0** All settings are valid.
- 1** At least one setting was forced into range.
- 1** An error occurred.

GetCalcRX

Gets the calculated impedance from the polarising unit.

```
[int error,
float real,
float imag ] ElmRelay.GetCalcRX(int inSec,
                                int unit)
```

ARGUMENTS

inSec

- 0** Get the value in pri. Ohm.
- 1** Get the value in sec. Ohm.

unit

- 0** Get the value from Phase-Phase or Multifunctional polarizing.
- 1** Get the value from Phase-Earth or Multifunctional polarizing.
- 2** Get the value from Multifunctional polarizing

real (out) Real part of the impedance in Ohm.

imag (out) Imaginary part of the impedance in Ohm.

RETURNS

- 0** No error occurred, the output is valid.
- 1** An error occurred, the output is invalid.

GetMaxFdetectCalcI

Get the current measured by the starting unit.

```
[int error,
float Iabs ] ElmRelay.GetMaxFdetectCalcI(int earth,
                                          int unit
                                          )
```

ARGUMENTS

labs (out) The measured current in A

earth

- | | |
|----------|------------------------|
| 0 | Get the phase current. |
| 1 | Get the earth current. |

unit

- | | |
|----------|----------------------------|
| 0 | Get the current in pri. A. |
| 1 | Get the current in sec. A. |

RETURNS

- | | |
|----------|---|
| 0 | No error, output is valid. |
| 1 | An error occurred, the output is invalid. |

GetOperatedSwitches

Returns the operated switches of this relay.

```
list ElmRelay.GetOperatedSwitches()
```

RETURNS

Switches operated by any trip logic inside this relay.

SEE ALSO

[RelLogic.GetOperatedSwitches\(\)](#),
[RelLogdip.GetOperatedSwitches\(\)](#),
[RelFuse.GetOperatedSwitches\(\)](#)

GetSlot

Returns the element in the slot with the given name.

```
DataObject ElmRelay.GetSlot(str name,  
                             [int iShowErr]  
                             )
```

ARGUMENTS

name Exact name of the slot to search for (no wildcards).

iShowErr (optional)

- | | |
|----------|--|
| 0 | Do not show error messages. |
| 1 | Show error messages if a slot is not found or empty. |

RETURNS

The object in the slot or None.

GetUnom

Returns the nominal voltage of the local bus of the relay.

```
float ElmRelay.GetUnom()
```

RETURNS

The nominal voltage of the local bus of the relay in kV.

IsStarted

Checks if the starting unit detected a fault.

```
int ElmRelay.IsStarted()
```

RETURNS

- 0** No fault was detected.
- 1** Fault was detected.
- 1** An error occurred.

SetImpedance

Sets the the given impedance to the distance blocks matching the criteria.

```
int ElmRelay.SetImpedance(float real,
                          float imag,
                          int inSec,
                          int zone,
                          int unit
                          )
int ElmRelay.SetImpedance(float real,
                          float imag,
                          float lineAngle,
                          float Rarc,
                          int inSec,
                          int zone,
                          int unit
                          )
```

ARGUMENTS

- real* Real part of the impedance in Ohm.
- imag* Imaginary part of the impedance in Ohm.
- inSec*
 - 0** The values are in pri. Ohm.
 - 1** The values are in sec. Ohm.
- zone* Set the impedance for elments with this zone number.
- unit*
 - 0** Set the impedance for Phase - Phase or Multifunctional elements.
 - 1** Set the impedance for Phase - Earth or Multifunctional elements.
 - 2** Set the impedance for Multifunctional elements.

ARGUMENTS

- real* Real part of the impedance in Ohm.
- imag* Imaginary part of the impedance in Ohm.

lineAngle The line angle in deg.

Rarc The arc resistance in Ohm.

inSec

0 The values are in pri. Ohm.

1 The values are in sec. Ohm.

zone Set the impedance for elements with this zone number.

unit

0 Set the impedance for Phase - Phase or Multifunctional elements.

1 Set the impedance for Phase - Earth or Multifunctional elements.

2 Set the impedance for Multifunctional elements.

RETURNS

0 No error occurred.

1 An error occurred or no element was found.

SetMaxI

Sets the “Max. Phase Fault Current” of the relay to the currently measured value.

```
None ElmRelay.SetMaxI()
```

SetMaxIearth

Sets the “Max. Earth Fault Current” of the relay to the currently measured value.

```
None ElmRelay.SetMaxIearth()
```

SetMinI

Sets the “Min. Phase Fault Current” of the relay to the currently measured value.

```
None ElmRelay.SetMinI()
```

SetMinIearth

Sets the “Min. Earth Fault Current” of the relay to the currently measured value.

```
None ElmRelay.SetMinIearth()
```

SetOutOfService

Sets the “Out of Service” flag of elements contained in the relay.

```
int ElmRelay.SetOutOfService(int outServ,
                              int type,
                              int zone,
                              int unit
                              )
```


ARGUMENTS

outServ

- 0** Set elements in service.
- 1** Set Elements out of service.

type

- 1** Set the flag for overcurrent elements.
- 2** Set the flag for distance elements.

zone

Set the flag for elements with this zone number (only when settings distance elements).

unit

- 0** Set the flag for Phase-Phase or Multifunctional elements.
- 1** Set the flag for Phase-Earth or Multifunctional elements.
- 2** Set the flag for Multifunctional elements.

RETURNS

- 0** No error occurred.
- 1** An error occurred or no element was found.

SetTime

Sets the tripping time for elements contained in the relay.

```
int ElmRelay.SetTime(double time,
                     int type,
                     int zone,
                     int unit
                     )
```

ARGUMENTS

time Time in s.*type*

- 1** Set the time for overcurrent elements.
- 2** Set the time for distance elements.

zone

Set the time for elements with this zone number (only when settings distance elements).

unit

- 0** Set the time for Phase-Phase or Multifunctional elements.
- 1** Set the time for Phase-Earth or Multifunctional elements.
- 2** Set the time for Multifunctional elements.

RETURNS

- 0** No error occurred.
- 1** An error occurred or no element was found.

SlotUpdate

Triggers a slot update of the relay.

```
None ElmRelay.SlotUpdate()
```

DEPRECATED NAMES

slotupd

5.2.28 ElmRes

Overview

AddVariable
Clear
ExecuteLoadingCommand
FindColumn
FindMaxInColumn
FindMaxOfVariableInRow
FindMaxOfVariableInRowEx
FindMaxRowsInColumns
FindMinInColumn
FindMinOfVariableInRow
FindMinOfVariableInRowEx
FindMinRowsInColumns
FinishWriting
Flush
GetColumnValues
GetDescription
GetFirstValidObject
GetFirstValidObjectVariable
GetFirstValidVariable
GetNextValidObject
GetNextValidObjectVariable
GetNextValidVariable
GetNumberOfColumns
GetNumberOfRows
GetObj
GetObject
GetObjectValue
GetRelCase
GetSubElmRes
GetUnit
GetValue
GetVariable
InitialiseWriting
Load
Release
SetAsDefault
SetObj
SetSubElmResKey
SortAccordingToColumn
Write
WriteDraw

AddVariable

Adds a variable to the list of monitored variables for the Result object.

```
int ElmRes.AddVariable(DataObject element,
                      str varname)
```

ARGUMENTS

element An object.

varname Variable name for object element.

RETURNS

0 On success.

1 An error occurred during adding of variables.

DEPRECATED NAMES

AddVars

Clear

Clears all data (calculation results) written to the result file. The Variable definitions stored in the contents of ElmRes are not modified.

```
int ElmRes.Clear()
```

RETURNS

Always 0 and can be ignored.

ExecuteLoadingCommand

Loads results into memory.

```
int ElmRes.ExecuteLoadingCommand()
```

RETURNS

0 Success

1 Failure

FindColumn

Returns the index of the first header column matching the given object and/or variable name. [ElmRes.Load\(\)](#) must be called before using this function.

```
int ElmRes.FindColumn(DataObject obj,
                     [str varName]
                     )
int ElmRes.FindColumn(DataObject obj,
                     [int startCol]
                     )
int ElmRes.FindColumn(DataObject obj,
                     str varName
                     )
```

ARGUMENTS

obj (optional)

Object of matching column.

varName (optional)

Variable name of matching column.

startCol (optional)

Index of first checked column; Search starts at first column if colIndex is not given.

RETURNS

 ≥ 0 column index < 0 no valid column found

The index can be used in the ElmRes method GetData to retrieve the value of the column.

FindMaxInColumnFind the maximum value of the variable in the given column. [ElmRes.Load\(\)](#) must be called before using this function.

```
[int row,
float value] ElmRes.FindMaxInColumn(int column)
```

ARGUMENTS

column The column index.*value* (optional, out)

The maximum value found. The value is 0. in case that the maximum value was not found.

RETURNS

 < 0 The maximum value of column was not found. ≥ 0 The row with the maximum value of the column.**FindMaxOfVariableInRow**Finds the index of the maximum value for the given row and variable. [ElmRes.Load\(\)](#) must be called before using this function.

```
int ElmRes.FindMaxOfVariableInRow(str variable,
int row)
```

ARGUMENTS

variable The variable name.*variable* The row.

RETURNS

 < 0 There is no valid value of the corresponding variable in the row. ≥ 0 Column index of variable.

SEE ALSO

[ElmRes.FindMaxOfVariableInRowEx\(\)](#),
[ElmRes.FindMinOfVariableInRow\(\)](#),
[ElmRes.FindMinOfVariableInRowEx\(\)](#)

FindMaxOfVariableInRowEx

Finds the maximum value for the given row and variable. [ElmRes.Load\(\)](#) must be called before using this function.

```
[int col,
float maxValue] ElmRes.FindMaxOfVariableInRowEx(str variable,
                                                int row)
```

ARGUMENTS

variable The variable name.
variable The row.
maxValue (out)
 The corresponding maximum value.

RETURNS

< 0 There is no valid value of the corresponding variable in the row.
 ≥ 0 Column index of variable.

SEE ALSO

[ElmRes.FindMaxOfVariableInRow\(\)](#),
[ElmRes.FindMinOfVariableInRow\(\)](#),
[ElmRes.FindMinOfVariableInRowEx\(\)](#)

FindMaxRowsInColumns

For a given vector of column indices, determines the row indices of the maxima of these columns. [ElmRes.Load\(\)](#) must be called before using this function.

```
int ElmRes.FindMaxRowsInColumns(DataObject colIndices,
                                DataObject rowIndicesOfMaxima)
```

ARGUMENTS

colIndices
 IntDplvec containing the column indices for which the maximum rows are required.
rowIndicesOfMaxima
 IntDplvec. Will be resized to the same length as *colIndices* and filled with the indices of the rows where the corresponding columns have their maximum. Indices < 0 indicate that the column is empty or does not exist.

RETURNS

-2 Arguments are of wrong type
 -1 Error reading results
 0 Success
 1 Invalid column indices found

FindMinInColumn

Find the minimum value of the variable in the given column. [ElmRes.Load\(\)](#) must be called before using this function.

```
[int row,
float value] ElmRes.FindMinInColumn(int column)
```

ARGUMENTS

column The column index.

value (optional, out)

The minimum value found. The value is 0. in case that the minimum value was not found.

RETURNS

< 0 The minimum value of column was not found.

≥ 0 The row with the minimum value of the column.

FindMinOfVariableInRow

Finds the index of the minimum value for the given row and variable. [ElmRes.Load\(\)](#) must be called before using this function.

```
int ElmRes.FindMinOfVariableInRow(str variable,
int row)
```

ARGUMENTS

variable The variable name.

variable The row.

RETURNS

< 0 There is no valid value of the corresponding variable in the row.

≥ 0 Column index of variable.

SEE ALSO

[ElmRes.FindMinOfVariableInRowEx\(\)](#),
[ElmRes.FindMaxOfVariableInRow\(\)](#),
[ElmRes.FindMaxOfVariableInRowEx\(\)](#)

FindMinOfVariableInRowEx

Finds the minimum value for the given row and variable. [ElmRes.Load\(\)](#) must be called before using this function.

```
[int col,
float minValue] ElmRes.FindMinOfVariableInRowEx(str variable,
int row)
```

ARGUMENTS

variable The variable name.

variable The row.

minValue (out)

The corresponding minimum value.

RETURNS

- < 0 There is no valid value of the corresponding variable in the row.
- ≥ 0 Column index of variable.

SEE ALSO

[ElmRes.FindMinOfVariableInRow\(\)](#),
[ElmRes.FindMaxOfVariableInRow\(\)](#),
[ElmRes.FindMaxOfVariableInRowEx\(\)](#)

FindMinRowsInColumns

For a given vector of column indices, determines the row indices of the minima of these columns. [ElmRes.Load\(\)](#) must be called before using this function.

```
int ElmRes.FindMinRowsInColumns(DataObject colIndices,
                                DataObject rowIndicesOfMinima)
```

ARGUMENTS

colIndices

IntDplvec containing the column indices for which the minimum rows are required.

rowIndicesOfMinima

IntDplvec. Will be resized to the same length as *colIndices* and filled with the indices of the rows where the corresponding columns have their minimum. Indices < 0 indicate that the column is empty or does not exist.

RETURNS

- 2 Arguments are of wrong type
- 1 Error reading results
- 0 Success
- 1 Invalid column indices found

FinishWriting

Finishes the writing of values to a result file.

```
None ElmRes.FinishWriting()
```

DEPRECATED NAMES

Close

SEE ALSO

[ElmRes.InitialiseWriting\(\)](#), [ElmRes.Write\(\)](#), [ElmRes.WriteDraw\(\)](#)

Flush

This function is required in scripts which perform both file writing and reading operations. While writing to a results object (ElmRes), a small portion of this data is buffered in memory. This is required for performance reasons. Therefore, all data must be written to the disk before attempting to read the file. 'Flush' copies all data buffered in memory to the disk. After calling 'Flush' all data is available to be read from the file.

```
int ElmRes.Flush()
```

GetColumnValues

Get complete column values. [ElmRes.Load\(\)](#) must be called before using this function.

```
int ElmRes.GetColumnValues(DataObject dataVector,
                           int column)
```

ARGUMENTS

dataVector IntVec which will be filled with column values.

column The column index. -1 for default (e.g. time).

RETURNS

- = 0 Column values were found.
- = 1 dataVector is None.
- = 2 dataVector is not of class IntVec.
- = 3 Column index is out of range.

GetDescription

Get the description of a column. [ElmRes.Load\(\)](#) must be called before using this function.

```
str ElmRes.GetDescription([int column],
                          [int short]
                          )
```

ARGUMENTS

column (optional) The column index. The description name of the default variable is returned if the parameter is not passed to the function.

short (optional)

0	long desc. (default)
1	short description

RETURNS

Returns the description which is empty in case that the column index is not part of the data.

GetFirstValidObject

Gets the index of the column for the first valid variable in the given line. Starts at the beginning of the given line and sets the internal iterator of the result file to the found position. [ElmRes.Load\(\)](#) must be called before using this function.

```
int ElmRes.GetFirstValidObject(int row,
                               [str classNames,]
                               [str variableName,]
                               [float limit,]
                               [int limitOperator,])
```



```

                                [float limit2,]
                                [int limitOperator2]
                                )
int ElmRes.GetFirstValidObject(int row,
                                list objects
                                )

```

ARGUMENTS

row Result file row

classNames (optional)

Comma separated list of class names for valid objects. The next object of one of the given classes is searched. If not set all objects are considered as valid (default).

variableName (optional)

Name of the limiting variable. The searched object must have this variable. If not set variables are not considered (default).

limit (optional)

Limiting value for the variable.

limitOperator (optional)

Operator for checking the limiting value:

- 0** all values are valid (default)
- 1** valid values must be < limit
- 2** valid values must be ≤ limit
- 3** valid values must be > limit
- 4** valid values must be ≥ limit

limit2 (optional)

Second limiting value for the variable.

limitOperator2 (optional)

Operator for checking the second limiting value:

- < 0 first OR second criterion must match,
- > 0 first AND second criterion must match,
- 0** all values are valid (default)
- 1/-1** valid values must be < limit2
- 2/-2** valid values must be ≤ limit2
- 3/-3** valid values must be > limit2
- 4/-4** valid values must be ≥ limit2

objects Valid objects

RETURNS

- ≥ 0 column index
- < 0 no valid column found

GetFirstValidObjectVariable

Gets the index of the first valid variable of the current object in the current line. Starts at the internal iterator of the given result file and sets it to the position found. [ElmRes.Load\(\)](#) must be called before using this function.

```
int ElmRes.GetFirstValidObjectVariable([str variableNames])
```

ARGUMENTS

variableNames (optional)

Comma separated list of valid variable names. The next column with one of the given variables is searched. If empty all variables of the current object are considered as valid (default).

RETURNS

≥ 0 column index
 < 0 no valid column found

GetFirstValidVariable

Gets the index of the column for the first valid variable in the given line. Starts at the beginning of the given line and sets the internal iterator of the result file to the found position. [ElmRes.Load\(\)](#) must be called before using this function.

```
int ElmRes.GetFirstValidVariable(int row,
                                [str variableNames]
                                )
```

ARGUMENTS

row Result file row.

variableNames (optional)

Comma separated list of valid variable names. The next column with one of the given variables is searched. If not set all variables are considered as valid (default).

RETURNS

≥ 0 column index
 < 0 no valid column found

GetNextValidObject

Gets the index of the column for the next valid variable (after current iterator) in the given line. Sets the internal iterator of the result file to the position found. [ElmRes.Load\(\)](#) must be called before using this function.

```
int ElmRes.GetNextValidObject([str classNames,]
                              [str variableName,]
                              [float limit,]
                              [int limitOperator,]
                              [float limit2,]
                              [int limitOperator2]
                              )
int ElmRes.GetNextValidObject(list objects)
```

ARGUMENTS

row Result file row.

classNames (optional)

Comma separated list of class names for valid objects. The next object of one of the given classes is searched. If not set all objects are considered as valid (default).

variableName (optional)

Name of the limiting variable. The searched object must have this variable. If not set variables are not considered (default).

limit (optional)

Limiting value for the variable.

limitOperator (optional)

Operator for checking the limiting value:

- 0** all values are valid (default)
- 1** valid values must be $<$ limit
- 2** valid values must be $\leq$ limit
- 3** valid values must be $>$ limit
- 4** valid values must be $\geq$ limit

limit2 (optional)

Second limiting value for the variable.

limitOperator2 (optional)

Operator for checking the second limiting value:

- < 0 first OR second criterion must match,
- > 0 first AND second criterion must match,
- 0** all values are valid (default)
- 1/-1** valid values must be $<$ limit2
- 2/-2** valid values must be $\leq$ limit2
- 3/-3** valid values must be $>$ limit2
- 4/-4** valid values must be $\geq$ limit2

objects Valid objects

RETURNS

- ≥ 0 column index
- < 0 no valid column found

GetNextValidObjectVariable

Gets the index of the column for the next valid variable of the current object in the current line. Starts at the internal iterator of the given result file and sets it to the found position. [ElmRes.Load\(\)](#) must be called before using this function.

```
int ElmRes.GetNextValidObjectVariable([str variableNames])
```

ARGUMENTS

variableNames (optional)

Comma separated list of valid variable names. The next column with one of the given variables is searched. If not set all variables are considered as valid (default).

RETURNS

- ≥ 0 column index
- < 0 no valid column found

GetNextValidVariable

Gets the index of the column for the next valid variable in the given line. Starts at the internal iterator of the given line and sets the internal iterator of the result file to the found position. [ElmRes.Load\(\)](#) must be called before using this function.

```
int ElmRes.GetNextValidVariable([str variableNames])
```

ARGUMENTS

variableNames (optional)

Comma separated list of valid variable names. The next column with one of the given variables is searched. If not set all variables are considered as valid (default).

RETURNS

- ≥ 0 column index
- < 0 no valid column found

GetNumberOfColumns

Returns the number of variables (columns) in result file excluding the default variable (e.g. time for time domain simulation). [ElmRes.Load\(\)](#) must be called before using this function.

```
int ElmRes.GetNumberOfColumns()
```

RETURNS

Number of variables (columns) in result file.

GetNumberOfRows

Returns the number of values per column (rows) stored in result object. [ElmRes.Load\(\)](#) must be called before using this function.

```
int ElmRes.GetNumberOfRows()
```

RETURNS

Returns the number of values per column stored in result object.

GetObj

Returns an object used in the result file. Positive index means objects for which parameters are being monitored (i.e. column objects). Negative index means objects which occur in written result rows as values. [ElmRes.Load\(\)](#) must be called before using this function.

```
DataObject ElmRes.GetObj(int index)
```

ARGUMENTS

index index of the object.

RETURNS

The object found or None.

GetObject

Get object of given column. [ElmRes.Load\(\)](#) must be called before using this function.

```
DataObject ElmRes.GetObject([int column])
```

ARGUMENTS

col Column index. Object of default column is returned if col is not passed.

RETURNS

The object of the variable stored in column 'column'.

GetObjectValue

Returns a value from a result object for row iX of curve col. [ElmRes.Load\(\)](#) must be called before using this function.

```
[int error,  
DataObject o ] ElmRes.GetObjectValue(int iX,  
                                     [int col])
```

ARGUMENTS

o (out) The object retrieved from the data.

iX The row.

col (optional)

The curve number, which equals the variable or column number, first column value (time,index, etc.) is returned when omitted.

RETURNS

- 0** when ok
- 1** when iX out of bound
- 2** when col out of bound
- 3** when invalid value is returned from a sparse file. Sparse files are written e.g. by the contingency analysis, the value is invalid in case that it was not written, because it was below the recording limit. Result files created using DPL/Python are always full and will not return invalid values.

GetRelCase

Get the contingency object for the given case number from the reliability result file.

```
DataObject ElmRes.GetRelCase(int caseNumber)
```

ARGUMENTS

caseNumber
The reliability case number

RETURNS

Returns the contingency of case number. None is returned if there is no corresponding contingency.

GetSubElmRes

Get sub-result file stored inside this.

```
DataObject ElmRes.GetSubElmRes(int value)
DataObject ElmRes.GetSubElmRes(DataObject obj)
```

ARGUMENTS

value The cnttime to look for
obj The pResElm to look for

RETURNS

None The sub result file with value=cnttime (obj=pResElm) was not found.
any other value The sub result file with value=cnttime (obj=pResElm).

GetUnit

Get the unit of a column. [ElmRes.Load\(\)](#) must be called before using this function.

```
str ElmRes.GetUnit([int column])
```

ARGUMENTS

column (optional)
The column index. The unit of the default variable is returned if the parameter is nor passed to the function.

RETURNS

Returns the unit which is empty in case that the column index is not part of the data.

GetValue

Returns a value from a result object for row iX of curve col. [ElmRes.Load\(\)](#) must be called before using this function.

```
[int error,
float d ] ElmRes.GetValue(int iX,
                          [int col])
```

ARGUMENTS

- d (out)* The value retrieved from the data.
- iX* The row.
- col (optional)*
The curve number, which equals the variable or column number, first column value (time,index, etc.) is returned when omitted.

RETURNS

- 0** when ok
- 1** when iX out of bound
- 2** when col out of bound
- 3** when invalid value is returned from a sparse file. Sparse files are written e.g. by the contingency analysis, the value is invalid in case that it was not written, because it was below the recording limit. Result files created using DPL/Python are always full and will not return invalid values.

GetVariable

Get variable name of column. `ElmRes.Load()` must be called before using this function.

```
str ElmRes.GetVariable([int column])
```

ARGUMENTS

- column (optional)*
The column index. The variable name of the default variable is returned if the parameter is not passed to the function.

RETURNS

Returns the variable name which is empty in case that the column index is not part of the data.

InitialiseWriting

Opens the result object for writing. This function must be called before writing data for result files not stored in the script object. If arguments are passed to the function they specify the variable name, unit... of the default variable (e.g. to be used by plots as x-axis).

```
int ElmRes.InitialiseWriting()
int ElmRes.InitialiseWriting(str variableName,
                             str unit,
                             str description,
                             [str shortDescription]
                             )
```

ARGUMENTS

- variableName*
The variable name for the default variable (e.g. "distance").
- unit* The unit (e.g. "km").
- description*
The description of the variable (e.g. "Distance from infeed").

shortDescription

The short description (e.g. "Dist. Infeed").

RETURNS

Always 0 and can be ignored

DEPRECATED NAMES

Init

SEE ALSO

[ElmRes.FinishWriting\(\)](#), [ElmRes.Write\(\)](#), [ElmRes.WriteDraw\(\)](#)

Load

Loads the data of a result object (**ElmRes**) in memory for reading.

```
None ElmRes.Load()
```

Release

Releases the data loaded to memory. This function should be used whenever several result objects are processed in a loop. Data is always released from memory automatically after execution of the current script.

```
None ElmRes.Release()
```

SetAsDefault

Sets this results object as the default results object. Plots using the default result file will use this file for displaying data.

```
None ElmRes.SetAsDefault()
```

SetObj

Adds an object to the objects assigned to the result file

```
int ElmRes.SetObj(DataObject element)
```

ARGUMENTS

element Element to store in result file

RETURNS

The index which can be used to retrieve the object from the results file. The index is < 0 if no results are recorded for the given object (e.g. a contingency in reliability calculation). The index is ≥ 0 if variables are recorded for the object.

SetSubElmResKey

Assigns a value or an object to the according ElmRes parameter.

```
None ElmRes.SetSubElmResKey(int value)
None ElmRes.SetSubElmResKey(DataObject obj)
```

ARGUMENTS

- value* Value to be assigned to parameter cnttime of ElmRes
- value* Object to be assigned to parameter pResElm of ElmRes

SortAccordingToColumn

Sorts all rows in the data loaded according to the given column. The ElmRes itself remains unchanged. [ElmRes.Load\(\)](#) must be called before using this function.

```
int ElmRes.SortAccordingToColumn(int column)
```

ARGUMENTS

- col* The column number.

RETURNS

- 0** The function executed correctly, the data was sorted correctly according to the given column.
- 1** The column with index column does not exist.

Write

Writes the current results to the result object.

```
int ElmRes.Write([float defaultValue])
```

RETURNS

- 0 on success

SEE ALSO

[ElmRes.WriteDraw\(\)](#), [ElmRes.InitialiseWriting\(\)](#), [ElmRes.FinishWriting\(\)](#)

WriteDraw

Writes current results to the result objects and updates all plots that display values from the result object.

```
int ElmRes.WriteDraw()
```

RETURNS

- 0 on success

5.2.29 ElmShnt

Overview

[GetGroundingImpedance](#)

GetGroundingImpedance

Returns the impedance of the internal grounding. Single phase shunts connected to neutral or R-L type DC shunts are considered as grounding devices themselves; i.e. instead of the dedicated grounding parameters, the shunt parameters are used.

```
[int valid,
float resistance,
float reactance ] ElmShnt.GetGroundingImpedance(int busIdx)
```

ARGUMENTS

busIdx Bus index where the grounding should be determined.

resistance (out)
Real part of the grounding impedance in Ohm.

reactance (out)
Imaginary part of the grounding impedance in Ohm.

RETURNS

- 0** The values are invalid (e.g. because there is no internal grounding)
- 1** The values are valid.

5.2.30 ElmStactrl

Overview

[GetControlledHVNode](#)
[GetControlledLVNode](#)
[GetStepupTransformer](#)
[Info](#)

GetControlledHVNode

Returns the corresponding voltage controlled HV node for the machine at the specified index. Switch status are always considered.

```
DataObject ElmStactrl.GetControlledHVNode([int index = 0])
```

ARGUMENTS

index (optional)
Index of machine (starting from 0 — ...). Default is 0.

RETURNS

object Busbar/Terminal ()
None not found

GetControlledLVNode

Returns the corresponding voltage controlled LV node for the machine at specified index. Switch status are always considered.

```
DataObject ElmStactrl.GetControlledLVNode(int index)
```

ARGUMENTS

index Index of machine (starting from 0 – ...).

RETURNS

object Terminal ()
None not found

GetStepupTransformer

Performs a topological search to find the step-up transformer of the machine at the specified index.

```
DataObject ElmStactrl.GetStepupTransformer([int index,]  
                                             [int iBrkMode,]  
                                             [double voltage]  
                                             )
```

ARGUMENTS

index Index of machine (starting from 0 – ...).

iBrkMode (optional)

- 0 (default)** All switch status (open,close) are considered
- 1** Ignore breaker status (jump over open breakers)
- 2** Ignore all switch status (jump over open switches)

voltage voltage level at which the search will stop

RETURNS

object step-up transformer
None step-up transformer not found

Info

Prints the control information in the output window. It is the same information that the button "Info" of the Station Control dialog prints.

```
int ElmStactrl.Info()
```

5.2.31 ElmSubstat

Overview

[ApplyAndResetRA](#)
[GetSplit](#)
[GetSplitCal](#)
[GetSplitIndex](#)
[GetSuppliedElements](#)
[OverwriteRA](#)
[ResetRA](#)
[SaveAsRA](#)
[SaveAsSwSc](#)
[SetRA](#)

ApplyAndResetRA

This function applies switch statuses of currently selected running arrangement to corresponding switches and resets the running arrangement selection afterwards. Nothing happens if no running arrangement is selected.

```
int ElmSubstat.ApplyAndResetRA()
```

RETURNS

- 1** on success
- 0** otherwise, especially if no running arrangement is selected

GetSplit

A split of a station is a group of topologically connected elements. Such a group is called split if all contained components are energized and there is at least one busbar (terminal of usage 'busbar') contained or it has connections to at least two main components (= all components except switch devices and terminals).

These splits are ordered according to the count of nodes contained and according to their priority. So each split becomes a unique index.

The function GetSplit offers access to the elements contained in a split. By calling GetSplit with an index from 0 to n, the elements belonging to the corresponding split are filled into given sets and returned.

```
[int error
list mainNodes,
list connectionCubicles,
list allElements       ] ElmSubstat.GetSplit(int index)
```

ARGUMENTS

index Index of the split used to access the elements of the corresponding split. Value must be ≥ 0 .

mainNodes (out)

Terminals of same usage considered to form the most important nodes for that group. In most cases, this is the group of contained busbars.

connectionCubicles (optional, out)

All cubicles (of terminals inside the station) that point to an element that sits outside the station or to an element that is connected to a terminal outside the station are filled into the set `connectionCubicles`. (The connection element (branch) can be accessed by calling `GetBranch()` on each of these cubicles. The terminals of these cubicles (parents) must not necessarily be contained in any split. They could also be separated by a disconnecting component.)

allElements(optional, out)

All elements (class `Elm*`) of the split that have no connection to elements outside the station are filled into this set.

RETURNS

- 0** success, split of that index exists and is returned.
- 1** indicates that there exists no split with given index. (Moreover, this means that there is no split with index `n` greater than this value.)

SEE ALSO

[ElmSubstat.GetSplitCal\(\)](#), [ElmSubstat.GetSplitIndex\(\)](#),

GetSplitCal

This function determines the elements that belong to a split. In contrast to [ElmSubstat.GetSplit\(\)](#) it is based on calculation instead of pure edit object topology. This means the returned nodes correspond to the calculation nodes, the interconnecting cubicles are those connecting nodes of different splits.

Note: As this function relies on calculation nodes it can only be executed after a calculation has been performed (e.g. load flow calculation).

```
[int error,
list nodes,
list connectionCubicles,
list elements          ] ElmSubstat.GetSplitCal(int index)
```

ARGUMENTS

index Index of the split used to access the elements of the corresponding split. Refers to same split as index in [ElmSubstat.GetSplit\(\)](#). Value must be ≥ 0 .

nodes (out)

A set that is filled with terminals. There is one terminal returned for each calculation node in the split.

connectionCubicles (optional, out)

This set is filled with all cubicles that point from a calculation node of current split to another calculation node that does not belong to that split. The connecting element can be accessed by calling `GetBranch()` on such a cubicle.

elements (optional, out)

This set is filled with network elements that are connected to a calculation node of current split and have exactly one connection, i.e. these elements are completely contained in the split.

RETURNS

- 0** success, split of that index exists and is returned.
- 1** indicates that there exists no split with given index. (Moreover, this means that there is no split with index `n` greater than this value.)

SEE ALSO

[ElmSubstat.GetSplit\(\)](#)

GetSplitIndex

This function returns the index of the split that contains passed object.

```
int ElmSubstat.GetSplitIndex(DataObject o)
```

ARGUMENTS

o Object for which the split index is to be determined.

RETURNS

- ≥ 0 index of split in which element is contained
- 1** given object does not belong to any split of that station

SEE ALSO

[ElmSubstat.GetSplit\(\)](#)

GetSuppliedElements

Returns the network components that are supplied by the transformer (located in the station). A network component is considered to be supplied by a transformer if a topological path from the transformer to the component exists. A valid topological path in this sense is a path that starts at the transformer's HV side in direction of transformer (not in direction of HV connected node) and stops at

- network components that are out of calculation,
- network components that are not active (e.g. hidden or those of currently inactive grids),
- open switches,
- connections leading to a higher voltage level.

Generally, all network components of such a path are considered to be supplied by the transformer.

Exceptions are components that are out of calculation or in-active. Those components are never considered to be supplied by any transformer. A transformer is never considered to supply itself. Composite components such as ElmBranch, ElmSubstat, ElmTrfstat are considered to be supplied by a transformer if all energized components inside that composite are supplied by the transformer.

```
list ElmSubstat.GetSuppliedElements([int inclNested])
```

ARGUMENTS

inclNested (optional)

- 0** Do not include components that are supplied by nested supplying stations
- 1** (default) Include components that are supplied by nested stations

SEE ALSO

[ElmTr2.GetSuppliedElements\(\)](#), [ElmTr3.GetSuppliedElements\(\)](#)

OverwriteRA

This function overwrites switch statuses stored in an existing running arrangement with actual switch statuses of the substation. This is only possible if the substation has no running arrangement selected and given running arrangement is valid for substation the method was called on.

```
int ElmSubstat.OverwriteRA(DataObject ra)
```

ARGUMENTS

ra Given running arrangement

RETURNS

1 If given running arrangement was successfully overwritten;
0 otherwise

ResetRA

This function resets the running arrangement selection for the substation it was called on.

```
None ElmSubstat.ResetRA()
```

SaveAsRA

When called on a substation that has no running arrangement selected, a new running arrangement is created and all switch statuses of all running arrangement relevant switches (for that substation) are saved in it. The running arrangement is stored in project folder "Running Arrangement" and its name is set to given locname. The new running arrangement is not selected automatically.

(No new running arrangement is created if this method is called on a substation that has currently a running arrangement selected).

```
DataObject ElmSubstat.SaveAsRA(str locname)
```

ARGUMENTS

locname Name of the new running arrangement (if name is already used, an increment (postfix) is added to make it unique).

RETURNS

Newly created 'IntRunarrange' object on success, otherwise None.

SaveAsSwSc

Create a Switching Rules object and assign to this station.

```
DataObject ElmSubstat.SaveAsSwSc(str name)
```

ARGUMENTS

name The name of the created Switching Rules object.

RETURNS

The created Switching Rules object.

SetRA

This function sets the running arrangement selection for the substation it was called on. The switch statuses are now determined by the values stored in the running arrangement.

```
int ElmSubstat.SetRA(DataObject ra)
```

ARGUMENTS

ra running arrangement that is valid for the substation

RETURNS

1 If given running arrangement was successfully set;
0 otherwise (e.g. given ra is not valid for that substation)

5.2.32 ElmSvs**Overview**

[GetStepupTransformer](#)

GetStepupTransformer

Performs a topological search to find the step-up transformer of the static VAR system.

```
DataObject ElmSvs.GetStepupTransformer(float voltage,  
                                         int swStatus  
                                         )
```

ARGUMENTS

voltage voltage level at which the search will stop

swStatus consideration of switch status. Possible values are:

0 consider all switch status
1 ignore breaker status
2 ignore all switch status

RETURNS

Returns the first collected step-up transformer object. It is empty if not found (e.g. start terminal already at hvVoltage).

5.2.33 ElmSym

Overview

[CalcEfficiency](#)
[Derate](#)
[Disconnect](#)
[GetAvailableGenPower](#)
[GetGroundingImpedance](#)
[GetMotorStartingFlag](#)
[GetStepupTransformer](#)
[IsConnected](#)
[Reconnect](#)
[ResetDerating](#)

CalcEfficiency

Calculate efficiency for connected storage model at given active power value.

```
float ElmSym.CalcEfficiency(float activePowerMW)
```

ARGUMENTS

activePowerMW
Active power value to calculate efficiency for.

RETURNS

Returns the resulting efficiency in p.u.

Derate

Derates the value of the Max. Active Power Rating according to the specified value given in MW.

The following formula is used: $P_{max_uc} = P_{max_uc} - "Deratingvalue"$.

```
None ElmSym.Derate(float deratingP)
```

ARGUMENTS

deratingP Derating value

Disconnect

Disconnects a synchronous machine by opening the first circuit breaker. The topological search performed to find such a breaker, stops at any busbar.

```
int ElmSym.Disconnect()
```

RETURNS

0 breaker already open or successfully opened
1 an error occurred (no breaker found, open action not possible (earthing / RA))

GetAvailableGenPower

Returns the available power that can be dispatched from the generator, for the particular study time.

For the case of conventional generators (no wind generation selected), the available power is equal to the nominal power specified.

For wind generators, the available power will depend on the wind model specified:

- No Wind Model: No available power.
- Stochastic Wind Model: Given the specified mean wind speed, the available power is calculated from the Power Curve. If the units of the Power Curve are in MW, the returned value is directly the available power. In the other hand, if the units are in PU, the returned value is multiplied by the nominal power of the generator to return the available power.
- Time Series Characteristics of Active Power Contribution: The available power is the average of the power values (in MW) obtained from all the specified time characteristics for the current study time.
- Time Series Characteristics of Wind Speed: The available power is calculated with the average of the power values (in MW) calculated for all the specified time characteristics. A power value for any time characteristic is calculated by obtaining the wind speed for the current study time, and then calculating the power from the specified Power Curve. If the units of the Power Curve are in MW, the returned value is directly the power value. In the other hand, if the units are in PU, the returned value is multiplied by the nominal power of the generator to return the power value.

For motors, the available power is zero.

```
float ElmSym.GetAvailableGenPower()
```

RETURNS

Available generation power

GetGroundingImpedance

Returns the impedance of the internal grounding.

```
[int valid,
float resistance,
float reactance ] ElmSym.GetGroundingImpedance(int busIdx)
```

ARGUMENTS

busIdx Bus index where the grounding should be determined.

resistance (out)
Real part of the grounding impedance in Ohm.

reactance (out)
Imaginary part of the grounding impedance in Ohm.

RETURNS

- 0** The values are invalid (e.g. because there is no internal grounding)
- 1** The values are valid.

GetMotorStartingFlag

Returns the starting motor condition.

```
int ElmSym.GetMotorStartingFlag()
```

RETURNS

Returns the motor starting condition. Possible values are:

- | | |
|-----------|------------------------------------|
| -1 | in the process of being calculated |
| 0 | not calculated |
| 1 | successful start |
| 2 | unsuccessful start |

GetStepupTransformer

Performs a topological search to find the step-up transformer of the synchronous machine.

```
DataObject ElmSym.GetStepupTransformer(float voltage,  
                                         int swStatus  
                                         )
```

ARGUMENTS

voltage voltage level at which the search will stop

swStatus consideration of switch status. Possible values are:

- | | |
|----------|----------------------------|
| 0 | consider all switch status |
| 1 | ignore breaker status |
| 2 | ignore all switch status |

RETURNS

Returns the first collected step-up transformer object. It is empty if not found (e.g. start terminal already at hvVoltage).

IsConnected

Checks if a synchronous machine is already connected to any busbar.

```
int ElmSym.IsConnected()
```

RETURNS

- | | |
|----------|--|
| 0 | false, not connected to a busbar |
| 1 | true, generator is connected to a busbar |

Reconnect

Connects a synchronous machine by closing all switches (breakers and isolators) up to the first breaker on the HV side of a transformer. The topological search to find all the switches, stops at any busbar.

```
int ElmSym.Reconnect()
```

RETURNS

- 0** the machine was successfully closed
- 1** a error occurred and the machine could not be connected to any busbar

ResetDerating

Resets the derating value, setting the Max. Active Power Rating according to the rating factor. The following formula is used: $P_{max_uc} = p_{maxratf} * P_n * n_{gnum}$.

```
None ElmSym.ResetDerating()
```

5.2.34 ElmTerm**Overview**

[GetBusType](#)
[GetCalcRelevantCubicles](#)
[GetConnectedBrkCubicles](#)
[GetConnectedCubicles](#)
[GetConnectedMainBuses](#)
[GetConnectionInfo](#)
[GetEquivalentTerminals](#)
[GetMinDistance](#)
[GetNextHVBus](#)
[GetNodeName](#)
[GetSepStationAreas](#)
[GetShortestPath](#)
[GetShortestPathWithIndex](#)
[HasCreatedCalBus](#)
[InitAllShortestPaths](#)
[IsElectrEquivalent](#)
[IsEquivalent](#)
[IsInternalNodeInStation](#)
[UpdateSubstationTerminals](#)

GetBusType

Gets busbar calculation type.

```
int ElmTerm.GetBusType()
```

RETURNS

- 0** No valid calculation (load flow).
- 1** PQ busbar.
- 2** PV busbar.
- 3** Slack busbar.

GetCalcRelevantCubicles

This function gets calculation relevant cubicles of this terminal.

```
list ElmTerm.GetCalcRelevantCubicles()
```

RETURNS

Set of calculation relevant cubicles.

GetConnectedBrkCubicles

Function gets the set of cubicles connected with the breaker and this terminal.

```
list ElmTerm.GetConnectedBrkCubicles([int ignoreSwitchStates])
```

ARGUMENTS

ignoreSwitchStates (optional)
Ignore switch status flag 1 or not 0 (=default).

RETURNS

Set of cubicles.

GetConnectedCubicles

Function gets the set of cubicles connected with this terminal.

```
list ElmTerm.GetConnectedCubicles([int ignoreSwitchStates])
```

ARGUMENTS

ignoreSwitchStates (optional)
Ignore switch status flag 1 or not 0 (=default).

RETURNS

Set of cubicles.

GetConnectedMainBuses

Function gets the set of connected main buses.

```
list ElmTerm.GetConnectedMainBuses([int considerSwitches])
```

ARGUMENTS

considerSwitches (optional)
Consider switch state (default 1).

RETURNS

Set of main buses connected to the terminal.

GetConnectionInfo

Gets connection information of this terminal. Requires valid load flow calculation. Input arguments are filled with the value after function call.

```
[int error,
float closedSwitches,
float allSwitches,
float nonSwitchingDevices,
float closedAndNonSwitchingDevices,
float allDevices,
float connectedNodes,
float mainNodes] ElmTerm.GetConnectionInfo()
```

ARGUMENTS

closedSwitches

Number of closed switch devices.

allSwitches

Number of total switch devices.

nonSwitchingDevices

Number of non-switch devices.

closedAndNonSwitchingDevices

Number of total closed and non-switch devices (closedSwitches + nonSwitchingDevices).

allDevices

Number of total switch and non-switch devices (allSwitches + nonSwitchingDevices).

connectedNodes

Number of total nodes connected via couplers.

mainNodes

Number of total main nodes.

RETURNS

Return value is always 0 and has no meaning.

GetEquivalentTerminals

Returns a set of all terminals that are equivalent to current one. Equivalent means that those terminals are topologically connected only by

- closed switching devices (ElmCoup, RelFuse) or
- lines of zero length (line droppers).

```
list ElmTerm.GetEquivalentTerminals()
```

RETURNS

All terminals that are equivalent to current one. Current one is also included so the set is never empty.

SEE ALSO

[ElmTerm.IsEquivalent\(\)](#)

GetMinDistance

This function determines the shortest path between the terminal the function was called on and the terminal that was passed as first argument. The distance is determined on network topology regarding the length of the traversed component (i.e. only lines have an influence on distance).

```
float ElmTerm.GetMinDistance(DataObject term)
[ float minDistance,
  list path          ] ElmTerm.GetMinDistance(DataObject term,
                                              [int considerSwitches,]
                                              [list limitToNodes,]
                                              [list elementsToIgnore]
                                              )
```

ARGUMENTS

term Terminal to which the shortest path is determined.

considerSwitches (optional)

- 0** Traverse all components, ignore switch states
- 1** Do not traverse open switch devices (default)

path (optional, out)

If given, all components of the found shortest path are put into this set.

limitToNodes(optional)

If given, the shortest path is searched only within this set of nodes. Please note, when limiting search to a given set of nodes, the start and end terminals (for which the distance is determined) must be part of this set (otherwise distance = -1).

elementsToIgnore(optional)

If given, these objects (e.g. nodes) are ignored in the search and not traversed (=considered as not existing).

RETURNS

- < 0 If there is no path between the two terminals
- ≥ 0 Distance of shortest path in km

SEE ALSO

[ElmTerm.GetShortestPath\(\)](#)

GetNextHVBus

This function returns the nearest connected busbar that has a higher voltage level. To detect this bus, a breadth-first search on the net topology is executed. The traversal stops on each element that is out of service and on each opened switch device. The criterion for higher voltage level is passing a transformer to HV side. No junction nor internal nodes shall be considered. Two winding transformers with equal voltage on both sides are ignored (simply passed by the search).

```
DataObject ElmTerm.GetNextHVBus()
```

RETURNS

object First busbar found.
None If no busbar was found.

GetNodeName

For terminals inside a station, this function returns a unique name for the split the terminal is located in. The name is built on first five characters of the station's short name plus the split index separated by an underscore. E.g. "USTAT_1".

For terminals inside a branch (*ElmBranch*) the returned name is just a concatenation of the branch name and the terminal's name.

For all other terminals not inside a branch or a station the node name corresponds to the terminal's name.

```
str ElmTerm.GetNodeName()
```

RETURNS

Node name as described above. Never empty.

GetSepStationAreas

Function gets all separate areas within the substation linked to this terminal. In this manner, area is any part between two nodes.

```
list ElmTerm.GetSepStationAreas([int considerSwitches])
```

ARGUMENTS

considerSwitches (optional)
 Consider switch state (default 1).

RETURNS

Set of all separate areas in this substation.

GetShortestPath

This function determines the shortest path between the terminal the function was called on and the terminal that was passed as argument. The shortest path is determined on network topology according to the given settings. If all shortest paths should be returned, use [ElmTerm.InitAllShortestPaths\(\)](#) followed by [ElmTerm.GetShortestPathWithIndex\(\)](#).

```
float ElmTerm.GetShortestPath(DataObject term)
[float minDistance,
list path          ] ElmTerm.GetShortestPath(int criterion,
                                              DataObject term,
                                              [int considerSwitches,]
                                              [list limitToNodes,]
                                              [list elementsToIgnore]
                                              )
```

ARGUMENTS

criterion
0 According to line length, same as [ElmTerm.GetMinDistance\(\)](#)

- 1 According to node count
- 2 According to impedance
- 3 According to resistance
- 4 According to reactance

term Terminal to which the shortest path is determined.

considerSwitches (optional)

- 0 Traverse all components, ignore switch states
- 1 Do not traverse open switch devices (default)

path (optional, out)

If given, all components of the found shortest path are put into this set.

limitToNodes (optional)

If given, the shortest path is searched only within this set of nodes. Please note, when limiting search to a given set of nodes, the start and end terminals (for which the distance is determined) must be part of this set (otherwise distance = -1).

elementsToIgnore (optional)

If given, these objects (e.g. nodes) are ignored in the search and not traversed (=considered as not existing).

RETURNS

- < 0 If there is no path between the two terminals
- ≥ 0 Distance of shortest path according to given criterion

SEE ALSO

[ElmTerm.GetMinDistance\(\)](#)

GetShortestPathWithIndex

This function returns the shortest path of the given index in the previously cached shortest paths. Requires function call to [ElmTerm.InitAllShortestPaths\(\)](#) beforehand.

```
list ElmTerm.GetShortestPathWithIndex(int index)
```

ARGUMENTS

index Index of the path to be retrieved.

RETURNS

Path at the given index.

EXAMPLE

```
#assume startTerm and endTerm are objects of class ElmTerm
import powerfactory
app = powerfactory.GetApplicationExt()
script = app.GetCurrentScript()

criterion = 0 #Linelenhth
number = script.startTerm.InitAllShortestPaths(criterion,endTerm)
app.PrintPlain(number)
for i in range(number):
    path = startTerm.GetShortestPathWithIndex(i)
    app.PrintPlain(path)
```

HasCreatedCalBus

This function checks if the valid calculation exists for this terminal (i.e. load flow). If it exists, then the calculation parameters could be retrieved.

```
int ElmTerm.HasCreatedCalBus()
```

RETURNS

- 1** Valid calculation exists.
- 0** No valid calculation.

InitAllShortestPaths

This function computes all shortest paths between the terminal the function was called on and the terminal that was passed as argument. The shortest paths are determined on network topology according to the given settings. Paths can be retrieved using the function [ElmTerm.GetShortestPathWithIndex\(\)](#).

```
int ElmTerm.InitAllShortestPaths(int criterion,
                                DataObject term,
                                [int considerSwitches,]
                                [int pathDifferenceType,]
                                [list limitToNodes,]
                                [list elementsToIgnore]
                                )
```

ARGUMENTS

criterion

- 0** According to line length
- 1** According to node count
- 2** According to impedance
- 3** According to resistance
- 4** According to reactance

term Terminal to which the shortest paths are determined.

considerSwitches (optional)

- 0** Traverse all components, ignore switch states
- 1** Do not traverse open switch devices (default)

pathDifferenceType

- 0** Paths differ in at least one node (default)
- 1** Paths are edge-disjoint
- 2** Paths are node-disjoint

limitToNodes(optional)

If given, the shortest paths are searched only within this set of nodes. Please note, when limiting search to a given set of nodes, the start and end terminals must be part of this set.

elementsToIgnore(optional)

If given, these objects (e.g. nodes) are ignored in the search and not traversed (=considered as not existing).

RETURNS

Number of shortest paths found.

IsElectrEquivalent

Function checks if two terminals are electrically equivalent. Two terminals are said to be electrically equivalent if they are topologically connected only by

- closed switching devices (*ElmCoup*, *RelFuse*) or
- lines of zero length (line droppers) or
- branch components whose impedance is below given thresholds ($R \leq \text{maxR}$ and $X \leq \text{maxX}$)

```
int ElmTerm.IsElectrEquivalent(DataObject terminal,
                               float maxR,
                               float maxX
                               )
```

ARGUMENTS

- terminal* Terminal to which the 'method called terminal' is connected to.
- maxR* Given threshold for the resistance of branch elements (must be given in Ohm).
- maxX* Given threshold for the reactance of branch elements (must be given in Ohm).

RETURNS

- 1** If terminal on which the method was called is electrical equivalent to terminal that was passed as argument
- 0** Otherwise

SEE ALSO

[ElmTerm.IsEquivalent\(\)](#)

IsEquivalent

Function checks if two terminals are topologically connected only by

- closed switching devices (*ElmCoup*, *RelFuse*) or
- lines of zero length (line droppers).

IsEquivalent() defines a relation that is

- symmetric (*Term1.IsEquivalent(Term2) -> Term2.IsEquivalent(Term1)*),
- reflexive (*Term1.IsEquivalent(Term1)*) and
- transitive (*Term1.IsEquivalent(Term2)* and *Term2.IsEquivalent(Term3)* -> *Term1.IsEquivalent(Term3)*).

```
int ElmTerm.IsEquivalent(DataObject terminal)
```

ARGUMENTS

terminal Terminal (object of class `ElmTerm`) that is checked to be equivalent to the terminal on which the function was called on. Passing `None` is not allowed and will result in a scripting error.

RETURNS

- 1** If terminal on which the method was called is connected to terminal that was passed as argument only by closed switching devices or by lines of zero length.
- 0** Otherwise (terminals are not connected or connected by other components than switching devices / lines of zero length).

SEE ALSO

[ElmTerm.GetEquivalentTerminals\(\)](#) [ElmTerm.IsElectrEquivalent\(\)](#)

IsInternalNodeInStation

Function checks if the terminal is an internal node located in a station (*ElmSubstat*, *ElmTrfstat*).

```
int ElmTerm.IsInternalNodeInSubStation()
```

RETURNS

- 1** Terminal is a node of usage 'internal' and is located in a station.
- 0** Not internal node or not in a station, or both.

UpdateSubstationTerminals

Updates all nodes within the substation to the new voltage and/or phase technology. Applicable for all busbars and junction nodes. The highest voltage is taken as the leading one.

```
None ElmTerm.UpdateSubstationTerminals(int volt,
                                         int phs
                                         )
```

ARGUMENTS

volt Updates nominal voltages (<> 0)

phs Updates phase technology (<> 0)

5.2.35 ElmTow**Overview**

[FitParams](#)
[PrintFreqDepParams](#)
[Update](#)

FitParams

Calculates distributed parameters for tower elements. Whether this function calculates constant parameters or frequency dependent parameters depends on the user setting of the parameter 'i_model' in the ElmTow dialogue. The settings are as follows: i_model=0: constant parameters; i_model=1: frequency dependent parameters.

```
int ElmTow.FitParams()
```

RETURNS

0	on success
1	on error

PrintFreqDepParams

Prints the calculated frequency dependent parameters for tower elements in a tabular format to the output window. This table includes for each mode, the surge impedance, wave propagation, travel time and the number of poles and zeros of Z and A. It can only be called after the function oElmTow.FitParams() has been executed; either in DPL/Python/API or via the ElmTow dialogue.

```
None ElmTow.PrintFreqDepParams()
```

Update

Updates line couplings element depending on configuration of the associated tower types or tower geometries.

```
None ElmTow.Update()
```

RETURNS

1	Line couplings element was updated.
0	Update was not required.

5.2.36 ElmTr2

Overview

[CreateEvent](#)
[GetGroundingImpedance](#)
[GetSuppliedElements](#)
[GetTapPhi](#)
[GetTapRatio](#)
[GetZ0pu](#)
[GetZpu](#)
[IsQuadBooster](#)
[NTap](#)

CreateEvent

For the corresponding transformer, a Tap Event (EvtTap) is created for the simulation.

```
int ElmTr2.CreateEvent ([int tapAction,]
                      [int tapPos]
                      )
```

ARGUMENTS

tapAction (optional)

0=increase tap; 1=decrease tap; 2=set tap to tapPos; 3>manual; 4=automatic

tapPos (optional)

Position of tap.

RETURNS

0 on success

GetGroundingImpedance

Returns the impedance of the internal grounding.

```
[int valid,
float resistance,
float reactance ] ElmTr2.GetGroundingImpedance(int busIdx)
```

ARGUMENTS

busIdx Bus index where the grounding should be determined.

resistance (out)

Real part of the grounding impedance in Ohm.

reactance (out)

Imaginary part of the grounding impedance in Ohm.

RETURNS

- 0** The values are invalid (e.g. because there is no internal grounding)
- 1** The values are valid.

GetSuppliedElements

Returns the network components that are supplied by the transformer.

A transformer is treated as supplying if it is located in a station. Transformers outside stations are not supplying in this sense.

A network component is considered to be supplied by a transformer if a topological path from the transformer to the component exists. A valid topological path in this sense is a path that starts at the transformer's HV side in direction of transformer (not in direction of HV connected node) and stops at

- network components that are out of calculation,
- network components that are not active (e.g. hidden or those of currently inactive grids),
- open switches,
- connections leading to a higher voltage level.

Generally all network components of such a path are considered to be supplied by the transformer. Exceptions are components that are out of calculation or in-active. Those components are never considered to be supplied by any transformer.

A transformer is never considered to supply itself.

Composite components such as *ElmBranch*, *ElmSubstat*, *ElmTrfstat* are considered to be supplied by a transformer if all energized components inside that composite are supplied by the transformer.

```
list ElmTr2.GetSuppliedElements([int inclNested])
```

ARGUMENTS

inclNested (optional)

- | | |
|----------|--|
| 0 | Only include components which are directly supplied by the transformer (not nested components) |
| 1 | Include nested components and components that are directly supplied by the transformer (default) |

RETURNS

Elements supplied by this transformer. The set is empty if the transformer is located outside a station or if no element is topologically connected its HV side.

SEE ALSO

[ElmTr3.GetSuppliedElements\(\)](#), [ElmSubstat.GetSuppliedElements\(\)](#), [ElmTrfstat.GetSuppliedElements\(\)](#)

GetTapPhi

Gets the tap phase shift in deg of the transformer for given tap position.

```
float ElmTr2.GetTapPhi(int itappos,
                       int inclPhaseShift
                       )
```

ARGUMENTS

itappos Tap position

inclPhaseShift

1 = Includes the vector group phase shift, 0 = consider only the tap phase shift

RETURNS

Returns the tap phase shift angle of the transformer for given tap position

GetTapRatio

Gets the voltage ratio of the transformer for given tap position.

```
float ElmTr2.GetTapRatio(int itappos,
                          int onlyTapSide,
                          int includeNomRatio
                          )
```

ARGUMENTS

itappos Tap position*onlyTapSide*

1 = ratio only for given side., 0 = total ratio

includeNomRatio

1 = Includes nominal ratio of the transformer, 0 = consider only tap ratio

RETURNS

Returns the voltage ratio of the transformer for given tap position

GetZ0pu

Gets the zero-sequence impedance in p.u. of the transformer for the specified tap position. If the tap position is out of the tap changer range, the respective min. or max. position will be used.

```
[float r0pu,
float x0pu ] ElmTr2.GetZ0pu(int itappos,
                             int systembase)
```

ARGUMENTS

itappos Tap position*r0pu (out)*

Resistance in p.u.

x0pu (out)

Reactance in p.u.

*systembase***0** p.u. is based on rated power.**1** p.u. is based on system base (e.g. 100MVA).**GetZpu**

Gets the impedance in p.u. of the transformer for the specified tap position. If the tap position is out of the tap changer range, the respective min. or max. position will be used.

```
[float rpu,
float xpu ] ElmTr2.GetZpu(int itappos,
                           int systembase)
```

ARGUMENTS

itappos Tap position*rpu (out)*

Resistance in p.u.

xpu (out)

Reactance in p.u.

*systembase***0** p.u. is based on rated power.**1** p.u. is based on system base (e.g. 100MVA).

IsQuadBooster

Returns whether transformer is a quadbooster; i.e. checks phase shift angle modulus 180° .

```
int ElmTr2.IsQuadBooster()
```

RETURNS

'1' if quadbooster, else '0'

NTap

Gets the transformer tap position.

```
int ElmTr2.NTap()
```

RETURNS

The tap position.

5.2.37 ElmTr3**Overview**

[CreateEvent](#)
[GetGroundingImpedance](#)
[GetSuppliedElements](#)
[GetTapPhi](#)
[GetTapRatio](#)
[GetTapZDependentSide](#)
[GetZ0pu](#)
[GetZpu](#)
[IsQuadBooster](#)
[NTap](#)

CreateEvent

For the corresponding transformer, a Tap Event (EvtTap) is created for the simulation.

```
None ElmTr3.CreateEvent([int tapAction = 2,]  
                        [int tapPos = 0,]  
                        [int busIdx = 0]  
                        )
```

ARGUMENTS

tapAction (optional)

0=increase tap; 1=decrease tap; 2=set tap to tapPos; 3>manual; 4=automatic

tapPos (optional)

Position of tap.

busIdx (optional)

Bus index.

GetGroundingImpedance

Returns the impedance of the internal grounding.

```
[int valid,
float resistance,
float reactance ] ElmTr3.GetGroundingImpedance(int busIdx)
```

ARGUMENTS

busIdx Bus index where the grounding should be determined.

resistance (out)
Real part of the grounding impedance in Ohm.

reactance (out)
Imaginary part of the grounding impedance in Ohm.

RETURNS

- 0** The values are invalid (e.g. because there is no internal grounding)
- 1** The values are valid.

GetSuppliedElements

Returns the network components that are supplied by the transformer.

A transformer is treated as supplying if it is located in a station. Transformers outside stations are not supplying in this sense.

A network component is considered to be supplied by a transformer if a topological path from the transformer to the component exists. A valid topological path in this sense is a path that starts at the transformer's HV side in direction of transformer (not in direction of HV connected node) and stops at

- network components that are out of calculation,
- network components that are not active (e.g. hidden or those of currently inactive grids),
- open switches,
- connections leading to a higher voltage level.

Generally all network components of such a path are considered to be supplied by the transformer. Exceptions are components that are out of calculation or in-active. Those components are never considered to be supplied by any transformer.

A transformer is never considered to supply itself.

Composite components such as *ElmBranch*, *ElmSubstat*, *ElmTrfstat* are considered to be supplied by a transformer if all energized components inside that composite are supplied by the transformer.

```
list ElmTr3.GetSuppliedElements([int inclNested])
```

ARGUMENTS

inclNested (optional)

- 0** Only include components which are directly supplied by the transformer (not nested components)
- 1** Include nested components and components that are directly supplied by the transformer (default)

RETURNS

Elements supplied by this transformer. The set is empty if the transformer is located outside a station or if no element is topologically connected its HV side.

SEE ALSO

[ElmTr2.GetSuppliedElements\(\)](#), [ElmSubstat.GetSuppliedElements\(\)](#),
[ElmTrfstat.GetSuppliedElements\(\)](#)

GetTapPhi

Gets the tap phase shift in deg of the transformer for given tap position and side.

```
float ElmTr2.GetTapPhi(int iSide,
                      int itappos,
                      int inclPhaseShift
                      )
```

ARGUMENTS

iSide for tap at side (0=Hv, 1=Mv, 2=Lv)

itappos Tap position for corresponding side

inclPhaseShift

1 = Includes the vector group phase shift, 0 = consider only the tap phase shift

RETURNS

Returns the tap phase shift angle of the transformer for given tap position and side

GetTapRatio

Gets the voltage ratio of the transformer for given tap position and side.

```
float ElmTr2.GetTapRatio(int iSide,
                        int itappos,
                        int includeNomRatio
                        )
```

ARGUMENTS

iSide for tap at side (0=Hv, 1=Mv, 2=Lv)

itappos Tap position at corresponding side

includeNomRatio

1 = Includes nominal ratio of the transformer, 0 = consider only tap ratio

RETURNS

Returns the voltage ratio of the transformer for given tap position and side

GetTapZDependentSide

Get tap side used for the dependent impedance

```
int ElmTr3.GetTapZDependentSide()
```

RETURNS

- 1** if no tap dependent impedance is defined
- 0** for HV tap
- 1** for MV tap
- 2** for LV tap

GetZ0pu

Gets the zero-sequence impedance in p.u. of the transformer for the specified tap position. If the tap position is out of the tap changer range, the respective min. or max. position will be used.

```
[float r0pu,
float x0pu ] ElmTr3.GetZ0pu(int itappos,
                           int iSide,
                           int systembase)
```

ARGUMENTS

itappos Tap position of the z-dependent tap

iSide

- 0** Get the HV-MV impedance.
- 1** Get the MV-LV impedance.
- 2** Get the LV-HV impedance.

r0pu (out)

Resistance in p.u.

x0pu (out)

Reactance in p.u.

systembase

- 0** p.u. is based on rated power.
- 1** p.u. is based on system base (e.g. 100MVA).

GetZpu

Gets the impedance in p.u. of the transformer for the specified tap position. If the tap position is out of the tap changer range, the respective min. or max. position will be used.

```
[float rpu,
float xpu ] ElmTr3.GetZpu(int itappos,
                          int iSide,
                          int systembase)
```

ARGUMENTS

itappos Tap position of the z-dependent tap

iSide

- 0** Get the HV-MV impedance.
- 1** Get the MV-LV impedance.
- 2** Get the LV-HV impedance.

rpu (out) Resistance in p.u.

xpu (out) Reactance in p.u.

systembase

0 p.u. is based on rated power.

1 p.u. is based on system base (e.g. 100MVA).

IsQuadBooster

Returns whether transformer is a quadbooster or not, i.e. checks phase shift angle modulus 180°.

```
int ElmTr3.IsQuadBooster()
```

RETURNS

'1' if the transformer phase shift angle modulus 180° does not equal 0 at any of the sides LV, MV, HV, else '0'

NTap

Gets the transformer tap position of a given bus.

```
int ElmTr3.NTap(int bus)
```

ARGUMENTS

bus 0=HV, 1=MV, 2=LV

RETURNS

The tap position.

5.2.38 ElmTr4

Overview

[CreateEvent](#)
[GetGroundingImpedance](#)
[GetSuppliedElements](#)
[GetTapPhi](#)
[GetTapRatio](#)
[GetTapZDependentSide](#)
[GetZ0pu](#)
[GetZpu](#)
[IsQuadBooster](#)
[NTap](#)

CreateEvent

For the corresponding transformer, a Tap Event (EvtTap) is created for the simulation.

```
None ElmTr4.CreateEvent([int tapAction = 2,
                        [int tapPos = 0,]
                        [int busIdx = 0]
                        ])
```

ARGUMENTS

tapAction (optional)

0=increase tap; 1=decrease tap; 2=set tap to tapPos; 3>manual; 4=automatic

tapPos (optional)

Position of tap.

busIdx (optional)

Bus index.

GetGroundingImpedance

Returns the impedance of the internal grounding.

```
[int valid,
float resistance,
float reactance ] ElmTr4.GetGroundingImpedance(int busIdx)
```

ARGUMENTS

busIdx Bus index where the grounding should be determined.

resistance (out)

Real part of the grounding impedance in Ohm.

reactance (out)

Imaginary part of the grounding impedance in Ohm.

RETURNS

- 0** The values are invalid (e.g. because there is no internal grounding)
- 1** The values are valid.

GetSuppliedElements

Returns the network components that are supplied by the transformer.

A transformer is treated as supplying if it is located in a station. Transformers outside stations are not supplying in this sense.

A network component is considered to be supplied by a transformer if a topological path from the transformer to the component exists. A valid topological path in this sense is a path that starts at the transformer's HV side in direction of transformer (not in direction of HV connected node) and stops at

- network components that are out of calculation,
- network components that are not active (e.g. hidden or those of currently inactive grids),
- open switches,

- connections leading to a higher voltage level.

Generally all network components of such a path are considered to be supplied by the transformer. Exceptions are components that are out of calculation or in-active. Those components are never considered to be supplied by any transformer.

A transformer is never considered to supply itself.

Composite components such as *ElmBranch*, *ElmSubstat*, *ElmTrfstat* are considered to be supplied by a transformer if all energized components inside that composite are supplied by the transformer.

```
list ElmTr4.GetSuppliedElements([int inclNested])
```

ARGUMENTS

inclNested (optional)

- | | |
|----------|--|
| 0 | Only include components which are directly supplied by the transformer (not nested components) |
| 1 | Include nested components and components that are directly supplied by the transformer (default) |

RETURNS

Elements supplied by this transformer. The set is empty if the transformer is located outside a station or if no element is topologically connected its HV side.

SEE ALSO

[ElmTr2.GetSuppliedElements\(\)](#), [ElmSubstat.GetSuppliedElements\(\)](#),
[ElmTrfstat.GetSuppliedElements\(\)](#)

GetTapPhi

Gets the tap phase shift in deg of the transformer for given tap position and side.

```
float ElmTr4.GetTapPhi(int iSide,
                      int itappos,
                      int inclPhaseShift
                      )
```

ARGUMENTS

iSide for tap at side (0=HV, 1=LV1, 2=Lv2, 3=Lv3)

itappos Tap position for corresponding side

inclPhaseShift

1 = Includes the vector group phase shift, 0 = consider only the tap phase shift

RETURNS

Returns the tap phase shift angle of the transformer for given tap position and side

GetTapRatio

Gets the voltage ratio of the transformer for given tap position and side.

```
float ElmTr4.GetTapRatio(int iSide,
                        int itappos,
                        int includeNomRatio
                        )
```

ARGUMENTS

- iSide* for tap at side (0=HV, 1=LV1, 2=Lv2, 3=Lv3)
- itappos* Tap position at corresponding side
- includeNomRatio*
1 = Includes nominal ratio of the transformer, 0 = consider only tap ratio

RETURNS

Returns the voltage ratio of the transformer for given tap position and side

GetTapZDependentSide

Get tap side used for the dependent impedance

```
int ElmTr4.GetTapZDependentSide()
```

RETURNS

- 1** if no tap dependent impedance is defined
- 0** for HV tap
- 1** for LV1 tap
- 2** for LV2 tap
- 2** for LV3 tap

GetZ0pu

Gets the zero-sequence impedance in p.u. of the transformer for the specified tap position. If the tap position is out of the tap changer range, the respective min. or max. position will be used.

```
[float r0pu,
float x0pu ] ElmTr4.GetZ0pu(int itappos,
                             int iSide,
                             int systembase)
```

ARGUMENTS

- itappos* Tap position of the z-dependent tap
- iSide*
- 0** Get the HV-LV1 impedance.
 - 1** Get the HV-LV2 impedance.
 - 2** Get the HV-LV3 impedance.
 - 3** Get the LV1-LV2 impedance.
 - 4** Get the LV1-LV3 impedance.
 - 5** Get the LV2-LV3 impedance.

r0pu (out)
Resistance in p.u.

x0pu (out)
Reactance in p.u.

systembase

- 0** p.u. is based on rated power.
- 1** p.u. is based on system base (e.g. 100MVA).

GetZpu

Gets the impedance in p.u. of the transformer for the specified tap position. If the tap position is out of the tap changer range, the respective min. or max. position will be used.

```
[float rpu,
float xpu ] ElmTr4.GetZpu(int itappos,
                          int iSide,
                          int systembase)
```

ARGUMENTS

itappos Tap position of the z-dependent tap

iSide

- 0** Get the HV-LV1 impedance.
- 1** Get the HV-LV2 impedance.
- 2** Get the HV-LV3 impedance.
- 3** Get the LV1-LV2 impedance.
- 4** Get the LV1-LV3 impedance.
- 5** Get the LV2-LV3 impedance.

rpu (out) Resistance in p.u.

xpu (out) Reactance in p.u.

systembase

- 0** p.u. is based on rated power.
- 1** p.u. is based on system base (e.g. 100MVA).

IsQuadBooster

Returns whether transformer is a quadbooster or not, i.e. checks phase shift angle modulus 180°.

```
int ElmTr4.IsQuadBooster()
```

RETURNS

'1' if the transformer phase shift angle modulus 180° does not equal 0 at any of the sides HV, LV1, LV2, LV3, else '0'

NTap

Gets the transformer tap position.

```
int ElmTr4.NTap(float busIdx)
```

ARGUMENTS

busIdx 0=HV, 1=MV, 2=LV

RETURNS

The tap position.

5.2.39 ElmTrain

Overview

[SetPosition](#)

SetPosition

Set the position (line and position in km) of the train

```
int ElmTrain.SetPosition(DBObject* line, double position)
```

RETURNS

1	error, train position cannot be set
0	ok

5.2.40 ElmTrb

Overview

[GetGroundingImpedance](#)

GetGroundingImpedance

Returns the impedance of the internal grounding.

```
[int valid,
float resistance,
float reactance ] ElmTrb.GetGroundingImpedance(int busIdx)
```

ARGUMENTS

busIdx Bus index where the grounding should be determined.

resistance (out)
Real part of the grounding impedance in Ohm.

reactance (out)
Imaginary part of the grounding impedance in Ohm.

RETURNS

- 0** The values are invalid (e.g. because there is no internal grounding)
- 1** The values are valid.

5.2.41 ElmTrfstat

Overview

[GetSplit](#)
[GetSplitCal](#)
[GetSplitIndex](#)
[GetSuppliedElements](#)
[SaveAsSwSc](#)

GetSplit

A split of a station is a group of topologically connected elements. Such a group is called split if all contained components are energized and there is at least one busbar (terminal of usage 'busbar') contained or it has connections to at least two main components (= all components except switch devices and terminals).

These splits are ordered according to the count of nodes contained and according to their priority. So each split becomes a unique index.

The function `GetSplit` offers access to the elements contained in a split. By calling `GetSplit` with an index from 0 to n, the elements belonging to the corresponding split are filled into given sets and returned.

```
[int error
list mainNodes,
list connectionCubicles,
list allElements      ] ElmTrfstat.GetSplit(int index)
```

ARGUMENTS

index Index of the split used to access the elements of the corresponding split. Value must be ≥ 0 .

mainNodes (out)

Terminals of same usage considered to form the most important nodes for that group. In most cases, this is the group of contained busbars.

connectionCubicles (optional, out)

All cubicles (of terminals inside the station) that point to an element that sits outside the station or to an element that is connected to a terminal outside the station are filled into the set `connectionCubicles`. (The connection element (branch) can be accessed by calling `GetBranch()` on each of these cubicles. The terminals of these cubicles (parents) must not necessarily be contained in any split. They could also be separated by a disconnecting component.)

allElements(optional, out)

All elements (class `Elm*`) of the split that have no connection to elements outside the station are filled into this set.

RETURNS

- 0** success, split of that index exists and is returned.
- 1** indicates that there exists no split with given index. (Moreover, this means that there is no split with index n greater than this value.)

SEE ALSO

[ElmTrfstat.GetSplitCal\(\)](#), [ElmTrfstat.GetSplitIndex\(\)](#),

GetSplitCal

This function determines the elements that belong to a split. In contrast to [ElmTrfstat.GetSplit\(\)](#) it is based on calculation instead of pure edit object topology. This means the returned nodes correspond to the calculation nodes, the interconnecting cubicles are those connecting nodes of different splits.

Note: As this function relies on calculation nodes it can only be executed after a calculation has been performed (e.g. load flow calculation).

```
[int error,
list nodes,
list connectionCubicles,
list elements          ] ElmTrfstat.GetSplitCal(int index)
```

ARGUMENTS

- index* Index of the split used to access the elements of the corresponding split. Refers to same split as index in [ElmTrfstat.GetSplit\(\)](#). Value must be ≥ 0 .
- nodes (out)* A set that is filled with terminals. There is one terminal returned for each calculation node in the split.
- connectionCubicles (optional, out)* This set is filled with all cubicles that point from a calculation node of current split to another calculation node that does not belong to that split. The connecting element can be accessed by calling [GetBranch\(\)](#) on such a cubicle.
- elements (optional, out)* This set is filled with network elements that are connected to a calculation node of current split and have exactly one connection, i.e. these elements are completely contained in the split.

RETURNS

- 0** success, split of that index exists and is returned.
- 1** indicates that there exists no split with given index. (Moreover, this means that there is no split with index n greater than this value.)

SEE ALSO

[ElmTrfstat.GetSplit\(\)](#)

GetSplitIndex

This function returns the index of the split that contains passed object.

```
int ElmTrfstat.GetSplitIndex(DataObject o)
```

ARGUMENTS

o Object for which the split index is to be determined.

RETURNS

≥ 0 index of split in which element is contained
-1 given object does not belong to any split of that station

SEE ALSO

[ElmTrfstat.GetSplit\(\)](#)

GetSuppliedElements

Returns the network components that are supplied by the transformer (located in the station). A network component is considered to be supplied by a transformer if a topological path from the transformer to the component exists. A valid topological path in this sense is a path that starts at the transformer's HV side in direction of transformer (not in direction of HV connected node) and stops at

- network components that are out of calculation,
- network components that are not active (e.g. hidden or those of currently inactive grids),
- open switches,
- connections leading to a higher voltage level.

Generally, all network components of such a path are considered to be supplied by the transformer.

Exceptions are components that are out of calculation or in-active. Those components are never considered to be supplied by any transformer. A transformer is never considered to supply itself. Composite components such as ElmBranch, ElmSubstat, ElmTrfstat are considered to be supplied by a transformer if all energized components inside that composite are supplied by the transformer.

```
list ElmTrfstat.GetSuppliedElements([int inclNested])
```

ARGUMENTS

inclNested (optional)

0 Do not include components that are supplied by nested supplying stations
1 (default) Include components that are supplied by nested stations

SEE ALSO

[ElmTr2.GetSuppliedElements\(\)](#), [ElmTr3.GetSuppliedElements\(\)](#)

SaveAsSwSc

Create a Switching Rules object and assign to this station.

```
DataObject ElmTrfstat.SaveAsSwSc(str name)
```

ARGUMENTS

name The name of the created Switching Rules object.

RETURNS

The created Switching Rules object.

5.2.42 ElmTrmult

Overview

[CreateEvent](#)
[GetGroundingImpedance](#)
[GetSuppliedElements](#)
[GetTapPhi](#)
[GetTapRatio](#)
[GetZpu](#)
[IsQuadBooster](#)
[NTap](#)

CreateEvent

For the corresponding transformer, a Tap Event (EvtTap) is created for the simulation.

```
None ElmTrmult.CreateEvent([int tapAction = 2,]
                           [int tapPos = 0,]
                           )
```

ARGUMENTS

tapAction (optional)

0=increase tap; 1=decrease tap; 2=set tap to tapPos; 3>manual; 4=automatic

tapPos (optional)

Position of tap.

GetGroundingImpedance

Returns the impedance of the internal grounding.

```
[int valid,
 float resistance,
 float reactance ] ElmTrmult.GetGroundingImpedance(int busIdx)
```

ARGUMENTS

busIdx Bus index where the grounding should be determined.

resistance (out)

Real part of the grounding impedance in Ohm.

reactance (out)

Imaginary part of the grounding impedance in Ohm.

RETURNS

- 0** The values are invalid (e.g. because there is no internal grounding)
- 1** The values are valid.

GetSuppliedElements

Returns the network components that are supplied by the transformer.

A transformer is treated as supplying if it is located in a station. Transformers outside stations are not supplying in this sense.

A network component is considered to be supplied by a transformer if a topological path from the transformer to the component exists. A valid topological path in this sense is a path that starts at the transformer's HV side in direction of transformer (not in direction of HV connected node) and stops at

- network components that are out of calculation,
- network components that are not active (e.g. hidden or those of currently inactive grids),
- open switches,
- connections leading to a higher voltage level.

Generally all network components of such a path are considered to be supplied by the transformer. Exceptions are components that are out of calculation or in-active. Those components are never considered to be supplied by any transformer.

A transformer is never considered to supply itself.

Composite components such as *ElmBranch*, *ElmSubstat*, *ElmTrfstat* are considered to be supplied by a transformer if all energized components inside that composite are supplied by the transformer.

```
list ElmTrmult.GetSuppliedElements([int inclNested])
```

ARGUMENTS

inclNested (optional)

- | | |
|----------|--|
| 0 | Only include components which are directly supplied by the transformer (not nested components) |
| 1 | Include nested components and components that are directly supplied by the transformer (default) |

RETURNS

Elements supplied by this transformer. The set is empty if the transformer is located outside a station or if no element is topologically connected its HV side.

SEE ALSO

[ElmTr2.GetSuppliedElements\(\)](#), [ElmSubstat.GetSuppliedElements\(\)](#), [ElmTrfstat.GetSuppliedElements\(\)](#)

GetTapPhi

Gets the tap phase shift in deg of the transformer for given tap position and side.

```
float ElmTrmult.GetTapPhi(int iSide,
                          int itappos,
                          int inclPhaseShift
                          )
```

ARGUMENTS

iSide for tap at side *iSide*

itappos Tap position for corresponding side

inclPhaseShift

1 = Includes the vector group phase shift, 0 = consider only the tap phase shift

RETURNS

Returns the tap phase shift angle of the transformer for given tap position and side

GetTapRatio

Gets the voltage ratio of the transformer for given tap position and side.

```
float ElmTrmult.GetTapRatio(int iSide,
                           int itappos,
                           int includeNomRatio
                           )
```

ARGUMENTS

iSide for tap at side iSide

itappos Tap position at corresponding side

includeNomRatio

1 = Includes nominal ratio of the transformer, 0 = consider only tap ratio

RETURNS

Returns the voltage ratio of the transformer for given tap position and side

GetZpu

Gets the impedance in p.u. of the transformer between iSide1 and iSide2. The resistance is that of iSide1 winding.

```
[float rpu,
 float xpu ] ElmTrmult.GetZpu(int iSide1,
                              int iSide2,
                              int systembase)
```

ARGUMENTS

iSide1

iSide2

rpu (out) Resistance in p.u.

xpu (out) Reactance in p.u.

systembase

0 p.u. is based on rated power.

1 p.u. is based on system base (e.g. 100MVA).

IsQuadBooster

Returns whether transformer is a quadbooster or not, i.e. checks phase shift angle modulus 180°.

```
int ElmTrmult.IsQuadBooster()
```


RETURNS

'1' if the transformer phase shift angle modulus 180° does not equal 0, else '0'

NTap

Gets the transformer tap position.

```
int ElmTrmult.NTap()
```

RETURNS

The tap position.

5.2.43 ElmVac**Overview**

[GetGroundingImpedance](#)

GetGroundingImpedance

Returns the impedance of the internal grounding. Single phase voltage source connected to neutral are considered as grounding devices themselves; i.e. instead of the dedicated grounding parameters, the R1,X1 parameters are used.

```
[int valid,
float resistance,
float reactance ] ElmVac.GetGroundingImpedance(int busIdx)
```

ARGUMENTS

busIdx Bus index where the grounding should be determined.

resistance (out)
Real part of the grounding impedance in Ohm.

reactance (out)
Imaginary part of the grounding impedance in Ohm.

RETURNS

- 0** The values are invalid (e.g. because there is no internal grounding)
- 1** The values are valid.

5.2.44 ElmVoltreg

Overview

[CreateEvent](#)
[GetGroundingImpedance](#)
[GetZpu](#)
[NTap](#)

CreateEvent

For the corresponding voltage regulator, a Tap Event (EvtTap) is created for the simulation.

```
None ElmVoltreg.CreateEvent([int tapAction = 2,]
                           [float tapPos = 0]
                           )
```

ARGUMENTS

tapAction (optional)
 0=increase tap; 1=decrease tap; 2=set tap to tapPos; 3>manual; 4=automatic
tapPos (optional)
 Position of tap

GetGroundingImpedance

Returns the impedance of the internal grounding.

```
[int valid,
float resistance,
float reactance ] ElmVoltreg.GetGroundingImpedance(int busIdx)
```

ARGUMENTS

busIdx Bus index where the grounding should be determined.
resistance (out)
 Real part of the grounding impedance in Ohm.
reactance (out)
 Imaginary part of the grounding impedance in Ohm.

RETURNS

0 The values are invalid (e.g. because there is no internal grounding)
1 The values are valid.

GetZpu

Gets the impedance in p.u. of the voltage regulator for the specified tap position. If the tap position is out of the tap changer range, the respective min. or max. position will be used.

```
[float rpu,
float xpu ] ElmVoltreg.GetZpu(int itappos,
                             int systembase)
```

ARGUMENTS

itappos Tap position*rpu (out)* Resistance in p.u.*xpu (out)* Reactance in p.u.*systembase***0** p.u. is based on rated power.**1** p.u. is based on system base (e.g. 100MVA).**NTap**

Gets the voltage regulator tap position.

```
int ElmVltreg.NTap(int tap)
```

ARGUMENTS

tap 0=Tap 1, 1=Tap 2, 2=Tap 3

RETURNS

The tap position.

5.2.45 ElmVscmono**Overview**[GetGroundingImpedance](#)**GetGroundingImpedance**

Returns the impedance of the internal grounding. Only thhe DC side is considered to to be grounded.

```
[int valid,  
float resistance,  
float reactance ] ElmVscmono.GetGroundingImpedance(int busIdx)
```

ARGUMENTS

busIdx Bus index where the grounding should be determined.*resistance (out)*

Real part of the grounding impedance in Ohm.

reactance (out)

Imaginary part of the grounding impedance in Ohm.

RETURNS

- 0** The values are invalid (e.g. because there is no internal grounding)
- 1** The values are valid.

5.2.46 ElmXnet

Overview

[CalcEfficiency](#)
[Disconnect](#)
[GetGroundingImpedance](#)
[GetStepupTransformer](#)
[Reconnect](#)

CalcEfficiency

Calculate efficiency for connected storage model at given active power value.

```
float ElmXnet.CalcEfficiency(float activePowerMW)
```

ARGUMENTS

activePowerMW
Active power value to calculate efficiency for.

RETURNS

Returns the resulting efficiency in p.u.

Disconnect

Disconnects a static generator by opening the first circuit breaker. The topological search performed to find such a breaker, stops at any busbar.

```
int ElmXnet.Disconnect()
```

RETURNS

- 0** breaker already open or successfully opened
- 1** an error occurred (no breaker found, open action not possible (earthing / RA))

GetGroundingImpedance

Returns the impedance of the internal grounding.

```
[int valid,  
float resistance,  
float reactance ] ElmXnet.GetGroundingImpedance(int busIdx)
```

ARGUMENTS

busIdx Bus index where the grounding should be determined.

resistance (out)
Real part of the grounding impedance in Ohm.

reactance (out)
Imaginary part of the grounding impedance in Ohm.

RETURNS

- 0** The values are invalid (e.g. because there is no internal grounding)
- 1** The values are valid.

GetStepupTransformer

Performs a topological search to find the step-up transformer of an external grid

```
DataObject ElmXnet.GetStepupTransformer(float voltage,
                                         int swStatus
                                         )
```

ARGUMENTS

voltage voltage level at which the search will stop

swStatus consideration of switch status. Possible values are:

- 0** consider all switch status
- 1** ignore breaker status
- 2** ignore all switch status

RETURNS

Returns the first collected step-up transformer object. It is empty if not found (e.g. start terminal already at hvVoltage).

Reconnect

Connects a static generator by closing all switches (breakers and isolators) up to the first breaker on the HV side of a transformer. The topological search to find all the switches, stops at any busbar.

```
int ElmXnet.Reconnect()
```

RETURNS

- 0** the machine was successfully closed
- 1** a error occurred and the machine could not be connected to any busbar

5.2.47 ElmZone

Overview

[CalculateInterchangeTo](#)
[CalculateVoltageLevel](#)
[CalculateVoltInterVolt](#)
[DefineBoundary](#)
[GetAll](#)
[GetBranches](#)
[GetBuses](#)
[GetObjs](#)
[SetLoadScaleAbsolute](#)

CalculateInterchangeTo

Calculates interchange power to the given zone (calculated quantities are: Pinter, Qinter, Pexport, Qexport, Pimport, Qimport). Prior the calculation the valid load flow calculation is required.

```
int ElmZone.CalculateInterchangeTo(DataObject zone)
```

ARGUMENTS

zone zone to which the interchange is calculated

RETURNS

< 0 calculation error (i.e. no valid load flow, empty zone...)
0 no interchange power to the given zone
1 interchange power calculated

CalculateVoltageLevel

Internal function to calculate per voltage level the corresponding summary results. The values are stored in current zone (values from the previous load flow calculation are overwritten):

```
int ElmZone.CalculateVoltageLevel(double U)
```

ARGUMENTS

U for voltage level (in kV)

RETURNS

< 0 error
= 0 voltage level not exists in the zone
> 0 ok

CalculateVoltInterVolt

This function calculates the power flow from voltage level to voltage level. The values are stored in current area in the following attributes (values from the previous load flow calculation are overwritten):

- Pinter: Active Power Flow
- Qinter: Reactive Power Flow
- ExportP: Export Active Power Flow
- ExportQ: Export Reactive Power Flow
- ImportP: Import Active Power Flow
- ImportQ: Import Reactive Power Flow

```
int ElmZone.CalculateVoltInterVolt(double Ufrom,
                                   double Uto)
```

ARGUMENTS

Ufrom from voltage level (in kV)

Uto to voltage level (in kV)

RETURNS

- < 0 error
- = 0 voltage levels not exists in the area, no interchange exists
- > 0 ok

DefineBoundary

Defines boundary with this zone as interior part. Resulting cubicles of boundary are busbar-oriented towards the zone.

```
DataObject ElmZone.DefineBoundary(int shift)
```

ARGUMENTS

shift Elements outside the zone that are within a distance of shift many elements to a boundary cubicle of the zone are added to the interior part of the resulting boundary

RETURNS

The defined boundary is returned in case of success. Otherwise None, if an error appeared in the definition of the boundary.

GetAll

Returns all objects which belong to this zone.

```
list ElmZone.GetAll()
```

RETURNS

The set of objects.

GetBranches

Returns all branches which belong to this zone.

```
list ElmZone.GetBranches()
```

RETURNS

The set of branch objects.

GetBuses

Returns all buses which belong to this zone.

```
list ElmZone.GetBuses()
```

RETURNS

The set of objects.

GetObjs

Returns all objects of the given class which belong to this zone.

```
list ElmZone.GetObjs(str classname)
```

ARGUMENTS

classname
name of the class (i.e. "ElmTr2")

RETURNS

The set of contained objects.

SetLoadScaleAbsolute

Readjusts zonal load scaling factor to the given active power. The zonal load scaling factor is the ratio of the given active power and the loads total actual power.

```
None ElmZone.SetLoadScaleAbsolute(float Pin)
```

ARGUMENTS

Pin active power in MW used for the load scaling factor.

5.3 Station Elements

5.3.1 StaCombi

Overview

[SetPrimaryCtTap](#)
[SetPrimaryVtTap](#)

SetPrimaryCtTap

Determines the best matching primary CT tap for the connected branch, so that $I_{Nom,Branch} \cdot safety \leq I_{Pri}$. If no tap satisfies the equation, the largest tap is used.

```
int StaCombi.SetPrimaryCtTap([float safety])
```

ARGUMENTS

safety (optional)
 Safety factor (default 1.0)

RETURNS

0 Correctly set.
1 Error.

SetPrimaryVtTap

Determines the best matching primary VT tap for the connected node, so that $U_{Nom,Node} \cdot safety \leq U_{Pri}$. If no tap satisfies the equation, the largest tap is used.

```
int StaCombi.SetPrimaryVtTap([float safety])
```

ARGUMENTS

safety (optional)
 Safety factor (default 1.0)

RETURNS

0 Correctly set.
1 Error.

5.3.2 StaCt

Overview

[SetPrimaryTap](#)

SetPrimaryTap

Determines the best matching primary tap for the connected branch, so that $I_{Nom,Branch} \cdot safety \leq I_{pri}$. If no tap satisfies the equation, the largest tap is used.

```
int StaCt.SetPrimaryTap([float safety])
```

ARGUMENTS

safety (optional)
Safety factor (default 1.0)

RETURNS

0 Correctly set.
1 Error.

5.3.3 StaCubic

Overview

[GetAll](#)
[GetBranch](#)
[GetConnectedMajorNodes](#)
[GetConnections](#)
[GetNearestBusbars](#)
[GetPathToNearestBusbar](#)
[IsClosed](#)
[IsConnected](#)

GetAll

This function returns a set of network components that are collected by a topological traversal starting from this cubicle.

```
list StaCubic.GetAll([int direction = 1,]  
                    [int ignoreOpenSwitches = 0]  
                    )
```

ARGUMENTS

direction (optional)
Specifies the direction in which the network topology is traversed.

1 Traversal to the branch element (default).
0 Traversal to the terminal element.

ignoreOpenSwitches (optional)
Determines whether to pass open switches or to stop at them.

0 The traversal stops in a direction if an open switch is reached (default).
1 Ignore all switch statuses and pass every switch.

RETURNS

A set of network components that are collected by a topological traversal starting at the cubicle (StaCubic) where the function is called.

GetBranch

Function gets the branch of this cubicle.

```
DataObject StaCubic.GetBranch()
```

RETURNS

Branch object.

GetConnectedMajorNodes

This function returns all busbars being part of a split (inside a station) that can be reached by starting a topology search from the cubicle in direction of the branch element.

```
list StaCubic.GetConnectedMajorNodes ([float swtStat])
```

ARGUMENTS

swtStat

- 0 (default)** First perform a search that respects switch states (stopping at open switches). If no switches are found, an additional search with ignoring switch states.
- 1** Perform one search ignoring switch states (passing open and closed switches).
- 2** Search with respecting switch states. But do no additional search when switch is found.

RETURNS

A set of all busbars that can be reached starting a topology search from the cubicle in direction of the branch element.

GetConnections

Function gets all elements connected with this cubicle.

```
list StaCubic.GetConnections (int swtStat)
```

ARGUMENTS

swtStat Consider switch status (1) or not (0).

RETURNS

Set of elements.

GetNearestBusbars

Function searches for connected and connectable nearest busbars starting at the cubicle. Search stops at the nearest busbars and out of service elements. Internal and junction nodes, all types of branch elements and all types of switches - i.e. circuit breakers and disconnectors - are passed.

Connected busbars are all busbars which are topologically connected to the start cubicle passing at least one closed switch and stopping at open switches. Connectable busbars are all busbars which are connectable to the start cubicle by closing switches. If the start cubicles terminal is a busbar then this busbar is not included in the result sets.

If more than one path exists between cubicle and a nearest busbar the relevant busbar is added only once to the result set.

```
[list connectedBusbars,
list connectableBusbars] StaCubic.GetNearestBusbars(int searchDirection, [int excludeZPUs])
```

ARGUMENTS

connectedBusbars (out)

Found connected busbars.

connectableBusbars (out)

Found connectable busbars.

searchDirection

Direction of the search relative to the cubicle. Possible values are

- 0** search in all directions
- 1** search in direction of cubicles terminal
- 2** search towards connected branch element

excludeZPUs (optional)

Whether ZPU (ElmZpu) should be ignored in the search. Default=0.

GetPathToNearestBusbar

Function determines the path from the cubicle to the given busbar. The busbar must be connected or connectable to the start cubicle without passing additional busbars. If the given busbar is not a nearest busbar in relation to the cubicle an empty path is returned.

If more than one closed path exists between cubicle and busbar the elements of all these paths are combined.

```
list StaCubic.GetPathToNearestBusbar(DataObject nearestBusbar,
[int excludeZPUs])
```

ARGUMENTS

nearestBusbar

Nearest busbar in relation to cubicle.

excludeZPUs (optional)

Whether ZPU (ElmZpu) should be ignored in the search. Default=0.

RETURNS

Net elements of the path from cubicle to busbar.

IsClosed

Function checks if this cubicle is directly connected with the busbar, considering the switch status.

```
int StaCubic.IsClosed()
```

RETURNS

- 0** Disconnected cubicle.
- 1** Connected cubicle.

IsConnected

Function checks if the cubicle is connected to the passed terminal or coupler.

```
int StaCubic.IsConnected(DataObject elm,
                          int swtStat
                          )
```

ARGUMENTS

- elm* Terminal or coupler to check connection with.
- swtStat* Consider switch status (1) or not (0).

RETURNS

- 0** Not connected.
- 1** Connected.

5.3.4 StaExtbrkmea**Overview**

- CopyExtMeaStatusToStatusTmp
- GetMeaValue
- GetStatus
- GetStatusTmp
- InitTmp
- IsStatusBitSet
- IsStatusBitSetTmp
- ResetStatusBit
- ResetStatusBitTmp
- SetMeaValue
- SetStatus
- SetStatusBit
- SetStatusBitTmp
- SetStatusTmp
- UpdateControl
- UpdateCtrl

CopyExtMeaStatusToStatusTmp

Copies the (persistent) status of current measurement object to temporary (in memory) status.

```
None StaExtbrkmea.CopyExtMeaStatusToStatusTmp()
```

GetMeaValue

Returns the value for the switch position currently stored in the measurement object.

```
[int error,
float value] StaExtbrkmea.GetMeaValue()
```

ARGUMENTS

value (out)
Value for switch status.

RETURNS

0 on success
1 error searching position in mapping table

GetStatus

Returns the status flags. Please note, this value is interpreted as a bitfield. See [StaExtbrkmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtbrkmea.GetStatuts()
```

RETURNS

Status bitfield as an integer value.

GetStatusTmp

Returns the temporary (in memory) status flags. Please note, this value is interpreted as a bitfield. See [StaExtbrkmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtbrkmea.GetStatusTmp()
```

RETURNS

Status bitfield as an integer value.

InitTmp

Initialises the temporary (in memory) fields of the measurement object with the values currently stored in the corresponding persistent fields. This affects temporary measurement value and temporary status fields. The temporary measurement value is used internally for comparison of new and old values for deadband violation. The temporary status is used during calculation in order to not modify initial value.

This function should be called once after the link has been established and before the calculation loop is executed.

```
None StaExtbrkmea.InitTmp()
```

IsStatusBitSet

Checks if specific bit(s) are set in the status bitfield. See [StaExtbrkmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtbrkmea.IsStatusBitSet(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

IsStatusBitSetTmp

Checks if specific bit(s) are set in the temporary (in memory) status bitfield. See [StaExtbrkmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtbrkmea.IsStatusBitSetTmp(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

ResetStatusBit

Resets specific bits in the status bitfield. See [StaExtbrkmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtbrkmea.ResetStatusBit(int mask, int dbSync)
```

ARGUMENTS

mask Mask of bits to set to 0. A bit is unchanged if already unset before.

dbSync (optional)

- 0** New status flags are applied in memory only
- 1** Default, new status flags are stored on db (persistent)

ResetStatusBitTmp

Resets specific bits in the temporary (in memory) status bitfield. See [StaExtbrkmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtbrkmea.ResetStatusBitTmp(int mask)
```

ARGUMENTS

mask Mask of bits to set to 0. A bit is unchanged if already unset before.

SetMeaValue

Sets the value for the switch position currently stored in the measurement object.

```
int StaExtbrkmea.SetMeaValue(int value)
```

ARGUMENTS

value New value for switch status.

RETURNS

Return value has no meaning. It is always 0.

SetStatus

Sets the status flags of the measurement object. Please note, this value is interpreted as a bitfield where the bits have the following meaning. An option is considered enabled if the corresponding bit is set to 1.

bit0 0x00000001 Manually entered data

bit1 0x00000002 Tele-Measurement

bit2 0x00000004 Disturbance

bit3 0x00000008 Protection

bit4 0x00000010 Marked suspect

bit5 0x00000020 Violated constraint

bit6 0x00000040 On Event

bit7 0x00000080 Event Block.

bit8 0x00000100 Alarm Block.

bit9 0x00000200 Update Block.

bit10 0x00000400 Control Block.

bit29 0x20000000 Read

bit30 0x40000000 Write

bit31 0x80000000 Neglected by SE

```
None StaExtbrkmea.SetStatus(int status, int dbSync)
```

ARGUMENTS

status Bitfield for status flags, see above

dbSync (optional)

0 New status flags are applied in memory only

1 Default, new status flags are stored on db (persistent)

SetStatusBit

Sets specific bits in the status bitfield. See [StaExtbrkmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtbrkmea.SetStatusBit(int mask, int dbSync)
```


ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

dbSync (optional)

0 New status flags are applied in memory only

1 Default, new status flags are stored on db (persistent)

SetStatusBitTmp

Sets specific bits in the temporary (in memory) status bitfield. See [StaExtbrkmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtbrkmea.SetStatusBitTmp(int mask)
```

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

SetStatusTmp

Sets the temporary (in memory) status flags of the measurement object. This temporary value is used during calculations so that changes do not lead to object modifications and initial value remains unchanged.

Please note, this value is interpreted as a bitfield. See [StaExtbrkmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtbrkmea.SetStatusTmp(int status)
```

ARGUMENTS

status Bitfield for status flags, see above

UpdateControl

Transfers the value of current measurement object to the controller object (target object 'pCtrl' and target attribute 'varName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExtbrkmea.UpdateControl(int dbSync)
```

ARGUMENTS

dbSync (optional)

0 Value is copied in memory only

1 Default, copied value is stored on db (persistent)

RETURNS

0 on success

1 on error, e.g. target object does not have an attribute with given name

UpdateCtrl

Transfers the value of current measurement object to the controlled object (target object 'pObject' and target attribute 'variabName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExtbrkmea.UpdateCtrl(int dbSync)
```

ARGUMENTS

dbSync (optional)

- | | |
|----------|--|
| 0 | Value is copied in memory only |
| 1 | Default, copied value is stored on db (persistent) |

RETURNS

- | | |
|----------|---|
| 0 | on success |
| 1 | on error, e.g. target object does not have an attribute with given name |

5.3.5 StaExtcmdmea

Overview

[CopyExtMeaStatusToStatusTmp](#)
[CreateEvent](#)
[GetMeaValue](#)
[GetStatus](#)
[GetStatusTmp](#)
[InitTmp](#)
[IsStatusBitSet](#)
[IsStatusBitSetTmp](#)
[ResetStatusBit](#)
[ResetStatusBitTmp](#)
[SetMeaValue](#)
[SetStatus](#)
[SetStatusBit](#)
[SetStatusBitTmp](#)
[SetStatusTmp](#)
[UpdateControl](#)
[UpdateCtrl](#)

CopyExtMeaStatusToStatusTmp

Copies the (persistent) status of current measurement object to temporary (in memory) status.

```
None StaExtcmdmea.CopyExtMeaStatusToStatusTmp()
```

CreateEvent

Creates a parameter event (EvtParam) into the simulation event queue for 'Variable' name and the corresponding 'Measurement Value' for the value of the event.

```
int StaExtcmdmea.CreateEvent()
```

GetMeaValue

Returns the value for command interpreted as floating point value.

```
[int error,  
float value] StaExtcmdmea.GetMeaValue()
```

ARGUMENTS

value (out)

Value obtained by parsing stored command string as floating point value.

RETURNS

Return value has no meaning. It is always 0.

GetStatus

Returns the status flags. Please note, this value is interpreted as a bitfield. See [StaExtcmdmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtcmdmea.GetStatuts()
```

RETURNS

Status bitfield as an integer value.

GetStatusTmp

Returns the temporary (in memory) status flags. Please note, this value is interpreted as a bitfield. See [StaExtcmdmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtcmdmea.GetStatusTmp()
```

RETURNS

Status bitfield as an integer value.

InitTmp

Initialises the temporary (in memory) fields of the measurement object with the values currently stored in the corresponding persistent fields. This affects temporary measurement value and temporary status fields. The temporary measurement value is used internally for comparison of new and old values for deadband violation. The temporary status is used during calculation in order to not modify initial value.

This function should be called once after the link has been established and before the calculation loop is executed.

```
None StaExtcmdmea.InitTmp()
```

IsStatusBitSet

Checks if specific bit(s) are set in the status bitfield. See [StaExtcmdmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtcmdmea.IsStatusBitSet(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

IsStatusBitSetTmp

Checks if specific bit(s) are set in the temporary (in memory) status bitfield. See [StaExtcmdmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtcmdmea.IsStatusBitSetTmp(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

ResetStatusBit

Resets specific bits in the status bitfield. See [StaExtcmdmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtcmdmea.ResetStatusBit(int mask, int dbSync)
```

ARGUMENTS

- mask* Mask of bits to set to 0. A bit is unchanged if already unset before.
- dbSync (optional)*
 - 0** New status flags are applied in memory only
 - 1** Default, new status flags are stored on db (persistent)

ResetStatusBitTmp

Resets specific bits in the temporary (in memory) status bitfield. See [StaExtcmdmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtcmdmea.ResetStatusBitTmp(int mask)
```

ARGUMENTS

- mask* Mask of bits to set to 0. A bit is unchanged if already unset before.

SetMeaValue

Sets the value stored in the measurement object.

```
int StaExtcmdmea.SetMeaValue(float value)
```

ARGUMENTS

- value* New value.

RETURNS

Return value has no meaning. It is always 0.

SetStatus

Sets the status flags of the measurement object. Please note, this value is interpreted as a bitfield where the bits have the following meaning. An option is considered enabled if the corresponding bit is set to 1.

bit0 0x00000001 Manually entered data

bit1 0x00000002 Tele-Measurement

bit2 0x00000004 Disturbance

bit3 0x00000008 Protection

bit4 0x00000010 Marked suspect

bit5 0x00000020 Violated constraint

bit6 0x00000040 On Event

bit7 0x00000080 Event Block.

bit8 0x00000100 Alarm Block.

bit9 0x00000200 Update Block.

bit10 0x00000400 Control Block.

bit29 0x20000000 Read

bit30 0x40000000 Write

bit31 0x80000000 Neglected by SE

```
None StaExtcmdmea.SetStatus(int status, int dbSync)
```

ARGUMENTS

status Bitfield for status flags, see above

dbSync (optional)

0 New status flags are applied in memory only

1 Default, new status flags are stored on db (persistent)

SetStatusBit

Sets specific bits in the status bitfield. See [StaExtcmdmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtcmdmea.SetStatusBit(int mask, int dbSync)
```

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

dbSync (optional)

0 New status flags are applied in memory only

1 Default, new status flags are stored on db (persistent)

SetStatusBitTmp

Sets specific bits in the temporary (in memory) status bitfield. See [StaExtcmdmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtcmdmea.SetStatusBitTmp(int mask)
```

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

SetStatusTmp

Sets the temporary (in memory) status flags of the measurement object. This temporary value is used during calculations so that changes do not lead to object modifications and initial value remains unchanged.

Please note, this value is interpreted as a bitfield. See [StaExtcmdmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtcmdmea.SetStatusTmp(int status)
```

ARGUMENTS

status Bitfield for status flags, see above

UpdateControl

Transfers the value of current measurement object to the controller object (target object 'pCtrl' and target attribute 'varName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExtcmdmea.UpdateControl(int dbSync)
```

ARGUMENTS

dbSync (optional)

0 Value is copied in memory only

1 Default, copied value is stored on db (persistent)

RETURNS

0 on success

1 on error, e.g. target object does not have an attribute with given name

UpdateCtrl

Transfers the value of current measurement object to the controlled object (target object 'pObject' and target attribute 'variabName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExtcmdmea.UpdateCtrl(int dbSync)
```

ARGUMENTS

dbSync (optional)

- | | |
|----------|--|
| 0 | Value is copied in memory only |
| 1 | Default, copied value is stored on db (persistent) |

RETURNS

- | | |
|----------|---|
| 0 | on success |
| 1 | on error, e.g. target object does not have an attribute with given name |

5.3.6 StaExtdatmea

Overview

[CopyExtMeaStatusToStatusTmp](#)
[CreateEvent](#)
[GetMeaValue](#)
[GetStatus](#)
[GetStatusTmp](#)
[InitTmp](#)
[IsStatusBitSet](#)
[IsStatusBitSetTmp](#)
[ResetStatusBit](#)
[ResetStatusBitTmp](#)
[SetMeaValue](#)
[SetStatus](#)
[SetStatusBit](#)
[SetStatusBitTmp](#)
[SetStatusTmp](#)
[UpdateControl](#)
[UpdateCtrl](#)

CopyExtMeaStatusToStatusTmp

Copies the (persistent) status of current measurement object to temporary (in memory) status.

```
None StaExtdatmea.CopyExtMeaStatusToStatusTmp()
```

CreateEvent

Creates a “parameter change” event for controller object ('pCtrl') and attribute ('varName'). The event is stored in simulation event list and executed immediately.

```
None StaExtdatmea.CreateEvent()
```

GetMeaValue

Returns the value stored in the measurement object.

```
[int error,
float value] StaExtDatMea.GetMeaValue([int unused,]
                                     [int applyMultiplier])
```

ARGUMENTS

value (out)

Value, optionally modified by configured multiplier

unused (optional)

Not used.

applyMultiplier (optional)

If 1 (default), returned value will be modified by the multiplier stored in the measurement object (depending on Mode incremental/absolute). If 0, raw value will be returned.

RETURNS

Return value has no meaning. It is always 0.

GetStatus

Returns the status flags. Please note, this value is interpreted as a bitfield. See [StaExtDatMea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtDatMea.GetStatus()
```

RETURNS

Status bitfield as an integer value.

GetStatusTmp

Returns the temporary (in memory) status flags. Please note, this value is interpreted as a bitfield. See [StaExtDatMea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtDatMea.GetStatusTmp()
```

RETURNS

Status bitfield as an integer value.

InitTmp

Initialises the temporary (in memory) fields of the measurement object with the values currently stored in the corresponding persistent fields. This affects temporary measurement value and temporary status fields. The temporary measurement value is used internally for comparison of new and old values for deadband violation. The temporary status is used during calculation in order to not modify initial value.

This function should be called once after the link has been established and before the calculation loop is executed.

```
None StaExtDatMea.InitTmp()
```


IsStatusBitSet

Checks if specific bit(s) are set in the status bitfield. See [StaExtdatmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtdatmea.IsStatusBitSet(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

IsStatusBitSetTmp

Checks if specific bit(s) are set in the temporary (in memory) status bitfield. See [StaExtdatmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtdatmea.IsStatusBitSetTmp(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

ResetStatusBit

Resets specific bits in the status bitfield. See [StaExtdatmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtdatmea.ResetStatusBit(int mask, int dbSync)
```

ARGUMENTS

mask Mask of bits to set to 0. A bit is unchanged if already unset before.

dbSync (optional)

- 0** New status flags are applied in memory only
- 1** Default, new status flags are stored on db (persistent)

ResetStatusBitTmp

Resets specific bits in the temporary (in memory) status bitfield. See [StaExtdatmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtdatmea.ResetStatusBitTmp(int mask)
```

ARGUMENTS

mask Mask of bits to set to 0. A bit is unchanged if already unset before.

SetMeaValue

Sets the value stored in the measurement object.

```
int StaExtdatmea.SetMeaValue(float value)
```

ARGUMENTS

value New value.

RETURNS

Return value has no meaning. It is always 0.

SetStatus

Sets the status flags of the measurement object. Please note, this value is interpreted as a bitfield where the bits have the following meaning. An option is considered enabled if the corresponding bit is set to 1.

bit0 0x00000001 Manually entered data

bit1 0x00000002 Tele-Measurement

bit2 0x00000004 Disturbance

bit3 0x00000008 Protection

bit4 0x00000010 Marked suspect

bit5 0x00000020 Violated constraint

bit6 0x00000040 On Event

bit7 0x00000080 Event Block.

bit8 0x00000100 Alarm Block.

bit9 0x00000200 Update Block.

bit10 0x00000400 Control Block.

bit29 0x20000000 Read

bit30 0x40000000 Write

bit31 0x80000000 Neglected by SE

```
None StaExtDatmea.SetStatus(int status, int dbSync)
```

ARGUMENTS

status Bitfield for status flags, see above

dbSync (optional)

0 New status flags are applied in memory only

1 Default, new status flags are stored on db (persistent)

SetStatusBit

Sets specific bits in the status bitfield. See [StaExtDatmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtDatmea.SetStatusBit(int mask, int dbSync)
```

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

dbSync (optional)

0 New status flags are applied in memory only

1 Default, new status flags are stored on db (persistent)

SetStatusBitTmp

Sets specific bits in the temporary (in memory) status bitfield. See [StaExtdatmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtdatmea.SetStatusBitTmp(int mask)
```

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

SetStatusTmp

Sets the temporary (in memory) status flags of the measurement object. This temporary value is used during calculations so that changes do not lead to object modifications and initial value remains unchanged.

Please note, this value is interpreted as a bitfield. See [StaExtdatmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtdatmea.SetStatusTmp(int status)
```

ARGUMENTS

status Bitfield for status flags, see above

UpdateControl

Transfers the value of current measurement object to the controller object (target object 'pCtrl' and target attribute 'varName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExtdatmea.UpdateControl(int dbSync)
```

ARGUMENTS

dbSync (optional)

0 Value is copied in memory only

1 Default, copied value is stored on db (persistent)

RETURNS

0 on success

1 on error, e.g. target object does not have an attribute with given name

UpdateCtrl

Transfers the value of current measurement object to the controlled object (target object 'pObject' and target attribute 'variabName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExtDatMea.UpdateCtrl(int dbSync)
```

ARGUMENTS

dbSync (optional)

- | | |
|----------|--|
| 0 | Value is copied in memory only |
| 1 | Default, copied value is stored on db (persistent) |

RETURNS

- | | |
|----------|---|
| 0 | on success |
| 1 | on error, e.g. target object does not have an attribute with given name |

5.3.7 StaExtfmea

Overview

[CopyExtMeaStatusToStatusTmp](#)
[GetMeaValue](#)
[GetStatus](#)
[GetStatusTmp](#)
[InitTmp](#)
[IsStatusBitSet](#)
[IsStatusBitSetTmp](#)
[ResetStatusBit](#)
[ResetStatusBitTmp](#)
[SetMeaValue](#)
[SetStatus](#)
[SetStatusBit](#)
[SetStatusBitTmp](#)
[SetStatusTmp](#)
[UpdateControl](#)
[UpdateCtrl](#)

CopyExtMeaStatusToStatusTmp

Copies the (persistent) status of current measurement object to temporary (in memory) status.

```
None StaExtfmea.CopyExtMeaStatusToStatusTmp()
```

GetMeaValue

Returns the value for frequency currently stored in the measurement object.

```
[int error,  
float value] StaExtfmea.GetMeaValue()
```

ARGUMENTS

value (out)
Value for frequency.

RETURNS

Return value has no meaning. It is always 0.

GetStatus

Returns the status flags. Please note, this value is interpreted as a bitfield. See [StaExtfmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtfmea.GetStatuts()
```

RETURNS

Status bitfield as an integer value.

GetStatusTmp

Returns the temporary (in memory) status flags. Please note, this value is interpreted as a bitfield. See [StaExtfmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtfmea.GetStatusTmp()
```

RETURNS

Status bitfield as an integer value.

InitTmp

Initialises the temporary (in memory) fields of the measurement object with the values currently stored in the corresponding persistent fields. This affects temporary measurement value and temporary status fields. The temporary measurement value is used internally for comparison of new and old values for deadband violation. The temporary status is used during calculation in order to not modify initial value.

This function should be called once after the link has been established and before the calculation loop is executed.

```
None StaExtfmea.InitTmp()
```

IsStatusBitSet

Checks if specific bit(s) are set in the status bitfield. See [StaExtfmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtfmea.IsStatusBitSet(int mask)
```

RETURNS

0	if at least one bit in mask is not set
1	if all bit(s) in mask are set

IsStatusBitSetTmp

Checks if specific bit(s) are set in the temporary (in memory) status bitfield. See [StaExtfmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtfmea.IsStatusBitSetTmp(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

ResetStatusBit

Resets specific bits in the status bitfield. See [StaExtfmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtfmea.ResetStatusBit(int mask, int dbSync)
```

ARGUMENTS

- mask* Mask of bits to set to 0. A bit is unchanged if already unset before.
- dbSync (optional)*
 - 0** New status flags are applied in memory only
 - 1** Default, new status flags are stored on db (persistent)

ResetStatusBitTmp

Resets specific bits in the temporary (in memory) status bitfield. See [StaExtfmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtfmea.ResetStatusBitTmp(int mask)
```

ARGUMENTS

- mask* Mask of bits to set to 0. A bit is unchanged if already unset before.

SetMeaValue

Sets the value stored in the measurement object.

```
int StaExtfmea.SetMeaValue(float value)
```

ARGUMENTS

- value* New value.

RETURNS

- Return value has no meaning. It is always 0.

SetStatus

Sets the status flags of the measurement object. Please note, this value is interpreted as a bitfield where the bits have the following meaning. An option is considered enabled if the corresponding bit is set to 1.

bit0 0x00000001 Manually entered data

bit1 0x00000002 Tele-Measurement

bit2 0x00000004 Disturbance

bit3 0x00000008 Protection

bit4 0x00000010 Marked suspect

bit5 0x00000020 Violated constraint

bit6 0x00000040 On Event

bit7 0x00000080 Event Block.

bit8 0x00000100 Alarm Block.

bit9 0x00000200 Update Block.

bit10 0x00000400 Control Block.

bit29 0x20000000 Read

bit30 0x40000000 Write

bit31 0x80000000 Neglected by SE

```
None StaExtfmea.SetStatus(int status, int dbSync)
```

ARGUMENTS

status Bitfield for status flags, see above

dbSync (optional)

0 New status flags are applied in memory only

1 Default, new status flags are stored on db (persistent)

SetStatusBit

Sets specific bits in the status bitfield. See [StaExtfmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtfmea.SetStatusBit(int mask, int dbSync)
```

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

dbSync (optional)

0 New status flags are applied in memory only

1 Default, new status flags are stored on db (persistent)

SetStatusBitTmp

Sets specific bits in the temporary (in memory) status bitfield. See [StaExtfmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtfmea.SetStatusBitTmp(int mask)
```

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

SetStatusTmp

Sets the temporary (in memory) status flags of the measurement object. This temporary value is used during calculations so that changes do not lead to object modifications and initial value remains unchanged.

Please note, this value is interpreted as a bitfield. See [StaExtfmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtfmea.SetStatusTmp(int status)
```

ARGUMENTS

status Bitfield for status flags, see above

UpdateControl

Transfers the value of current measurement object to the controller object (target object 'pCtrl' and target attribute 'varName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExtfmea.UpdateControl(int dbSync)
```

ARGUMENTS

dbSync (optional)

- | | |
|----------|--|
| 0 | Value is copied in memory only |
| 1 | Default, copied value is stored on db (persistent) |

RETURNS

- | | |
|----------|---|
| 0 | on success |
| 1 | on error, e.g. target object does not have an attribute with given name |

UpdateCtrl

Transfers the value of current measurement object to the controlled object (target object 'pObject' and target attribute 'variabName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExtfmea.UpdateCtrl(int dbSync)
```


ARGUMENTS

dbSync (optional)

- | | |
|----------|--|
| 0 | Value is copied in memory only |
| 1 | Default, copied value is stored on db (persistent) |

RETURNS

- | | |
|----------|---|
| 0 | on success |
| 1 | on error, e.g. target object does not have an attribute with given name |

5.3.8 StaExtfuelmea

Overview

[CopyExtMeaStatusToStatusTmp](#)
[GetMeaValue](#)
[GetStatus](#)
[GetStatusTmp](#)
[InitTmp](#)
[IsStatusBitSet](#)
[IsStatusBitSetTmp](#)
[ResetStatusBit](#)
[ResetStatusBitTmp](#)
[SetMeaValue](#)
[SetStatus](#)
[SetStatusBit](#)
[SetStatusBitTmp](#)
[SetStatusTmp](#)
[UpdateControl](#)
[UpdateCtrl](#)

CopyExtMeaStatusToStatusTmp

Copies the (persistent) status of current measurement object to temporary (in memory) status.

```
None StaExtfuelmea.CopyExtMeaStatusToStatusTmp()
```

GetMeaValue

Returns the value for fuel currently stored in the measurement object.

```
[int error,
float value] StaExtfuelmea.GetMeaValue([int unused,]
                                         [int applyMultiplier])
```

ARGUMENTS

value (out)

Value for fuel, optionally multiplied by configured multiplier

unused (optional)

Not used.

applyMultiplier (optional)

If 1 (default), returned value will be multiplied by the multiplier stored in the measurement object. If 0, raw value will be returned.

RETURNS

Return value has no meaning. It is always 0.

GetStatus

Returns the status flags. Please note, this value is interpreted as a bitfield. See [StaExtfuelmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtfuelmea.GetStatuts()
```

RETURNS

Status bitfield as an integer value.

GetStatusTmp

Returns the temporary (in memory) status flags. Please note, this value is interpreted as a bitfield. See [StaExtfuelmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtfuelmea.GetStatusTmp()
```

RETURNS

Status bitfield as an integer value.

InitTmp

Initialises the temporary (in memory) fields of the measurement object with the values currently stored in the corresponding persistent fields. This affects temporary measurement value and temporary status fields. The temporary measurement value is used internally for comparison of new and old values for deadband violation. The temporary status is used during calculation in order to not modify initial value.

This function should be called once after the link has been established and before the calculation loop is executed.

```
None StaExtfuelmea.InitTmp()
```

IsStatusBitSet

Checks if specific bit(s) are set in the status bitfield. See [StaExtfuelmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtfuelmea.IsStatusBitSet(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

IsStatusBitSetTmp

Checks if specific bit(s) are set in the temporary (in memory) status bitfield. See [StaExtfuelmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtfuelmea.IsStatusBitSetTmp(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

ResetStatusBit

Resets specific bits in the status bitfield. See [StaExtfuelmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtfuelmea.ResetStatusBit(int mask, int dbSync)
```

ARGUMENTS

- mask* Mask of bits to set to 0. A bit is unchanged if already unset before.
- dbSync (optional)*
 - 0** New status flags are applied in memory only
 - 1** Default, new status flags are stored on db (persistent)

ResetStatusBitTmp

Resets specific bits in the temporary (in memory) status bitfield. See [StaExtfuelmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtfuelmea.ResetStatusBitTmp(int mask)
```

ARGUMENTS

- mask* Mask of bits to set to 0. A bit is unchanged if already unset before.

SetMeaValue

Sets the value stored in the measurement object.

```
int StaExtfuelmea.SetMeaValue(float value)
```

ARGUMENTS

- value* New value.

RETURNS

- Return value has no meaning. It is always 0.

SetStatus

Sets the status flags of the measurement object. Please note, this value is interpreted as a bitfield where the bits have the following meaning. An option is considered enabled if the corresponding bit is set to 1.

bit0 0x00000001 Manually entered data

bit1 0x00000002 Tele-Measurement

bit2 0x00000004 Disturbance

bit3 0x00000008 Protection

bit4 0x00000010 Marked suspect

bit5 0x00000020 Violated constraint

bit6 0x00000040 On Event

bit7 0x00000080 Event Block.

bit8 0x00000100 Alarm Block.

bit9 0x00000200 Update Block.

bit10 0x00000400 Control Block.

bit29 0x20000000 Read

bit30 0x40000000 Write

bit31 0x80000000 Neglected by SE

```
None StaExtfuelmea.SetStatus(int status, int dbSync)
```

ARGUMENTS

status Bitfield for status flags, see above

dbSync (optional)

0 New status flags are applied in memory only

1 Default, new status flags are stored on db (persistent)

SetStatusBit

Sets specific bits in the status bitfield. See [StaExtfuelmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtfuelmea.SetStatusBit(int mask, int dbSync)
```

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

dbSync (optional)

0 New status flags are applied in memory only

1 Default, new status flags are stored on db (persistent)

SetStatusBitTmp

Sets specific bits in the temporary (in memory) status bitfield. See [StaExtfuelmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtfuelmea.SetStatusBitTmp(int mask)
```

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

SetStatusTmp

Sets the temporary (in memory) status flags of the measurement object. This temporary value is used during calculations so that changes do not lead to object modifications and initial value remains unchanged.

Please note, this value is interpreted as a bitfield. See [StaExtfuelmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtfuelmea.SetStatusTmp(int status)
```

ARGUMENTS

status Bitfield for status flags, see above

UpdateControl

Transfers the value of current measurement object to the controller object (target object 'pCtrl' and target attribute 'varName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExtfuelmea.UpdateControl(int dbSync)
```

ARGUMENTS

dbSync (optional)

- | | |
|----------|--|
| 0 | Value is copied in memory only |
| 1 | Default, copied value is stored on db (persistent) |

RETURNS

- | | |
|----------|---|
| 0 | on success |
| 1 | on error, e.g. target object does not have an attribute with given name |

UpdateCtrl

Transfers the value of current measurement object to the controlled object (target object 'pObject' and target attribute 'variabName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExtfuelmea.UpdateCtrl(int dbSync)
```

ARGUMENTS

dbSync (optional)

- | | |
|----------|--|
| 0 | Value is copied in memory only |
| 1 | Default, copied value is stored on db (persistent) |

RETURNS

- | | |
|----------|---|
| 0 | on success |
| 1 | on error, e.g. target object does not have an attribute with given name |

5.3.9 StaExtimea

Overview

[CopyExtMeaStatusToStatusTmp](#)
[GetMeaValue](#)
[GetStatus](#)
[GetStatusTmp](#)
[InitTmp](#)
[IsStatusBitSet](#)
[IsStatusBitSetTmp](#)
[ResetStatusBit](#)
[ResetStatusBitTmp](#)
[SetMeaValue](#)
[SetStatus](#)
[SetStatusBit](#)
[SetStatusBitTmp](#)
[SetStatusTmp](#)
[UpdateControl](#)
[UpdateCtrl](#)

CopyExtMeaStatusToStatusTmp

Copies the (persistent) status of current measurement object to temporary (in memory) status.

```
None StaExtimea.CopyExtMeaStatusToStatusTmp()
```

GetMeaValue

Returns the value for current currently stored in the measurement object.

```
[int error,
float value] StaExtimea.GetMeaValue([int phase,]
                                     [int applyMultiplier])
```

ARGUMENTS

value (out)

Value for current, optionally multiplied by configured multiplier

phase (optional)

If measurement is unbalanced specifies which value to get.

- 0** Current of phase 1 (default)
- 1** Current of phase 2
- 2** Current of phase 3

applyMultiplier (optional)

If 1 (default), returned value will be multiplied by the multiplier stored in the measurement object. If 0, raw value will be returned.

RETURNS

Return value has no meaning. It is always 0.

GetStatus

Returns the status flags. Please note, this value is interpreted as a bitfield. See [StaExtimea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtimea.GetStatuts()
```

RETURNS

Status bitfield as an integer value.

GetStatusTmp

Returns the temporary (in memory) status flags. Please note, this value is interpreted as a bitfield. See [StaExtimea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtimea.GetStatusTmp()
```

RETURNS

Status bitfield as an integer value.

InitTmp

Initialises the temporary (in memory) fields of the measurement object with the values currently stored in the corresponding persistent fields. This affects temporary measurement value and temporary status fields. The temporary measurement value is used internally for comparison of new and old values for deadband violation. The temporary status is used during calculation in order to not modify initial value.

This function should be called once after the link has been established and before the calculation loop is executed.

```
None StaExtimea.InitTmp()
```

IsStatusBitSet

Checks if specific bit(s) are set in the status bitfield. See [StaExtimea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtimea.IsStatusBitSet(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

IsStatusBitSetTmp

Checks if specific bit(s) are set in the temporary (in memory) status bitfield. See [StaExtimea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtimea.IsStatusBitSetTmp(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

ResetStatusBit

Resets specific bits in the status bitfield. See [StaExtimea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtimea.ResetStatusBit(int mask, int dbSync)
```

ARGUMENTS

- mask* Mask of bits to set to 0. A bit is unchanged if already unset before.
- dbSync (optional)*
 - 0** New status flags are applied in memory only
 - 1** Default, new status flags are stored on db (persistent)

ResetStatusBitTmp

Resets specific bits in the temporary (in memory) status bitfield. See [StaExtimea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtimea.ResetStatusBitTmp(int mask)
```

ARGUMENTS

- mask* Mask of bits to set to 0. A bit is unchanged if already unset before.

SetMeaValue

Sets the value stored in the measurement object.

```
int StaExtimea.SetMeaValue(float value,
                           [int phase,]
                           [int copyToCtrlObj,]
                           [int dbSync])
```


ARGUMENTS

value New value.

phase (optional)

If measurement is unbalanced specifies which value to set.

- 0** Current of phase 1 (default)
- 1** Current of phase 2
- 2** Current of phase 3

copyToCtrlObj (optional)

Only for balanced measurement object. Default 0 (=off), else sets value additionally to variables of controlled object with given “dbSync” mode.

dbSync (optional)

Only relevant if parameter “copyToCtrlObj” is non-zero, see descriptiong there.

RETURNS

- 0** on success
- 1** copying to controlled object was selected but measurement is unbalanced

SetStatus

Sets the status flags of the measurement object. Please note, this value is interpreted as a bitfield where the bits have the following meaning. An option is considered enabled if the corresponding bit is set to 1.

bit0 0x00000001 Manually entered data

bit1 0x00000002 Tele-Measurement

bit2 0x00000004 Disturbance

bit3 0x00000008 Protection

bit4 0x00000010 Marked suspect

bit5 0x00000020 Violated constraint

bit6 0x00000040 On Event

bit7 0x00000080 Event Block.

bit8 0x00000100 Alarm Block.

bit9 0x00000200 Update Block.

bit10 0x00000400 Control Block.

bit29 0x20000000 Read

bit30 0x40000000 Write

bit31 0x80000000 Neglected by SE

```
None StaExtimea.SetStatus(int status, int dbSync)
```

ARGUMENTS

status Bitfield for status flags, see above

dbSync (optional)

0	New status flags are applied in memory only
1	Default, new status flags are stored on db (persistent)

SetStatusBit

Sets specific bits in the status bitfield. See [StaExtimea.SetStatus\(\)](#) for details on the status bits.

`None StaExtimea.SetStatusBit(int mask, int dbSync)`

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

dbSync (optional)

0	New status flags are applied in memory only
1	Default, new status flags are stored on db (persistent)

SetStatusBitTmp

Sets specific bits in the temporary (in memory) status bitfield. See [StaExtimea.SetStatus\(\)](#) for details on the status bits.

`None StaExtimea.SetStatusBitTmp(int mask)`

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

SetStatusTmp

Sets the temporary (in memory) status flags of the measurement object. This temporary value is used during calculations so that changes do not lead to object modifications and initial value remains unchanged.

Please note, this value is interpreted as a bitfield. See [StaExtimea.SetStatus\(\)](#) for details on the status bits.

`None StaExtimea.SetStatusTmp(int status)`

ARGUMENTS

status Bitfield for status flags, see above

UpdateControl

Transfers the value of current measurement object to the controller object (target object 'pCtrl' and target attribute 'varName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

`int StaExtimea.UpdateControl(int dbSync)`

ARGUMENTS

dbSync (optional)

- | | |
|----------|--|
| 0 | Value is copied in memory only |
| 1 | Default, copied value is stored on db (persistent) |

RETURNS

- | | |
|----------|---|
| 0 | on success |
| 1 | on error, e.g. target object does not have an attribute with given name |

UpdateCtrl

Transfers the value of current measurement object to the controlled object (target object 'pObject' and target attribute 'variabName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExtimea.UpdateCtrl(int dbSync)
```

ARGUMENTS

dbSync (optional)

- | | |
|----------|--|
| 0 | Value is copied in memory only |
| 1 | Default, copied value is stored on db (persistent) |

RETURNS

- | | |
|----------|---|
| 0 | on success |
| 1 | on error, e.g. target object does not have an attribute with given name |

5.3.10 StaExtpfmea**Overview**

[CopyExtMeaStatusToStatusTmp](#)
[GetMeaValue](#)
[GetStatus](#)
[GetStatusTmp](#)
[InitTmp](#)
[IsStatusBitSet](#)
[IsStatusBitSetTmp](#)
[ResetStatusBit](#)
[ResetStatusBitTmp](#)
[SetMeaValue](#)
[SetStatus](#)
[SetStatusBit](#)
[SetStatusBitTmp](#)
[SetStatusTmp](#)
[UpdateControl](#)
[UpdateCtrl](#)

CopyExtMeaStatusToStatusTmp

Copies the (persistent) status of current measurement object to temporary (in memory) status.

```
None StaExtpfmea.CopyExtMeaStatusToStatusTmp()
```

GetMeaValue

Returns the value for power factor currently stored in the measurement object.

```
[int error,
float value] StaExtpfmea.GetMeaValue([int unused,]
                                     [int applyMultiplier])
```

ARGUMENTS

value (out)

Value for current, optionally multiplied by configured multiplier

unused (optional)

Not used.

applyMultiplier (optional)

If 1 (default), returned value will be multiplied by the multiplier stored in the measurement object. If 0, raw value will be returned.

RETURNS

Return value has no meaning. It is always 0.

GetStatus

Returns the status flags. Please note, this value is interpreted as a bitfield. See [StaExtpfmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtpfmea.GetStatus()
```

RETURNS

Status bitfield as an integer value.

GetStatusTmp

Returns the temporary (in memory) status flags. Please note, this value is interpreted as a bitfield. See [StaExtpfmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtpfmea.GetStatusTmp()
```

RETURNS

Status bitfield as an integer value.

InitTmp

Initialises the temporary (in memory) fields of the measurement object with the values currently stored in the corresponding persistent fields. This affects temporary measurement value and temporary status fields. The temporary measurement value is used internally for comparison of new and old values for deadband violation. The temporary status is used during calculation in order to not modify initial value.

This function should be called once after the link has been established and before the calculation loop is executed.

```
None StaExtpfmea.InitTmp()
```

IsStatusBitSet

Checks if specific bit(s) are set in the status bitfield. See [StaExtpfmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtpfmea.IsStatusBitSet(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

IsStatusBitSetTmp

Checks if specific bit(s) are set in the temporary (in memory) status bitfield. See [StaExtpfmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtpfmea.IsStatusBitSetTmp(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

ResetStatusBit

Resets specific bits in the status bitfield. See [StaExtpfmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtpfmea.ResetStatusBit(int mask, int dbSync)
```

ARGUMENTS

mask Mask of bits to set to 0. A bit is unchanged if already unset before.

dbSync (optional)

- 0** New status flags are applied in memory only
- 1** Default, new status flags are stored on db (persistent)

ResetStatusBitTmp

Resets specific bits in the temporary (in memory) status bitfield. See [StaExtpfmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtpfmea.ResetStatusBitTmp(int mask)
```

ARGUMENTS

mask Mask of bits to set to 0. A bit is unchanged if already unset before.

SetMeaValue

Sets the value stored in the measurement object.

```
int StaExtpfmea.SetMeaValue(float value)
```

ARGUMENTS

value New value.

RETURNS

Return value has no meaning. It is always 0.

SetStatus

Sets the status flags of the measurement object. Please note, this value is interpreted as a bitfield where the bits have the following meaning. An option is considered enabled if the corresponding bit is set to 1.

bit0 0x00000001 Manually entered data

bit1 0x00000002 Tele-Measurement

bit2 0x00000004 Disturbance

bit3 0x00000008 Protection

bit4 0x00000010 Marked suspect

bit5 0x00000020 Violated constraint

bit6 0x00000040 On Event

bit7 0x00000080 Event Block.

bit8 0x00000100 Alarm Block.

bit9 0x00000200 Update Block.

bit10 0x00000400 Control Block.

bit29 0x20000000 Read

bit30 0x40000000 Write

bit31 0x80000000 Neglected by SE

```
None StaExtpfmea.SetStatus(int status, int dbSync)
```

ARGUMENTS

status Bitfield for status flags, see above

dbSync (optional)

- 0** New status flags are applied in memory only
- 1** Default, new status flags are stored on db (persistent)

SetStatusBit

Sets specific bits in the status bitfield. See [StaExtpfmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtpfmea.SetStatusBit(int mask, int dbSync)
```

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

dbSync (optional)

- 0** New status flags are applied in memory only
- 1** Default, new status flags are stored on db (persistent)

SetStatusBitTmp

Sets specific bits in the temporary (in memory) status bitfield. See [StaExtpfmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtpfmea.SetStatusBitTmp(int mask)
```

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

SetStatusTmp

Sets the temporary (in memory) status flags of the measurement object. This temporary value is used during calculations so that changes do not lead to object modifications and initial value remains unchanged.

Please note, this value is interpreted as a bitfield. See [StaExtpfmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtpfmea.SetStatusTmp(int status)
```

ARGUMENTS

status Bitfield for status flags, see above

UpdateControl

Transfers the value of current measurement object to the controller object (target object 'pCtrl' and target attribute 'varName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExtpfmea.UpdateControl(int dbSync)
```

ARGUMENTS

dbSync (optional)

- | | |
|----------|--|
| 0 | Value is copied in memory only |
| 1 | Default, copied value is stored on db (persistent) |

RETURNS

- | | |
|----------|---|
| 0 | on success |
| 1 | on error, e.g. target object does not have an attribute with given name |

UpdateCtrl

Transfers the value of current measurement object to the controlled object (target object 'pObject' and target attribute 'variabName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExtpfmea.UpdateCtrl(int dbSync)
```

ARGUMENTS

dbSync (optional)

- | | |
|----------|--|
| 0 | Value is copied in memory only |
| 1 | Default, copied value is stored on db (persistent) |

RETURNS

- | | |
|----------|---|
| 0 | on success |
| 1 | on error, e.g. target object does not have an attribute with given name |

5.3.11 StaExtpmea

Overview

[CopyExtMeaStatusToStatusTmp](#)
[GetMeaValue](#)
[GetStatus](#)
[GetStatusTmp](#)
[InitTmp](#)
[IsStatusBitSet](#)
[IsStatusBitSetTmp](#)
[ResetStatusBit](#)
[ResetStatusBitTmp](#)
[SetMeaValue](#)

[SetStatus](#)
[SetStatusBit](#)
[SetStatusBitTmp](#)
[SetStatusTmp](#)
[UpdateControl](#)
[UpdateCtrl](#)

CopyExtMeaStatusToStatusTmp

Copies the (persistent) status of current measurement object to temporary (in memory) status.

```
None StaExtPmea.CopyExtMeaStatusToStatusTmp()
```

GetMeaValue

Returns the value for active power stored in the measurement object.

```
[int error,  
float value] StaExtPmea.GetMeaValue([int phase,]  
                                     [int applyMultiplier])
```

ARGUMENTS

value (out)

Value for active power, optionally multiplied by configured multiplier

phase (optional)

If measurement is unbalanced specifies which value to get.

- 0** Active power of phase 1 (default)
- 1** Active power of phase 2
- 2** active power of phase 3

applyMultiplier (optional)

If 1 (default), returned value will be multiplied by the multiplier stored in the measurement object. If 0, raw value will be returned.

RETURNS

Return value has no meaning. It is always 0.

GetStatus

Returns the status flags. Please note, this value is interpreted as a bitfield. See [StaExtPmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtPmea.GetStatuts()
```

RETURNS

Status bitfield as an integer value.

GetStatusTmp

Returns the temporary (in memory) status flags. Please note, this value is interpreted as a bitfield. See [StaExtpmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtpmea.GetStatusTmp()
```

RETURNS

Status bitfield as an integer value.

InitTmp

Initialises the temporary (in memory) fields of the measurement object with the values currently stored in the corresponding persistent fields. This affects temporary measurement value and temporary status fields. The temporary measurement value is used internally for comparison of new and old values for deadband violation. The temporary status is used during calculation in order to not modify initial value.

This function should be called once after the link has been established and before the calculation loop is executed.

```
None StaExtpmea.InitTmp()
```

IsStatusBitSet

Checks if specific bit(s) are set in the status bitfield. See [StaExtpmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtpmea.IsStatusBitSet(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

IsStatusBitSetTmp

Checks if specific bit(s) are set in the temporary (in memory) status bitfield. See [StaExtpmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtpmea.IsStatusBitSetTmp(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

ResetStatusBit

Resets specific bits in the status bitfield. See [StaExtpmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtpmea.ResetStatusBit(int mask, int dbSync)
```

ARGUMENTS

mask Mask of bits to set to 0. A bit is unchanged if already unset before.

dbSync (optional)

0 New status flags are applied in memory only

1 Default, new status flags are stored on db (persistent)

ResetStatusBitTmp

Resets specific bits in the temporary (in memory) status bitfield. See [StaExtpmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtpmea.ResetStatusBitTmp(int mask)
```

ARGUMENTS

mask Mask of bits to set to 0. A bit is unchanged if already unset before.

SetMeaValue

Sets the value stored in the measurement object.

```
int StaExtpmea.SetMeaValue(float value,
                           [int phase,]
                           [int copyToCtrlObj,]
                           [int dbSync])
```

ARGUMENTS

value New value.

phase (optional)

If measurement is unbalanced specifies which value to set.

0 Active power of phase 1 (default)

1 Active power of phase 2

2 Active power of phase 3

copyToCtrlObj (optional)

Only for balanced measurement object. Default 0 (=off), else sets value additionally to variables of controlled object with given “dbSync” mode.

dbSync (optional)

Only relevant if parameter “copyToCtrlObj” is non-zero, see descriptiong there.

RETURNS

0 on success

1 copying to controlled object was selected but measurement is unbalanced

SetStatus

Sets the status flags of the measurement object. Please note, this value is interpreted as a bitfield where the bits have the following meaning. An option is considered enabled if the corresponding bit is set to 1.

bit0 0x00000001 Manually entered data

bit1 0x00000002 Tele-Measurement

bit2 0x00000004 Disturbance

bit3 0x00000008 Protection

bit4 0x00000010 Marked suspect

bit5 0x00000020 Violated constraint

bit6 0x00000040 On Event

bit7 0x00000080 Event Block.

bit8 0x00000100 Alarm Block.

bit9 0x00000200 Update Block.

bit10 0x00000400 Control Block.

bit29 0x20000000 Read

bit30 0x40000000 Write

bit31 0x80000000 Neglected by SE

```
None StaExtpmea.SetStatus(int status, int dbSync)
```

ARGUMENTS

status Bitfield for status flags, see above

dbSync (optional)

- | | |
|----------|---|
| 0 | New status flags are applied in memory only |
| 1 | Default, new status flags are stored on db (persistent) |

SetStatusBit

Sets specific bits in the status bitfield. See [StaExtpmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtpmea.SetStatusBit(int mask, int dbSync)
```

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

dbSync (optional)

- | | |
|----------|---|
| 0 | New status flags are applied in memory only |
| 1 | Default, new status flags are stored on db (persistent) |

SetStatusBitTmp

Sets specific bits in the temporary (in memory) status bitfield. See [StaExtpmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtpmea.SetStatusBitTmp(int mask)
```

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

SetStatusTmp

Sets the temporary (in memory) status flags of the measurement object. This temporary value is used during calculations so that changes do not lead to object modifications and initial value remains unchanged.

Please note, this value is interpreted as a bitfield. See [StaExtpmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtpmea.SetStatusTmp(int status)
```

ARGUMENTS

status Bitfield for status flags, see above

UpdateControl

Transfers the value of current measurement object to the controller object (target object 'pCtrl' and target attribute 'varName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExtpmea.UpdateControl(int dbSync)
```

ARGUMENTS

dbSync (optional)

- | | |
|----------|--|
| 0 | Value is copied in memory only |
| 1 | Default, copied value is stored on db (persistent) |

RETURNS

- | | |
|----------|---|
| 0 | on success |
| 1 | on error, e.g. target object does not have an attribute with given name |

UpdateCtrl

Transfers the value of current measurement object to the controlled object (target object 'pObject' and target attribute 'variabName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExtpmea.UpdateCtrl(int dbSync)
```

ARGUMENTS

dbSync (optional)

- | | |
|----------|--|
| 0 | Value is copied in memory only |
| 1 | Default, copied value is stored on db (persistent) |

RETURNS

- | | |
|----------|---|
| 0 | on success |
| 1 | on error, e.g. target object does not have an attribute with given name |

5.3.12 StaExtqmea

Overview

[CopyExtMeaStatusToStatusTmp](#)
[GetMeaValue](#)
[GetStatus](#)
[GetStatusTmp](#)
[InitTmp](#)
[IsStatusBitSet](#)
[IsStatusBitSetTmp](#)
[ResetStatusBit](#)
[ResetStatusBitTmp](#)
[SetMeaValue](#)
[SetStatus](#)
[SetStatusBit](#)
[SetStatusBitTmp](#)
[SetStatusTmp](#)
[UpdateControl](#)
[UpdateCtrl](#)

CopyExtMeaStatusToStatusTmp

Copies the (persistent) status of current measurement object to temporary (in memory) status.

```
None StaExtqmea.CopyExtMeaStatusToStatusTmp()
```

GetMeaValue

Returns the value for reactive power currently stored in the measurement object.

```
[int error,
float value] StaExtqmea.GetMeaValue([int phase,]
                                     [int applyMultiplier])
```

ARGUMENTS

value (out)

Value for reactive power, optionally multiplied by configured multiplier

phase (optional)

If measurement is unbalanced specifies which value to get.

- 0** Reactive power of phase 1 (default)
- 1** Reactive power of phase 2
- 2** Reactive power of phase 3

applyMultiplier (optional)

If 1 (default), returned value will be multiplied by the multiplier stored in the measurement object. If 0, raw value will be returned.

RETURNS

Return value has no meaning. It is always 0.

GetStatus

Returns the status flags. Please note, this value is interpreted as a bitfield. See [StaExtqmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtqmea.GetStatus()
```

RETURNS

Status bitfield as an integer value.

GetStatusTmp

Returns the temporary (in memory) status flags. Please note, this value is interpreted as a bitfield. See [StaExtqmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtqmea.GetStatusTmp()
```

RETURNS

Status bitfield as an integer value.

InitTmp

Initialises the temporary (in memory) fields of the measurement object with the values currently stored in the corresponding persistent fields. This affects temporary measurement value and temporary status fields. The temporary measurement value is used internally for comparison of new and old values for deadband violation. The temporary status is used during calculation in order to not modify initial value.

This function should be called once after the link has been established and before the calculation loop is executed.

```
None StaExtqmea.InitTmp()
```

IsStatusBitSet

Checks if specific bit(s) are set in the status bitfield. See [StaExtqmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtqmea.IsStatusBitSet(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

IsStatusBitSetTmp

Checks if specific bit(s) are set in the temporary (in memory) status bitfield. See [StaExtqmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtqmea.IsStatusBitSetTmp(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

ResetStatusBit

Resets specific bits in the status bitfield. See [StaExtqmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtqmea.ResetStatusBit(int mask, int dbSync)
```

ARGUMENTS

- mask* Mask of bits to set to 0. A bit is unchanged if already unset before.
- dbSync (optional)*
 - 0** New status flags are applied in memory only
 - 1** Default, new status flags are stored on db (persistent)

ResetStatusBitTmp

Resets specific bits in the temporary (in memory) status bitfield. See [StaExtqmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtqmea.ResetStatusBitTmp(int mask)
```

ARGUMENTS

- mask* Mask of bits to set to 0. A bit is unchanged if already unset before.

SetMeaValue

Sets the value stored in the measurement object.

```
int StaExtqmea.SetMeaValue(float value,
                           [int phase,]
                           [int copyToCtrlObj,]
                           [int dbSync])
```


ARGUMENTS

value New value.

phase (optional)

If measurement is unbalanced specifies which value to set.

- 0** Reactive power of phase 1 (default)
- 1** Reactive power of phase 2
- 2** Reactive power of phase 3

copyToCtrlObj (optional)

Only for balanced measurement object. Default 0 (=off), else sets value additionally to variables of controlled object with given “dbSync” mode.

dbSync (optional)

Only relevant if parameter “copyToCtrlObj” is non-zero, see description there.

RETURNS

- 0** on success
- 1** copying to controlled object was selected but measurement is unbalanced

SetStatus

Sets the status flags of the measurement object. Please note, this value is interpreted as a bitfield where the bits have the following meaning. An option is considered enabled if the corresponding bit is set to 1.

bit0 0x00000001 Manually entered data

bit1 0x00000002 Tele-Measurement

bit2 0x00000004 Disturbance

bit3 0x00000008 Protection

bit4 0x00000010 Marked suspect

bit5 0x00000020 Violated constraint

bit6 0x00000040 On Event

bit7 0x00000080 Event Block.

bit8 0x00000100 Alarm Block.

bit9 0x00000200 Update Block.

bit10 0x00000400 Control Block.

bit29 0x20000000 Read

bit30 0x40000000 Write

bit31 0x80000000 Neglected by SE

```
None StaExtgmea.SetStatus(int status, int dbSync)
```

ARGUMENTS

status Bitfield for status flags, see above

dbSync (optional)

- 0** New status flags are applied in memory only
- 1** Default, new status flags are stored on db (persistent)

SetStatusBit

Sets specific bits in the status bitfield. See [StaExtqmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtqmea.SetStatusBit(int mask, int dbSync)
```

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

dbSync (optional)

- 0** New status flags are applied in memory only
- 1** Default, new status flags are stored on db (persistent)

SetStatusBitTmp

Sets specific bits in the temporary (in memory) status bitfield. See [StaExtqmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtqmea.SetStatusBitTmp(int mask)
```

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

SetStatusTmp

Sets the temporary (in memory) status flags of the measurement object. This temporary value is used during calculations so that changes do not lead to object modifications and initial value remains unchanged.

Please note, this value is interpreted as a bitfield. See [StaExtqmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtqmea.SetStatusTmp(int status)
```

ARGUMENTS

status Bitfield for status flags, see above

UpdateControl

Transfers the value of current measurement object to the controller object (target object 'pCtrl' and target attribute 'varName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExtqmea.UpdateControl(int dbSync)
```

ARGUMENTS

dbSync (optional)

- | | |
|----------|--|
| 0 | Value is copied in memory only |
| 1 | Default, copied value is stored on db (persistent) |

RETURNS

- | | |
|----------|---|
| 0 | on success |
| 1 | on error, e.g. target object does not have an attribute with given name |

UpdateCtrl

Transfers the value of current measurement object to the controlled object (target object 'pObject' and target attribute 'variabName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExtqmea.UpdateCtrl(int dbSync)
```

ARGUMENTS

dbSync (optional)

- | | |
|----------|--|
| 0 | Value is copied in memory only |
| 1 | Default, copied value is stored on db (persistent) |

RETURNS

- | | |
|----------|---|
| 0 | on success |
| 1 | on error, e.g. target object does not have an attribute with given name |

5.3.13 StaExtsmea

Overview

[CopyExtMeaStatusToStatusTmp](#)
[GetStatus](#)
[GetStatusTmp](#)
[InitTmp](#)
[IsStatusBitSet](#)
[IsStatusBitSetTmp](#)
[ResetStatusBit](#)
[ResetStatusBitTmp](#)
[SetStatus](#)
[SetStatusBit](#)

[SetStatusBitTmp](#)
[SetStatusTmp](#)
[UpdateControl](#)
[UpdateCtrl](#)

CopyExtMeaStatusToStatusTmp

Copies the (persistent) status of current measurement object to temporary (in memory) status.

```
None StaExtsmea.CopyExtMeaStatusToStatusTmp()
```

GetStatus

Returns the status flags. Please note, this value is interpreted as a bitfield. See [StaExtsmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtsmea.GetStatuts()
```

RETURNS

Status bitfield as an integer value.

GetStatusTmp

Returns the temporary (in memory) status flags. Please note, this value is interpreted as a bitfield. See [StaExtsmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtsmea.GetStatusTmp()
```

RETURNS

Status bitfield as an integer value.

InitTmp

Initialises the temporary (in memory) fields of the measurement object with the values currently stored in the corresponding persistent fields. This affects temporary measurement value and temporary status fields. The temporary measurement value is used internally for comparison of new and old values for deadband violation. The temporary status is used during calculation in order to not modify initial value.

This function should be called once after the link has been established and before the calculation loop is executed.

```
None StaExtsmea.InitTmp()
```

IsStatusBitSet

Checks if specific bit(s) are set in the status bitfield. See [StaExtsmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtsmea.IsStatusBitSet(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

IsStatusBitSetTmp

Checks if specific bit(s) are set in the temporary (in memory) status bitfield. See [StaExtsmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtsmea.IsStatusBitSetTmp(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

ResetStatusBit

Resets specific bits in the status bitfield. See [StaExtsmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtsmea.ResetStatusBit(int mask, int dbSync)
```

ARGUMENTS

- mask* Mask of bits to set to 0. A bit is unchanged if already unset before.
- dbSync (optional)*
- 0** New status flags are applied in memory only
 - 1** Default, new status flags are stored on db (persistent)

ResetStatusBitTmp

Resets specific bits in the temporary (in memory) status bitfield. See [StaExtsmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtsmea.ResetStatusBitTmp(int mask)
```

ARGUMENTS

- mask* Mask of bits to set to 0. A bit is unchanged if already unset before.

SetStatus

Sets the status flags of the measurement object. Please note, this value is interpreted as a bitfield where the bits have the following meaning. An option is considered enabled if the corresponding bit is set to 1.

bit0 0x00000001 Manually entered data

bit1 0x00000002 Tele-Measurement

bit2 0x00000004 Disturbance

bit3 0x00000008 Protection
bit4 0x00000010 Marked suspect
bit5 0x00000020 Violated constraint
bit6 0x00000040 On Event
bit7 0x00000080 Event Block.
bit8 0x00000100 Alarm Block.
bit9 0x00000200 Update Block.
bit10 0x00000400 Control Block.
bit29 0x20000000 Read
bit30 0x40000000 Write
bit31 0x80000000 Neglected by SE

```
None StaExtsmea.SetStatus(int status, int dbSync)
```

ARGUMENTS

status Bitfield for status flags, see above

dbSync (optional)

- | | |
|----------|---|
| 0 | New status flags are applied in memory only |
| 1 | Default, new status flags are stored on db (persistent) |

SetStatusBit

Sets specific bits in the status bitfield. See [StaExtsmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtsmea.SetStatusBit(int mask, int dbSync)
```

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

dbSync (optional)

- | | |
|----------|---|
| 0 | New status flags are applied in memory only |
| 1 | Default, new status flags are stored on db (persistent) |

SetStatusBitTmp

Sets specific bits in the temporary (in memory) status bitfield. See [StaExtsmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtsmea.SetStatusBitTmp(int mask)
```

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

SetStatusTmp

Sets the temporary (in memory) status flags of the measurement object. This temporary value is used during calculations so that changes do not lead to object modifications and initial value remains unchanged.

Please note, this value is interpreted as a bitfield. See [StaExtsmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtsmea.SetStatusTmp(int status)
```

ARGUMENTS

status Bitfield for status flags, see above

UpdateControl

Transfers the value of current measurement object to the controller object (target object 'pCtrl' and target attribute 'varName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExtsmea.UpdateControl(int dbSync)
```

ARGUMENTS

dbSync (optional)

- | | |
|----------|--|
| 0 | Value is copied in memory only |
| 1 | Default, copied value is stored on db (persistent) |

RETURNS

- | | |
|----------|---|
| 0 | on success |
| 1 | on error, e.g. target object does not have an attribute with given name |

UpdateCtrl

Transfers the value of current measurement object to the controlled object (target object 'pObject' and target attribute 'variabName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExtsmea.UpdateCtrl(int dbSync)
```

ARGUMENTS

dbSync (optional)

- | | |
|----------|--|
| 0 | Value is copied in memory only |
| 1 | Default, copied value is stored on db (persistent) |

RETURNS

- | | |
|---|---|
| 0 | on success |
| 1 | on error, e.g. target object does not have an attribute with given name |

5.3.14 StaExttapmea

Overview

[CopyExtMeaStatusToStatusTmp](#)
[CreateEvent](#)
[GetMeaValue](#)
[GetStatus](#)
[GetStatusTmp](#)
[InitTmp](#)
[IsStatusBitSet](#)
[IsStatusBitSetTmp](#)
[ResetStatusBit](#)
[ResetStatusBitTmp](#)
[SetMeaValue](#)
[SetStatus](#)
[SetStatusBit](#)
[SetStatusBitTmp](#)
[SetStatusTmp](#)
[UpdateControl](#)
[UpdateCtrl](#)

CopyExtMeaStatusToStatusTmp

Copies the (persistent) status of current measurement object to temporary (in memory) status.

```
None StaExttapmea.CopyExtMeaStatusToStatusTmp()
```

CreateEvent

Creates a tap event (EvtTap) into the simulation event queue for nTapAction = 0,1 and 2 or when nTapAction = 3 and 4 a parameter event (EvtParam) for 'Variable' name.

```
int StaExttapmea.CreateEvent(int nTapAction, int nTapPos_in, int nBusIndex)
```

ARGUMENTS

nTapAction

Tap action

- 0: increase tap by one step (argument nTapPos_in is neglected)
- 1: decrease tap by one step (argument nTapPos_in is neglected)
- 2: set tap to the corresponding step of argument nTapPos_in
- 3: a parameter event (EvtParam) is create for 'Variable', the value is set to 0
- 4: a parameter event (EvtParam) is create for 'Variable', the value is set to 1

GetMeaValue

Returns the value for tap position and tap info currently stored in the measurement object.

```
[int error,
float value] StaExttapmea.GetMeaValue([int type,]
                                       [int useTranslationTable])
```

ARGUMENTS

value (out)

Value.

type (optional)

type of value to return

- | | |
|----------|----------------------------|
| 0 | tap position (default) |
| 1 | operation mode |
| 2 | tap changer command |
| 3 | tap operation mode |
| 4 | tap operation mode command |

useTranslationTable (optional)

Only supported if type=0 (tap step), if 1 (default) returned value will be translated according to given table. If 0 is passed, the raw value will be returned.

RETURNS

- | | |
|----------|---------------------------------|
| 0 | on success |
| 1 | on error, e.g. unsupported type |

GetStatus

Returns the status flags. Please note, this value is interpreted as a bitfield. See [StaExttapmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExttapmea.GetStatus()
```

RETURNS

Status bitfield as an integer value.

GetStatusTmp

Returns the temporary (in memory) status flags. Please note, this value is interpreted as a bitfield. See [StaExttapmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExttapmea.GetStatusTmp()
```

RETURNS

Status bitfield as an integer value.

InitTmp

Initialises the temporary (in memory) fields of the measurement object with the values currently stored in the corresponding persistent fields. This affects temporary measurement value and temporary status fields. The temporary measurement value is used internally for comparison of new and old values for deadband violation. The temporary status is used during calculation in order to not modify initial value.

This function should be called once after the link has been established and before the calculation loop is executed.

```
None StaExttapmea.InitTmp()
```

IsStatusBitSet

Checks if specific bit(s) are set in the status bitfield. See [StaExttapmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExttapmea.IsStatusBitSet(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

IsStatusBitSetTmp

Checks if specific bit(s) are set in the temporary (in memory) status bitfield. See [StaExttapmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExttapmea.IsStatusBitSetTmp(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

ResetStatusBit

Resets specific bits in the status bitfield. See [StaExttapmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExttapmea.ResetStatusBit(int mask, int dbSync)
```

ARGUMENTS

mask Mask of bits to set to 0. A bit is unchanged if already unset before.

dbSync (optional)

- 0** New status flags are applied in memory only
- 1** Default, new status flags are stored on db (persistent)

ResetStatusBitTmp

Resets specific bits in the temporary (in memory) status bitfield. See [StaExttapmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExttapmea.ResetStatusBitTmp(int mask)
```

ARGUMENTS

mask Mask of bits to set to 0. A bit is unchanged if already unset before.

SetMeaValue

Sets the value stored in the measurement object.

```
int StaExttapmea.SetMeaValue(float value,
                             [int type],
                             [int copyToCtrlObj],
                             [int dbSync])
```

ARGUMENTS

value New value.

type (optional)

type of value to set

- 0** tap position (default)
- 1** operation mode
- 2** tap changer command
- 3** tap operation mode
- 4** tap operation mode command

copyToCtrlObj (optional)

Only for “type” is 0 or 1. Default 0 (=off), else sets value additionally to variables of controlled object with given “dbSync” mode.

dbSync (optional)

Default 1(=on), synchronizes set value to DB.

RETURNS

- 0** on success
- 0** on error

SetStatus

Sets the status flags of the measurement object. Please note, this value is interpreted as a bitfield where the bits have the following meaning. An option is considered enabled if the corresponding bit is set to 1.

bit0 0x00000001 Manually entered data

bit1 0x00000002 Tele-Measurement

bit2 0x00000004 Disturbance

bit3 0x00000008 Protection

bit4 0x00000010 Marked suspect

bit5 0x00000020 Violated constraint

bit6 0x00000040 On Event

bit7 0x00000080 Event Block.

bit8 0x00000100 Alarm Block.

bit9 0x00000200 Update Block.

bit10 0x00000400 Control Block.

bit29 0x20000000 Read

bit30 0x40000000 Write

bit31 0x80000000 Neglected by SE

```
None StaExttapmea.SetStatus(int status, int dbSync)
```

ARGUMENTS

status Bitfield for status flags, see above

dbSync (optional)

0	New status flags are applied in memory only
1	Default, new status flags are stored on db (persistent)

SetStatusBit

Sets specific bits in the status bitfield. See [StaExttapmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExttapmea.SetStatusBit(int mask, int dbSync)
```

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

dbSync (optional)

0	New status flags are applied in memory only
1	Default, new status flags are stored on db (persistent)

SetStatusBitTmp

Sets specific bits in the temporary (in memory) status bitfield. See [StaExttapmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExttapmea.SetStatusBitTmp(int mask)
```

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

SetStatusTmp

Sets the temporary (in memory) status flags of the measurement object. This temporary value is used during calculations so that changes do not lead to object modifications and initial value remains unchanged.

Please note, this value is interpreted as a bitfield. See [StaExttapmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExttapmea.SetStatusTmp(int status)
```

ARGUMENTS

status Bitfield for status flags, see above

UpdateControl

Transfers the value of current measurement object to the controller object (target object 'pCtrl' and target attribute 'varName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExttapmea.UpdateControl(int dbSync)
```

ARGUMENTS

dbSync (optional)

- | | |
|----------|--|
| 0 | Value is copied in memory only |
| 1 | Default, copied value is stored on db (persistent) |

RETURNS

- | | |
|----------|---|
| 0 | on success |
| 1 | on error, e.g. target object does not have an attribute with given name |

UpdateCtrl

Transfers the value of current measurement object to the controlled object (target object 'pObject' and target attribute 'variabName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExttapmea.UpdateCtrl(int dbSync)
```

ARGUMENTS

dbSync (optional)

- | | |
|----------|--|
| 0 | Value is copied in memory only |
| 1 | Default, copied value is stored on db (persistent) |

RETURNS

- 0** on success
- 1** on error, e.g. target object does not have an attribute with given name

5.3.15 StaExtv3mea

Overview

[CopyExtMeaStatusToStatusTmp](#)
[GetMeaValue](#)
[GetStatus](#)
[GetStatusTmp](#)
[InitTmp](#)
[IsStatusBitSet](#)
[IsStatusBitSetTmp](#)
[ResetStatusBit](#)
[ResetStatusBitTmp](#)
[SetMeaValue](#)
[SetStatus](#)
[SetStatusBit](#)
[SetStatusBitTmp](#)
[SetStatusTmp](#)
[UpdateControl](#)
[UpdateCtrl](#)

CopyExtMeaStatusToStatusTmp

Copies the (persistent) status of current measurement object to temporary (in memory) status.

```
None StaExtv3mea.CopyExtMeaStatusToStatusTmp()
```

GetMeaValue

Returns the value for voltage currently stored in the measurement object.

```
[int error,
float value] StaExtv3mea.GetMeaValue([int unused,]
                                     [int applyMultiplier])
```

ARGUMENTS

value (out)

Value for voltage, optionally multiplied by configured multiplier

phase (optional)

Index of desired phase. Index must be 0 (default), 1 or 2.

applyMultiplier (optional)

If 1 (default), returned value will be multiplied by the multiplier stored in the measurement object. If 0, raw value will be returned.

RETURNS

- 0** on success
- 1** on error, e.g. phase index does not exist

GetStatus

Returns the status flags. Please note, this value is interpreted as a bitfield. See [StaExtv3mea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtv3mea.GetStatus()
```

RETURNS

Status bitfield as an integer value.

GetStatusTmp

Returns the temporary (in memory) status flags. Please note, this value is interpreted as a bitfield. See [StaExtv3mea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtv3mea.GetStatusTmp()
```

RETURNS

Status bitfield as an integer value.

InitTmp

Initialises the temporary (in memory) fields of the measurement object with the values currently stored in the corresponding persistent fields. This affects temporary measurement value and temporary status fields. The temporary measurement value is used internally for comparison of new and old values for deadband violation. The temporary status is used during calculation in order to not modify initial value.

This function should be called once after the link has been established and before the calculation loop is executed.

```
None StaExtv3mea.InitTmp()
```

IsStatusBitSet

Checks if specific bit(s) are set in the status bitfield. See [StaExtv3mea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtv3mea.IsStatusBitSet(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

IsStatusBitSetTmp

Checks if specific bit(s) are set in the temporary (in memory) status bitfield. See [StaExtv3mea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtv3mea.IsStatusBitSetTmp(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

ResetStatusBit

Resets specific bits in the status bitfield. See [StaExtv3mea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtv3mea.ResetStatusBit(int mask, int dbSync)
```

ARGUMENTS

- mask* Mask of bits to set to 0. A bit is unchanged if already unset before.
- dbSync (optional)*
 - 0** New status flags are applied in memory only
 - 1** Default, new status flags are stored on db (persistent)

ResetStatusBitTmp

Resets specific bits in the temporary (in memory) status bitfield. See [StaExtv3mea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtv3mea.ResetStatusBitTmp(int mask)
```

ARGUMENTS

- mask* Mask of bits to set to 0. A bit is unchanged if already unset before.

SetMeaValue

Sets the value stored in the measurement object.

```
int StaExtv3mea.SetMeaValue(float value,
                             [int meaIdx])
```

ARGUMENTS

- value* New value.
- meaIdx (optional)*
 - Specifies which value to set.
 - 0** Measured voltage of measurement 1 (default)
 - 1** Measured voltage of measurement 2
 - 2** Measured voltage of measurement 3

RETURNS

- 0** on success
- 1** on error, mealDx out of range

SetStatus

Sets the status flags of the measurement object. Please note, this value is interpreted as a bitfield where the bits have the following meaning. An option is considered enabled if the corresponding bit is set to 1.

bit0 0x00000001 Manually entered data

bit1 0x00000002 Tele-Measurement

bit2 0x00000004 Disturbance

bit3 0x00000008 Protection

bit4 0x00000010 Marked suspect

bit5 0x00000020 Violated constraint

bit6 0x00000040 On Event

bit7 0x00000080 Event Block.

bit8 0x00000100 Alarm Block.

bit9 0x00000200 Update Block.

bit10 0x00000400 Control Block.

bit29 0x20000000 Read

bit30 0x40000000 Write

bit31 0x80000000 Neglected by SE

```
None StaExtv3mea.SetStatus(int status, int dbSync)
```

ARGUMENTS

status Bitfield for status flags, see above

dbSync (optional)

- 0** New status flags are applied in memory only
- 1** Default, new status flags are stored on db (persistent)

SetStatusBit

Sets specific bits in the status bitfield. See [StaExtv3mea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtv3mea.SetStatusBit(int mask, int dbSync)
```

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

dbSync (optional)

0 New status flags are applied in memory only

1 Default, new status flags are stored on db (persistent)

SetStatusBitTmp

Sets specific bits in the temporary (in memory) status bitfield. See [StaExtv3mea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtv3mea.SetStatusBitTmp(int mask)
```

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

SetStatusTmp

Sets the temporary (in memory) status flags of the measurement object. This temporary value is used during calculations so that changes do not lead to object modifications and initial value remains unchanged.

Please note, this value is interpreted as a bitfield. See [StaExtv3mea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtv3mea.SetStatusTmp(int status)
```

ARGUMENTS

status Bitfield for status flags, see above

UpdateControl

Transfers the value of current measurement object to the controller object (target object 'pCtrl' and target attribute 'varName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExtv3mea.UpdateControl(int dbSync)
```

ARGUMENTS

dbSync (optional)

0 Value is copied in memory only

1 Default, copied value is stored on db (persistent)

RETURNS

0 on success

1 on error, e.g. target object does not have an attribute with given name

UpdateCtrl

Transfers the value of current measurement object to the controlled object (target object 'pObject' and target attribute 'variabName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExtv3mea.UpdateCtrl(int dbSync)
```

ARGUMENTS

dbSync (optional)

- | | |
|----------|--|
| 0 | Value is copied in memory only |
| 1 | Default, copied value is stored on db (persistent) |

RETURNS

- | | |
|----------|---|
| 0 | on success |
| 1 | on error, e.g. target object does not have an attribute with given name |

5.3.16 StaExtvmea

Overview

[CopyExtMeaStatusToStatusTmp](#)
[GetMeaValue](#)
[GetStatus](#)
[GetStatusTmp](#)
[InitTmp](#)
[IsStatusBitSet](#)
[IsStatusBitSetTmp](#)
[ResetStatusBit](#)
[ResetStatusBitTmp](#)
[SetMeaValue](#)
[SetStatus](#)
[SetStatusBit](#)
[SetStatusBitTmp](#)
[SetStatusTmp](#)
[UpdateControl](#)
[UpdateCtrl](#)

CopyExtMeaStatusToStatusTmp

Copies the (persistent) status of current measurement object to temporary (in memory) status.

```
None StaExtvmea.CopyExtMeaStatusToStatusTmp()
```

GetMeaValue

Returns the value for voltage currently stored in the measurement object.

```
[int error,  
float value] StaExtvmea.GetMeaValue([int phase,]  
                                     [int applyMultiplier])
```

ARGUMENTS

value (out)

Value for voltage, optionally multiplied by configured multiplier

phase (optional)

If measurement is unbalanced specifies which value to get, also depending on voltage input type of the measurement object.

- 0** Measured voltage of Phase 1 - Ground or Phase 1 - Phase 2 (default)
- 1** Measured voltage of Phase 2 - Ground or Phase 2 - Phase 3
- 2** Measured voltage of Phase 3 - Ground or Phase 3 - Phase 1

applyMultiplier (optional)

If 1 (default), returned value will be multiplied by the multiplier stored in the measurement object. If 0, raw value will be returned.

RETURNS

Return value has no meaning. It is always 0.

GetStatusReturns the status flags. Please note, this value is interpreted as a bitfield. See [StaExtvmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtvmea.GetStatus()
```

RETURNS

Status bitfield as an integer value.

GetStatusTmpReturns the temporary (in memory) status flags. Please note, this value is interpreted as a bitfield. See [StaExtvmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtvmea.GetStatusTmp()
```

RETURNS

Status bitfield as an integer value.

InitTmp

Initialises the temporary (in memory) fields of the measurement object with the values currently stored in the corresponding persistent fields. This affects temporary measurement value and temporary status fields. The temporary measurement value is used internally for comparison of new and old values for deadband violation. The temporary status is used during calculation in order to not modify initial value.

This function should be called once after the link has been established and before the calculation loop is executed.

```
None StaExtvmea.InitTmp()
```

IsStatusBitSet

Checks if specific bit(s) are set in the status bitfield. See [StaExtvmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtvmea.IsStatusBitSet(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

IsStatusBitSetTmp

Checks if specific bit(s) are set in the temporary (in memory) status bitfield. See [StaExtvmea.SetStatus\(\)](#) for details on the status bits.

```
int StaExtvmea.IsStatusBitSetTmp(int mask)
```

RETURNS

- 0** if at least one bit in mask is not set
- 1** if all bit(s) in mask are set

ResetStatusBit

Resets specific bits in the status bitfield. See [StaExtvmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtvmea.ResetStatusBit(int mask, int dbSync)
```

ARGUMENTS

- mask* Mask of bits to set to 0. A bit is unchanged if already unset before.
- dbSync (optional)*
 - 0** New status flags are applied in memory only
 - 1** Default, new status flags are stored on db (persistent)

ResetStatusBitTmp

Resets specific bits in the temporary (in memory) status bitfield. See [StaExtvmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtvmea.ResetStatusBitTmp(int mask)
```

ARGUMENTS

- mask* Mask of bits to set to 0. A bit is unchanged if already unset before.

SetMeaValue

Sets the value stored in the measurement object.

```
int StaExtvmea.SetMeaValue(float value,
                           [int phase],
                           [int copyToCtrlObj],
                           [int dbSync])
```

ARGUMENTS

value New value.

phase (optional)

If measurement is unbalanced specifies which value to set, also depending on voltage input type of the measurement object.

- 0** Measured voltage of Phase 1 - Ground or Phase 1 - Phase 2 (default)
- 1** Measured voltage of Phase 2 - Ground or Phase 2 - Phase 3
- 2** Measured voltage of Phase 3 - Ground or Phase 3 - Phase 1

copyToCtrlObj (optional)

Only for balanced measurement object. Default 0 (=off), else sets value additionally to variables of controlled object with given "dbSync" mode.

dbSync (optional)

Only relevant if parameter "copyToCtrlObj" is non-zero, see description there.

RETURNS

- 0** on success
- 1** copying to controlled object was selected but measurement is unbalanced

SetStatus

Sets the status flags of the measurement object. Please note, this value is interpreted as a bitfield where the bits have the following meaning. An option is considered enabled if the corresponding bit is set to 1.

bit0 0x00000001 Manually entered data

bit1 0x00000002 Tele-Measurement

bit2 0x00000004 Disturbance

bit3 0x00000008 Protection

bit4 0x00000010 Marked suspect

bit5 0x00000020 Violated constraint

bit6 0x00000040 On Event

bit7 0x00000080 Event Block.

bit8 0x00000100 Alarm Block.

bit9 0x00000200 Update Block.

bit10 0x00000400 Control Block.

bit29 0x20000000 Read

bit30 0x40000000 Write

bit31 0x80000000 Neglected by SE

```
None StaExtvmea.SetStatus(int status, int dbSync)
```

ARGUMENTS

status Bitfield for status flags, see above

dbSync (optional)

- 0** New status flags are applied in memory only
- 1** Default, new status flags are stored on db (persistent)

SetStatusBit

Sets specific bits in the status bitfield. See [StaExtvmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtvmea.SetStatusBit(int mask, int dbSync)
```

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

dbSync (optional)

- 0** New status flags are applied in memory only
- 1** Default, new status flags are stored on db (persistent)

SetStatusBitTmp

Sets specific bits in the temporary (in memory) status bitfield. See [StaExtvmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtvmea.SetStatusBitTmp(int mask)
```

ARGUMENTS

mask Mask of bits to set to 1. A bit is unchanged if already set before.

SetStatusTmp

Sets the temporary (in memory) status flags of the measurement object. This temporary value is used during calculations so that changes do not lead to object modifications and initial value remains unchanged.

Please note, this value is interpreted as a bitfield. See [StaExtvmea.SetStatus\(\)](#) for details on the status bits.

```
None StaExtvmea.SetStatusTmp(int status)
```

ARGUMENTS

status Bitfield for status flags, see above

UpdateControl

Transfers the value of current measurement object to the controller object (target object 'pCtrl' and target attribute 'varName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExtvmea.UpdateControl(int dbSync)
```

ARGUMENTS

dbSync (optional)

- 0** Value is copied in memory only
- 1** Default, copied value is stored on db (persistent)

RETURNS

- 0** on success
- 1** on error, e.g. target object does not have an attribute with given name

UpdateCtrl

Transfers the value of current measurement object to the controlled object (target object 'pObject' and target attribute 'variabName'). If target object is a command, it is automatically executed afterwards.

Note: Calculation results will not be reset by this value transfer.

```
int StaExtvmea.UpdateCtrl(int dbSync)
```

ARGUMENTS

dbSync (optional)

- 0** Value is copied in memory only
- 1** Default, copied value is stored on db (persistent)

RETURNS

- 0** on success
- 1** on error, e.g. target object does not have an attribute with given name

5.3.17 StaSwitch**Overview**

[Close](#)
[IsClosed](#)
[IsOpen](#)
[Open](#)

Close

Closes the switch by changing its status to 'close'. This action will fail if the status is currently determined by an active running arrangement.

```
int StaSwitch.Close()
```

RETURNS

0	On success
≠ 0	On error

SEE ALSO

[StaSwitch.Open\(\)](#)

IsClosed

Returns information about current switch state.

```
int StaSwitch.IsClosed()
```

RETURNS

1	switch is closed
0	switch is open

SEE ALSO

[StaSwitch.IsOpen\(\)](#)

IsOpen

Returns information about current switch state.

```
int StaSwitch.IsOpen()
```

RETURNS

1	switch is open
0	switch is closed

SEE ALSO

[StaSwitch.IsClosed\(\)](#)

Open

Opens the switch by changing its status to 'open'. This action will fail if the status is currently determined by an active running arrangement.

```
int StaSwitch.Open()
```

RETURNS

0	On success
≠ 0	On error

SEE ALSO

[StaSwitch.Close\(\)](#)

5.3.18 StaVt

Overview

[SetPrimaryTap](#)

SetPrimaryTap

Determines the best matching primary tap for the connected node, so that $U_{Nom,Node} \cdot safety \leq U_{Pri}$. If no tap satisfies the equation, the largest tap is used.

```
int StaVt.SetPrimaryTap([float safety])
```

ARGUMENTS

safety (optional)
Safety factor (default 1.0)

RETURNS

0	Correctly set.
1	Error.

5.4 Commands

Overview

[Execute](#)

Execute

Executes the command.

```
int Com*.Execute()
```

RETURNS

0 on success and 1 on error.

5.4.1 ComAddlabel

Overview

[Execute](#)

Execute

This function executes the Add Statistic Labels command itself for a given plot and curve.

```
int ComAddlabel.Execute(DataObject plot, int curveIndex)
```

ARGUMENTS

plot The plot to modify.

curveIndex
The index of the curve inside the plot's table. The index is zero based, therefore the index of the first curve is 0.

RETURNS

- 0** The function executed without any errors.
- 1** The plot is visible on a single line graphic only.
- 2** The parameter plot is None.
- 3** The parameter plot is not a valid plot object (classname should either be `PltLinebarplot` or it should start with `Vis`).
- 4** The object plot was found in any open graphic.
- 5** The object plot is not a diagram.
- 6** An internal error occurred (plot is incomplete).

5.4.2 ComAddon

Overview

[CreateModule](#)
[DefineDouble](#)
[DefineDoubleMatrix](#)
[DefineDoublePerConnection](#)
[DefineDoubleVector](#)
[DefineDoubleVectorPerConnection](#)
[DefineInteger](#)
[DefineIntegerPerConnection](#)
[DefineIntegerVector](#)
[DefineIntegerVectorPerConnection](#)
[DefineObject](#)
[DefineObjectPerConnection](#)
[DefineObjectVector](#)
[DefineObjectVectorPerConnection](#)
[DefineString](#)
[DefineStringPerConnection](#)

[DeleteModule](#)
[FinaliseModule](#)
[GetActiveModule](#)
[ModuleExists](#)
[SetActiveModule](#)

CreateModule

Creates the calculation module of this AddOn. Volatile object parameters are created for all variable definitions stored inside this command. They are accessible like any other built in object parameter.

```
int ComAddon.CreateModule()
```

RETURNS

- 0** Ok, module was created.
- 1** An error occurred.

SEE ALSO

[ComAddon.FinaliseModule\(\)](#) [ComAddon.DeleteModule\(\)](#)

DefineDouble

Creates a new floating-point-number parameter for the given type of objects.

```
int ComAddon.DefineDouble(str class,
                          str name,
                          str desc,
                          str unit,
                          float initial)
```

ARGUMENTS

- class* The type of objects for which the new parameter is to be created, e.g. ElmLne for the line.
- name* Name of the new parameter
- desc* Parameter description
- unit* Parameter's unit
- initial* Default value of new parameter

RETURNS

- 0** Ok, Parameter was created.
- Other than 0** An error occurred, possible reasons:
 - The module of this add on does not exist.
 - An object with the given class does not exist in PowerFactory.
 - The parameter name for the given class already exists in the module.

SEE ALSO

[ComAddon.DefineDoublePerConnection\(\)](#)

DefineDoubleMatrix

Creates a new floating-point-matrix parameter for the given type of objects.

```
int ComAddon.DefineDoubleMatrix(string class,
                                str name,
                                str desc,
                                str unit,
                                float initial,
                                int rows,
                                int columns)
```

ARGUMENTS

- | | |
|----------------|---|
| <i>class</i> | The type of objects for which the new parameter is to be created, e.g. ElmLne for the line. |
| <i>name</i> | Name of the new parameter. |
| <i>desc</i> | Parameter description. |
| <i>unit</i> | Parameter's unit. |
| <i>initial</i> | Default value for all entries of new parameter. |
| <i>rows</i> | Number of initial rows. Number of rows will be 0 if a value smaller than 0 is given. |
| <i>columns</i> | Number of initial columns. Number of columns will be 0 if a value smaller than 0 is given. |

RETURNS

- 0** Ok, Parameter was created.
- Other than 0** An error occurred, possible reasons:
- The module of this add on does not exist.
 - An object with the given class does not exist in PowerFactory.
 - The parameter name for the given class already exists in the module.

DefineDoublePerConnection

Creates a new floating-point-number parameter for every connection for the given type of objects.

```
int ComAddon.DefineDoublePerConnection(str class,
                                        str name,
                                        str desc,
                                        str unit,
                                        float initial)
```

ARGUMENTS

- | | |
|--------------|---|
| <i>class</i> | The type of objects for which the new parameter is to be created, e.g. ElmLne for the line. |
| <i>name</i> | Name of the new parameter |

<i>desc</i>	Parameter description
<i>unit</i>	Parameter's unit
<i>initial</i>	Default value of new parameter

RETURNS

0 Ok, Parameter was created.

Other than 0 An error occurred, possible reasons:

- The module of this add on does not exist.
- An object with the given class does not exist in PowerFactory.
- The parameter name for the given class already exists in the module.
- The elements of class are not branch elements. Therefore there is no connection count. DefineDouble shall be used instead.

SEE ALSO

[ComAddon.DefineDouble\(\)](#)

DefineDoubleVector

Creates a new floating-point-number vector parameter for the given type of objects.

```
int ComAddon.DefineDoubleVector(str class,
                                str name,
                                str desc,
                                str unit,
                                float initial,
                                int size)
```

ARGUMENTS

<i>class</i>	The type of objects for which the new parameter is to be created, e.g. ElmLne for the line.
<i>name</i>	Name of the new parameter
<i>desc</i>	Parameter description
<i>unit</i>	Parameter's unit
<i>initial</i>	Default value of new parameter
<i>size</i>	Initial size of vector. Size will be 0 if a value smaller than 0 is given.

RETURNS

0 Ok, Parameter was created.

Other than 0 An error occurred, possible reasons:

- The module of this add on does not exist.
- An object with the given class does not exist in PowerFactory.
- The parameter name for the given class already exists in the module.

SEE ALSO

[ComAddon.DefineDouble\(\)](#) [ComAddon.DefineDoublePerConnection\(\)](#)

DefineDoubleVectorPerConnection

Creates a new floating-point-number vector parameter for the given type of objects for every connection of the object.

```
int ComAddon.DefineDoubleVectorPerConnection(str class,
                                             str name,
                                             str desc,
                                             str unit,
                                             float initial,
                                             int size)
```

ARGUMENTS

<i>class</i>	The type of objects for which the new parameter is to be created, e.g. Elmlne for the line.
<i>name</i>	Name of the new parameter
<i>desc</i>	Parameter description
<i>unit</i>	Parameter's unit
<i>initial</i>	Default value of new parameter
<i>size</i>	Initial size of vector. Size will be 0 if a value smaller than 0 is given.

RETURNS

0 Ok, Parameter was created.

Other than 0 An error occurred, possible reasons:

- The module of this add on does not exist.
- An object with the given class does not exist in PowerFactory.
- The parameter name for the given class already exists in the module.
- The elements of class are not branch elements. Therefore there is no connection count. DefineDoubleVector shall be used instead.

SEE ALSO

[ComAddon.DefineDoubleVector\(\)](#)

DefineInteger

Creates a new integer parameter for the given type of objects.

```
int ComAddon.DefineInteger(str class,
                           str name,
                           str desc,
                           str unit,
                           int initial)
```

ARGUMENTS

<i>class</i>	The type of objects for which the new parameter is to be created, e.g. <code>ElmLne</code> for the line.
<i>name</i>	Name of the new parameter
<i>desc</i>	Parameter description
<i>unit</i>	Parameter's unit
<i>initial</i>	Default value of new parameter

RETURNS

0 Ok, Parameter was created.

Other than 0 An error occurred, possible reasons:

- The module of this add on does not exist.
- An object with the given class does not exist in PowerFactory.
- The parameter name for the given class already exists in the module.

SEE ALSO

[ComAddOn.DefineIntegerPerConnection\(\)](#)

DefineIntegerPerConnection

Creates a new integer parameter for every connection for the given type of objects.

```
int ComAddOn.DefineIntegerPerConnection(str class,
                                       str name,
                                       str desc,
                                       str unit,
                                       int initial)
```

ARGUMENTS

<i>class</i>	The type of objects for which the new parameter is to be created, e.g. <code>ElmLne</code> for the line.
<i>name</i>	Name of the new parameter
<i>desc</i>	Parameter description
<i>unit</i>	Parameter's unit
<i>initial</i>	Default value of new parameter

RETURNS

0 Ok, Parameter was created.

Other than 0 An error occurred, possible reasons:

- The module of this add on does not exist.
- An object with the given class does not exist in PowerFactory.
- The parameter name for the given class already exists in the module.
- The elements of class are not branch elements. Therefore there is no connection count. `DefineInteger` shall be used instead.

SEE ALSO

[ComAddon.DefineInteger\(\)](#)

DefineIntegerVector

Creates a new integer vector parameter for the given type of objects.

```
int ComAddon.DefineIntegerVector(str class,
                                str name,
                                str desc,
                                str unit,
                                int initial,
                                int size)
```

ARGUMENTS

<i>class</i>	The type of objects for which the new parameter is to be created, e.g. ElmLne for the line.
<i>name</i>	Name of the new parameter
<i>desc</i>	Parameter description
<i>unit</i>	Parameter's unit
<i>initial</i>	Default value of new parameter
<i>size</i>	Initial size of vector. Size will be 0 if a value smaller than 0 is given.

RETURNS

0 Ok, Parameter was created.

Other than 0 An error occurred, possible reasons:

- The module of this add on does not exist.
- An object with the given class does not exist in PowerFactory.
- The parameter name for the given class already exists in the module.

SEE ALSO

[ComAddon.DefineInteger\(\)](#) [ComAddon.DefineIntegerPerConnection\(\)](#)

DefineIntegerVectorPerConnection

Creates a new integer vector parameter for the given type of objects for every connection of the object.

```
int ComAddon.DefineIntegerVectorPerConnection(str class,
                                                str name,
                                                str desc,
                                                str unit,
                                                int initial,
                                                int size)
```

ARGUMENTS

<i>class</i>	The type of objects for which the new parameter is to be created, e.g. ElmLne for the line.
<i>name</i>	Name of the new parameter

<i>desc</i>	Parameter description
<i>unit</i>	Parameter's unit
<i>initial</i>	Default value of new parameter
<i>size</i>	Initial size of vector. Size will be 0 if a value smaller than 0 is given.

RETURNS

0 Ok, Parameter was created.

Other than 0 An error occurred, possible reasons:

- The module of this add on does not exist.
- An object with the given class does not exist in PowerFactory.
- The parameter name for the given class already exists in the module.
- The elements of class are not branch elements. Therefore there is no connection count. DefineIntegerVector shall be used instead.

SEE ALSO

[ComAddon.DefineIntegerVector\(\)](#)

DefineObject

Creates a new object parameter for the given type of objects.

```
int ComAddon.DefineObject(str class,
                          str name,
                          str desc,
                          DataObject initial)
```

ARGUMENTS

<i>class</i>	The type of objects for which the new parameter is to be created, e.g. Elmlne for the line.
<i>name</i>	Name of the new parameter
<i>desc</i>	Parameter description
<i>initial</i>	Default object of new parameter

RETURNS

0 Ok, Parameter was created.

Other than 0 An error occurred, possible reasons:

- The module of this add on does not exist.
- An object with the given class does not exist in PowerFactory.
- The parameter name for the given class already exists in the module.

SEE ALSO

[ComAddon.DefineObjectPerConnection\(\)](#)

DefineObjectPerConnection

Creates a new object parameter for every connection for the given type of objects.

```
int ComAddon.DefineObjectPerConnection(str class,
                                       str name,
                                       str desc,
                                       DataObject initial)
```

ARGUMENTS

<i>class</i>	The type of objects for which the new parameter is to be created, e.g. ElmLne for the line.
<i>name</i>	Name of the new parameter
<i>desc</i>	Parameter description
<i>initial</i>	Default value of new parameter

RETURNS

- 0** Ok, Parameter was created.
- Other than 0** An error occurred, possible reasons:
- The module of this add on does not exist.
 - An object with the given class does not exist in PowerFactory.
 - The parameter name for the given class already exists in the module.
 - The elements of class are not branch elements. Therefore there is no connection count. DefineObject shall be used instead.

SEE ALSO

[ComAddon.DefineObject\(\)](#)

DefineObjectVector

Creates a new object vector parameter for the given type of objects.

```
int ComAddon.DefineObjectVector(str class,
                                str name,
                                str desc,
                                DataObject initial,
                                int size)
```

ARGUMENTS

<i>class</i>	The type of objects for which the new parameter is to be created, e.g. ElmLne for the line.
<i>name</i>	Name of the new parameter.
<i>desc</i>	Parameter description.
<i>initial</i>	Default value of new parameter.
<i>size</i>	Initial size of vector. Size will be 0 if a value smaller than 0 is given.

RETURNS

- 0** Ok, Parameter was created.
- Other than 0** An error occurred, possible reasons:
- The module of this add on does not exist.
 - An object with the given class does not exist in PowerFactory.
 - The parameter name for the given class already exists in the module.

SEE ALSO

[ComAddon.DefineObject\(\)](#) [ComAddon.DefineObjectPerConnection\(\)](#)

DefineObjectVectorPerConnection

Creates a new object vector parameter for the given type of objects for every connection of the object.

```
int ComAddon.DefineObjectVectorPerConnection(str class,
                                             str name,
                                             str desc,
                                             DataObject initial,
                                             int size)
```

ARGUMENTS

<i>class</i>	The type of objects for which the new parameter is to be created, e.g. ElmLne for the line.
<i>name</i>	Name of the new parameter.
<i>desc</i>	Parameter description.
<i>initial</i>	Default value of new parameter.
<i>size</i>	Initial size of vector. Size will be 0 if a value smaller than 0 is given.

RETURNS

0 Ok, Parameter was created.

Other than 0 An error occurred, possible reasons:

- The module of this add on does not exist.
- An object with the given class does not exist in PowerFactory.
- The parameter name for the given class already exists in the module.
- The elements of class are not branch elements. Therefore there is no connection count. DefineObjectVector shall be used instead.

SEE ALSO

[ComAddon.DefineObjectVector\(\)](#)

DefineString

Creates a new text parameter for the given type of objects.

```
int ComAddon.DefineString(str class,
                          str name,
                          str desc,
                          str unit,
                          str initial)
```

ARGUMENTS

<i>class</i>	The type of objects for which the new parameter is to be created, e.g. ElmLne for the line.
<i>name</i>	Name of the new parameter
<i>desc</i>	Parameter description

<i>unit</i>	Parameter's unit
<i>initial</i>	Default value of new parameter

RETURNS

0 Ok, Parameter was created.

Other than 0 An error occurred, possible reasons:

- The module of this add on does not exist.
- An object with the given class does not exist in PowerFactory.
- The parameter name for the given class already exists in the module.

SEE ALSO

[ComAddon.DefineStringPerConnection\(\)](#)

DefineStringPerConnection

Creates a new text parameter for every connection for the given type of objects.

```
int ComAddon.DefineStringPerConnection(str class,
                                       str name,
                                       str desc,
                                       str unit,
                                       str initial)
```

ARGUMENTS

<i>class</i>	The type of objects for which the new parameter is to be created, e.g. Elmlne for the line.
<i>name</i>	Name of the new parameter
<i>desc</i>	Parameter description
<i>unit</i>	Parameter's unit
<i>initial</i>	Default value of new parameter

RETURNS

0 Ok, Parameter was created.

Other than 0 An error occurred, possible reasons:

- The module of this add on does not exist.
- An object with the given class does not exist in PowerFactory.
- The parameter name for the given class already exists in the module.
- The elements of class are not branch elements. Therefore there is no connection count. DefineString shall be used instead.

SEE ALSO

[ComAddon.DefineString\(\)](#)

DeleteModule

Deletes the module of this add on.

```
int ComAddon.DeleteModule()
```

- 0 Success. The module is deleted completely.
- 1 Failure. The module does not exist and can therefore not be deleted.

SEE ALSO

[ComAddon.CreateModule\(\)](#)

FinaliseModule

Finalises a user defined module which was created using the method CreateModule. All user defined variables defined for this module are read-only after the call of finalise module. The module is the one being used in the flexible data, single line graphic text boxes and colouring. It can be reset like any other built-in calculation using the reset button.

```
int ComAddon.FinaliseModule()
```

RETURNS

- 0 Ok, module was finalised.
- 1 An error occurred, this command is not the one being currently active.

SEE ALSO

[ComAddon.CreateModule\(\)](#)

GetActiveModule

Gets the key of the module being currently active. An empty string is returned if there is no active module.

```
str ComAddon.GetActiveModule()
```

RETURNS

The key of the active module. an empty string is returned if there is no active module.

SEE ALSO

[ComAddon.SetActiveModule\(\)](#)

ModuleExists

Checks if the module for this add-on was already created using the method CreateModule.

```
int ComAddon.ModuleExists()
```

RETURNS

- 0 The module was not created yet.
- 1 The module was already created.

SEE ALSO

[ComAddon.CreateModule\(\)](#) [ComAddon.FinaliseModule\(\)](#) [ComAddon.DeleteModule\(\)](#)

SetActiveModule

Set this module as active module. This method is required only if several modules are created concurrently. In case that only one module is being used, there is no need to use this method, because CreateModule sets the created module automatically as active module.

```
int ComAddon.SetActiveModule()
```

RETURNS

- 0** Success. This command is set as active module.
- 1** Failure. This command is already the active module.

SEE ALSO

[ComAddon.CreateModule\(\)](#) [ComAddon.FinaliseModule\(\)](#) [ComAddon.DeleteModule\(\)](#)

5.4.3 ComAmpacity

Overview

[ExecuteAmpacityCalc](#)

ExecuteAmpacityCalc

The function executes ampacity calculation with or without the tabular report at the end.

```
int ComAmpacity.ExecuteAmpacityCalc([int ireport = 1])
```

ARGUMENTS

- ireport (optional)*
Show report or not, default = 1.

5.4.4 ComArcreport

Overview

[GetLocationsToReport](#)
[GetUnitFor](#)
[GetValueFor](#)
[IsDguv](#)
[IsEpri](#)

GetLocationsToReport

Returns the accessible locations with stored results, i.e. which can be reported.

```
list ComArcreport.GetLocationsToReport()
```

RETURNS

Container with reportable accessible locations.

GetUnitFor

Returns the unit for the given variable. The unit corresponds the selected display unit for each variable at the time the result file was read.

```
str ComArcreport.GetUnitFor(str variable)
```

ARGUMENTS

variable Variable for which to retrieve the unit.

RETURNS

The unit or an empty string if no stored result exists for the given arguments.

GetValueFor

Returns the stored value for the given location and variable.

```
float ComArcreport.GetValueFor(DataObject location,
                               str variable,
                               [int arc])
```

ARGUMENTS

location Accessible location for which to retrieve the result.

variable Variable for which to retrieve the result. In addition to the arc-flash related monitor variables stored in the result file, the following artificial variables can be retrieved. The availability of the artificial variables depends on the arc-flash standard used to write the result file.

m:Ik Short-circuit current
m:Ikmax Max. short-circuit current
m:Ikmin Min. short-circuit current

arc (optional)

Flag which result should be retrieved:

-1 Worst case (default)
0 Full arcing current
1 Reduced arcing current

RETURNS

The stored value or 0.0 if no stored result exists for the given arguments.

IsDguv

Returns whether or not the results were written for a DGUV 203-077 calculation.

```
int ComArcreport.IsDguv()
```


RETURNS

- 1** The results were written for a DGUV 203-077 calculation.
- 0** The results were written for different calculation.

IsEpri

Returns whether or not the results were written for an EPRI calculation.

```
int ComArcreport.IsEpri()
```

RETURNS

- 1** The results were written for an EPRI calculation.
- 0** The results were written for a different calculation.

5.4.5 ComAuditlog

Overview

[Check](#)

Check

Checks integrity of Audit Log.

```
int ComAuditlog.Check()
```

RETURNS

number of errors

5.4.6 ComBoundary

Overview

[GetCreatedBoundaries](#)

GetCreatedBoundaries

Gets created boundaries after the command has been executed.

```
list ComBoundary.GetCreatedBoundaries()
```

RETURNS

Container of created boundaries.

5.4.7 ComCapo

Overview

[ConnectShuntToBus](#)
[LossCostAtBusTech](#)
[TotalLossCost](#)

ConnectShuntToBus

Connects the equivalent shunt in the specified terminal and executes the load flow command. The shunt is not physically added in the database, just the susceptance is added for the calculation.

```
int ComCapo.ConnectShuntToBus(DataObject terminal,
                              float phtech,
                              float Q
                              )
```

ARGUMENTS

terminal The terminal to which the shunt will be connected

phtech Phase technology. Possible values are

0	three-phase
1	ph-ph a-b
2	ph-ph b-c
3	ph-ph a-c
4	ph-e a
5	ph-e b
6	ph-e c

Note: In balanced load flow, the technology will always be three-phase.

Q Reactive power value in Mvar

RETURNS

- 0** On success.
- 1** An error occurred during load flow execution.

LossCostAtBusTech

Returns the losses cost of the selected terminal and configuration calculated during the sensitivity analysis or the optimization.

```
float ComCapo.LossCostAtBusTech(DataObject terminal,
                                float phtech
                                )
```

ARGUMENTS

<i>terminal</i>	Specified bus
<i>phtech</i>	Phase technology. Possible values are
0	three-phase
1	ph-ph a-b
2	ph-ph b-c
3	ph-ph a-c
4	ph-e a
5	ph-e b
6	ph-e c

RETURNS

Returns the losses cost

TotalLossCost

Returns the total cost calculated after the sensitivity analysis or the optimization.

```
float ComCapo.TotalLossCost([int iopt])
```

ARGUMENTS

<i>iopt (optional)</i>	Type of cost. Possible values are
0	Losses in MW (default)
1	Cost of losses
2	Cost of voltage violations
3	Cost of shunts

RETURNS

Returns losses in MW or cost value.

5.4.8 ComCheck**Overview**

[ClearGroundingAreas](#)
[GetGroundingAreaCouplings](#)
[GetGroundingAreaElements](#)
[GetGroundingAreaGroundings](#)
[GetNumberOfGroundingAreas](#)
[InitGroundingAreas](#)

ClearGroundingAreas

Clears the internal cache of grounding areas.

```
None ComCheck.ClearGroundingAreas()
```

GetGroundingAreaCouplings

Returns elments, such as YNyn transformers, that may connect the given grounding area with other grounding areas. Requires [ComCheck.InitGroundingAreas\(\)](#) to have been called already.

```
list ComCheck.GetGroundingAreaCouplings(int areaIndex)
```

RETURNS

Elments coupling the grounding area with other areas.

GetGroundingAreaElements

Returns elements belonging to the grounding area with the given index. Requires [ComCheck.InitGroundingAreas\(\)](#) to have been called already.

```
list ComCheck.GetGroundingAreaElements(int areaIndex)
```

RETURNS

Elements belonging to the given grounding area.

GetGroundingAreaGroundings

Returns the ground connections of the grounding area with the given index. The connections are provided in the form of the connecting cubicle (StaCubic) so that it is possible to identify the corresponding side with the ground connection. Requires [ComCheck.InitGroundingAreas\(\)](#) to have been called already.

```
list ComCheck.GetGroundingAreaGroundings(int areaIndex)
```

RETURNS

Cubicles connected to ground connections of the given grounding area.

GetNumberOfGroundingAreas

Returns the number of cached grounding areas. Requires [ComCheck.InitGroundingAreas\(\)](#) to have been called already.

```
int ComCheck.GetNumberOfGroundingAreas()
```

RETURNS

The number of cached grounding areas.

InitGroundingAreas

Initialises the internal cache of grounding areas to enable the index-based access for the other grounding area related functions. Please note that changes to the network topology after this function has been called will only be reflected once the function is called again.

```
None ComCheck.InitGroundingAreas()
```

5.4.9 ComCimdbexp

Overview

Execute

Execute

Executes the export. In case of a validation error the export is not performed.

```
int ComCimdbexp.Execute([int validate])
```

ARGUMENTS

validate (optional)

Option to execute CIM Data Validation before export. If not provided, the validation is executed. Possible values are

0	Do not validate
1	Validate

RETURNS

0	OK
1	Error: export failed

EXAMPLE

The following example exports CIM archive to a file using a preconfigured CIM Data Export command from the active project.

```
import powerfactory
app = powerfactory.GetApplicationExt()

cimdbexp = app.GetFromStudyCase("ComCimdbexp")
result = cimdbexp.Execute()
if result == 0:
    app.PrintInfo("OK")
else:
    app.PrintError("Error: export failed")
```

5.4.10 ComCimdbimp

Overview

[Execute](#)
[ImportAndConvert](#)

Execute

Executes the import.

```
int ComCimdbimp.Execute([int validate])
```

ARGUMENTS

validate (optional)

Option to execute CIM Data Validation after import. If not provided, the validation is executed. Possible values are

0	Do not validate
1	Validate

RETURNS

0	OK
1	Error: import failed

EXAMPLE

The following example creates a new CIM Data Import command, configures it and imports the data into the active project.

```
import powerfactory
app = powerfactory.GetApplicationExt()

cimdbimp = app.GetFromStudyCase("ComCimdbimp")
cimdbimp.SetAttribute("targetName", "testArchive")
cimdbimp.SetAttribute("fileName", "E:\\test\\test.zip")
result = cimdbimp.Execute()
if result == 0:
    app.PrintInfo("OK")
else:
    app.PrintError("Error: import failed")
```

ImportAndConvert

Imports CIM data from file path provided in the 'CIM Data Import' command without storing CIM data into database, and converts CIM to Grid using the 'CIM to Grid Conversion' command object provided in the function call as template. The CIM to Grid Conversion will be executed with default settings if the command object is not provided in the function call.

```
int ComCimdbimp.ImportAndConvert([int validate],
                                  [DataObject cimToGrid])
```

ARGUMENTS

validate (optional)

Option to execute CIM Data Validation after import. If not provided, the validation is executed. Possible values are

0	Do not validate
1	Validate

cimToGrid (optional)

ComCimtogrid object with preconfigured settings for converting imported CIM data. If not provided, the default CIM to Grid Conversion settings will be used.

RETURNS

0	OK
1	Error: import failed
2	Error: conversion failed

EXAMPLE

The following example imports and converts a *CimArchive* from a specified ZIP file.

```
import powerfactory
app = powerfactory.GetApplicationExt()

cimdbimp = app.GetFromStudyCase("ComCimdbimp")
cimdbimp.SetAttribute("fileName", "E:\\test\\test.zip")
result = cimdbimp.ImportAndConvert()
if result == 0:
    app.PrintInfo("OK")
elif result == 1:
    app.PrintError("Error: import failed")
else:
    app.PrintError("Error: conversion failed")
```

5.4.11 ComCimtogrid

Overview

[AppendMessage](#)
[GetMessageDescription](#)
[GetMessageObject](#)
[GetMessageSeverity](#)
[GetNumberOfMessages](#)

AppendMessage

Appends the conversion message.

```
None ComCimtogrid.AppendMessage(str severity,
                                str description,
                                str objectFullname
                                )
```

ARGUMENTS

severity Message severity.

description
Message description.

objectFullname
Full name of the object for which the message is reported, or type and name of the object.

EXAMPLE

The following example appends the conversion message.

```
import powerfactory
app = powerfactory.GetApplicationExt()
cimtogrid = app.GetFromStudyCase("ComCimtogrid")
objectFullname = cimtogrid.GetFullPath()
cimtogrid.AppendMessage("Warning",
                        "This is a sample message.",
                        objectFullname)
```

GetMessageDescription

Returns the description from the selected conversion message.

```
str ComCimtogrid.GetMessageDescription(int messageIndex)
```

ARGUMENTS

messageIndex
Index of the conversion message.

RETURNS

Message description.

EXAMPLE

The following example prints the description text from each conversion message.

```
import powerfactory
app = powerfactory.GetApplicationExt()

cimtogrid = app.GetFromStudyCase("ComCimtogrid")
nMessages = cimtogrid.GetNumberOfMessages()
for i in range(nMessages):
    descriptionText = cimtogrid.GetMessageDescription(i)
    app.PrintInfo("%s" % descriptionText)
```

GetMessageObject

Returns the object from the selected conversion message.

```
str ComCimtogrid.GetMessageObject(int messageIndex)
```


ARGUMENTS

messageIndex

Index of the conversion message.

RETURNS

Object for which the message is reported.

EXAMPLE

The following example prints the object from each conversion message.

```
import powerfactory
app = powerfactory.GetApplicationExt()

cimtogrid = app.GetFromStudyCase("ComCimtogrid")
nMessages = cimtogrid.GetNumberOfMessages()
for i in range(nMessages):
    messageObject = cimtogrid.GetMessageObject(i)
    app.PrintInfo("%s" % messageObject)
```

GetMessageSeverity

Returns the severity of the selected conversion message.

```
str ComCimtogrid.GetMessageSeverity(int messageIndex)
```

ARGUMENTS

messageIndex

Index of the conversion message.

RETURNS

Message severity.

EXAMPLE

The following example prints the severity for each conversion message.

```
import powerfactory
app = powerfactory.GetApplicationExt()

cimtogrid = app.GetFromStudyCase("ComCimtogrid")
nMessages = cimtogrid.GetNumberOfMessages()
for i in range(nMessages):
    severity = cimtogrid.GetMessageSeverity(i)
    app.PrintInfo("%s" % severity)
```

GetNumberOfMessages

Returns the number of conversion messages generated.

```
int ComCimtogrid.GetNumberOfMessages()
```

RETURNS

Number of conversion messages.

EXAMPLE

The following example prints the number of conversion messages got for the last grid to CIM conversion.

```
import powerfactory
app = powerfactory.GetApplicationExt()

cimtogrid = app.GetFromStudyCase("ComCimtogrid")
nMessages = cimtogrid.GetNumberOfMessages()
app.PrintInfo("Number of messages: %d" % nMessages)
```

5.4.12 ComCimvalidate

Overview

[Execute](#)
[GetClassType](#)
[GetDescriptionText](#)
[GetInputObject](#)
[GetModel](#)
[GetModelId](#)
[GetNumberOfValidationMessages](#)
[GetObject](#)
[GetObjectId](#)
[GetProfile](#)
[GetSeverity](#)
[GetType](#)

Execute

Executes the validation. Creates no validation report if no errors, or warnings were found.

```
int ComCimvalidate.Execute([int openReport])
```

ARGUMENTS

openReport (optional)

Option to open report after validation. If not provided, the report is opened.
Possible values are

0	Do not open report
1	Open report

RETURNS

0	OK
1	Error: validation failed

EXAMPLE

The following example executes the validation for the configured CIM Data Validation (ComCimvalidate) command in the active project. In case of error the validation report is not opened.

```
import powerfactory
app = powerfactory.GetApplicationExt()

cimvalidate = app.GetFromStudyCase("ComCimvalidate")
error = cimvalidate.Execute(0)
if error == 0:
    app.PrintInfo("OK")
else:
    app.PrintError("Error: validation failed")
```

GetClassType

Returns the object class type from the selected validation message.

```
str ComCimvalidate.GetClassType(int messageIndex)
```

ARGUMENTS

messageIndex
Index of the validation message.

RETURNS

Object class type.

EXAMPLE

The following example prints the object class type from each validation message.

```
import powerfactory
app = powerfactory.GetApplicationExt()

cimvalidate = app.GetFromStudyCase("ComCimvalidate")
nMessages = cimvalidate.GetNumberOfValidationMessages()
for i in range(nMessages):
    classType = cimvalidate.GetClassType(i)
    app.PrintInfo("%s" % classType)
```

GetDescriptionText

Returns the description from the selected validation message.

```
str ComCimvalidate.GetDescriptionText(int messageIndex)
```

ARGUMENTS

messageIndex
Index of the validation message.

RETURNS

Message description.

EXAMPLE

The following example prints the description text from each validation message.

```
import powerfactory
app = powerfactory.GetApplicationExt()

cimvalidate = app.GetFromStudyCase("ComCimvalidate")
nMessages = cimvalidate.GetNumberOfValidationMessages()
for i in range(nMessages):
    descriptionText = cimvalidate.GetDescriptionText(i)
    app.PrintInfo("%s" % descriptionText)
```

GetInputObject

Returns the object selected for validation.

```
DataObject ComCimvalidate.GetInputObject()
```

RETURNS

Pointer to *CimArchive*, *CimModel*, or *SetSelect*.

EXAMPLE

The following example prints the class of object and object selected for validation in the active project.

```
import powerfactory
app = powerfactory.GetApplicationExt()

cimvalidate = app.GetFromStudyCase("ComCimvalidate")
selectedObject = cimvalidate.GetInputObject()
objectClass = selectedObject.GetClassName()
app.PrintInfo("%s: %s" % (objectClass, selectedObject))
```

GetModel

This function is deprecated. Please use `ComCimValidate.GetObject()` to access to the CIM model, or CIM object affected by the validation message.

```
DataObject ComCimvalidate.GetModel(int messageIndex)
```

EXAMPLE

The following example prints the *CimModel* object for each validation message.

```
import powerfactory
app = powerfactory.GetApplicationExt()

cimvalidate = app.GetFromStudyCase("ComCimvalidate")
nMessages = cimvalidate.GetNumberOfValidationMessages()
for i in range(nMessages):
    object = cimvalidate.GetObject(i)
    if object.GetClassName() == "CimModel":
        cimModel = object
    else:
        cimClassFolder = object.GetParent()
        cimModel = cimClassFolder.GetParent()
    app.PrintInfo(cimModel)
```

GetModelId

This function is deprecated. Please use `ComCimValidate.GetObject()` to access to the CIM model, or CIM object affected by the validation message.

```
str ComCimValidate.GetModelId(int messageIndex)
```

EXAMPLE

The following example prints the ID of the CIM model for each validation message.

```
import powerfactory
app = powerfactory.GetApplicationExt()

cimvalidate = app.GetFromStudyCase("ComCimvalidate")
nMessages = cimvalidate.GetNumberOfValidationMessages()
for i in range(nMessages):
    object = cimvalidate.GetObject(i)
    if object.GetClassName() == "CimModel":
        modelId = object.GetAttribute("resID")
    else:
        cimClassFolder = object.GetParent()
        model = cimClassFolder.GetParent()
        modelId = model.GetAttribute("resID")
    app.PrintInfo(modelId)
```

GetNumberOfValidationMessages

Returns the number of validation messages generated.

```
int ComCimValidate.GetNumberOfValidationMessages()
```

RETURNS

Number of validation messages.

EXAMPLE

The following example prints the number of validation messages got for the last CIM data validation.

```
import powerfactory
app = powerfactory.GetApplicationExt()

cimvalidate = app.GetFromStudyCase("ComCimvalidate")
nMessages = cimvalidate.GetNumberOfValidationMessages()
app.PrintInfo("Number of validation messages: %d" % nMessages)
```

GetObject

Returns the *CimObject* object from the selected validation message.

```
DataObject ComCimValidate.GetObject(int messageIndex)
```

ARGUMENTS

messageIndex

Index of the validation message.

RETURNS

Pointer to *CimObject*.

EXAMPLE

The following example prints the *CimObject* object from each validation message.

```
import powerfactory
app = powerfactory.GetApplicationExt()

cimvalidate = app.GetFromStudyCase("ComCimvalidate")
nMessages = cimvalidate.GetNumberOfValidationMessages()
for i in range(nMessages):
    cimObject = cimvalidate.GetObject(i)
    app.PrintInfo("%s" % cimObject)
```

GetObjectId

This function is deprecated. Please use `ComCimValidate.GetObject()` to access to the CIM model, or CIM object affected by the validation message.

```
str ComCimvalidate.GetObjectId(int messageIndex)
```

EXAMPLE

The following example prints the object ID for each validation message.

```
import powerfactory
app = powerfactory.GetApplicationExt()

cimvalidate = app.GetFromStudyCase("ComCimvalidate")
nMessages = cimvalidate.GetNumberOfValidationMessages()
for i in range(nMessages):
    object = cimvalidate.GetObject(i);
    objectId = object.GetAttribute("resID")
    app.PrintInfo(objectId)
```

GetProfile

Returns the model profile from the selected validation message.

```
str ComCimvalidate.GetProfile(int messageIndex)
```

ARGUMENTS

messageIndex

Index of the validation message.

RETURNS

Model profile.

EXAMPLE

The following example prints the profile for each validation message.

```
import powerfactory
app = powerfactory.GetApplicationExt()

cimvalidate = app.GetFromStudyCase("ComCimvalidate")
nMessages = cimvalidate.GetNumberOfValidationMessages()
for i in range(nMessages):
    profile = cimvalidate.GetProfile(i)
    app.PrintInfo("%s" % profile)
```

GetSeverity

Returns the severity of the selected validation message.

```
str ComCimvalidate.GetSeverity(int messageIndex)
```

ARGUMENTS

messageIndex
Index of the validation message.

RETURNS

Message severity.

EXAMPLE

The following example prints the severity for each validation message.

```
import powerfactory
app = powerfactory.GetApplicationExt()

cimvalidate = app.GetFromStudyCase("ComCimvalidate")
nMessages = cimvalidate.GetNumberOfValidationMessages()
for i in range(nMessages):
    severity = cimvalidate.GetSeverity(i)
    app.PrintInfo("%s" % severity)
```

GetType

This function is deprecated. There is no replacement function offered. Please use `ComCimValidate.GetDescriptionText()` to retrieve the description of the validation message instead.

```
str ComCimvalidate.GetType(int messageIndex)
```

5.4.13 ComConreq

Overview

[Execute](#)

Execute

Performs a Connection Request Assessment according to the selected method. Results are provided for connection request elements in the single line graphic, and are summarised in a report in the output window.

```
int ComConreq.Execute()
```

RETURNS

- | | |
|---|--|
| 0 | OK |
| 1 | Error: calculation function |
| 2 | Error: settings/initialisation/load flow |

5.4.14 ComContingency

Overview

[ContinueTrace](#)
[CreateRecoveryInformation](#)
[GetGeneratorEvent](#)
[GetInterruptedPowerAndCustomersForStage](#)
[GetInterruptedPowerAndCustomersForTimeStep](#)
[GetLoadEvent](#)
[GetNumberOfGeneratorEventsForTimeStep](#)
[GetNumberOfLoadEventsForTimeStep](#)
[GetNumberOfSwitchEventsForTimeStep](#)
[GetNumberOfTimeSteps](#)
[GetObj](#)
[GetSwitchEvent](#)
[GetTimeOfStepInSeconds](#)
[GetTotalInterruptedPower](#)
[JumpToLastStep](#)
[RemoveEvents](#)
[StartTrace](#)
[StopTrace](#)

ContinueTrace

Continues trace execution for this contingency.

```
int ComContingency.ContinueTrace()
```


RETURNS

- 0** On success.
- 1** On error.

CreateRecoveryInformation

Creates recovery information for a contingency. The recovery information can later be retrieved e.g. via [ComContingency.GetInterruptedPowerAndCustomersForStage\(\)](#).
Can only save one contingency at the same time.

```
int ComContingency.CreateRecoveryInformation(DataObject resultFileInput)
```

ARGUMENTS

resultFileInput
Read from this result file.

RETURNS

- 0** On success.
- 1** On error.

GetGeneratorEvent

Gets generator event of a certain time step during recovery.
[ComContingency.CreateRecoveryInformation\(\)](#) has to be called beforehand to collect the data.

```
[ DataObject generator,  
float changedP,  
float changedQ ]  
ComContingency.GetGeneratorEvent(int currentTimeStep,  
int loadEvent)
```

ARGUMENTS

currentTimeStep
Input: Number of time steps are get via
[ComContingency.GetNumberOfTimeSteps\(\)](#)

switchEvent
Input: Number of generator events for a certain time step are get via [ComContingency.GetNumberOfSwitchEventsForTimeStep\(\)](#)

generator (out)
Output: Generator that dispatched

changedP (out)
Output: Changed active power

changedQ (out)
Output: Changed reactive power

GetInterruptedPowerAndCustomersForStage

Gets recovery information of a contingency.

[ComContingency.CreateRecoveryInformation\(\)](#) has to be called beforehand to collect the data.

```
[ int error,
float interruptedPower,
float newInterruptedPower,
float interruptedCustomers,
float newInterruptedCustomers ]
ComContingency.
GetInterruptedPowerAndCustomersForStage(float timeOfStageInMinutes)
```

ARGUMENTS

timeOfStageInMinutes

Input: Get Information for this time.

interruptedPower (out)

Output: Interrupted Power at this time.

newInterruptedPower (out)

Output: New interrupted Power at this time.

interruptedCustomers (out)

Output: Interrupted Customers at this time.

newInterruptedCustomers (out)

Output: New interrupted Customers at this time.

RETURNS

0 On success.

1 On error.

GetInterruptedPowerAndCustomersForTimeStep

Gets recovery information of a contingency.

[ComContingency.CreateRecoveryInformation\(\)](#) has to be called beforehand to collect the data.

```
[ float interruptedPower,
float newInterruptedPower,
float interruptedCustomers,
float newInterruptedCustomers ]
ComContingency.
GetInterruptedPowerAndCustomersForTimeStep(int currentTimeStep)
```

ARGUMENTS

currentTimeStep

Input: Number of time steps are get via
[ComContingency.GetNumberOfTimeSteps\(\)](#)

interruptedPower (out)

Output: Interrupted Power at this time.

newInterruptedPower (out)

Output: New interrupted Power at this time.

interruptedCustomers (out)

Output: Interrupted Customers at this time.

newInterruptedCustomers (out)

Output: New interrupted Customers at this time.

GetLoadEvent

Gets load event of a certain time step during recovery.

[ComContingency.CreateRecoveryInformation\(\)](#) has to be called beforehand to collect the data.

```
[ DataObject load,
float changedP,
float changedQ,
int isTransfer ]
ComContingency.GetLoadEvent (int currentTimeStep,
                             int loadEvent)
```

ARGUMENTS

currentTimeStep

Input: Number of time steps are get via

[ComContingency.GetNumberOfTimeSteps\(\)](#)

switchEvent

Input: Number of load events for a certain time step are get via [ComContingency.GetNumberOfSwitchEventsForTimeStep\(\)](#)

load (out) Output: Load that is shed or transfered

changedP (out)

Output: Changed active power

changedQ (out)

Output: Changed reactive power

isTransfer (out)

Output: = 0 : is load shedding event. >0 is load transfer event.

GetNumberOfGeneratorEventsForTimeStep

Returns the number of generator events of a certain step during recovery.

[ComContingency.CreateRecoveryInformation\(\)](#) has to be called beforehand to collect the data.

```
int ComContingency.GetNumberOfGeneratorEventsForTimeStep ([int currentTimeStep])
```

ARGUMENTS

currentTimeStep

Input: Number of time steps are get via

[ComContingency.GetNumberOfTimeSteps\(\)](#)

GetNumberOfLoadEventsForTimeStep

Returns the number of load events of a certain step during recovery.

[ComContingency.CreateRecoveryInformation\(\)](#) has to be called beforehand to collect the data.

```
int ComContingency.GetNumberOfLoadEventsForTimeStep ([int currentTimeStep])
```

ARGUMENTS

currentTimeStep

Input: Number of time steps are get via
[ComContingency.GetNumberOfTimeSteps\(\)](#)

GetNumberOfSwitchEventsForTimeStep

Returns the number of switch events of a certain step during recovery.

[ComContingency.CreateRecoveryInformation\(\)](#) has to be called beforehand to collect the data.

```
int ComContingency.GetNumberOfSwitchEventsForTimeStep([int currentTimeStep])
```

ARGUMENTS

currentTimeStep

Input: Number of time steps are get via
[ComContingency.GetNumberOfTimeSteps\(\)](#)

GetNumberOfTimeSteps

Returns the number of time steps during recovery.

[ComContingency.CreateRecoveryInformation\(\)](#) has to be called beforehand to collect the data.

```
int ComContingency.GetNumberOfTimeSteps()
```

GetObj

Gets interrupted element by index (zero based).

```
DataObject ComContingency.GetObj(int index)
```

ARGUMENTS

index Element order index, 0 for the first object.

RETURNS

object Interrupted element for given index.

None Index out of range.

GetSwitchEvent

Gets switch event of a certain time step during recovery.

[ComContingency.CreateRecoveryInformation\(\)](#) has to be called beforehand to collect the data.

```
[ DataObject switchToBeActuated,  
int isClosed,  
int sectionalizingStep ]  
ComContingency.GetSwitchEvent(int currentTimeStep,  
int switchEvent)
```

ARGUMENTS

currentTimeStep

Input: Number of time steps are get via
[ComContingency.GetNumberOfTimeSteps\(\)](#)

switchEvent

Input: Number of switch event for a certain time step are get via [ComContingency.GetNumberOfSwitchEventsForTimeStep\(\)](#)

switchToBeActuated (out)

Output: Switch to be actuated

isClosed (out)

Output: > 0 if switch is closed

sectionalizingStep (out)

Output: sectionalizing step when this switch is actuated

GetTimeOfStepInSeconds

Returns the time of the current step during recovery.

[ComContingency.CreateRecoveryInformation\(\)](#) has to be called beforehand to collect the data.

```
int ComContingency.GetTimeOfStepInSeconds(int currentTimeStep)
```

ARGUMENTS

currentTimeStep

Input: Number of time steps are get via
[ComContingency.GetNumberOfTimeSteps\(\)](#)

GetTotalInterruptedPower

Gets the total interrupted power (in kW) during restoration.

[ComContingency.CreateRecoveryInformation\(\)](#) has to be called beforehand to collect the data.

```
float ComContingency.GetTotalInterruptedPower()
```

JumpToLastStep

Gets the last trace execution for this contingency.

```
int ComContingency.JumpToLastStep([int timeDelay])
```

ARGUMENTS

timeDelay (optional)

time delay in seconds between trace steps

RETURNS

- 0** On success.
- 1** On error.

RemoveEvents

Removes events from this contingency.

```
None ComContingency.RemoveEvents([float emitMessage])
None ComContingency.RemoveEvents(str whichEvents)
None ComContingency.RemoveEvents(float emitMessage,
                                   str whichEvents
                                   )
None ComContingency.RemoveEvents(str whichEvents,
                                   float emitMessage
                                   )
```

ARGUMENTS

emitMessage(optional)

0: no info message shall be issued after event removal

whichEvents(optional)

'lod' removed load events, 'gen' removes generator events, 'switch' removes switching events

StartTrace

Starts trace execution for this contingency.

```
int ComContingency.StartTrace()
```

RETURNS

- 0** On success.
- 1** Error, e.g. Contingency is not in trace.
- 2** On error.

StopTrace

Stops trace execution for this contingency.

```
int ComContingency.StopTrace([int emitMessage])
```

ARGUMENTS

emitMessage (optional)

= 0: no trace-stop info messages shall be issued

RETURNS

- 0** On Success.
- 1** Contingency is not in Trace.

5.4.15 ComCoordreport

Overview

[DevicesToReport](#)
[HasResultsForDirectionalBackup](#)
[HasResultsForFuse](#)
[HasResultsForInstantaneous](#)
[HasResultsForNonDirectionalBackup](#)
[HasResultsForOverload](#)
[HasResultsForOverreach](#)
[HasResultsForShortCircuit](#)
[HasResultsForZone](#)
[MaxZoneNumberFor](#)
[ResultForDirectionalBackupVariable](#)
[ResultForFuseVariable](#)
[ResultForInstantaneousVariable](#)
[ResultForMaxCurrent](#)
[ResultForNonDirectionalBackupVariable](#)
[ResultForOverloadVariable](#)
[ResultForOverreachVariable](#)
[ResultForShortCircuitVariable](#)
[ResultForZoneVariable](#)
[TopologyForDirectionalBackupVariable](#)
[TopologyForFuseVariable](#)
[TopologyForInstantaneousVariable](#)
[TopologyForMaxCurrent](#)
[TopologyForNonDirectionalBackupVariable](#)
[TopologyForOverloadVariable](#)
[TopologyForOverreachVariable](#)
[TopologyForShortCircuitVariable](#)
[TopologyForZoneVariable](#)
[TransferDirectionalBackupResultsTo](#)
[TransferNonDirectionalBackupResultsTo](#)
[TransferOverreachResultsTo](#)
[TransferResultsTo](#)
[TransferZoneResultsTo](#)

DevicesToReport

Returns the devices with stored results, i.e. which can be reported.

```
list ComCoordreport.DevicesToReport ()
```

RETURNS

Container with reportable devices.

HasResultsForDirectionalBackup

Checks whether there is a stored directional backup result for the given device.

```
int ComCoordreport.HasResultsForDirectionalBackup (DataObject device)
```

ARGUMENTS

device Device for which to check.

RETURNS

- 1** A directional backup result is stored for this device.
- 0** The device has no stored results or no result for the directional backup.

SEE ALSO

[ComCoordreport.HasResultsForZone\(\)](#),
[ComCoordreport.HasResultsForOverreach\(\)](#),
[ComCoordreport.HasResultsForNonDirectionalBackup\(\)](#)

HasResultsForFuse

Checks whether there is a stored fuse result for the given device.

```
int ComCoordreport.HasResultsForFuse(DataObject device)
```

ARGUMENTS

device Device for which to check.

RETURNS

- 1** An fuse result is stored for this device.
- 0** The device has no stored results or no fuse result.

HasResultsForInstantaneous

Checks whether there is a stored instantaneous stage result for the given device.

```
int ComCoordreport.HasResultsForInstantaneous(DataObject device)
```

ARGUMENTS

device Device for which to check.

RETURNS

- 1** An instantaneous stage result is stored for this device.
- 0** The device has no stored results or no result for the instantaneous stage.

SEE ALSO

[ComCoordreport.HasResultsForOverload\(\)](#),
[ComCoordreport.HasResultsForShortCircuit\(\)](#)

HasResultsForNonDirectionalBackup

Checks whether there is a stored non-directional backup result for the given device.

```
int ComCoordreport.HasResultsForNonDirectionalBackup(object device)
```

ARGUMENTS

device Device for which to check.

RETURNS

- 1** A non-directional backup result is stored for this device.
- 0** The device has no stored results or no result for the non-directional backup.

SEE ALSO

[ComCoordreport.HasResultsForZone\(\)](#),
[ComCoordreport.HasResultsForOverreach\(\)](#),
[ComCoordreport.HasResultsForDirectionalBackup\(\)](#)

HasResultsForOverload

Checks whether there is a stored overload stage result for the given device.

```
int ComCoordreport.HasResultsForOverload(DataObject device)
```

ARGUMENTS

device Device for which to check.

RETURNS

- 1** An overload stage result is stored for this device.
- 0** The device has no stored results or no result for the overload stage.

SEE ALSO

[ComCoordreport.HasResultsForShortCircuit\(\)](#),
[ComCoordreport.HasResultsForInstantaneous\(\)](#)

HasResultsForOverreach

Checks whether there is a stored overreach zone result for the given device.

```
int ComCoordreport.HasResultsForOverreach(DataObject device)
```

ARGUMENTS

device Device for which to check.

RETURNS

- 1** An overreach zone result is stored for this device.
- 0** The device has no stored results or no result for the overreach zone.

SEE ALSO

[ComCoordreport.HasResultsForZone\(\)](#),
[ComCoordreport.HasResultsForDirectionalBackup\(\)](#),
[ComCoordreport.HasResultsForNonDirectionalBackup\(\)](#)

HasResultsForShortCircuit

Checks whether there is a stored short-circuit stage result for the given device.

```
int ComCoordreport.HasResultsForShortCircuit(DataObject device)
```

ARGUMENTS

device Device for which to check.

RETURNS

- 1** An short-circuit stage result is stored for this device.
- 0** The device has no stored results or no result for the short-circuit stage.

SEE ALSO

[ComCoordreport.HasResultsForOverload\(\)](#),
[ComCoordreport.HasResultsForInstantaneous\(\)](#)

HasResultsForZone

Checks whether there is a stored result for the given device and zone number.

```
int ComCoordreport.HasResultsForZone(DataObject device,
                                     int zoneNumber)
```

ARGUMENTS

device Device for which to check.

zoneNumber
Zone number to check (1-4).

RETURNS

- 1** A result is stored for this device and zone number.
- 0** The device has no stored results or no result for this zone number.

SEE ALSO

[ComCoordreport.HasResultsForOverreach\(\)](#),
[ComCoordreport.HasResultsForDirectionalBackup\(\)](#),
[ComCoordreport.HasResultsForNonDirectionalBackup\(\)](#)

MaxZoneNumberFor

Returns the highest zone number in the stored results for the given device.

```
int ComCoordreport.MaxZoneNumberFor(DataObject device)
```

ARGUMENTS

device Device for which to retrieve the zone number.

RETURNS

Highest zone number in the stored results.

ResultForDirectionalBackupVariable

Provides access to the directional backup result for a given device and variable.

```
[ int error,
  float result ] ComCoordreport.ResultForDirectionalBackupVariable(DataObject device,
                                                                    str variable)
```

ARGUMENTS

device Device for which to retrieve the result.
variable Variable for which to retrieve the result:

dir Tripping direction
Tp Polygonal delay
Tc Circular delay

result (out)
 Value of the stored result.

RETURNS

- 0** The result is valid.
- 1** The result was not calculated or not found.
- 2** The corresponding topological search failed.
- 3** The corresponding topological search ended prematurely (e.g. end of network reached).
- 4** The corresponding equation required a nominal current and none could be determined.

SEE ALSO

[ComCoordreport.ResultForZoneVariable\(\)](#),
[ComCoordreport.ResultForOverreachVariable\(\)](#),
[ComCoordreport.ResultForNonDirectionalBackupVariable\(\)](#)

ResultForFuseVariable

Provides access to the fuse result for a given device and variable.

```
[ int error,
float result ] ComCoordreport.ResultForFuseVariable(DataObject device,
                                                    str variable)
```

ARGUMENTS

device Device for which to retrieve the result.
variable Variable for which to retrieve the result:

char Overcurrent characteristic
dir Tripping direction
Iset Overcurrent setpoint

result (out)
 Value of the stored result.

RETURNS

- 0** The result is valid.
- 1** The result was not calculated or not found.
- 3** The corresponding topological search ended prematurely (e.g. end of network reached).
- 4** The corresponding equation required a nominal current and none could be determined.
- 5** The calculated value exceeded the calculated maximum current.

SEE ALSO

[ComCoordreport.ResultForMaxCurrent\(\)](#)

ResultForInstantaneousVariable

Provides access to the instantaneous result for a given device and variable.

```
[ int error,
float result ]
ComCoordreport.ResultForInstantaneousVariable(DataObject device,
                                              str variable)
```

ARGUMENTS

device Device for which to retrieve the result.

variable Variable for which to retrieve the result:

char Overcurrent characteristic
dir Tripping direction
Iset Overcurrent setpoint
Tset Overcurrent delay

result (out)
Value of the stored result.

RETURNS

- 0** The result is valid.
- 1** The result was not calculated or not found.
- 3** The corresponding topological search ended prematurely (e.g. end of network reached).
- 4** The corresponding equation required a nominal current and none could be determined.
- 5** The calculated value exceeded the calculated maximum current.

SEE ALSO

[ComCoordreport.ResultForOverloadVariable\(\)](#),
[ComCoordreport.ResultForShortCircuitVariable\(\)](#),
[ComCoordreport.ResultForMaxCurrent\(\)](#)

ResultForMaxCurrent

Provides access to the maximum current result for a given device.

```
[ int error,
float result ] ComCoordreport.ResultForMaxCurrent(DataObject device)
```

ARGUMENTS

device Device for which to retrieve the result.

result (out)
Value of the stored result.

RETURNS

- 0** The result is valid.
- 1** The result was not calculated or not found.
- 3** The corresponding topological search ended prematurely (e.g. end of network reached).
- 4** The corresponding equation required a nominal current and none could be determined.
- 6** The orientation of the device is ambiguous.

SEE ALSO

[ComCoordreport.ResultForOverloadVariable\(\)](#),
[ComCoordreport.ResultForShortCircuitVariable\(\)](#),
[ComCoordreport.ResultForInstantaneousVariable\(\)](#)

ResultForNonDirectionalBackupVariable

Provides access to the non-directional backup result for a given device and variable.

```
[ int error,
float result ]
ComCoordreport.ResultForNonDirectionalBackupVariable(DataObject device,
                                                    str variable)
```

ARGUMENTS

- device* Device for which to retrieve the result.
- variable* Variable for which to retrieve the result:
- dir** Tripping direction
 - Tp** Polygonal delay
 - Tc** Circular delay

result (out) Value of the stored result.

RETURNS

- 0** The result is valid.
- 1** The result was not calculated or not found.
- 2** The corresponding topological search failed.
- 3** The corresponding topological search ended prematurely (e.g. end of network reached).
- 4** The corresponding equation required a nominal current and none could be determined.

SEE ALSO

[ComCoordreport.ResultForZoneVariable\(\)](#),
[ComCoordreport.ResultForOverreachVariable\(\)](#),
[ComCoordreport.ResultForDirectionalBackupVariable\(\)](#)

ResultForOverloadVariable

Provides access to the overload result for a given device and variable.

```
[ int error,
float result ] ComCoordreport.ResultForOverloadVariable(DataObject device,
                                                         str variable)
```

ARGUMENTS

device Device for which to retrieve the result.

variable Variable for which to retrieve the result:

char Overcurrent characteristic
dir Tripping direction
Iset Overcurrent setpoint
Tset Overcurrent delay

result (out)

Value of the stored result.

RETURNS

- 0** The result is valid.
- 1** The result was not calculated or not found.
- 3** The corresponding topological search ended prematurely (e.g. end of network reached).
- 4** The corresponding equation required a nominal current and none could be determined.
- 5** The calculated value exceeded the calculated maximum current.

SEE ALSO

[ComCoordreport.ResultForShortCircuitVariable\(\)](#),
[ComCoordreport.ResultForInstantaneousVariable\(\)](#),
[ComCoordreport.ResultForMaxCurrent\(\)](#)

ResultForOverreachVariable

Provides access to the overreach result for a given device and variable.

```
[ int error,
float result ] ComCoordreport.ResultForOverreachVariable(DataObject device,
                                                         str variable)
```

ARGUMENTS

device Device for which to retrieve the result.

variable Variable for which to retrieve the result:

X Polygonal reactance
R Polygonal phase-phase resistance
RE Polygonal phase-earth resistance
Z Circular impedance
phi Circular angle

dir	Tripping direction
Tp	Polygonal delay
Tc	Circular delay

result (out)

Value of the stored result.

RETURNS

- 0** The result is valid.
- 1** The result was not calculated or not found.
- 2** The corresponding topological search failed.
- 3** The corresponding topological search ended prematurely (e.g. end of network reached).
- 4** The corresponding equation required a nominal current and none could be determined.

SEE ALSO

[ComCoordreport.ResultForZoneVariable\(\)](#),
[ComCoordreport.ResultForDirectionalBackupVariable\(\)](#),
[ComCoordreport.ResultForNonDirectionalBackupVariable\(\)](#)

ResultForShortCircuitVariable

Provides access to the short-circuit result for a given device and variable.

```
[ int error,
float result ]
ComCoordreport.ResultForShortCircuitVariable(DataObject device,
                                              str variable)
```

ARGUMENTS

device Device for which to retrieve the result.

variable Variable for which to retrieve the result:

char	Overcurrent characteristic
dir	Tripping direction
Iset	Overcurrent setpoint
Tset	Overcurrent delay

result (out)

Value of the stored result.

RETURNS

- 0** The result is valid.
- 1** The result was not calculated or not found.
- 3** The corresponding topological search ended prematurely (e.g. end of network reached).
- 4** The corresponding equation required a nominal current and none could be determined.
- 5** The calculated value exceeded the calculated maximum current.

SEE ALSO

[ComCoordreport.ResultForOverloadVariable\(\)](#),
[ComCoordreport.ResultForInstantaneousVariable\(\)](#),
[ComCoordreport.ResultForMaxCurrent\(\)](#)

ResultForZoneVariable

Provides access to the result for a given device, zone number and variable.

```
[ int error,
float result ] ComCoordreport.ResultForZoneVariable(DataObject device,
                                                    int zoneNumber,
                                                    str variable)
```

ARGUMENTS

device Device for which to retrieve the result.
zoneNumber Zone number for which to retrieve the result (1-4).
variable Variable for which to retrieve the result:

X	Polygonal reactance
R	Polygonal phase-phase resistance
RE	Polygonal phase-earth resistance
Z	Circular impedance
phi	Circular angle
dir	Tripping direction
Tp	Polygonal delay
Tc	Circular delay

result (out) Value of the stored result.

RETURNS

- 0** The result is valid.
- 1** The result was not calculated or not found.
- 2** The corresponding topological search failed.
- 3** The corresponding topological search ended prematurely (e.g. end of network reached).
- 4** The corresponding equation required a nominal current and none could be determined.

SEE ALSO

[ComCoordreport.ResultForOverreachVariable\(\)](#),
[ComCoordreport.ResultForDirectionalBackupVariable\(\)](#),
[ComCoordreport.ResultForNonDirectionalBackupVariable\(\)](#)

TopologyForDirectionalBackupVariable

Returns the associated directional backup topology for a given device and variable.

```
list ComCoordreport.TopologyForDirectionalBackupVariable(DataObject device,
                                                         str variable)
```


ARGUMENTS

- device* Device for which to retrieve the topology.
- variable* Variable for which to retrieve the topology:
- Tp** Polygonal delay
 - Tc** Circular delay

RETURNS

Elements traversed by the topological search determining this variables result.

SEE ALSO

[ComCoordreport.TopologyForZoneVariable\(\)](#),
[ComCoordreport.TopologyForOverreachVariable\(\)](#),
[ComCoordreport.TopologyForNonDirectionalBackupVariable\(\)](#)

TopologyForFuseVariable

Returns the associated fuse topology for a given device and variable.

```
list ComCoordreport.TopologyForFuseVariable(DataObject device,
                                             str variable)
```

ARGUMENTS

- device* Device for which to retrieve the topology.
- variable* Variable for which to retrieve the topology:
- Iset** Overcurrent setpoint

RETURNS

Elements traversed by the topological search determining this variables result.

SEE ALSO

[ComCoordreport.TopologyForMaxCurrent\(\)](#)

TopologyForInstantaneousVariable

Returns the associated instantaneous stage topology for a given device and variable.

```
list ComCoordreport.TopologyForInstantaneousVariable(DataObject device,
                                                       str variable)
```

ARGUMENTS

- device* Device for which to retrieve the topology.
- variable* Variable for which to retrieve the topology:
- Iset** Overcurrent setpoint
 - Tset** Overcurrent delay

RETURNS

Elements traversed by the topological search determining this variables result.

SEE ALSO

[ComCoordreport.TopologyForOverloadVariable\(\)](#),
[ComCoordreport.TopologyForShortCircuitVariable\(\)](#),
[ComCoordreport.TopologyForMaxCurrent\(\)](#)

TopologyForMaxCurrent

Returns the associated maximum current topology for a given device.

```
list ComCoordreport.TopologyForMaxCurrent(DataObject device)
```

ARGUMENTS

device Device for which to retrieve the topology.

RETURNS

Elements traversed by the topological search determining this variables result.

SEE ALSO

[ComCoordreport.TopologyForOverloadVariable\(\)](#),
[ComCoordreport.TopologyForShortCircuitVariable\(\)](#),
[ComCoordreport.TopologyForInstantaneousVariable\(\)](#)

TopologyForNonDirectionalBackupVariable

Returns the associated non-directional backup topology for a given device and variable.

```
list ComCoordreport.TopologyForNonDirectionalBackupVariable(DataObject device,  
                                                             str variable)
```

ARGUMENTS

device Device for which to retrieve the topology.

variable Variable for which to retrieve the topology:

Tp Polygonal delay

Tc Circular delay

RETURNS

Elements traversed by the topological search determining this variables result.

SEE ALSO

[ComCoordreport.TopologyForZoneVariable\(\)](#),
[ComCoordreport.TopologyForOverreachVariable\(\)](#),
[ComCoordreport.TopologyForDirectionalBackupVariable\(\)](#)

TopologyForOverloadVariable

Returns the associated overload stage topology for a given device and variable.

```
list ComCoordreport.TopologyForOverloadVariable(DataObject device,  
                                                  str variable)
```

ARGUMENTS

<i>device</i>	Device for which to retrieve the topology.
<i>variable</i>	Variable for which to retrieve the topology:
Iset	Overcurrent setpoint
Tset	Overcurrent delay

RETURNS

Elements traversed by the topological search determining this variables result.

SEE ALSO

[ComCoordreport.TopologyForShortCircuitVariable\(\)](#),
[ComCoordreport.TopologyForInstantaneousVariable\(\)](#),
[ComCoordreport.TopologyForMaxCurrent\(\)](#)

TopologyForOverreachVariable

Returns the associated overreach zone topology for a given device and variable.

```
list ComCoordreport.TopologyForOverreachVariable(DataObject device,
                                                  str variable)
```

ARGUMENTS

<i>device</i>	Device for which to retrieve the topology.
<i>variable</i>	Variable for which to retrieve the topology:
X	Polygonal reactance
R	Polygonal phase-phase resistance
RE	Polygonal phase-earth resistance
Z	Circular impedance
phi	Circular angle
Tp	Polygonal delay
Tc	Circular delay

RETURNS

Elements traversed by the topological search determining this variables result.

SEE ALSO

[ComCoordreport.TopologyForZoneVariable\(\)](#),
[ComCoordreport.TopologyForDirectionalBackupVariable\(\)](#),
[ComCoordreport.TopologyForNonDirectionalBackupVariable\(\)](#)

TopologyForShortCircuitVariable

Returns the associated short-circuit stage topology for a given device and variable.

```
list ComCoordreport.TopologyForShortCircuitVariable(DataObject device,
                                                  str variable)
```

ARGUMENTS

<i>device</i>	Device for which to retrieve the topology.
<i>variable</i>	Variable for which to retrieve the topology:
Iset	Overcurrent setpoint
Tset	Overcurrent delay

RETURNS

Elements traversed by the topological search determining this variables result.

SEE ALSO

[ComCoordreport.TopologyForOverloadVariable\(\)](#),
[ComCoordreport.TopologyForInstantaneousVariable\(\)](#),
[ComCoordreport.TopologyForMaxCurrent\(\)](#)

TopologyForZoneVariable

Returns the associated topology for a given device, zone number and variable.

```
list ComCoordreport.TopologyForZoneVariable(DataObject device,
                                             int zoneNumber,
                                             str variable)
```

ARGUMENTS

<i>device</i>	Device for which to retrieve the topology.
<i>zoneNumber</i>	Zone number for which to retrieve the topology (1-4).
<i>variable</i>	Variable for which to retrieve the topology:
X	Polygonal reactance
R	Polygonal phase-phase resistance
RE	Polygonal phase-earth resistance
Z	Circular impedance
phi	Circular angle
Tp	Polygonal delay
Tc	Circular delay

RETURNS

Elements traversed by the topological search determining this variables result.

SEE ALSO

[ComCoordreport.TopologyForOverreachVariable\(\)](#),
[ComCoordreport.TopologyForDirectionalBackupVariable\(\)](#),
[ComCoordreport.TopologyForNonDirectionalBackupVariable\(\)](#)

TransferDirectionalBackupResultsTo

Transfers the results of the directional backup for the given variables to the device.

```
int ComCoordreport.TransferDirectionalBackupResultsTo(DataObject device,
                                                       str variables)
```

ARGUMENTS

<i>device</i>	Device to transfer the results to.
<i>variable</i>	Variables to transfer as semi-colon separated string:
dir	Tripping direction
Tp	Polygonal delay
Tc	Circular delay

RETURNS

0	Transfer did non succeed.
1	Result transfer successful.

SEE ALSO

[ComCoordreport.TransferZoneResultsTo\(\)](#),
[ComCoordreport.TransferOverreachResultsTo\(\)](#),
[ComCoordreport.TransferNonDirectionalBackupResultsTo\(\)](#)

TransferNonDirectionalBackupResultsTo

Transfers the results of the non-directional backup for the given variables to the device.

```
int ComCoordreport.TransferNonDirectionalBackupResultsTo(DataObject device,
                                                         str variables)
```

ARGUMENTS

<i>device</i>	Device to transfer the results to.
<i>variable</i>	Variables to transfer as semi-colon separated string:
dir	Tripping direction
Tp	Polygonal delay
Tc	Circular delay

RETURNS

0	Transfer did non succeed.
1	Result transfer successful.

SEE ALSO

[ComCoordreport.TransferZoneResultsTo\(\)](#),
[ComCoordreport.TransferOverreachResultsTo\(\)](#),
[ComCoordreport.TransferDirectionalBackupResultsTo\(\)](#)

TransferOverreachResultsTo

Transfers the results of the overreach zone for the given variables to the device.

```
int ComCoordreport.TransferOverreachResultsTo(DataObject device,
                                              str variables)
```

ARGUMENTS

<i>device</i>	Device to transfer the results to.
<i>variable</i>	Variables to transfer as semi-colon separated string:
X	Polygonal reactance
R	Polygonal phase-phase resistance
RE	Polygonal phase-earth resistance
Z	Circular impedance
phi	Circular angle
dir	Tripping direction
Tp	Polygonal delay
Tc	Circular delay

RETURNS

0	Transfer did non succeed.
1	Result transfer successful.

SEE ALSO

[ComCoordreport.TransferZoneResultsTo\(\)](#),
[ComCoordreport.TransferDirectionalBackupResultsTo\(\)](#),
[ComCoordreport.TransferNonDirectionalBackupResultsTo\(\)](#)

TransferResultsTo

Transfers the results for the given variables to one or more devices.

```

int ComCoordreport.TransferResultsTo(DataObject device,
                                     str variables)

int ComCoordreport.TransferResultsTo(list devices,
                                     str variables)

```

ARGUMENTS

<i>devices</i>	Devices to transfer the results to.
<i>variable</i>	Variables to transfer as semi-colon separated string:
X	Polygonal reactance
R	Polygonal phase-phase resistance
RE	Polygonal phase-earth resistance
Z	Circular impedance
phi	Circular angle
dir	Tripping direction
Tp	Polygonal delay
Tc	Circular delay
char	Overcurrent characteristic
Iset	Overcurrent setpoint
Tset	Overcurrent delay

RETURNS

- 0** At least one transfer did non succeed.
1 Result transfer successful.

TransferZoneResultsTo

Transfers the results of a particular zone for the given variables to the device.

```
int ComCoordreport.TransferZoneResultsTo(DataObject device,
                                         int zoneNumber,
                                         str variables)
```

ARGUMENTS

- device* Device to transfer the results to.
- zoneNumber* Zone number for which to to transfer the results (1-4).
- variable* Variables to transfer as semi-colon separated string:
- | | |
|------------|----------------------------------|
| X | Polygonal reactance |
| R | Polygonal phase-phase resistance |
| RE | Polygonal phase-earth resistance |
| Z | Circular impedance |
| phi | Circular angle |
| dir | Tripping direction |
| Tp | Polygonal delay |
| Tc | Circular delay |

RETURNS

- 0** Transfer did non succeed.
1 Result transfer successful.

SEE ALSO

[ComCoordreport.TransferOverreachResultsTo\(\)](#),
[ComCoordreport.TransferDirectionalBackupResultsTo\(\)](#),
[ComCoordreport.TransferNonDirectionalBackupResultsTo\(\)](#)

5.4.16 ComCosim**Overview**

[GetAdmissibleLines](#)
[GetAllBoundaryBranches](#)
[PartitionNetwork](#)

GetAdmissibleLines

Get all lines from the network that would be valid boundary lines between regions used for implicit Co-Simulation. The selection of lines depends on the synchronisation period and settings from the network partitioning frame. Lumped parameter lines are included unless the option is selected that only allows lines that already have distributed parameter.

```
list ComCosim.GetAdmissibleLines()
```

RETURNS

Container with all admissible lines.

GetAllBoundaryBranches

Get all boundary branches of the regions selected in the table at the 'Regions' tab.

```
list ComCosim.GetAllBoundaryBranches()
```

RETURNS

Container with all boundary lines.

PartitionNetwork

Detects and defines regions usable for single-domain internal co-simulation. The regions are displayed on the subpage 'Regions' of the *ComCosim* command window. Here, optimisation parameters such as the number of regions and the minimum travel time of boundary elements can be set too.

```
int ComCosim.PartitionNetwork()
```

RETURNS

False on success, true otherwise.

5.4.17 ComDiffoutage

Overview

[Start](#)

Start

Executes the contingency comparison command for a set/list of contingency cases.

```
int ComDiffoutage.Start(list outageObjects)
```

ARGUMENTS

outageObjects

Contingency cases (ComOutage)

RETURNS

0 not relevant

5.4.18 ComDllmanager

Overview

[Report](#)

Report

Prints a status report of currently available external user-defined dlls (e.g. dpl, exdyn) to the output window. (Same as pressing the 'Report' button in the dialog.)

```
None ComDllmanager.Report()
```

5.4.19 ComDpl

Overview

[CheckSyntax](#)
[Encrypt](#)
[Execute](#)
[GetExternalObject](#)
[GetInputParameterDouble](#)
[GetInputParameterInt](#)
[GetInputParameterString](#)
[IsEncrypted](#)
[ResetThirdPartyModule](#)
[SetExternalObject](#)
[SetInputParameterDouble](#)
[SetInputParameterInt](#)
[SetInputParameterString](#)
[SetThirdPartyModule](#)

CheckSyntax

Checks the syntax and input parameter of the DPL script and all its subscripts.

```
int ComDpl.CheckSyntax()
```

RETURNS

0 On success.
1 On error.

SEE ALSO

[ComDpl.Execute\(\)](#)

Encrypt

Encrypts a script and all its subscripts. An encrypted script can be executed without password but decrypted only with password. If no password is given a 'Choose Password' dialog appears.

```
int ComDpl.Encrypt([str password = "",
                  [int removeObjectHistory = 1],
                  [int masterCode = 0])
```

ARGUMENTS

password (optional)

Password for decryption. If no password is given a 'Choose Password' dialog appears.

removeObjectHistory (optional)

Handling of unencrypted object history in database, e.g. used by project versions or by undo:

- | | |
|----------|----------------------|
| 0 | Do not remove. |
| 1 | Do remove (default). |
| 2 | Show dialog and ask. |

masterCode (optional)

Used for re-selling scripts. 3rd party licence codes already set in the script will be overwritten by this value (default = 0).

RETURNS

- | | |
|----------|-------------|
| 0 | On success. |
| 1 | On error. |

SEE ALSO

[ComDpl.IsEncrypted\(\)](#)

Execute

Executes the DPL script as subscript.

```
int ComDpl.Execute([input parameter])
```

ARGUMENTS

input parameter (optional)

All input parameter from the 'Basic Options' page of the 'Edit' dialog can be given as arguments. If a parameter is not given then the value from the dialog is used. The values from the dialog itself are not modified. These can be modified via

- [ComDpl.SetInputParameterInt\(\)](#)
- [ComDpl.SetInputParameterDouble\(\)](#)
- [ComDpl.SetInputParameterString\(\)](#).

The arguments are not given by reference. Thus when a subscript changes the value of a variable then the value from the main script is not changed.

RETURNS

For scripts without the use of `Application.exit()` the following values are returned:

- 0** On a successful execution.
- 1** An error occurred.
- 6** User hit the break button.

SEE ALSO

[ComDpl.CheckSyntax\(\)](#)

GetExternalObject

Gets the external object defined in the ComDpl edit dialog.

```
[int error,  
DataObject value] ComDpl.GetExternalObject(str name)
```

ARGUMENTS

name Name of the external object parameter.

value (out)
The external object.

RETURNS

- 0** On success.
- 1** On error.

SEE ALSO

[ComDpl.SetExternalObject\(\)](#), [ComDpl.GetInputParameterInt\(\)](#),
[ComDpl.GetInputParameterDouble\(\)](#), [ComDpl.GetInputParameterString\(\)](#)

GetInputParameterDouble

Gets the double input parameter value defined in the ComDpl edit dialog.

```
[int error,  
float value] ComDpl.GetInputParameterDouble(str name)
```

ARGUMENTS

name Name of the double input parameter.

value (out)
Value of the double input parameter.

RETURNS

- 0** On success.
- 1** On error.

SEE ALSO

[ComDpl.SetInputParameterDouble\(\)](#), [ComDpl.GetInputParameterInt\(\)](#),
[ComDpl.GetInputParameterString\(\)](#), [ComDpl.GetExternalObject\(\)](#)

GetInputParameterInt

Gets the integer input parameter value defined in the ComDpl edit dialog.

```
[int error,  
int value ] ComDpl.GetInputParameterInt(str name)
```

ARGUMENTS

name Name of the integer input parameter.

value (out)
Value of the integer input parameter.

RETURNS

0 On success.

1 On error.

SEE ALSO

[ComDpl.SetInputParameterInt\(\)](#), [ComDpl.GetInputParameterDouble\(\)](#),
[ComDpl.GetInputParameterString\(\)](#), [ComDpl.GetExternalObject\(\)](#)

GetInputParameterString

Gets the string input parameter value defined in the ComDpl edit dialog.

```
[int error,  
str value ] ComDpl.GetInputParameterString(str name)
```

ARGUMENTS

name Name of the string input parameter.

value (out)
Value of the string input parameter.

RETURNS

0 On success.

1 On error.

SEE ALSO

[ComDpl.SetInputParameterString\(\)](#), [ComDpl.GetInputParameterInt\(\)](#),
[ComDpl.GetInputParameterDouble\(\)](#), [ComDpl.GetExternalObject\(\)](#)

IsEncrypted

Returns the encryption state of the script.

```
int ComDpl.IsEncrypted()
```

RETURNS

1 Script is encrypted.

0 Script is not encrypted.

SEE ALSO

[ComDpl.Encrypt\(\)](#)

ResetThirdPartyModule

Resets the third party licence. Only possible for non-encrypted scripts. Requires masterkey licence for third party module currently set.

```
int ComDpl.ResetThirdPartyModule()
```

RETURNS

0	On success.
1	On error.

SetExternalObject

Sets the external object defined in the ComDpl edit dialog.

```
int ComDpl.SetExternalObject(str name,  
                             DataObject value  
                             )
```

ARGUMENTS

<i>name</i>	Name of the external object parameter.
<i>value</i>	The external object.

RETURNS

0	On success.
1	On error.

SEE ALSO

[ComDpl.GetExternalObject\(\)](#), [ComDpl.SetInputParameterInt\(\)](#),
[ComDpl.SetInputParameterDouble\(\)](#), [ComDpl.SetInputParameterString\(\)](#)

SetInputParameterDouble

Sets the double input parameter value defined in the ComDpl edit dialog.

```
int ComDpl.SetInputParameterDouble(str name,  
                                    float value  
                                    )
```

ARGUMENTS

<i>name</i>	Name of the double input parameter.
<i>value</i>	Value of the double input parameter.

RETURNS

0	On success.
1	On error.

SEE ALSO

[ComDpl.GetInputParameterDouble\(\)](#), [ComDpl.SetInputParameterInt\(\)](#),
[ComDpl.SetInputParameterString\(\)](#), [ComDpl.SetExternalObject\(\)](#)

SetInputParameterInt

Sets the integer input parameter value defined in the ComDpl edit dialog.

```
int ComDpl.SetInputParameterInt(str name,  
                                int value  
                                )
```

ARGUMENTS

name Name of the integer input parameter.
value Value of the integer input parameter.

RETURNS

0 On success.
1 On error.

SEE ALSO

[ComDpl.GetInputParameterInt\(\)](#), [ComDpl.SetInputParameterDouble\(\)](#),
[ComDpl.SetInputParameterString\(\)](#), [ComDpl.SetExternalObject\(\)](#)

SetInputParameterString

Sets the string input parameter value defined in the ComDpl edit dialog.

```
int ComDpl.SetInputParameterString(str name,  
                                    str value  
                                    )
```

ARGUMENTS

name Name of the string input parameter.
value Value of the string input parameter.

RETURNS

0 On success.
1 On error.

SEE ALSO

[ComDpl.GetInputParameterString\(\)](#), [ComDpl.SetInputParameterInt\(\)](#),
[ComDpl.SetInputParameterDouble\(\)](#), [ComDpl.SetExternalObject\(\)](#)

SetThirdPartyModule

Sets the third party licence to a specific value. Only possible for non-encrypted scripts with no third party licence set so far. Requires masterkey licence for third party module to be set.

```
int ComDpl.SetThirdPartyModule(str companyCode,  
                                str moduleCode  
                                )
```

ARGUMENTS

companyCode

Display name or numeric value of company code.

moduleCode

Display name or numeric value of third party module.

RETURNS

0 On success.**1** On error.

5.4.20 ComFlickermeter

Overview

[Execute](#)

Execute

Calculates the short- and long-term flicker according to IEC 61000-4-15.

```
int ComFlickermeter.Execute()
```

RETURNS

- 0** OK
- 1** Error: column not found in file; other internal errors
- 2** Error: empty input file
- 3** Error: cannot open file
- 4** Internal error: matrix empty

5.4.21 ComGenrelinc

Overview

[GetCurrentIteration](#)[GetMaxNumIterations](#)

GetCurrentIteration

The command returns the current iteration number of the 'Run Generation Adequacy' command (ComGenrel).

```
int ComGenrelinc.GetCurrentIteration()
```

RETURNS

Returns the current iteration number.

GetMaxNumIterations

The command returns the maximum number of iterations specified in the 'Run Generation Adequacy' command (ComGenrel).

```
int ComGenrelinc.GetMaxNumIterations()
```

RETURNS

Returns the maximum number of iterations.

5.4.22 ComGridtocim

Overview

[AppendMessage](#)
[AssignCimRdflds](#)
[ConvertAndExport](#)
[GetMessageDescription](#)
[GetMessageObject](#)
[GetMessageSeverity](#)
[GetNumberOfMessages](#)
[SetAuthorityUri](#)
[SetBoundaries](#)
[SetGridsToExport](#)

AppendMessage

Appends the conversion message.

```
None ComGridtocim.AppendMessage(str severity,  
                                str description,  
                                str objectFullname  
                                )
```

ARGUMENTS

severity Message severity.

description
Message description.

objectFullname
Full name of the object for which the message is reported, or type and name of the object.

EXAMPLE

The following example appends the conversion message.

```
import powerfactory  
app = powerfactory.GetApplicationExt()
```



```
gridtocim = app.GetFromStudyCase("ComGridtocim")
objectFullname = gridtocim.GetFullPath()
gridtocim.AppendMessage("Warning", "This is a sample message.", objectFullname)
```

AssignCimRdfIds

Assigns CIM RDF IDs for all PowerFactory objects in the active project.

```
int ComGridtocim.AssignCimRdfIds()
```

RETURNS

- 0** OK
- 1** Error: The active project was not found
- 2** Error: Duplicate CIM RDF IDs found in the active project

EXAMPLE

The following example sets CIM RDF IDs to all PowerFactory objects in the active project.

```
import powerfactory
app = powerfactory.GetApplicationExt()

gridtocim = app.GetFromStudyCase("ComGridtocim")
result = gridtocim.AssignCimRdfIds()
if result == 0:
    app.PrintInfo("CIM RDF IDs are successfully assigned.")
elif result == 1:
    app.PrintError("The active project was not found.")
elif result == 2:
    app.PrintError("Duplicate CIM RDF IDs found in the active project.")
```

ConvertAndExport

Convert Grid to CIM and export CIM data to given file path without storing into database. If no file path is provided, the file path from the corresponding CIM Data Export command in the study will be used. In case of a validation error the export is not performed.

```
int ComGridtocim.ConvertAndExport([int validate])
int ComGridtocim.ConvertAndExport(str filePath,
                                   [int validate])
```

ARGUMENTS

filePath File path for CIM data.

validate (optional)

Option to execute CIM Data Validation before export. If not provided, the validation is executed. Possible values are

- 0** Do not validate
- 1** Validate

RETURNS

- 0** OK
- 1** Error: conversion failed
- 2** Error: export failed

EXAMPLE

This example converts the configured grids in the Grid to the CIM Conversion command, and export the results to a specified ZIP archive.

```
import powerfactory
app = powerfactory.GetApplicationExt()

gridtocim = app.GetFromStudyCase("ComGridtocim")
error = gridtocim.ConvertAndExport("e:\export.zip", 1)
if error == 0:
    app.PrintInfo("OK")
elif error == 1:
    app.PrintError("Error: conversion failed")
else:
    app.PrintError("Error: export failed")
```

GetMessageDescription

Returns the description from the selected conversion message.

```
str ComGridtocim.GetMessageDescription(int messageIndex)
```

ARGUMENTS

messageIndex
Index of the conversion message.

RETURNS

Message description.

EXAMPLE

The following example prints the description text from each conversion message.

```
import powerfactory
app = powerfactory.GetApplicationExt()

gridtocim = app.GetFromStudyCase("ComGridtocim")
nMessages = gridtocim.GetNumberOfMessages()
for i in range(nMessages):
    descriptionText = gridtocim.GetMessageDescription(i)
    app.PrintInfo("%s" % descriptionText)
```

GetMessageObject

Returns the object from the selected conversion message.

```
str ComGridtocim.GetMessageObject(int messageIndex)
```

ARGUMENTS

messageIndex

Index of the conversion message.

RETURNS

Object for which the message is reported.

EXAMPLE

The following example prints the object from each conversion message.

```
import powerfactory
app = powerfactory.GetApplicationExt()

gridtocim = app.GetFromStudyCase("ComGridtocim")
nMessages = gridtocim.GetNumberOfMessages()
for i in range(nMessages):
    messageObject = gridtocim.GetMessageObject(i)
    app.PrintInfo("%s" % messageObject)
```

GetMessageSeverity

Returns the severity of the selected conversion message.

```
str ComGridtocim.GetMessageSeverity(int messageIndex)
```

ARGUMENTS

messageIndex

Index of the conversion message.

RETURNS

Message severity.

EXAMPLE

The following example prints the severity for each conversion message.

```
import powerfactory
app = powerfactory.GetApplicationExt()

gridtocim = app.GetFromStudyCase("ComGridtocim")
nMessages = gridtocim.GetNumberOfMessages()
for i in range(nMessages):
    severity = gridtocim.GetMessageSeverity(i)
    app.PrintInfo("%s" % severity)
```

GetNumberOfMessages

Returns the number of conversion messages generated.

```
int ComGridtocim.GetNumberOfMessages()
```

RETURNS

Number of conversion messages.

EXAMPLE

The following example prints the number of conversion messages got for the last grid to CIM conversion.

```
import powerfactory
app = powerfactory.GetApplicationExt()

gridtocim = app.GetFromStudyCase("ComGridtocim")
nMessages = gridtocim.GetNumberOfMessages()
app.PrintInfo("Number of messages: %d" % nMessages)
```

SetAuthorityUri

Sets the authority uri for a specific grid.

```
None ComGridtocim.SetAuthorityUri(DataObject grid,
                                   str uri)
```

ARGUMENTS

grid Grid for which the URI is to be set.
uri URI of the model authority to be set.

EXAMPLE

This example sets the URI of the model authority for all grids in Grid to the CIM Conversion command in the active study case.

```
import powerfactory
app = powerfactory.GetApplicationExt()

project = app.GetActiveProject()
grids = project.GetContents("*.ElmNet", 1)
gridtocim = app.GetFromStudyCase("ComGridtocim")
for grid in grids:
    gridtocim.SetAuthorityUri(grid, "testUri")
```

SetBoundaries

Sets "Fictitious border grid" parameter on the grids.

```
None ComGridtocim.SetBoundaries(list grids)
```

ARGUMENTS

grids The grids to be set as boundary.

EXAMPLE

This example sets a selected grid as a boundary grid. The grid is selected in the grid variable in External objects.

```
import powerfactory
app = powerfactory.GetApplicationExt()
```

```
script = app.GetCurrentScript()
[error, grid] = script.GetExternalObject("grid")
boundaries = [grid] # create a list of boundary grids
gridtocim = app.GetFromStudyCase("ComGridtocim")
gridtocim.SetBoundaries(boundaries)
```

SetGridsToExport

Sets the grids as "Selected" and clears any previous setting.

```
None ComGridtocim.SetGridsToExport(list grids)
```

ARGUMENTS

grids The grids to be exported.

EXAMPLE

This example sets all non-boundary grids in the active project for conversion from grid to CIM.

```
import powerfactory
app = powerfactory.GetApplicationExt()

project = app.GetActiveProject()
gridsToExport = []
grids = project.GetContents("*.ElmNet", 1)
for grid in grids:
    if grid.GetAttribute("fictborder") == 0:
        gridsToExport.append(grid)

gridtocim = app.GetFromStudyCase("ComGridtocim")
gridtocim.SetGridsToExport(gridsToExport)
```

5.4.23 ComHostcap

Overview

[CalcMaxHostedPower](#)

CalcMaxHostedPower

The function executes predefined hosting capacity analysis command and returns the max. hosted power (P, Q) at the given terminal. In addition, object where the violation has occurred is returned.

```
[int returnValue,
float P,
float Q,
violatedElement ] ComHostcap.CalcMaxHostedPower(DataObject terminal)
```

ARGUMENTS

- terminal* Hosting site.
- P (out)* Max. active power.
- Q (out)* Max. reactive power.
- limitingComponent (out)*
 Element where the limiting violation occurs.

RETURNS

- 1** Selected object is not a terminal.
- 0** Calculation OK. No violations.
- 1** Calculation failed.
- 2** Thermal violation.
- 3** Voltage violation.
- 4** Thermal and voltage violation.
- 5** Protection violation.
- 6** Power quality violation.
- 7** Base case violations.
- 8** Calculation interrupted.

5.4.24 ComImport

Overview

[GetCreatedObjects](#)
[GetModifiedObjects](#)

GetCreatedObjects

Returns the newly created objects after execution of a DGS import.

```
list ComImport.GetCreatedObjects()
```

RETURNS

Collection of objects that have been created during DGS import.

GetModifiedObjects

Returns the modified objects after execution of a DGS import.

```
list ComImport.GetModifiedObjects()
```

RETURNS

Collection of objects that have been modified during DGS import.

5.4.25 ComInc

Overview

[CompileDynamicModelTypes](#)
[CreateRemainingRegion](#)
[GetAdmissibleLines](#)
[GetAllBoundaryLines](#)
[PartitionNetwork](#)
[ZeroDerivative](#)

CompileDynamicModelTypes

Compile automatically all relevant dynamic model types.

```
int ComInc.CompileDynamicModelTypes([int modelType = 0],
                                     [int forceRebuild = 0],
                                     [int outputLevel = 0])
```

ARGUMENTS

modelType (optional)

- 0** All relevant dynamic model types are considered.
- 1** All relevant Modelica Model Types are considered.
- 2** All relevant DSL Model Types are considered.

forceRebuild (optional)

- 0** Dynamic model types already compiled and valid will not be recompiled.
- 1** Force all dynamic model types to be compiled.

outputLevel (optional)

- 0** No output messages regarding compilation of dynamic model types.
- 1** Warnings and error messages will be printed to the output window regarding compilation of dynamic model types.

RETURNS

- 0** On success.
- 1** On success but some DSL Model Types will run interpreted.
- 2** On error.

CreateRemainingRegion

If one or more regions have been selected in the table on the parallel computing page, this function creates an ElmBoundary object that covers the remainder of the network.

```
None ComInc.CreateRemainingRegion()
```

GetAdmissibleLines

Get all lines from the network that would be valid boundary lines between regions used for parallel simulation. The same set of lines is given when the button "Output admissible lines" is clicked.

```
list ComInc.GetAdmissibleLines()
```

RETURNS

Container with all admissible lines.

GetAllBoundaryLines

Get all boundary lines of the regions selected for parallel simulation.

```
list ComInc.GetAllBoundaryLines()
```

RETURNS

Container with all boundary lines.

PartitionNetwork

Detects and defines regions, which partition the network. This function is only available, if the parallel simulation of partitioned network is set to manual. The created regions are set to the *ComInc*'s 'Regions' table.

```
int ComInc.PartitionNetwork()
```

RETURNS

- | | |
|---|-------------|
| 0 | On success. |
| 1 | On error. |

ZeroDerivative

This function returns 1 if the state variable derivatives are less than the tolerance for the initial conditions, provided that the *Simulation method* is set to *RMS values* and the *Verify initial conditions* option is selected in the *Calculation of initial conditions* command. The tolerance is defined on the *Solver options* page in the *Maximum error for dynamic model equations* field. The function returns 0 if the aforementioned conditions are not met, or if at least one state variable has a derivative larger than the tolerance.

```
int ComInc.ZeroDerivative()
```

RETURNS

- | | |
|---|--|
| 0 | At least one state variable has a derivative larger than the tolerance, or the required command options have not been set. |
| 1 | All state variable derivatives are less than the tolerance. |

5.4.26 ComLdf

Overview

[CheckControllers](#)
[DoNotResetCalc](#)
[EstimateOutage](#)
[Execute](#)
[IsAC](#)
[IsBalanced](#)
[IsDC](#)
[PrintCheckResults](#)
[SetOldDistributeLoadMode](#)

CheckControllers

Check the conditions of all controllers based on available load flow results. The report will be printed out in output window.

```
int ComLdf.CheckControllers()
```

RETURNS

Always return 1.

DoNotResetCalc

The load flow results will not be reset even the load flow calculation fails.

```
int ComLdf.DoNotResetCalc(int doNotReset)
```

ARGUMENTS

doNotReset

Specifies whether the results shall be reset or not.

0 Reset load flow results if load flow fails.

1 Load flow results will remain even load flow fails.

RETURNS

Always return 0.

EstimateOutage

Estimate the loading of all branches with outages of given set of branch elements.

```
int ComLdf.EstimateOutage(list branches,  
                           int init  
)
```

ARGUMENTS

branches The branch elements to be in outage.

init Initialisation of sensitivities.

- 0** No need to calculate sensitivities; it assumes that sensitivities have been calculated before hand.
- 1** Sensitivities will be newly calculated.

RETURNS

- 0** On success.
- 1** On error.

Execute

Performs a load flow analysis on a network. Results are displayed in the single line graphic and available in relevant elements.

```
int ComLdf.Execute()
```

RETURNS

- 0** OK
- 1** Load flow failed due to divergence of inner loops.
- 2** Load flow failed due to divergence of outer loops.

IsAC

Check whether this load flow is configured as AC method or not.

```
int ComLdf.IsAC()
```

RETURNS

- 0** Is a DC method.
- 1** Is an AC method.

IsBalanced

Check whether this load flow command is configured as balanced or unbalanced.

```
int ComLdf.IsBalanced()
```

RETURNS

Returns true if the load flow is balanced.

IsDC

Check whether this load flow is configured as DC method or not.

```
int ComLdf.IsDC()
```

RETURNS

- 0** Is an AC method.
- 1** Is a DC method.

PrintCheckResults

Shows the verification report in the output window.

```
int ComLdf.PrintCheckResults()
```

RETURNS

Always return 1.

SetOldDistributeLoadMode

Set the old scaling mode in case of Distributed Slack by loads.

```
None ComLdf.SetOldDistributeLoadMode(int iOldMode)
```

ARGUMENTS

iOldMode The flag showing if the old model is used.

- 0** Use standard mode.
- 1** Use old mode.

5.4.27 ComLink**Overview**

[LoadMicroSCADAFile](#)
[ReceiveData](#)
[SendData](#)
[SentDataStatus](#)
[SetOPCReceiveQuality](#)
[SetSwitchShcEventMode](#)

LoadMicroSCADAFile

Reads in a MicroSCADA snapshot file.

```
int ComLink.LoadMicroSCADAFile(str filename,
                                [int populate]
                                )
```

ARGUMENTS

filename name of the file to read

populate (optional)

determines whether new values should be populated to the network elements
(0=no, 1=yes)

RETURNS

- 0** On success.
- 1** On error.

ReceiveData

Reads and processes values for all (in PowerFactory configured) items from OPC server (OPC only).

```
int ComLink.ReceiveData([int force])
```

ARGUMENTS

force (optional)

- 0** (default) Processes changed values (asynchronously) received by PowerFactory via callback
- 1** Forces (synchronous) reading and processing of all values (independent of value changes)

RETURNS

Number of read items

SendData

Sends values from configured measurement objects to OPC server (OPC only).

```
int ComLink.SendData([int force])
```

ARGUMENTS

force (optional)

- 0** (default) Send only data that have been changed and difference between old and new value is greater than configured deadband
- 1** Forces writing of all values (independent of previous value)

RETURNS

Number of written items

SentDataStatus

Outputs status of all items marked for sending to output window.

```
int ComLink.SentDataStatus()
```

RETURNS

Number of items configured for sending.

SetOPCReceiveQuality

Allows to override the actual OPC receive quality by this value. (Can be used for testing.)

```
int ComLink.SetOPCReceiveQuality(int quality)
```

ARGUMENTS

quality new receive quality (bitmask)

RETURNS

0 On success.
1 On error.

SetSwitchShcEventMode

Configures whether value changes for switches are directly transferred to the object itself or whether shc switch events shall be created instead.

```
None ComLink.SetSwitchShcEventMode(int enabled)
```

ARGUMENTS

enabled

0 Values are directly written to switches
1 For each value change a switch event will be created

5.4.28 ComMerge**Overview**

[CheckAssignments](#)
[Compare](#)
[CompareActive](#)
[CompareRecording](#)
[ExecuteRecording](#)
[ExecuteWithActiveProject](#)
[GetCorrespondingObject](#)
[GetModification](#)
[GetModificationResult](#)
[GetModifiedObjects](#)
[Merge](#)
[PrintComparisonReport](#)
[PrintModifications](#)
[Reset](#)
[SetAutoAssignmentForAll](#)
[SetObjectsToCompare](#)
[ShowBrowser](#)
[WereModificationsFound](#)

CheckAssignments

Checks if all assignments are correct and merge can be done.

```
int ComMerge.CheckAssignments()
```

RETURNS

- 0** On success.
- 1** Cancelled by user.
- 2** Missing assignments found.
- 3** Conflicts found.
- 4** On other errors.

Compare

Starts a comparison according to the settings in this ComMerge object. The merge browser is not shown.

```
int ComMerge.Compare()
```

RETURNS

- 0** On success.
- 1** On errors.
- 2** Cancelled by user.

CompareActive

Starts a comparison according to the settings in this ComMerge object. The merge browser is not shown. Can compare with the active project.

```
int ComMerge.CompareActive()
```

RETURNS

- 0** On success.
- 1** On errors.
- 2** Cancelled by user.

CompareRecording

Starts a comparison according to the settings in this ComMerge object. Allows comparing to an active target project and recording modifications in the active scenario and/or expansion stage of the target project, but assignments are not set, the merge browser is not shown and no merge is executed.

```
int ComMerge.CompareRecording()
```

RETURNS

- 0** On success.
- 1** On errors.
- 2** Cancelled by user.

ExecuteRecording

Starts a comparison according to the settings in this ComMerge object and sets assignments, shows the merge browser or merges automatically, depending on settings of this ComMerge. Records modifications in the active scenario and/or expansion stage of the target project.

```
int ComMerge.ExecuteRecording()
```

RETURNS

- 0** On success.
- 1** Cancelled by user.
- 2** On other errors.

ExecuteWithActiveProject

Starts a comparison according to the settings in this ComMerge object and shows the merge browser. Can compare with the active project.

```
None ComMerge.ExecuteWithActiveProject()
```

GetCorrespondingObject

Searches corresponding object for given object.

```
DataObject ComMerge.GetCorrespondingObject(DataObject sourceObj,  
                                           [int target]  
                                           )
```

ARGUMENTS

sourceObj

Object for which corresponding object is searched.

target

- 0** Get corresponding object from “Base” (default)
- 1** Get corresponding object from “1st”
- 2** Get corresponding object from “2nd”

RETURNS

- object** Corresponding object.
- None** Corresponding object not found.

GetModification

Gets kind of modification between corresponding objects of “Base” and “1st” or “2nd”.

```
int ComMerge.GetModification(DataObject sourceObj,  
                             [int target]  
                             )
```

ARGUMENTS

sourceObj

Object from any source for which modification is searched.

target

- 1 Get modification from “Base” to “1st” (default)
- 2 Get modification from “Base” to “2nd”

RETURNS

- 0 On error.
- 1 No modifications (equal).
- 2 Modified.
- 3 Added in “1st”/“2nd”.
- 4 Removed in “1st”/“2nd”.

GetModificationResult

Gets kind of modifications between compared objects in “1st” and “2nd”.

```
int ComMerge.GetModificationResult(DataObject obj)
```

ARGUMENTS

obj

Object from any source for which modification is searched.

RETURNS

- 0 On error.
- 1 No modifications (equal).
- 2 Same modifications in “1st” and “2nd” (no conflict).
- 3 Different modifications in “1st” and “2nd” (conflict).

GetModifiedObjects

Gets all objects with a certain kind of modification.

```
list ComMerge.GetModifiedObjects(int modType,
                                [int modSource]
                                )
```

ARGUMENTS

modType

- 1 get unmodified objects
- 2 get modified objects
- 3 get added objects
- 4 get removed objects

modSource

- 1 consider modification between “Base” and “1st” (default)
- 2 consider modification between “Base” and “2nd”

RETURNS

Set with matching objects.

Unmodified, modified and added objects are always from given “modSource”, removed objects are always from “Base” .

Merge

Checks assignments, merges modifications according to assignments into target and prints merge report to output window.

```
None ComMerge.Merge(int printReport)
```

ARGUMENTS

printReport

1 print merge report

0 do not print merge report

always set to 0 in paste and split mode

PrintComparisonReport

Prints the modifications of all compared objects as a report to the output window.

```
None ComMerge.PrintComparisonReport(int mode)
```

ARGUMENTS

mode

0 no report

1 only modified compare objects

2 all compare objects

PrintModifications

Prints modifications of given objects (if any) to the output window.

```
int ComMerge.PrintModifications(list objs)
int ComMerge.PrintModifications(DataObject obj)
```

ARGUMENTS

objs Set of objects for which the modifications are printed.

obj Object for which the modifications are printed.

RETURNS

0 On error: object(s) not found in comparison.

1 On success: modifications were printed.

Reset

Resets/clears and deletes all temp. object sets, created internally for the comparison.

```
None ComMerge.Reset()
```

SetAutoAssignmentForAll

Sets the assignment of all compared objects automatically.

```
None ComMerge.SetAutoAssignmentForAll(int conflictVal)
```

ARGUMENTS

conflictVal

Assignment of compared objects with undefined automatic values (e.g. conflicts)

- 0** no assignment
- 1** assign from “Base”
- 2** assign from 1st
- 3** assign from 2nd

SetObjectsToCompare

Sets top level objects for comparison.

```
None ComMerge.SetObjectsToCompare(DataObject base,
                                   [DataObject first,]
                                   [DataObject second]
                                   )
```

ARGUMENTS

- base* Top level object to be set as “Base”
- first* Top level object to be set as “1st”
- second* Top level object to be set as “2nd”

ShowBrowser

Shows merge browser with initialized settings and all compared objects. Can only be called after a comparison was executed.

```
int ComMerge.ShowBrowser()
```

RETURNS

- 0** The browser was left with ok button.
- 1** The browser was left with cancel button.
- 2** On error.

WereModificationsFound

Checks, if modifications were found in comparison.

```
int ComMerge.WereModificationsFound()
```

RETURNS

- 0 All objects in comparison are equal.
- 1 Modifications found in comparison.

5.4.29 ComMot

Overview

[GetMotorConnections](#)
[GetMotorSwitch](#)
[GetMotorTerminal](#)

GetMotorConnections

Finds the cables connecting the motor to the switch.

```
list ComMot.GetMotorConnections(DataObject motor)
```

ARGUMENTS

motor The motor element

RETURNS

Returns the set of cables connecting the motor to the switch.

GetMotorSwitch

Finds the switch which will connect the motor to the network.

```
DataObject ComMot.GetMotorSwitch(DataObject motor)
```

ARGUMENTS

motor The motor element

RETURNS

Returns the switch element.

GetMotorTerminal

Finds the terminal to which the motor will be connected.

```
DataObject ComMot.GetMotorTerminal(DataObject motor)
```

ARGUMENTS

motor The motor element

RETURNS

Returns the terminal element.

5.4.30 ComNmink

Overview

[AddRef](#)
[Clear](#)
[GenerateContingenciesForAnalysis](#)
[GetAll](#)

AddRef

Adds shortcuts to the objects to the existing selection.

```
None ComNmink.AddRef(DataObject O)  
None ComNmink.AddRef(list S)
```

ARGUMENTS

O(optional)
an object

S(optional)
a Set of objects

Clear

Delete all contents, i.e. to empty the selection.

```
None ComNmink.Clear()
```

GenerateContingenciesForAnalysis

Generates Contingencies for Contingency Analysis. Similar to calling 'Execute' but does not pop-up the contingency command.

```
int ComNmink.GenerateContingenciesForAnalysis()
```

RETURNS

0 On success.
1 On error.

GetAll

Returns all objects which are of the class 'ClassName'.

```
list ComNmink.GetAll(str className)
```

ARGUMENTS

className
The object class name.

RETURNS

The set of objects

5.4.31 ComOmr

Overview

[GetFeeders](#)
[GetOMR](#)
[GetRegionCount](#)

GetFeeders

Get all feeders for which optimal manual switches have been determined. This function can be used after execution of an Optimal Manual Restoration command only.

```
list ComOmr.GetFeeders()
```

RETURNS

The set of all feeders used for optimisation.

GetOMR

Get terminal and connected optimal manual switches determined by the optimisation for the given feeder and its region(pocket) of the given index. For a detailed description of a pocket, please consult the manual. This function can be used after execution of an Optimal Manual Restoration command only.

```
list ComOmr.GetOMR(DataObject arg0,  
                    int arg1  
                    )
```

ARGUMENTS

- arg0* The feeder to derive the resulting optimal terminal with its connected (optimal) manual switches for.
- arg1* The index of the region(pocket) inside the given feeder to derive the resulting optimal terminal with its connected (optimal) manual switches for.

RETURNS

The resulting optimal terminal with its connected (optimal) manual switches for the region in the feeder.

GetRegionCount

Get total number of regions(pockets) separated by infeeding point, feeder ends and certain switches for the provided feeder. For a detailed description of a pocket, please consult the manual. This function can be used after execution of an Optimal Manual Restoration command only.

```
int ComOmr.GetRegionCount(DataObject feeder)
```

ARGUMENTS

feeder Feeder to derive number of regions(pockets) for.

RETURNS

Number of regions(pockets) for the feeder.

5.4.32 ComOpc

Overview

[GetCertificatePath](#)
[ReceiveData](#)
[SendData](#)

GetCertificatePath

Gets the path to the PowerFactory certificate (OpenSSL file in DER format) used for the OPC communication. The certificate is always placed in the workspace directory of the running PowerFactory instance.

```
str ComOpc.GetCertificatePath([int create = 0])
```

ARGUMENTS

create (optional)

- | | |
|----------|---|
| 0 | Do not create the certificate if it does not exist (default). |
| 1 | Create the certificate if it does not exist or has expired. |
| 2 | Always recreate the certificate. |

RETURNS

The path to the certificate file. The string is empty if the certificate file does not exist.

ReceiveData

Reads and processes values for all (in PowerFactory configured) items from OPC server (OPC only).

```
int ComOpc.ReceiveData([int force])
```

ARGUMENTS

force (optional)

- | | |
|----------|--|
| 1 | Forces (synchronous) reading and processing of all values (independent of value changes) |
|----------|--|

RETURNS

1 if successfully received data -1 if an error occurred -2 if the link is not connected

SendData

Sends values from configured measurement objects to OPC server (OPC only).

```
int ComOpc.SendData([int force])
```

ARGUMENTS

force (optional)

- 0** (default) Send only data that have been changed and difference between old and new value is greater than configured deadband
- 1** Forces writing of all values (independent of previous value)

RETURNS

1 if successfully received data -1 if an error occurred -2 if the link is not connected

5.4.33 ComOutage

Overview

[ContinueTrace](#)
[ExecuteTime](#)
[GetObject](#)
[RemoveEvents](#)
[SetObjs](#)
[StartTrace](#)
[StopTrace](#)

ContinueTrace

Continue the next step of the trace.

```
int ComOutage.ContinueTrace()
```

RETURNS

- 0** On success.
- $\neq 0$ On error.

ExecuteTime

Execute contingency (with multiple time phase) for the given time.

```
int ComOutage.ExecuteTime(float time)
```

ARGUMENTS

time the given time to be executed.

RETURNS

- = 0** On success.
- $\neq 0$ On error.

GetObject

Get the element stored in line number “line” in the table of ComOutage. The line index starts with 0.

```
DataObject ComOutage.GetObject(int line)
```

ARGUMENTS

line line index, if index exceeds the range None is returned

RETURNS

the element of line “line” in the table.

RemoveEvents

Remove all events defined in this contingency.

```
None ComOutage.RemoveEvents([int info = 1],
                             [str type = ''])
None ComOutage.RemoveEvents(str type,
                             [int info = 1])
```

ARGUMENTS

type

" Remove all events.
'Gen' Remove all dispatch events (EvtGen).
'Lod' Remove all load events (EvtLod).
'Switch' Remove all switch events (EvtSwitch).
'Trf' Remove all power transfer events (EvtTransfer).
'Tap' Remove all tap events (EvtTap).

info(optional)

1 show info message in output window (default)
0 do not show info message

SetObjs

To fill up the "interrupted components" with given elements.

Sets the list of objects according to S.

```
int ComOutage.SetObjs(list S)
```

ARGUMENTS

S the set of objects

RETURNS

0 On success.
1 On error.

StartTrace

Start trace all post fault events of this contingency.

```
int ComOutage.StartTrace()
```

RETURNS

= 0 On success.
≠ 0 On error.

StopTrace

To stop the trace.

```
int ComOutage.StopTrace([int msg])
```

ARGUMENTS

msg (optional)
Emit messages or not.

0	Suppress messages.
1	Emit messages.

RETURNS

= 0 On success.
≠ 0 On error.

5.4.34 ComPfdimport

Overview

[GetImportedObjects](#)

GetImportedObjects

Returns the imported objects of last execution of command.

```
list ComPfdimport.GetImportedObjects()
```

RETURNS

Returns the imported objects of the last execution of the command.

5.4.35 ComPrjconnector

Overview

[GetSuccessfullyConnectedItems](#)
[GetUnsuccessfullyConnectedItems](#)

GetSuccessfullyConnectedItems

Returns a list of elements which were correctly processed in the last run of the command

```
list ComPrjconnector.GetSuccessfullyConnectedItems()
```

GetUnsuccessfullyConnectedItems

Returns a list of elements which were not correctly processed in the last run of the command

```
list ComPrjconnector.GetUnsuccessfullyConnectedItems()
```

5.4.36 ComProtgraphic

Overview

[AddToUpdatePages](#)
[ClearUpdatePages](#)

AddToUpdatePages

Adds pages (*.GrpPage, *.SetVipage) to the user-defined selection of plot pages to update.

```
None ComProtgraphic.AddToUpdatePages(list pages)
```

ClearUpdatePages

Clears the user-defined selection of plot pages to update.

```
None ComProtgraphic.ClearUpdatePages()
```

5.4.37 ComPvcurves

Overview

[FindCriticalBus](#)

FindCriticalBus

Returns the critical bus for a given PV-Curve result file. The critical bus is the one with the highest gradient at the last iteration. If a bus is found, whose voltage drop is twice as high, as the one with the highest gradient, the bus with the higher voltage drop is the critical one.

```
DataObject ComPvcurves.FindCriticalBus(DataObject resultfile)
```

5.4.38 ComPython

Overview

[GetExternalObject](#)
[GetInputParameterDouble](#)
[GetInputParameterInt](#)
[GetInputParameterString](#)
[SetExternalObject](#)
[SetInputParameterDouble](#)
[SetInputParameterInt](#)
[SetInputParameterString](#)

GetExternalObject

Gets the external object defined in the ComPython edit dialog.

```
[int error,  
DataObject value] ComPython.GetExternalObject(str name)
```

ARGUMENTS

name Name of the external object parameter.

value (out)
The external object.

RETURNS

0 On success.

1 On error.

SEE ALSO

[ComPython.SetExternalObject\(\)](#), [ComPython.GetInputParameterInt\(\)](#),
[ComPython.GetInputParameterDouble\(\)](#), [ComPython.GetInputParameterString\(\)](#)

GetInputParameterDouble

Gets the double input parameter value defined in the ComPython edit dialog.

```
[int error,  
float value] ComPython.GetInputParameterDouble(str name)
```

ARGUMENTS

name Name of the double input parameter.

value (out)
Value of the double input parameter.

RETURNS

- 0** On success.
- 1** On error.

SEE ALSO

[ComPython.SetInputParameterDouble\(\)](#), [ComPython.GetInputParameterInt\(\)](#),
[ComPython.GetInputParameterString\(\)](#), [ComPython.GetExternalObject\(\)](#)

GetInputParameterInt

Gets the integer input parameter value defined in the ComPython edit dialog.

```
[int error,  
int value ] ComPython.GetInputParameterInt(str name)
```

ARGUMENTS

- name* Name of the integer input parameter.
- value (out)* Value of the integer input parameter.

RETURNS

- 0** On success.
- 1** On error.

SEE ALSO

[ComPython.SetInputParameterInt\(\)](#), [ComPython.GetInputParameterDouble\(\)](#),
[ComPython.GetInputParameterString\(\)](#), [ComPython.GetExternalObject\(\)](#)

GetInputParameterString

Gets the string input parameter value defined in the ComPython edit dialog.

```
[int error,  
str value ] ComPython.GetInputParameterString(str name)
```

ARGUMENTS

- name* Name of the string input parameter.
- value (out)* Value of the string input parameter.

RETURNS

- 0** On success.
- 1** On error.

SEE ALSO

[ComPython.SetInputParameterString\(\)](#), [ComPython.GetInputParameterInt\(\)](#),
[ComPython.GetInputParameterDouble\(\)](#), [ComPython.GetExternalObject\(\)](#)

SetExternalObject

Sets the external object defined in the ComPython edit dialog.

```
int ComPython.SetExternalObject(str name,  
                               DataObject value  
                               )
```

ARGUMENTS

name Name of the external object parameter.
value The external object.

RETURNS

0 On success.
1 On error.

SEE ALSO

[ComPython.GetExternalObject\(\)](#), [ComPython.SetInputParameterInt\(\)](#),
[ComPython.SetInputParameterDouble\(\)](#), [ComPython.SetInputParameterString\(\)](#)

SetInputParameterDouble

Sets the double input parameter value defined in the ComPython edit dialog.

```
int ComPython.SetInputParameterDouble(str name,  
                                       float value  
                                       )
```

ARGUMENTS

name Name of the double input parameter.
value Value of the double input parameter.

RETURNS

0 On success.
1 On error.

SEE ALSO

[ComPython.GetInputParameterDouble\(\)](#), [ComPython.SetInputParameterInt\(\)](#),
[ComPython.SetInputParameterString\(\)](#), [ComPython.SetExternalObject\(\)](#)

SetInputParameterInt

Sets the integer input parameter value defined in the ComPython edit dialog.

```
int ComPython.SetInputParameterInt(str name,  
                                   int value  
                                   )
```

ARGUMENTS

name Name of the integer input parameter.
value Value of the integer input parameter.

RETURNS

- 0** On success.
- 1** On error.

SEE ALSO

[ComPython.GetInputParameterInt\(\)](#), [ComPython.SetInputParameterDouble\(\)](#),
[ComPython.SetInputParameterString\(\)](#), [ComPython.SetExternalObject\(\)](#)

SetInputParameterString

Sets the string input parameter value defined in the ComPython edit dialog.

```
int ComPython.SetInputParameterString(str name,
                                     str value
                                     )
```

ARGUMENTS

- name* Name of the string input parameter.
- value* Value of the string input parameter.

RETURNS

- 0** On success.
- 1** On error.

SEE ALSO

[ComPython.GetInputParameterString\(\)](#), [ComPython.SetInputParameterInt\(\)](#),
[ComPython.SetInputParameterDouble\(\)](#), [ComPython.SetExternalObject\(\)](#)

5.4.39 ComRed**Overview**

[LdfEquivalentVerification](#)
[ReductionInMemory](#)
[ResetReductionInMemory](#)
[SimEquivalentVerification](#)

LdfEquivalentVerification

Right after Network Reduction execution, get the verification results of the load flow equivalents.

```
int ComRed.LdfEquivalentVerification()
```

RETURNS

- 1** Calculation is not available or the varification is not enabled.
- 0** The reduced network is equivalent to the original network.
- 1** The load flow doesn't converge after reduction.
- 2** The load flow converges after reduction but the results differ from original network.

ReductionInMemory

Execute network reduction in memory, no change to database. Note: afterwards, the function `ResetReductionInMemory()` must be called to revert the reduction.

```
int ComRed.ReductionInMemory()
```

RETURNS

Returns 0 if successfully executed.

ResetReductionInMemory

Restore the network back to original after reduction in memory.

```
void ComRed.ResetReductionInMemory()
```

SimEquivalentVerification

Right after Network Reduction execution, get the verification results of the dynamic simulation equivalents.

```
int ComRed.SimEquivalentVerification()
```

RETURNS

- 1** Calculation is not available or the varification cannot be carried out.
- 0** The reduced network is equivalent to the original network.
- 1** The dynamic simulation fails after reduction.
- 2** The dynamic simulation works after reduction but the results differ from original network.

5.4.40 ComRel3

Overview

[AnalyseElmRes](#)
[ExeEvt](#)
[OvlAlleviate](#)
[RemoveEvents](#)
[RemoveOutages](#)
[ValidateConstraints](#)

AnalyseElmRes

Evaluate the results object created by the last calculation.

```
int ComRel3.AnalyseElmRes([int error])
```

ARGUMENTS

- error (optional)*
- 0** do not display an error message (default)
 - 1** display error messages in case of errors

RETURNS

- = 0 On success.
- ≠ 0 On error.

ExeEvt

Executes a given event.

```
None ComRel3.ExeEvt ([DataObject event])
```

ARGUMENTS

- event* The event that shall be executed.

OvlAlleviate

Performs an overload alleviation for given events.

```
int ComRel3.OvlAlleviate ([list preCalcEvents])
```

ARGUMENTS

- preCalcEvents (optional)*
The events which will be executed before the calculation.

RETURNS

- 0 On success.
- 1 Failure in load flow.
- 2 No overloading detected.
- > 2 On error.

RemoveEvents

Removes all events stored in all contingencies (*.ComContingency) inside the reliability command.

```
None ComRel3.RemoveEvents ()
```

RemoveOutages

Removes all contingency definitions (*.ComContingencies) stored inside the reliability command.

```
None ComRel3.RemoveOutages ([int msg])
```

ARGUMENTS

- msg (optional)*
 - 1** Show info message in output window (default value).
 - 0** Do not emit messages.

ValidateConstraints

Checks if the restoration of a contingency violates any constraint according to the current settings of the reliability calculation. These do not necessarily have to be the settings used during calculation. Of course the selected calculation method of ComRel3 has to be 'Load flow analysis' to check for constraint violations.

```
int ComRel3.ValidateConstraints(DataObject contingency)
```

ARGUMENTS

contingency

The contingency which will be checked for constraint violations.

RETURNS

- 0 No constraint violations, or all constraint violations could be solved.
- 1 Constraints are violated.
- 1 Contingency not valid.
- 2 Load flow did not converge.
- 3 Network error.

5.4.41 ComRelpost

Overview

[CalcContributions](#)

[GetContributionOfComponent](#)

CalcContributions

Calculates the contributions to load interruptions of the loads that are passed to this function. The loads can be e.g. inside a feeder or a zone as well. If nothing is passed as input all loads will be analysed.

```
int ComRelpost.CalcContributions([list elements])
```

ARGUMENTS

elements (optional)

Elements (Loads) for which the contributions shall be calculated (default: all loads, if no argument is passed).

RETURNS

- 0 Calculation successful.
- 1 On error.

GetContributionOfComponent

Gets the contributions of a component to a certain reliability indice.

```
float ComRelpost.GetContributionOfComponent(int componentNr,  
                                             str indice)
```

ARGUMENTS

componentNr 1. Lines
 2. Cables
 3. Transformers
 4. Busbars
 5. Generators
 6. Common Modes
 7. Double Earth Faults

indice Available indices are: 'SAIFI', 'SAIDI', 'ASIFI', 'ASIDI', 'ENS', 'EIC'

RETURNS

The contribution of this component to this reliability indice.

5.4.42 ComRelreport

Overview

[GetContingencies](#)
[GetContributionOfComponent](#)

GetContingencies

Gets all contingencies of reliability for reporting.

```
list ComRelpost.GetContingencies()
```

RETURNS

All contingencies of reliability for reporting.

GetContributionOfComponent

Is described in [ComRelpost.GetContributionOfComponent\(\)](#).

```
float ComRelreport.GetContributionOfComponent(int componentNr,  
                                              str indice)
```

5.4.43 ComReltabreport

Overview

[GetContingencies](#)
[GetContributionOfComponent](#)

GetContingencies

Gets all contingencies of reliability for reporting.

```
list ComReltabreport.GetContingencies()
```

RETURNS

All contingencies of reliability for reporting.

GetContributionOfComponent

Is described in [ComRelpost.GetContributionOfComponent\(\)](#).

```
float ComReltabreport.GetContributionOfComponent(int componentNr,  
                                                  str indice)
```

5.4.44 ComReport

Overview

[ExecuteWithCustomSelection](#)
[SetParameter](#)

ExecuteWithCustomSelection

Executes report generation with the given reports as well as front matter and header/footer template.

This method allows to override the regular report selection configured for the currently active calculation as well as the configured front matter and header/footer template, with a freely defined selection.

Since virtually any report templates can be selected (even those that were not designed for the currently active calculation), this method should be employed by experienced users only.

```
int ComReport.ExecuteWithCustomSelection(list reports,  
                                         [DataObject frontMatter],  
                                         [DataObject headerFooter])
```

ARGUMENTS

reports The reports to be selected.

frontMatter (optional)

The front matter template to be used. If not given, no front matter will be selected.

headerFooter (optional)

The header/footer template to be used. If not given, no header/footer will be selected.

RETURNS

The same return value as a regular 'Execute' call.

SetParameter

Overrides the initial value of the given report's parameter with the given value.

This method is the scripting equivalent of overriding the value of a report parameter in the Report Generation command (ComReport) dialog and should only be employed by experienced users.

```
int ComReport.SetParameter(DataObject report,
                           str parameterIdentifier,
                           int|float|str value)
```

ARGUMENTS

- report* The report that provides the desired parameter.
- parameterIdentifier*
 The identifier (not the localised name) of the parameter.
- value* The new value for the parameter.

RETURNS

An error code. Possible values are

- 0** No error has occurred, the parameter has been successfully set.
- 1** The given object is not a report template (either None or not of class IntReport).
- 2** There is no valid report parameter with the given identifier.
- 3** The data type of the given value cannot be converted to the data type of the parameter.
- 4** The data type of the given value is not supported by this method.

5.4.45 ComRes

Overview

[ExportFullRange](#)
[FileNmResNm](#)

ExportFullRange

Executes the export command for the whole data range.

```
None ComRes.ExportFullRange()
```

FileNmResNm

Sets the filename for the data export to the name of the result object being exported (classes: ElmRes, IntComtrade)

```
None ComRes.FileNmResNm()
```

5.4.46 ComShc

Overview

[ExecuteRXSweep](#)
[GetFaultType](#)
[GetOverLoadedBranches](#)
[GetOverLoadedBuses](#)

ExecuteRXSweep

Calculates RX Sweep. If no impedance passed, the value from the command shall be used. If argument passed then the impedance changes are stored to the command (Rf, Xf).

```
int ComShc.ExecuteRXSweep()
int ComShc.ExecuteRXSweep(float Zr,
                          float Zi
                          )
```

ARGUMENTS

Zr Impedance real part
Zi Impedance imaginary part

RETURNS

= 0 On success.
 ≠ 0 On error.

GetFaultType

Returns the short-circuit fault type.

```
int ComShc.GetFaultType()
```

RETURNS

0	three phase fault
1	single phase to ground
2	two phase fault
3	two phase to ground fault
4	three phase unbalanced fault
5	single phase to neutral fault
6	single phase, neutral to ground fault
7	two phase to neutral fault
8	two phase, neutral to ground fault
9	three phase to neutral fault
10	three phase, neutral to ground fault
20	DC fault

GetOverLoadedBranches

Get overloaded branches after a short-circuit calculation.

```
[int error,  
list branches] ComShc.GetOverLoadedBranches(float ip,  
                                             float ith)
```

ARGUMENTS

ip Max. peak-current loading, in %
ith Max. thermal loading, in %
branches (out)
 Set of branches which are checked

RETURNS

= 0 On error or 0 branches found.
≠ 0 Number of branches.

EXAMPLE

GetOverLoadedBuses

Get overloaded buses after a short-circuit calculation.

```
[int error,  
list buses] ComShc.GetOverLoadedBuses(float ip,  
                                       float ith)
```

ARGUMENTS

ip Max. peak-current loading, in %
ith Max. thermal loading, in %
buses (optional, out)
 Set of buses which are checked

RETURNS

= 0 On error or 0 buses found.
≠ 0 Number of buses.

EXAMPLE

5.4.47 ComShctrace

Overview

[BlockSwitch](#)
[ExecuteAllSteps](#)
[ExecuteInitialStep](#)
[ExecuteNextStep](#)
[GetBlockedSwitches](#)
[GetCurrentTimeStep](#)
[GetDeviceSequence](#)
[GetDeviceSwitches](#)
[GetDeviceTime](#)
[GetFaultLocations](#)
[GetNonStartedDevices](#)
[GetPreviousDeviceTime](#)
[GetStartedDevices](#)
[GetSwitchSequence](#)
[GetSwitchTime](#)
[GetTrippedDevices](#)
[IsSwitchScheduledToOpen](#)
[NextStepAvailable](#)

BlockSwitch

Blocks a switch from operating for the remainder of the trace.

```
int ComShctrace.BlockSwitch(DataObject switchDevice)
```

ARGUMENTS

switchDevice
 Switch device to block.

RETURNS

0 Switch can not be blocked (e.g. because it already operated).
1 Switch is blocked.

ExecuteAllSteps

Executes all steps of the short circuit trace. This function requires the trace to be already running

```
int ComShctrace.ExecuteAllSteps()
```

RETURNS

= 0 No error occurred, trace is complete.
 ≠ 0 An error occurred, calculation was reset.

SEE ALSO

ComShctrce.ExecuteInitialStep()

ExecuteInitialStep

Executes the first step of the short circuit trace.

```
int ComShctrace.ExecuteInitialStep()
```

RETURNS

- = 0 No error occurred, the short-circuit trace is now running.
- ≠ 0 An error occurred, calculation was reset.

ExecuteNextStep

Executes the next step of the short circuit trace. This function requires the trace to be already running

```
int ComShctrace.ExecuteNextStep()
```

RETURNS

- = 0 No error occurred, step was executed .
- ≠ 0 An error occurred, calculation was reset.

SEE ALSO

ComShctrace.ExecuteInitialStep()

GetBlockedSwitches

Returns all switches which are currently blocked.

```
list ComShctrace.GetBlockedSwitches()
```

RETURNS

All blocked switches.

GetCurrentTimeStep

Returns the current time step of the trace in seconds.

```
int ComShctrace.GetCurrentTimeStep()
```

RETURNS

The current time step in [s].

GetDeviceSequence

Returns the number of the step the device tripped in.

```
int ComShctrace.GetDeviceSequence(DataObject device)
```

RETURNS

- ≥ 1 Step number the device tripped in
- 1 The device did not trip in any step.

GetDeviceSwitches

Returns all switches operated by a protection device.

```
list ComShctrace.GetDeviceSwitches(DataObject device)
```

ARGUMENTS

device Protection device to get the switches for.

RETURNS

All switches devices operated by the protection device.

GetDeviceTime

Returns the time a protection device operated or will operate at.

```
int ComShctrace.GetDeviceTime(DataObject device)
```

ARGUMENTS

device Protection device to get the time for.

RETURNS

The tripping time of the device itself, if the device already tripped, or the prospective tripping time.

GetFaultLocations

Returns the fault locations defined in the short-circuit events.

```
list ComShctrace.GetFaultLocations()
```

RETURNS

Fault locations defined in the short-circuit events.

GetNonStartedDevices

Returns all protection devices which are not started.

```
list ComShctrace.GetNonStartedDevices()
```

RETURNS

All protection devices which are not started.

GetPreviousDeviceTime

Returns the time a protection device operated or would have operate at from the previous time step.

```
int ComShctrace.GetPreviousDeviceTime(DataObject device)
```

ARGUMENTS

device Protection device to get the time for.

RETURNS

The tripping time of the device itself, if the device already tripped, or the prospective tripping time from the last step.

GetStartedDevices

Returns all started but not yet tripped protection devices.

```
list ComShctrace.GetStartedDevices()
```

RETURNS

All started but not yet tripped protection devices.

GetSwitchSequence

Returns the number of the step the switch tripped in.

```
int ComShctrace.GetSwitchSequence(DataObject switchDevice)
```

RETURNS

- ≥ 1 Step number the switch tripped in
- 1 The switch did not trip in any step.

GetSwitchTime

Returns the time a switch device operated or will operate at.

```
int ComShctrace.GetSwitchTime(DataObject device,  
                               DataObject switchDevice)
```

ARGUMENTS

- device* Reference protection device for the switch.
- device* Switch device to get the time for.

RETURNS

The tripping time of the switch device, based on the tripping time of the reference protection device. If the switch already operated, the time of operation will be returned.

GetTrippedDevices

Returns all protection devices already tripped.

```
list ComShctrace.GetTrippedDevices()
```

RETURNS

All protection devices already tripped.

IsSwitchScheduledToOpen

Check if a switch will be opened in a future time step because a controlling device already tripped.

```
int ComShctrace.IsSwitchScheduledToOpen(DataObject switchDevice)
```

RETURNS

- 0** Switch is not scheduled to open.
- 1** Switch is scheduled to open.

NextStepAvailable

Indicates whether or not a next time step can be executed.

```
int ComShctrace.NextStepAvailable()
```

RETURNS

- 0** Next step is not available, the trace is completed.
- 1** A next step is available.

5.4.48 ComSim**Overview**

[GetSimulationTime](#)
[GetTotalWarnA](#)
[GetTotalWarnB](#)
[GetTotalWarnC](#)
[GetViolatedScanModules](#)
[LoadSnapshot](#)
[SaveSnapshot](#)

GetSimulationTime

Get the actual simulation time if the initial conditions are calculated.

```
int ComSim.GetSimulationTime()
```

RETURNS

Returns the simulation time in seconds. If the initial conditions are not calculated, then the function returns 'nan'.

GetTotalWarnA

Returns the total number of type-A (serious) warnings related to the time-domain simulation.

```
int ComSim.GetTotalWarnA()
```

RETURNS

Returns the total number of type-A (serious) warnings.

GetTotalWarnB

Returns the total number of type-B (moderate) warnings related to the time-domain simulation.

```
int ComSim.GetTotalWarnB()
```

RETURNS

Returns the total number of type-B (moderate) warnings.

GetTotalWarnC

Returns the total number of type-C (minor) warnings related to the time-domain simulation.

```
int ComSim.GetTotalWarnC()
```

RETURNS

Returns the total number of type-C (minor) warnings.

GetViolatedScanModules

Returns a set of scan modules of which each have at least one violation.

```
list ComSim.GetViolatedScanModules()
```

RETURNS

Returns a set of scan modules of which each have at least one violation.

LoadSnapshot

Load the state of a dynamic simulation from a file.

```
int ComSim.LoadSnapshot([string snapshotFilePath], [int suppressUserMessage])
```

DEPRECATED NAMES

LoadSimulationState

ARGUMENTS

snapshotFilePath (optional)

The snapshot file to load. If no file is specified, the last snapshot stored in the memory is used. (default = "")

suppressUserMessage (optional)

Pop-up suppression level:

- | | |
|----------|---|
| 0 | No pop-up suppression. All pop-ups are shown. (default) |
| 1 | The pop-up asking for data overwrite is suppressed. |
| 2 | All pop-ups are suppressed. |

RETURNS

- 0** Saved simulation state has been loaded.
- 1** Saved simulation state cannot be loaded.
- 2** Saved simulation state does not match actual model. Calculation will be reset.

SaveSnapshot

Save the state of a dynamic simulation to memory and to a file.

```
int ComSim.SaveSnapshot(string snapshotFilePath, [int suppressUserMessage])
```

DEPRECATED NAMES

SaveSimulationState

ARGUMENTS

snapshotFilePath (optional)

The snapshot file to save. If no file is specified, the last snapshot is saved in the non-persistent memory slot. (default = ")

suppressUserMessage (optional)

The pop-up window asking for file overwriting is not displayed if this value is set to 1. (default = 0)

RETURNS

- 0** OK
- 1** Error

5.4.49 ComSimoutage**Overview**

[AddCntcy](#)
[AddContingencies](#)
[AddRas](#)
[ClearCont](#)
[CreateFaultCase](#)
[Execute](#)
[ExecuteAndCheck](#)
[MarkRegions](#)
[RemoveAllRas](#)
[RemoveContingencies](#)
[RemoveRas](#)
[Reset](#)
[SetLimits](#)
[Update](#)

AddCntcy

Executes an (additional) ComOutage, without resetting results. The results of the outage analysis will be added to the intermediate results. Object “O” must be a ComOutage object. If the outage definition has already been analyzed, it will be ignored. The ComOutage will be renamed to “name” when “name” is given.

```
int ComSimoutage.AddCntcy(DataObject O,
                          [str name]
                          )
```

ARGUMENTS

O The ComOutage object
name A name for the outage

RETURNS

0 On success.
1 On error.

AddContingencies

Adds contingencies for fault cases/groups selected by the user to the command. Shows a modal window with the list of available fault cases and groups. Functionality as “Add Cases/Groups” button in dialog.

```
None ComSimoutage.AddContingencies()
```

AddRas

Adds a reference to a given IntRas to the ComSimoutage.

```
int ComSimoutage.AddRas(DataObject ras)
```

ARGUMENTS

ras The IntRas object

RETURNS

0 If the reference to the IntRas has been added.
1 If the reference to the IntRas has already been there or on error.

ClearCont

Reset existing contingency analysis results and delete existing contingency cases.

```
int ComSimoutage.ClearCont()
```

RETURNS

0 On success.
1 On error.

CreateFaultCase

Create fault cases from the given elements.

```
int ComSimoutage.CreateFaultCase(list elms,
                                int mode,
                                [int createEvt],
                                [DataObject folder]
                                )
```

ARGUMENTS

- elms* Selected elements to create fault cases.
- mode* How the fault cases are created:
- 0** Single fault case containing all elements.
 - 1** n-1 (multiple cases).
 - 2** n-2 (multiple cases).
 - 3** Collecting coupling elements and create fault cases for line couplings.
- createEvt (optional)*
Switch event:
- 0** Do NOT create switch events.
 - 1** Create switch events.
- folder (optional)*
Folder in which the fault case is stored.

RETURNS

- 0** On success.
- 1** On error.

Execute

Execute contingency analysis.

```
int ComSimoutage.Execute()
```

RETURNS

- 0** On success.
- 1** On error.

ExecuteAndCheck

Executes contingency analysis and checks the violated constraints. The constraints are defined in models, such as maximum and minimum voltage of buses, maximum loading of lines etc. On the first occurred constraint violation, the further contingency execution will be terminated, making the calculation faster, but with less information.

```
int ComSimoutage.ExecuteAndCheck([int workMode,]
                                  [int initMode,]
                                  [int considerOPFflags,]
                                  [int considerVstep]
                                  )
```

ARGUMENTS

workMode (optional)

the mode how the contingency analysis is executed; default is 0

- 0** Normal execution (doesn't check limits, write results file)
- 1** Check constraints (thermal loading, bus voltage range) and terminate execution if violates any limit, writes result file
- 2** Check constraints (thermal loading, bus voltage range) and terminate execution if violates any limit, does not write result file
- 3** Check thermal loading only and terminate execution if violates any limit, writes result file
- 4** Check thermal loading only and terminate execution if violates any limit, does not write result file
- 5** Check voltage limits only and terminate execution if violates any limit, writes result file
- 6** Check voltage limits only and terminate execution if violates any limit, does not write result file
- 7** Neither loading nor voltage limits are checked and terminate execution if any contingency fails, writes result file
- 8** Neither loading nor voltage limits are checked and terminate execution if any contingency fails, does not write result file

initMode (optional)

the mode how the contingency analysis is initialised; default is 0

- 0** full initialisation, new topology rebuild, and update all contingencies
- 1** new topology rebuild, but skip updating all contingencies
- 2** no topology rebuild, and no contingency update, which is the fastest mode

considerOPFflags (optional)

whether the voltage limit settings on OPF page will be considered or not; default is 1

- 0** the settings on OPF page are not considered.
- 1** the voltage limits are considered only when the check boxes on OPF page are ticked.

considerVstep (optional)

whether the voltage step limits will be considered or not; default is 1

- 0** the voltage step limits are not considered.
- 1** the voltage step limits are considered.

RETURNS

- 0** contingencies successfully executed without any violation
- 1** calculation was interrupted by the user
- 2** error occurred during contingency analysis
- 3** initialisation failed, such as base case load flow diverged
- 4** for AC/DC combined method, base case is already critical and calculation stopped
- 5** any loading constraint violated
- 6** any contingency cannot be analysed, non-convergent case
- 7** any voltage constraint violated
- 8** any constraint violated already in the base case

MarkRegions

To execute Region marker for certain system status (like prefault, post fault etc.), which will identifies energizing mode for each element.

```
int ComSimoutage.MarkRegions(int stage)
```

ARGUMENTS

stage which system stage to be analyzed, $0 \leq \text{stage} \leq 2$

RETURNS

0 On success.
1 On error.

RemoveAllRas

Removes all IntRas from to the ComSimoutage. Only deletes the references not the IntRas itself.

```
None ComSimoutage.RemoveAllRas()
```

RemoveContingencies

Removes all contingencies from the command. Functionality as "Remove All" button in dialog.

```
None ComSimoutage.RemoveContingencies()
```

RemoveRas

Removes the reference to a given IntRas from the ComSimoutage.

```
int ComSimoutage.RemoveRas(DataObject ras)
```

ARGUMENTS

ras The IntRas object

RETURNS

0 If the reference to the IntRas has been successfully removed.
1 If the reference to the IntRas has not been in the container or on error.

Reset

Resets the intermediate results of the outage simulation.

```
int ComSimoutage.Reset()
```

RETURNS

0 On success.
1 On error.

SetLimits

Sets the recording limits for the Contingency Analysis.

```
None ComSimoutage.SetLimits(float vmin,  
                             float vmax,  
                             float ldmax)
```

ARGUMENTS

<i>vmin</i>	The minimum voltage
<i>vmax</i>	The maximum voltage
<i>ldmax</i>	The maximum loading

Update

To update contingency cases via topology search. It will find interrupted elements, required switch actions for each contingency.

```
int ComSimoutage.Update()
```

RETURNS

0	On success.
1	On error.

5.4.50 ComStationware

Overview

[Connect](#)
[Disconnect](#)
[GetAuthenticationTicket](#)
[IsConnected](#)

Connect

Connect to the StationWare server.

```
int ComStationware.Connect()
```

RETURNS

0	connect was successful
1	an error occurred

Disconnect

Disconnect from the StationWare server.

```
int ComStationware.Disconnect()
```

RETURNS

- 0** disconnect was successful
- 1** an error occurred

GetAuthenticationTicket

Returns authentication ticket used by the current connection to the StationWare server.

```
str ComStationware.GetAuthenticationTicket()
```

RETURNS

Authentication ticket or "" if there is currently no open connection.

IsConnected

Check whether **PowerFactory** is connected to a StationWare server.

```
int ComStationware.IsConnected()
```

RETURNS

- 0** there is no connection to StationWare server
- 1** the connection to StationWare server is opened

5.4.51 ComSvgexport**Overview**

[SetFileName](#)
[SetObject](#)
[SetObjects](#)

SetFileName

Sets SVG file for export.

```
None ComSvgexport.SetFileName(str path)
```

ARGUMENTS

path Path of target SVG file

SetObject

Sets annotation layer or group for export.

```
None ComSvgexport.SetObject(DataObject obj)
```

ARGUMENTS

obj Annotation layer (IntGrflayer) or group (IntGrfgroup) to be exported

SetObjects

Sets annotation layers and groups for export.

```
None ComSvgexport.SetObjects(set objs)
```

ARGUMENTS

objs Set of annotation layers (IntGrflayer) and/or groups (IntGrfgroup) to be exported

5.4.52 ComSvgimport

Overview

[SetFileName](#)
[SetObject](#)

SetFileName

Sets source SVG file for import.

```
None ComSvgimport.SetFileName(str path)
```

ARGUMENTS

path Path of SVG file to be imported

SetObject

Sets target annotation layer or group for import.

```
None ComSvgimport.SetObject(DataObject obj)
```

ARGUMENTS

obj Target annotation layer (IntGrflayer) or group (IntGrfgroup)

5.4.53 ComTablereport

Overview

AddButton
AddCellAction
AddColumn
AddHeader
AddInvisibleFilter
AddListFilter
AddListFilterEntries
AddMultiListFilter
AddRow
AddTable
AddTabularFilter
AddTextFilter
ClearAll
DisableAutomaticRowNumbering
DisableSingleFilterRefresh
DisplayButtonsCollapsible
DisplayFiltersCollapsible
DisplayFiltersIn2Columns
DisplayHeadersCollapsible
EnableAutomaticRowNumbering
ExportToExcel
ExportToHTML
FindNextCell
FindNextRow
FindPreviousCell
FindPreviousRow
GetCellAccessObject
GetCellAlignment
GetCellBackgroundColor
GetCellColor
GetCellEditObjects
GetCellFontStyle
GetCellFormat
GetCellHelpText
GetCellValueType
GetCheckboxCellValue
GetColumnFilter
GetColumnHeader
GetColumnId
GetDateCellValue
GetDoubleCellValue
GetIntCellValue
GetNumberOfColumns
GetNumberOfRows
GetNumberOfSelectedCells
GetObjectCellValue
GetRowCaption
GetRowId
GetSelectedCell
GetSelectedElements
GetSelection
GetStringCellValue

GoToCell
 HasCell
 HasColumnAutoFilter
 IsColumnScrollable
 IsColumnSortable
 IsRowVisible
 RemoveRow
 SetBarLimits
 SetCellAccess
 SetCellAlignment
 SetCellBackgroundColor
 SetCellColor
 SetCellEdit
 SetCellFontStyle
 SetCellFormat
 SetCellStyle
 SetCellValueToBar
 SetCellValueToCheckbox
 SetCellValueToDate
 SetCellValueToDouble
 SetCellValueToInt
 SetCellValueToObject
 SetCellValueToString
 SetColumnHeader
 SetDialogSize
 SetExportHtml
 SetExportXls
 SetListFilterSelection
 SetRefresh
 SetSorting
 SetStatusText
 SetTitle

AddButton

Adds a button to the button section of the report.

```

int ComTablereport.AddButton(str id,
                             str label,
                             [int width,]
                             [int newLine,]
                             [int refresh]
                             )
  
```

ARGUMENTS

<i>id</i>	Identifier
<i>label</i>	Label text
<i>width (optional)</i>	Button width in pixel (default: 100)
<i>newLine (optional)</i>	
0	Place button floating (default)
1	Place button in a new line

refresh (optional)

- 0** Do not refresh report after button was handled (default)
- 1** Refresh report after button was handled

RETURNS

- 0** On error: button with given id already exists.
- 1** Button was added to the report.

AddCellAction

Adds a cell action to a table cell. This means that an entry is added to the right mouse button menu of the cell.

```
int ComTablereport.AddCellAction(str tableId,
                                str columnId,
                                str rowId,
                                str actionId,
                                str displayText,
                                [list actionObjects,]
                                [int refresh]
                                )
```

ARGUMENTS

tableId Identifier of the table

columnId Identifier of the column

rowId Identifier of the row

actionId Identifier for the action

displayText (optional)

Text to be displayed in the right mouse button menu for this action

actionObjects (optional)

Objects needed to handle this action (default: empty). These objects are passed as input to the “Action” script.

refresh (optional)

- 0** Do not refresh report after action was handled
- 1** Refresh report after action was handled (default)

RETURNS

- 0** On error: cell with given ids does not exist.
- 1** Action was added.

AddColumn

Adds a column to the table.

```
void ComTablereport.AddColumn(str tableId,
                              str columnId,
                              str caption,
                              [int columnWidth,]
                              [int hasAutoFilter,]
                              [int isSortable,]
                              [int isScrollable]
                              )
```

ARGUMENTS

tableId Identifier of the table

columnId Identifier for the column to be inserted

caption Text to be displayed in the column header (lines separated by "\n")

columnWidth (optional)

>0 Initial column width in pixel

-1 Determine column width automatically according to values in the column (default)

hasAutoFilter (optional)

0 No auto filter (default)

1 Display an auto filter in the column header

isSortable (optional)

0 Column is not sortable

1 Column is sortable (default)

isScrollable (optional)

0 Column is fix (all columns left of this column must also be fix)

1 Column is scrollable (default)

EXAMPLE

```
import powerfactory

app = powerfactory.GetApplicationExt()

script = app.GetCurrentScript()
if (script == None):
    raise Exception('Script not found.')

report = script.GetParent()
if (report == None):
    raise Exception('Report not found.')

report.AddTable('table')
report.AddColumn('table', 'scenario', 'Scenario', 100, 1, 1, 0)
```


AddHeader

Adds a header to the report.

```
None ComTablereport.AddHeader(str label,
                               str text
                               )
```

ARGUMENTS

label Label

text Text

AddInvisibleFilter

Adds an invisible filter to the report. This filter can be used for storing objects and/or strings that can then be accessed again at the next refresh of the report.

```
int ComTablereport.AddInvisibleFilter(str id,
                                       str value,
                                       DataObject obj
                                       )
```

ARGUMENTS

id Identifier

value String value to be stored

obj Object to be stored

RETURNS

0 On error: filter with given id already exists.

1 Filter was added to the report.

AddListFilter

Adds a list filter to the report.

```
int ComTablereport.AddListFilter(str id,
                                  str label,
                                  [str captions,]
                                  [list filterObjects,]
                                  [str selEntry,]
                                  [int showObjects]
                                  )
int ComTablereport.AddListFilter(str id,
                                  str label,
                                  int showObjects
                                  )
```

ARGUMENTS

id Identifier

label Label text

captions (optional)
Captions for list entries ("\n"-separated)

filterObjects (optional)

Objects for list entries (default: empty)

selEntry (optional)

Selected list entry (default: empty)

showObjects (optional)

0 Object dialogues are not accessible (default)

1 Object dialogues are accessible

RETURNS

0 On error: filter with given id already exists.

1 Filter was added to the report.

AddListFilterEntries

Adds entries to an existing list filter of the report.

```
int ComTablereport.AddListFilterEntries(str id,
                                       str captions,
                                       [list filterObjects]
                                       )
```

ARGUMENTS

id Identifier

captions Captions for list entries ("\n'-separated)

filterObjects (optional)

Objects for list entries (default: empty)

RETURNS

0 On error: filter with given id does not exist.

1 Entries were added to the filter.

AddMultiListFilter

Adds a multi-selection list filter to the report.

```
int ComTablereport.AddMultiListFilter(str id,
                                       str label,
                                       [str captions,]
                                       [list filterObjects,]
                                       [str selEntries,]
                                       [int showObjects]
                                       )
int ComTablereport.AddMultiListFilter(str id,
                                       str label,
                                       int showObjects
                                       )
```

ARGUMENTS

<i>id</i>	Identifier
<i>label</i>	Label text
<i>captions (optional)</i>	Captions for list entries ('\n'-separated; default: empty)
<i>filterObjects (optional)</i>	Objects for list entries (default: empty)
<i>selEntries (optional)</i>	selected list entries ('\n'-separated; default: empty)
<i>showObjects (optional)</i>	
0	Object dialogues are not accessible (default)
1	Object dialogues are accessible

RETURNS

0	On error: filter with given id already exists.
1	Filter was added to the report.

AddRow

Adds a row to the table.

```
None ComTablereport.AddRow(str tableId,
                           str rowId,
                           [str caption]
                           )
```

ARGUMENTS

<i>tableId</i>	Identifier of the table
<i>rowId</i>	Identifier for the row to be inserted
<i>caption (optional)</i>	Text to be displayed in the row header (only one line, default: empty)

EXAMPLE

```
import powerfactory

app = powerfactory.GetApplicationExt()

script = app.GetCurrentScript()
if (script == None):
    raise Exception('Script not found.')

report = script.GetParent()
if (report == None):
    raise Exception('Report not found.')

report.AddTable('table')
report.AddColumn('table', 'scenario', 'Scenario', 100, 1, 1, 0)
report.AddRow('table', 'peak', 'Peak Load')
```

AddTable

Adds a table to the report. A report can contain only one table or one plot.

```
None ComTablereport.AddTable(str id)
```

ARGUMENTS

id Identifier

EXAMPLE

```
import powerfactory

app = powerfactory.GetApplicationExt()

script = app.GetCurrentScript()
if (script == None):
    raise Exception('Script not found.')

report = script.GetParent()
if (report == None):
    raise Exception('Report not found.')

report.AddTable('table')
```

AddTabularFilter

Adds a tabular filter to the report.

```
int ComTablereport.AddTabularFilter(str id,
                                     str label,
                                     str columnLabels,
                                     str rowLabels,
                                     [str values]
                                     )
```

ARGUMENTS

id Identifier

label Label text for tabular filter

columnLabels

Label texts for table columns (';'-separated; several lines for one column separated by '\n')

rowLabels

Label texts for table rows (';'-separated; only one line per table row)

values (optional)

Values for text fields (';'-separated)

RETURNS

0 On error: filter with given id already exists.

1 Filter was added to the report.

AddTextFilter

Adds a text filter to the report.

```
int ComTablereport.AddTextFilter(str id,
                                str label,
                                [str unit,]
                                [str text]
                                )
```

ARGUMENTS

id Identifier

label Label text

unit (optional)
Unit text (default: empty)

text (optional)
Text for text field (default: empty)

RETURNS

0 On error: filter with given id already exists.

1 Filter was added to the report.

ClearAll

Clears all report data.

```
None ComTablereport.ClearAll()
```

DisableAutomaticRowNumbering

Disables automatic row numbering. Row labels are filled with user-defined row labels. Automatic row numbering is enabled per default.

```
None ComTablereport.DisableAutomaticRowNumbering(str tableId)
```

ARGUMENTS

tableId Identifier of the table

EXAMPLE

```
import powerfactory

app = powerfactory.GetApplicationExt()

script = app.GetCurrentScript()
if (script == None):
    raise Exception('Script not found.')

report = script.GetParent()
if (report == None):
    raise Exception('Report not found.')

report.AddTable('table')
report.DisableAutomaticRowNumbering('table')
```

DisableSingleFilterRefresh

Configures filter section to not refresh report immediatly after a filter value was changed. A refresh button for the whole filter section is displayed instead.

```
None ComTablereport.DisableSingleFilterRefresh()
```

DisplayButtonsCollapsible

Makes button section collapsible and expandable.

```
None ComTablereport.DisplayButtonsCollapsible([int startExpanded])
```

ARGUMENTS

startExpanded (optional)

- 0** Button section is initially collapsed
- 1** Button section is initially expanded (default)

DisplayFiltersCollapsible

Makes filter section collapsible and expandable.

```
None ComTablereport.DisplayFiltersCollapsible([int startExpanded])
```

ARGUMENTS

startExpanded (optional)

- 0** Filter section is initially collapsed.
- 1** Filter section is initially expanded (default).

DisplayFiltersIn2Columns

Displays filters in the filter section of the report in two columns.

```
int ComTablereport.DisplayFiltersIn2Columns(str id)
```

ARGUMENTS

id Identifier of filter to be displayed as first filter in the second column

RETURNS

- 0** On error: filter with given id does not exist.
- 1** Filter was set.

DisplayHeadersCollapsible

Makes header section collapsible and expandable.

```
None ComTablereport.DisplayHeadersCollapsible([int startExpanded])
```

ARGUMENTS

startExpanded (optional)

- 0** Header section is initially collapsed
- 1** Header section is initially expanded (default)

EnableAutomaticRowNumbering

Enables automatic row numbering. Row labels are filled automatically with ascending numbers (starting at 1), user-defined row labels are ignored. Automatic row numbering is enabled per default.

```
None ComTablereport.EnableAutomaticRowNumbering(str tableId)
```

ARGUMENTS

tableId Identifier of the table**ExportToExcel**

Exports the report with its current filter settings and sorting to Excel.

```
None ComTablereport.ExportToExcel([str file, ]
                                   [int show]
                                   )
```

ARGUMENTS

file (optional)

Path and name of file to be written (default: empty = temp. file is written)

show (optional)

- 0** Write only
- 1** Open written file in default application (default)

ExportToHTML

Exports the report with its current filter settings and sorting to HTML.

```
None ComTablereport.ExportToHTML([str file, ]
                                   [int show]
                                   )
```

ARGUMENTS

file (optional)

Path and name of file to be written (default: empty = temp. file is written)

show (optional)

- 0** Write only
- 1** Open written file in default application (default)

FindNextCell

Searches for the next table cell with the given value and sets the selection to that cell. Searches row-wise from the current position on until the table end and then from the top until the current cell is reached again considering filters and sorting.

```
int ComTablereport.FindNextCell(str tableId,  
                                str cellValue  
                                )
```

ARGUMENTS

tableId Identifier of the table
cellValue Display text of cell to be searched

RETURNS

0 On error: no matching cell found.
1 On success.

FindNextRow

Searches for the next row with the given values and sets the selection to that row. Searches from the current position on until the table end and then from the top until the current row is reached again considering filters and sorting.

```
int ComTablereport.FindNextRow(str tableId,  
                                str columnId1,  
                                str cellValue1,  
                                [str columnId2,]  
                                [str cellValue2,]  
                                [str columnId3,]  
                                [str cellValue3]  
                                )
```

ARGUMENTS

tableId Identifier of the table
columnId1 Column identifier of cell for first criterion to be searched
cellValue1 Display text of cell for first criterion to be searched
columnId2 Column identifier of cell for second criterion to be searched
cellValue2 Display text of cell for second criterion to be searched
columnId3 Column identifier of cell for third criterion to be searched
cellValue3 Display text of cell for third criterion to be searched

RETURNS

- 0** On error: no matching row found.
- 1** On success.

FindPreviousCell

Searches for previous table cell with the given value and sets the selection to that cell. Searches row-wise from the current position on until table begin and then from the end until the current cell is reached again considering filters and sorting.

```
int ComTablereport.FindPreviousCell(str tableId,
                                   str cellValue
                                   )
```

ARGUMENTS

- tableId* Identifier of the table
- cellValue* Display text of cell to be searched

RETURNS

- 0** On error: no matching cell found.
- 1** On success.

FindPreviousRow

Searches for the previous row with the given values and sets the selection to that row. Searches from the current position on until the table begin and then from the end until the current row is reached again considering filters and sorting.

```
int ComTablereport.FindPreviousRow(str tableId,
                                   str columnId1,
                                   str cellValue1,
                                   [str columnId2,]
                                   [str cellValue2,]
                                   [str columnId3,]
                                   [str cellValue3]
                                   )
```

ARGUMENTS

- tableId* Identifier of the table
- columnId1* Column identifier of cell for first criterion to be searched
- cellValue1* Display text of cell for first criterion to be searched
- columnId2* Column identifier of cell for second criterion to be searched
- cellValue2* Display text of cell for second criterion to be searched
- columnId3* Column identifier of cell for third criterion to be searched
- cellValue3* Display text of cell for third criterion to be searched

RETURNS

- 0** On error: no matching row found.
- 1** On success.

GetCellAccessObject

Gets the object accessible from a table cell.

```
[ int,  
DataObject ] ComTablereport.GetCellAccessObject(str tableId,  
                                                str columnId,  
                                                str rowId  
                                                )
```

ARGUMENTS

- tableId* Identifier of the table
- columnId* Identifier of the column
- rowId* Identifier of the row
- obj (out)* Object accessible from the cell if set, else None

RETURNS

- 0** On error: cell with given ids does not exist.
- 1** On success.

GetCellAlignment

Gets the alignment of a cell.

```
[ int,  
int ] ComTablereport.GetCellAlignment(str tableId,  
                                       str columnId,  
                                       str rowId  
                                       )
```

ARGUMENTS

- tableId* Identifier of the table
- columnId* Identifier of the column
- rowId* Identifier of the row
- value (out)*
Alignment of the cell

RETURNS

- 0** On error: cell with given ids does not exist.
- 1** On success.

GetCellBackgroundColor

Gets the value type of a cell.

```
[ int,  
int ] ComTablereport.GetCellBackgroundColor(str tableId,  
                                           str columnId,  
                                           str rowId  
                                           )
```

ARGUMENTS

tableId Identifier of the table
columnId Identifier of the column
rowId Identifier of the row
value (out) Background color of the cell

RETURNS

0 On error: cell with given ids does not exist.
1 On success.

GetCellColor

Gets the value type of a cell.

```
[ int,  
int ] ComTablereport.GetCellColor(str tableId,  
                                  str columnId,  
                                  str rowId  
                                  )
```

ARGUMENTS

tableId Identifier of the table
columnId Identifier of the column
rowId Identifier of the row
value (out) Color of the cell

RETURNS

0 On error: cell with given ids does not exist.
1 On success.

GetCellEditObjects

Gets the objects linked to a table cell for editing the cell.

```
[ int,  
list ] ComTablereport.GetCellEditObjects(str tableId,  
                                          str columnId,  
                                          str rowId  
                                          )
```

ARGUMENTS

- tableId* Identifier of the table
- columnId* Identifier of the column
- rowId* Identifier of the row
- objs (out)* Edit objects of the cell if any, else empty

RETURNS

- 0** On error: cell with given ids does not exist.
- 1** On success.

GetCellStyle

Gets the font style of a cell.

```
[ int,
int ] ComTablereport.GetCellStyle(str tableId,
                                   str columnId,
                                   str rowId
                                   )
```

ARGUMENTS

- tableId* Identifier of the table
- columnId* Identifier of the column
- rowId* Identifier of the row
- value (out)* Font style of the cell:

- | | |
|----------|-----------------------------|
| 0 | Normal (default) |
| 1 | Bold |
| 2 | Italic |
| 3 | Bold and italic |
| 4 | Underlined |
| 5 | Underlined and bold |
| 6 | Underlined and italic |
| 7 | Underlined, bold and italic |

RETURNS

- 0** On error: cell with given ids does not exist.
- 1** On success.

GetCellFormat

Gets the format of a cell.

```
[ int,
str ] ComTablereport.GetCellFormat(str tableId,
                                    str columnId,
                                    str rowId
                                    )
```

ARGUMENTS

tableId Identifier of the table
columnId Identifier of the column
rowId Identifier of the row
value (out)
Format of the cell

RETURNS

0 On error: cell with given ids does not exist.
1 On success.

GetCellHelpText

Gets the help text of a cell.

```
[ int,  
str ] ComTablereport.GetCellHelpText(str tableId,  
                                     str columnId,  
                                     str rowId  
                                     )
```

ARGUMENTS

tableId Identifier of the table
columnId Identifier of the column
rowId Identifier of the row
value (out)
Help text of the cell

RETURNS

0 On error: cell with given ids does not exist.
1 On success.

GetCellValueType

Gets the value type of a cell.

```
int ComTablereport.GetCellValueType(str tableId,  
                                     str columnId,  
                                     str rowId  
                                     )
```

ARGUMENTS

tableId Identifier of the table
columnId Identifier of the column
rowId Identifier of the row

RETURNS

- 0** Error: cell with given ids does not exist
- 1** String
- 2** Integer
- 3** Double
- 4** Check box
- 5** Bar
- 6** Date
- 7** Object

GetCheckboxCellValue

Gets the value of a check box cell.

```
[ int,  
int ] ComTablereport.GetCheckboxCellValue(str tableId,  
                                           str columnId,  
                                           str rowId  
                                           )
```

ARGUMENTS

- tableId* Identifier of the table
- columnId* Identifier of the column
- rowId* Identifier of the row
- value (out)* Value of the cell

RETURNS

- 0** On error: cell with given ids does not exist or has the wrong type.
- 1** On success.

GetColumnFilter

Get filter text of given column in table.

```
[ int,  
str ] ComTablereport.GetColumnFilter(str tableId,  
                                      str columnId  
                                      )
```

ARGUMENTS

- tableId* Identifier of the table
- columnId* Identifier of the column to be set
- filter (out)* Text that represents the filter of the column

RETURNS

- 0** Column was found.
- 1** Column not found.

GetColumnHeader

Gets caption text of existing column of the table.

```
[ int,
str ] ComTablereport.GetColumnHeader(str tableId,
                                     str columnId
                                     )
```

ARGUMENTS

- tableId* Identifier of the table
- columnId* Identifier of the column
- caption (out)* Text that is displayed in the column header (lines separated by '\n')

RETURNS

- 0** On success.
- 1** On error: column with given ids does not exist.

EXAMPLE

```
import powerfactory

app = powerfactory.GetApplicationExt()

script = app.GetCurrentScript()
if (script == None):
    raise Exception('Script not found.')

report = script.GetParent()
if (report == None):
    raise Exception('Report not found.')

report.AddTable('table')
report.AddColumn('table', 'scenario', '', 100, 1, 1, 0)
report.SetColumnHeader('table', 'scenario', 'Scenario')
header = report.GetColumnHeader('table', 'scenario')[1]
```

GetColumnId

Get the unique identifier of the n-th column.

```
[ int,
str ] ComTablereport.GetColumnId(str tableId,
                                 int columnIndex
                                 )
```

ARGUMENTS

- tableId* Identifier of the table
- columnIndex*
Index of the column - 0 based
- columnId (out)*
Column identifier at the given index

RETURNS

- 0** On success.
- 1** On error: No column with the given index was found.

GetDateCellValue

Gets the value of a date cell.

```
[ int,  
int ] ComTablereport.GetDateCellValue(str tableId,  
                                     str columnId,  
                                     str rowId  
                                     )
```

ARGUMENTS

- tableId* Identifier of the table
- columnId* Identifier of the column
- rowId* Identifier of the row
- value (out)*
Value of the cell

RETURNS

- 0** On error: cell with given ids does not exist or has the wrong type.
- 1** On success.

GetDoubleCellValue

Gets the value of a double cell.

```
[ int,  
float ] ComTablereport.GetDoubleCellValue(str tableId,  
                                          str columnId,  
                                          str rowId  
                                          )
```

ARGUMENTS

- tableId* Identifier of the table
- columnId* Identifier of the column
- rowId* Identifier of the row
- value (out)*
Value of the cell

RETURNS

- 0** On error: cell with given ids does not exist or has the wrong type.
- 1** On success.

GetIntCellValue

Gets the value of an integer cell.

```
[ int,  
int ] ComTablereport.GetIntCellValue(str tableId,  
                                     str columnId,  
                                     str rowId  
                                     )
```

ARGUMENTS

- tableId* Identifier of the table
- columnId* Identifier of the column
- rowId* Identifier of the row
- value (out)*
Value of the cell

RETURNS

- 0** Error: cell with given ids does not exist or has the wrong type
- 1** Ok

GetNumberOfColumns

Returns the number of columns that were added to the tabular report.

```
int ComTablereport.GetNumberOfColumns(str tableId)
```

ARGUMENTS

- tableId* Identifier of the table

RETURNS

- >=0** On success: the number of columns in the table.
- 1** On error: no table with the given ID was defined.

GetNumberOfRows

Returns the number of rows that were added to the tabular report.

```
int ComTablereport.GetNumberOfRows(str tableId)
```

ARGUMENTS

- tableId* Identifier of the table

RETURNS

- >=0** On success: the number of rows in the table.
- 1** On error: no table with the given ID was defined.

GetNumberOfSelectedCells

Gets the number of (visible) cells selected in the table.

```
int ComTablereport.GetNumberOfSelectedCells(str tableId,
                                           [str columnId,]
                                           [str rowId]
                                           )
```

ARGUMENTS

- tableId* Identifier of the table
- columnId (optional)*
 - set** Count only selected cells with this column id
 - empty** Count selected cells in all columns (default)
- rowId (optional)*
 - set** Count only selected cells with this row id
 - empty** Count selected cells in all rows (default)

RETURNS

Number of selected cells

GetObjectCellValue

Gets the value of an object cell.

```
[ int,
DataObject ] ComTablereport.GetObjectCellValue(str tableId,
                                                str columnId,
                                                str rowId
                                                )
```

ARGUMENTS

- tableId* Identifier of the table
- columnId* Identifier of the column
- rowId* Identifier of the row
- value (out)* Value of the cell

RETURNS

- 0** On error: cell with given ids does not exist or has the wrong type.
- 1** On success.

GetRowCaption

Gets caption text of existing row of the table.

```
[ int,  
str ] ComTablereport.GetRowCaption(str tableId,  
                                   str rowId  
                                   )
```

ARGUMENTS

tableId Identifier of the table
rowId Identifier of the row
caption (out)
 Text that is displayed in the row caption

RETURNS

0 On success.
1 On error: row with given ids does not exist.

GetRowId

Get the unique identifier of the n-th row.

```
[ int,  
str ] ComTablereport.GetRowId(str tableId,  
                              int rowIndex  
                              )
```

ARGUMENTS

tableId Identifier of the table
rowIndex Index of the row - 0 based
rowId (out)
 Row identifier at the given index

RETURNS

0 On success.
1 On error: No row with the given index was found.

GetSelectedCell

Gets the identifiers for a selected cell.

```
[ int sucess,  
str columnId,  
str rowId ] ComTablereport.GetSelectedCell(string tableId,  
                                             int index,  
                                             [str columnIdFilter = "",]  
                                             [str rowIdFilter = ""]  
                                             )
```

ARGUMENTS

- tableId* Identifier of the table
- index* Index of selected cell (1-based)
- columnIdFilter (optional)*
Consider only selected cells with this column id (empty: no filter; default)
- rowIdFilter (optional)*
Consider only selected cells with this row id (empty: no filter; default)
- columnId (out)*
Column id of selected cell
- rowId (out)*
Row id of selected cell

RETURNS

- 0** On error: cell with given ids does not exist.
- 1** On success.

GetSelectedElements

Gets objects selected for the report filtered according to filter in the report.

```
list ComTablereport.GetSelectedElements()
```

RETURNS

Filtered selected objects

GetSelection

Gets SetSelect with selected objects for the report.

```
DataObject ComTablereport.GetSelection()
```

RETURNS

SetSelect or None.

GetStringCellValue

Gets the value of a string cell.

```
[ int,
str ] ComTablereport.GetStringCellValue(str tableId,
                                         str columnId,
                                         str rowId
                                         )
```

ARGUMENTS

- tableId* Identifier of the table
- columnId* Identifier of the column

rowId Identifier of the row
value (out) Value of the cell

RETURNS

0 On error: cell with given ids does not exist or has the wrong type.
1 On success.

GoToCell

Sets the selection to a table cell.

```
int ComTablereport.GoToCell(str tableId,
                           str columnId,
                           str rowId
                           )
```

ARGUMENTS

tableId Identifier of the table
columnId Column identifier of the cell to be selected
rowId Row identifier of the cell to be selected

RETURNS

0 On error: cell with given ids does not exist.
1 On success.

HasCell

Checks if a table cell exists.

```
int ComTablereport.HasCell(str tableId,
                           str columnId,
                           str rowId
                           )
```

ARGUMENTS

tableId Identifier of the table
columnId Identifier of the column
rowId Identifier of the row

RETURNS

0 Cell with given ids does not exist.
1 Cell was found.

HasColumnAutoFilter

Checks if the column has an enabled auto filter.

```
int ComTablereport.HasColumnAutoFilter(str tableId,
                                       str columnId
                                       )
```

ARGUMENTS

tableId Identifier of the table
columnId Identifier of the column

RETURNS

-1 The column is not defined.
0 The column has no auto filter.
1 The column has an auto filter.

IsColumnScrollable

Checks if the column is marked as scrollable.

```
int ComTablereport.IsColumnScrollable(str tableId,  
                                      str columnId  
                                      )
```

ARGUMENTS

tableId Identifier of the table
columnId Identifier of the column

RETURNS

-1 The column is not defined.
0 The column is not scrollable.
1 The column is scrollable.

IsColumnSortable

Checks if the column is marked as sortable.

```
int ComTablereport.IsColumnSortable(str tableId,  
                                     str columnId  
                                     )
```

ARGUMENTS

tableId Identifier of the table
columnId Identifier of the column

RETURNS

-1 The column is not defined.
0 The column is not sortable.
1 The column is sortable.

IsRowVisible

Checks if the row with the given ID is visible for the user. The result depends on the filter settings of the report.

```
int ComTablereport.IsRowVisible(str tableId,  
                                str rowId  
                                )
```

ARGUMENTS

tableId Identifier of the table
rowId Identifier of the row

RETURNS

-1 The row is not defined.
0 The row is invisible.
1 The row is visible.

RemoveRow

Removes a row from the table.

```
int ComTablereport.RemoveRow(str tableId,  
                              str rowId  
                              )
```

ARGUMENTS

tableId Identifier of the table
rowId Identifier of the row to be removed

RETURNS

0 Row with given id does not exist.
1 Row was removed.

EXAMPLE

```
import powerfactory  
  
app = powerfactory.GetApplicationExt()  
  
script = app.GetCurrentScript()  
if (script == None):  
    raise Exception('Script not found.')  
  
report = script.GetParent()  
if (report == None):  
    raise Exception('Report not found.')  
  
report.AddTable('table')  
report.AddColumn('table', 'scenario', 'Scenario', 100, 1, 1, 0)  
report.AddRow('table', 'peak', 'Peak Load')  
report.RemoveRow('table', 'peak')
```

SetBarLimits

Sets bar limits for all bar cells in an existing table column.

```
int ComTablereport.SetBarLimits(str tableId,
                                str columnId,
                                int min,
                                int max
                                )
```

ARGUMENTS

tableId Identifier of the table
columnId Identifier of the column
min Minimum value for all bars in the column
max Maximum value for all bars in the column

RETURNS

0 On error: column with given ids does not exist.
1 Limits were set.

SetCellAccess

Makes a cell accessible. Accessible means that an object dialogue is displayed on double click and the right mouse button menu additionally provides the entries 'Edit', 'Edit and Browse' and 'Mark in Graphic'.

```
None ComTablereport.SetCellAccess(str tableId,
                                    str columnId,
                                    str rowId,
                                    DataObject accessObject,
                                    [str parameterName]
                                    )
```

ARGUMENTS

tableId Identifier of the table
columnId Identifier of the column
rowId Identifier of the row
accessObject Object to be accessible
parameterName (optional)
Set Dialog is shown at the page on that this variable is displayed
Empty Dialog is shown at stored dialog page (default)

SetCellAlignment

Sets the alignment of a table cell.

```
None ComTablereport.SetCellAlignment(str tableId,
                                       str columnId,
                                       str rowId,
                                       int align
                                       )
```


ARGUMENTS

<i>tableId</i>	Identifier of the table
<i>columnId</i>	Identifier of the column
<i>rowId</i>	Identifier of the row
<i>align (optional)</i>	Alignment for text:
0	Automatically according to data type (default)
1	Left
2	Center
3	Right

SetCellBackgroundColor

Fills a table cell with a string value.

```
None ComTablereport.SetCellBackgroundColor(str tableId,
                                           str columnId,
                                           str rowId,
                                           int backgroundColor
                                           )
```

ARGUMENTS

<i>tableId</i>	Identifier of the table
<i>columnId</i>	Identifier of the column
<i>rowId</i>	Identifier of the row
<i>backgroundColor</i>	Color for background

SetCellColor

Sets the text color of a table cell.

```
None ComTablereport.SetCellColor(str tableId,
                                  str columnId,
                                  str rowId,
                                  int color
                                  )
```

ARGUMENTS

<i>tableId</i>	Identifier of the table
<i>columnId</i>	Identifier of the column
<i>rowId</i>	Identifier of the row
<i>color</i>	Color for text

SetCellEdit

Makes a table cell editable. This means that the cell value can be modified in the report window.

```
None ComTablereport.SetCellEdit(str tableId,
                                str columnId,
                                str rowId,
                                list editObjects,
                                [str selectableValues])
```

ARGUMENTS

tableId Identifier of the table

columnId Identifier of the column

rowId Identifier of the row

editObjects

Objects to handle the modification. These objects are passed as input to the “Edit” script.

selectableValues

“\n”-separated list of selectable values:

Set A list dialogue with the given values is displayed for selection if the cell is edited

Empty Any text can be entered into the cell (default)

SetCellFontStyle

Sets the font style of a table cell.

```
None ComTablereport.SetCellFontStyle(str tableId,
                                       str columnId,
                                       str rowId,
                                       int fontStyle
                                       )
```

ARGUMENTS

tableId Identifier of the table

columnId Identifier of the column

rowId Identifier of the row

fontStyle

0	Normal
1	Bold
2	Italic
3	Bold and italic
4	Underlined
5	Underlined and bold
6	Underlined and italic
7	Underlined, bold and italic

SetCellFormat

Sets the format used for displaying the value of a table cell.

```
None ComTablereport.SetCellFormat(str tableId,
                                   str columnId,
                                   str rowId,
                                   str format
                                   )
```

ARGUMENTS

tableId Identifier of the table

columnId Identifier of the column

rowId Identifier of the row

format Printf-like format for displaying the value

SetCellStyle

Sets the style of a table cell.

```
None ComTablereport.SetCellStyle(str tableId,
                                  str columnId,
                                  str rowId,
                                  str format,
                                  int color,
                                  int fontStyle,
                                  int align,
                                  int backgroundColor
                                  )
```

ARGUMENTS

tableId Identifier of the table

columnId Identifier of the column

rowId Identifier of the row

format Printf-like format for displaying the value (default: ")

color Color for text

fontStyle

0	Normal
1	Bold
2	Italic
3	Bold and italic
4	Underlined
5	Underlined and bold
6	Underlined and italic
7	Underlined, bold and italic

align Alignment for text:

0	Automatically according to data type
----------	--------------------------------------

- 1** Left
- 2** Center
- 3** Right

backgroundColor
Color for background

SetCellValueToBar

Fills a table cell with a bar.

```
None ComTablereport.SetCellValueToBar(str tableId,
                                       str columnId,
                                       str rowId,
                                       str barDesc,
                                       [str helpText,]
                                       [int border,]
                                       [int align,]
                                       [int backgroundColor]
                                       )
```

ARGUMENTS

tableId Identifier of the table

columnId Identifier of the column

rowId Identifier of the row

barDesc Bar description containing limits and segment widths and colours. If limits are given the left cell side is considered to be the lower limit value and the right cell side is considered to be the upper limit value. If no limits are given the limits are implicitly set to 0 and 100. The available formats are listed below.

helpText (optional)
Text shown in balloon help of the cell (multiple lines separated by '\n'; default: empty)

border (optional)
Display a thin black border around the bar:

- 0** No border
- 1** Border (default)

align (optional)
Alignment for text:

- 0** Automatically according to data type (default)
- 1** Left
- 2** Center
- 3** Right

backgroundColor (optional)
Color for background (default: 0=white)

BAR DESCRIPTION FORMATS

<width>,<colour>;<width>,<colour>;<...>

Relative widths in % (old style; e.g. "20,1;14,2;36,3;30,4")

<lower limit>;<upper limit>#<width>,<colour>;<width>,<colour>;<...>

Relative widths in %, limits are ignored (old style; e.g. "90;140#10,1;7,2;18,3;15,4")

0#<width>,<colour>;<width>,<colour>;<...>

Relative widths in % (e.g. "0#20,1;14,2;36,3;30,4")

0#<lower limit>;<upper limit>#<width>,<colour>;<width>,<colour>;<...>

Relative widths within limits (e.g. "0#90;140#10,1;7,2;18,3;15,4")

1#<value>,<colour>;<value>,<colour>;<...>

Absolute values in % (e.g. "1#20,1;34,2;70,3;100,4")

1#<lower limit>;<upper limit>#<value>,<colour>;<value>,<colour>;<...>

Absolute values within limits (e.g. "1#90;140#100,1;107,2;125,3;140,4")

SetCellValueToCheckbox

Fills a table cell with a check box.

```
None ComTablereport.SetCellValueToCheckbox(str tableId,
                                           str columnId,
                                           str rowId,
                                           int value,
                                           [str helpText,]
                                           [int align,]
                                           [int backgroundColor]
                                           )
```

ARGUMENTS

tableId Identifier of the table

columnId Identifier of the column

rowId Identifier of the row

value Integer value to be set in the checkbox:

0 Check box is unchecked

1 Check box is checked

helpText (optional)

Text shown in balloon help of the cell (multiple lines separated by '\n'; default: empty)

align (optional)

Alignment for text:

0 Automatically according to data type (default)

1 Left

2 Center

3 Right

backgroundColor (optional)

Color for background (default: 0=white)

SetCellValueToDate

Fills a table cell with a date.

```
None ComTablereport.SetCellValueToDate(str tableId,
                                         str columnId,
                                         str rowId,
                                         int timeStamp,
                                         [str format,]
                                         [str helpText,]
                                         [int color,]
                                         [int fontStyle,]
                                         [int align,]
                                         [int backgroundColor]
                                         )
```

ARGUMENTS

tableId Identifier of the table

columnId Identifier of the column

rowId Identifier of the row

timeStamp
Time stamp value for date and time

format (optional)
Format for displaying date (currently ignored; default: "")

helpText (optional)
Text shown in balloon help of the cell (multiple lines separated by '\n'; default: empty)

color (optional)
Colour for text (default: 1=black)

fontStyle (optional)

0	Normal (default)
1	Bold
2	Italic
3	Bold and italic
4	Underlined
5	Underlined and bold
6	Underlined and italic
7	Underlined, bold and italic

align (optional)
Alignment for text:

0	Automatically according to data type (default)
1	Left
2	Center
3	Right

backgroundColor (optional)
Color for background (default: 0=white)

SetCellValueToDouble

Fills a table cell with a double value.

```
None ComTablereport.SetCellValueToDouble(str tableId,
                                          str columnId,
                                          str rowId,
                                          double value,
                                          [str format,]
                                          [str helpText,]
                                          [int color,]
                                          [int fontStyle,]
                                          [int align,]
                                          [int backgroundColor]
                                          )
```

ARGUMENTS

tableId Identifier of the table

columnId Identifier of the column

rowId Identifier of the row

value Double value to be set

format (optional)
Printf-like format for displaying the value (default: '%f')

helpText (optional)
Text shown in balloon help of the cell (multiple lines separated by '\n'; default: empty)

color (optional)
Color for text (default: 1=black)

fontStyle(optional)

0	Normal (default)
1	Bold
2	Italic
3	Bold and italic
4	Underlined
5	Underlined and bold
6	Underlined and italic
7	Underlined, bold and italic

align (optional)
Alignment for text:

0	Automatically according to data type (default)
1	Left
2	Center
3	Right

backgroundColor (optional)
Color for background (default: 0=white)

SetCellValueToInt

Fills a table cell with an integer value.

```
None ComTablereport.SetCellValueToInt (str tableId,
                                         str columnId,
                                         str rowId,
                                         int value,
                                         [str format,]
                                         [str helpText,]
                                         [int color,]
                                         [int fontStyle,]
                                         [int align,]
                                         [int backgroundColor]
                                         )
```

ARGUMENTS

tableId Identifier of the table

columnId Identifier of the column

rowId Identifier of the row

value Integer value to be set

format (optional)
Printf-like format for displaying the value (default: '%d')

helpText (optional)
Text shown in balloon help of the cell (multiple lines separated by '\n'; default: empty)

color (optional)
Color for text (default: 1=black)

fontStyle (optional)

0	Normal (default)
1	Bold
2	Italic
3	Bold and italic
4	Underlined
5	Underlined and bold
6	Underlined and italic
7	Underlined, bold and italic

align (optional)
Alignment for text:

0	Automatically according to data type (default)
1	Left
2	Center
3	Right

backgroundColor (optional)
Color for background (default: 0=white)

SetCellValueToObject

Fills a table cell with an object.

```
None ComTablereport.SetCellValueToObject (str tableId,
                                          str columnId,
                                          str rowId,
                                          object obj,
                                          [str format,]
                                          [str helpText,]
                                          [int color,]
                                          [int fontStyle,]
                                          [int align,]
                                          [int backgroundColor]
                                          )
```

ARGUMENTS

tableId Identifier of the table

columnId Identifier of the column

rowId Identifier of the row

obj Object to be set

format (optional)

Format for displaying object (currently ignored; default: "")

helpText (optional)

Text shown in balloon help of the cell (multiple lines separated by '\n'; default: empty)

color (optional)

Colour for text (default: 1=black)

fontStyle(optional)

- | | |
|----------|-----------------------------|
| 0 | Normal (default) |
| 1 | Bold |
| 2 | Italic |
| 3 | Bold and italic |
| 4 | Underlined |
| 5 | Underlined and bold |
| 6 | Underlined and italic |
| 7 | Underlined, bold and italic |

align (optional)

Alignment for text:

- | | |
|----------|--|
| 0 | Automatically according to data type (default) |
| 1 | Left |
| 2 | Center |
| 3 | Right |

backgroundColor (optional)

Color for background (default: 0=white)

SetCellValueToString

Fills a table cell with a string value.

```
None ComTablereport.SetCellValueToString(str tableId,
                                         str columnId,
                                         str rowId,
                                         str value,
                                         [str format,]
                                         [str helpText,]
                                         [int color,]
                                         [int fontStyle,]
                                         [int align,]
                                         [int backgroundColor]
                                         )
```

ARGUMENTS

tableId Identifier of the table

columnId Identifier of the column

rowId Identifier of the row

value String value to be set

format (optional)
Printf-like format for displaying the value (default: '%s')

helpText (optional)
Text shown in balloon help of the cell (multiple lines separated by '\n'; default: empty)

color (optional)
Color for text (default: 1=black)

fontStyle (optional)

0	Normal (default)
1	Bold
2	Italic
3	Bold and italic
4	Underlined
5	Underlined and bold
6	Underlined and italic
7	Underlined, bold and italic

align (optional)
Alignment for text:

0	Automatically according to data type (default)
1	Left
2	Center
3	Right

backgroundColor (optional)
Color for background (default: 0=white)

EXAMPLE

```

import powerfactory

app = powerfactory.GetApplicationExt()

script = app.GetCurrentScript()
if (script == None):
    raise Exception('Script not found.')

report = script.GetParent()
if (report == None):
    raise Exception('Report not found.')

report.AddTable('table')
report.AddColumn('table', 'scenario', 'Scenario', 100, 1, 1, 0)
report.AddRow('table', 'active', 'Active')

scenario = app.GetActiveScenario()
name = scenario.GetAttribute('loc_name')
report.SetCellValueToString('table', 'scenario', 'active', name)

```

SetColumnHeader

Sets caption text in existing column of the table.

```

None ComTableReport.SetColumnHeader(str tableId,
                                     str columnId,
                                     str caption
                                     )

```

ARGUMENTS

tableId Identifier of the table

columnId Identifier of the column to be set

captionId Text to be displayed in the column header (lines separated by '\n')

EXAMPLE

```

import powerfactory

app = powerfactory.GetApplicationExt()

script = app.GetCurrentScript()
if (script == None):
    raise Exception('Script not found.')

report = script.GetParent()
if (report == None):
    raise Exception('Report not found.')

report.AddTable('table')
report.AddColumn('table', 'scenario', '', 100, 1, 1, 0)
report.SetColumnHeader('table', 'scenario', 'Scenario')

```

SetDialogSize

Sets the width and height for the report dialog.

```
None ComTablereport.SetDialogSize(int width,  
                                   int height  
                                   )
```

ARGUMENTS

width Dialogue width in pixel
height Dialogue height in pixel

EXAMPLE

```
import powerfactory  
  
app = powerfactory.GetApplicationExt()  
  
script = app.GetCurrentScript()  
if (script == None):  
    raise Exception('Script not found.')  
  
report = script.GetParent()  
if (report == None):  
    raise Exception('Report not found.')  
  
report.SetDialogSize(700, 860);
```

SetExportHtml

Shows or hides html icon

```
None ComTablereport.SetExportHtml(int show)
```

ARGUMENTS

show

0	Hide html icon
1	Show html icon

SetExportXls

Shows or hides xlsx icon

```
None ComTablereport.SetExportXls(int show)
```

ARGUMENTS

show

0	Hide xlsx icon
1	Show xlsx icon

SetListFilterSelection

Sets selected entries in existing list filter.

```
int ComTablereport.SetListFilterSelection(str id,
                                         str selEntries
                                         )
```

ARGUMENTS

id Identifier

selEntries (optional)
Selected list entries ('\n'-separated; default: empty)

RETURNS

0 On error: filter with given id does not exist.

1 Entries were set as selected filter entries.

SetRefresh

Shows or hides refresh icon

```
None ComTablereport.SetRefresh(int show)
```

ARGUMENTS

show

0 Hide refresh icon

1 Show refresh icon

SetSorting

Sets initial sorting of table.

```
int ComTablereport.SetSorting(str tableId,
                              str columnId,
                              [int descending]
                              )
```

ARGUMENTS

tableId Identifier of the table

columnId Identifier of the column according to that is to be sorted

descending (optional)

0 Ascending order (default)

1 Descending order

RETURNS

0 On error.

1 Sorting set.

SetStatusText

Sets a text in the user-definable field of the report window's status bar.

```
None ComTablereport.SetStatusText(str tableId,  
                                   str text  
                                   )
```

ARGUMENTS

<i>tableId</i>	Identifier of the table
<i>text</i>	Text to be set

SetTitle

Sets the text in the title bar of the report window.

```
None ComTablereport.SetTitle(str title)
```

ARGUMENTS

<i>title</i>	Title text
--------------	------------

EXAMPLE

```
import powerfactory  
  
app = powerfactory.GetApplicationExt()  
  
script = app.GetCurrentScript()  
if (script == None):  
    raise Exception('Script not found.')  
  
report = script.GetParent()  
if (report == None):  
    raise Exception('Report not found.')  
  
report.SetTitle('Input Data Summary')
```

5.4.54 ComTasks

Overview

- [AppendCommand](#)
- [AppendStudyCase](#)
- [GetCommandsForStudyCase](#)
- [GetNumberOfCommandsForStudyCase](#)
- [GetNumberOfStudyCases](#)
- [GetStudyCases](#)
- [IsAdditionalResultsFlagSetForCommand](#)
- [IsCommandIgnored](#)
- [IsStudyCaseIgnored](#)
- [RemoveCmdsForStudyCaseRow](#)
- [RemoveCommand](#)

[RemoveStudyCase](#)
[RemoveStudyCases](#)
[SetAdditionalResultsFlagForCommand](#)
[SetIgnoreFlagForCommand](#)
[SetIgnoreFlagForStudyCase](#)
[SetResultsFolder](#)

AppendCommand

Appends a command for calculation.

```
int ComTasks.AppendCommand(DataObject command,
                           [int studyCaseRow]
                           )
```

RETURNS

- 0** Command could not be added for calculation.
- 1** Command has been successfully added for calculation.

ARGUMENTS

command

Command to add for calculation.

studyCaseRow

- ≤ 0 Command is added to the list of commands for its study case.
- > 0 Optionally, the row in the study case table containing the study case for which this command shall be added can be passed. This is helpful, e.g., if a study case has been added multiple times for calculation with different command lists.

AppendStudyCase

Appends a study case to the list of study cases for calculation.

```
int ComTasks.AppendStudyCase(DataObject studyCase)
```

RETURNS

- 0** Study case could not be added for calculation.
- 1** Study case has been successfully added for calculation.

ARGUMENTS

studyCase

Study case to add for calculation.

GetCommandsForStudyCase

Get all selected commands to be processed for a study case from the Task Automation command.

```
list ComTasks.GetCommandsForStudyCase(DataObject studyCase,
                                       [int studyCaseRow])
```

RETURNS

Returns ordered set of all selected commands to be processed for a study case.

ARGUMENTS

studyCase

Study case to get all selected commands to be processed from.

studyCaseRow

- ≤ 0 Commands for the first matching study case found will be returned.
- > 0 Optionally, the row in the study case table containing the study case for which commands shall be returned can be passed. This is helpful, e.g., if a study case has been added multiple times for calculation with different command lists.

GetNumberOfCommandsForStudyCase

Get number of all selected commands to be processed for a study case from the Task Automation command.

```
int ComTasks.GetNumberOfCommandsForStudyCase(DataObject studyCase,
                                             [int studyCaseRow])
```

RETURNS

Returns number of all selected commands to be processed for a study case.

ARGUMENTS

studyCase

Study case to get number of selected commands to be processed from.

studyCaseRow

- ≤ 0 Number of commands for the first matching study case found will be returned.
- > 0 Optionally, the row in the study case table containing the study case for which number of commands shall be returned can be passed. This is helpful, e.g., if a study case has been added multiple times for calculation with different command lists.

GetNumberOfStudyCases

Get number of selected study cases from the Task Automation command.

```
int ComTasks.GetNumberOfStudyCases()
```

RETURNS

Returns number of selected study cases from the Task Automation command.

GetStudyCases

Get all selected study cases from the Task Automation command.

```
list ComTasks.GetStudyCases()
```


RETURNS

Returns ordered set of all selected study cases from the Task Automation command, set is empty on failure.

IsAdditionalResultsFlagSetForCommand

Returns whether additional results flag of a command is set or not (using study case row and task row / using a command directly).

```
int ComTasks.IsAdditionalResultsFlagSetForCommand(int studyCaseRow,
                                                  int taskRow)
int ComTasks.IsAdditionalResultsFlagSetForCommand(DataObject command)
```

ARGUMENTS

studyCaseRow ≤ 0

The row in the study cases table of the command's study case for which the additional results flag shall be derived.

taskRow > 0

The row in the commands table for which the additional results flag shall be derived.

command

The command to get the additional results flag for.

RETURNS

0 Additional results flag of command is not set.

1 Additional results flag of command is set.

-1 Additional results flag was not found for provided study case row and task row / provided command.

IsCommandIgnored

Returns whether the processing of a command will be ignored or not (using study case row and task row / using provided command).

```
int ComTasks.IsCommandIgnored(int studyCaseRow,
                              int taskRow)
int ComTasks.IsCommandIgnored(DataObject command)
```

ARGUMENTS

studyCaseRow ≤ 0

The row in the study cases table of the command's study case for which the ignore flag shall be derived.

taskRow > 0

The row in the commands table for which the ignore flag shall be derived.

command

The command to get the ignore-flag for.

RETURNS

- 0** Processing of command will be done.
- 1** Processing of command will be ignored.
- 1** Command was not found (for provided study case row and task row / at all).

IsStudyCaseIgnored

Returns whether the command processing for a study case will be ignored or not.

```
int ComTasks.IsStudyCaseIgnored(DataObject studyCase,
                                [int studyCaseRow])
```

RETURNS

- 0** Command processing for study case will be done.
- 1** Command processing for study case will be ignored.
- 1** study case or row was not found.

ARGUMENTS

studyCase

Study case to get ignore-flag from.

studyCaseRow

- ≤ 0 Ignore flag for the first matching study case found will be returned.
- > 0 Optionally, the row in the study case table containing the study case for which ignore-flag shall be returned can be passed. This is helpful, e.g., if a study case has been added multiple times for calculation with different command lists.

RemoveCmdsForStudyCaseRow

Removes all commands selected for calculation for a given row in the study case table.

```
int ComTasks.RemoveCmdsForStudyCaseRow(int studyCaseRow)
```

RETURNS

- 0** Commands could not be removed from calculation.
- 1** All commands of study case row were successfully removed from calculation.

ARGUMENTS

studyCaseRow > 0

The row in the study case table containing the study case for which all commands shall be removed.

RemoveCommand

Remove a command from the calculation (for study case row and task row / for all appearances).

```
int ComTasks.RemoveCommand(int studyCaseRow,
                           int taskRow
                           )
int ComTasks.RemoveCommand(DataObject command)
```

ARGUMENTS

studyCaseRow > 0

The row in the study cases table of the command's study case for which the command shall be removed.

taskRow > 0

The row in the commands table for which the command shall be removed.

command

Command to remove.

RETURNS

- 0** Command could not be removed.
- 1** Command has been successfully removed.

RemoveStudyCase

Removes a study case from the study cases table.

```
int ComTasks.RemoveStudyCase(DataObject studyCase,
                             [int studyCaseRow]
                             )
```

RETURNS

- 0** Study case could not be removed.
- 1** Study case has been successfully removed.

ARGUMENTS

studyCase

Study case which shall be removed.

studyCaseRow

- ≤ 0 Study case is removed for all entries in the study cases table matching the provided study case.
- > 0 Optionally, the row in the study case table containing the study case which shall be removed can be passed. This is helpful, e.g., if a study case has been added multiple times for calculation with different command lists.

RemoveStudyCases

Removes all study cases from calculation.

```
None ComTasks.RemoveStudyCases()
```

SetAdditionalResultsFlagForCommand

Set the flag whether to record an additional result file for a command of the calculation (using study case row and task row / using command).

```
int ComTasks.SetAdditionalResultsFlagForCommand(int studyCaseRow,
                                              int taskRow,
                                              int addResVal
                                              )
int ComTasks.SetAdditionalResultsFlagForCommand(DataObject command,
                                              int addResVal
                                              )
```

ARGUMENTS

studyCaseRow > 0

The row in the study cases table of the command's study case for which the flag to record additional results shall be set.

taskRow > 0

The row in the commands table for which the flag to record additional results shall be set.

command

The command for which the flag to record additional results shall be set.

addResVal

- | | |
|---|--|
| 1 | Will set the command to record additional results for the calculation. |
| 0 | Will set the command to avoid recording of results for calculation. |

RETURNS

- | | |
|---|--|
| 0 | Flag to record (or not record) additional results could not be set. |
| 1 | Flag to record (or not record) additional results has been successfully set. |

SetIgnoreFlagForCommand

Set the flag whether to ignore a command for the calculation (using study case row and task row / using command).

```
int ComTasks.SetIgnoreFlagForCommand(int studyCaseRow,
                                    int taskRow,
                                    int ignoreVal
                                    )
int ComTasks.SetIgnoreFlagForCommand(DataObject command,
                                    int ignoreVal
                                    )
```

ARGUMENTS

studyCaseRow > 0

The row in the study cases table of the command's study case for which the ignore flag shall be set.

taskRow > 0

The row in the commands table for which the ignore flag shall be set.

command

Command for which the ignore flag shall be set.

ignoreVal

- | | |
|---|---|
| 1 | Will set the command to be ignored for calculation. |
| 0 | Will set the command to be processed for calculation. |

RETURNS

- | | |
|----------|--|
| 0 | Ignore flag could not be set. |
| 1 | Ignore flag has been successfully set. |

SetIgnoreFlagForStudyCase

Set the flag whether to ignore the processing of commands of a study case for the calculation.

```
int ComTasks.SetIgnoreFlagForStudyCase(DataObject studyCase,
                                       int ignoreVal,
                                       [int studyCaseRow]
                                       )
```

RETURNS

- | | |
|----------|--|
| 0 | Ignore flag could not be set. |
| 1 | Ignore flag has been successfully set. |

ARGUMENTS

studyCase

Study case for which the ignore flag shall be set.

ignoreVal

- | | |
|---|---|
| 1 | Will set the flag to ignore the processing of commands of a study case. |
| 0 | Will set the flag to process the commands of a study case. |

studyCaseRow

- | | |
|----------|--|
| ≤ 0 | Ignore flag is set for all entries in the study cases table matching the provided study case. |
| > 0 | Optionally, the row in the study case table containing the study case for which the ignore-flag shall be set can be passed. This is helpful, e.g., if a study case has been added multiple times for calculation with different command lists. |

SetResultsFolder

Set a folder to store results for a given row in the study case table.

```
int ComTasks.SetResultsFolder(DataObject folder, int studyCaseRow)
```

RETURNS

- | | |
|----------|--|
| 0 | New folder could not be set as results folder for the given row in the study case table. |
| 1 | Folder was successfully set as results folder for given row in the study case table. |

ARGUMENTS

- folder* The new folder to store results in.
- studyCaseRow*
The row in the study case table containing the study case for which results folder shall be set.

5.4.55 ComTececo

Overview

[UpdateTablesByCalcPeriod](#)

UpdateTablesByCalcPeriod

Update all calculation points with respect to a new start- and end year

```
int ComTececo.UpdateTablesByCalcPeriod(float start,
                                       float end
                                       )
```

ARGUMENTS

- start* Start year of the study period
- end* End year of the study period

RETURNS

- 0** Calculation points have been successfully set.
- 1** Invalid input data: end year of study period must be greater or equal to start year.

5.4.56 ComTececocmp

Overview

[AppendStudyCase](#)
[CalcDiscountedEstimatedPaybackPeriod](#)
[CalcEstimatedPaybackPeriod](#)
[CalcInternalRateOfReturn](#)
[RemoveStudyCases](#)

AppendStudyCase

Appends a study case to the list of study cases.

```
int ComTececocmp.AppendStudyCase(DataObject studyCase,
                                  [int ignored = 0])
```

RETURNS

- 0** Study case could not be added for calculation.
- 1** Study case has been successfully added for calculation.

ARGUMENTS

- studyCase* Study case to add for calculation.
- isIgnored* Sets the flag to ignore the study case to add or not (default 0).

CalcDiscountedEstimatedPaybackPeriod

Calculates the discounted estimated payback period (in years) for a grid expansion w.r.t. a base grid configuration. The grid expansion and base configurations must be given by means of two study cases and their configured variation. Moreover, these study cases must contain corresponding result files calculated by Techno-Economic Calculations. The calculatory interest rate from the result file written by the Techno-Economic Calculation to evaluate will be used for discounting.

```
[int error,
float epp]
Application.CalcDiscountedEstimatedPaybackPeriod(DataObject strategyToEval,
                                                  DataObject baseStrategy)
```

ARGUMENTS

- strategyToEval* Study case defining grid expansion to evaluate.
- baseStrategy* Study case defining base grid configuration.
- epp (out)* Resulting discounted estimated payback period (in years).

RETURNS

Returns 0, if calculation was successfull and 1 otherwise.

CalcEstimatedPaybackPeriod

Calculates the estimated payback period (in years) for a grid expansion w.r.t. a base grid configuration. The grid expansion and base configurations must be given by means of two study cases and their configured variation. Moreover, these study cases must contain corresponding result files calculated by Techno-Economic Calculations.

```
[int error,
float epp]
ComTececocmp.CalcEstimatedPaybackPeriod(DataObject strategyToEval,
                                          DataObject baseStrategy)
```

ARGUMENTS

- strategyToEval* Study case defining grid expansion to evaluate.
- baseStrategy* Study case defining base grid configuration.
- epp (out)* Resulting estimated payback period (in years).

RETURNS

Returns 0, if calculation was successful and 1 otherwise.

CalcInternalRateOfReturn

Calculates the internal rate of return for a grid expansion w.r.t. a base grid configuration. The grid expansion and base configurations must be given by means of two study cases and their configured variation. Moreover, these study cases must contain corresponding result files calculated by Techno-Economic Calculations.

```
[int error,
float irr]
ComTecocomp.CalcInternalRateOfReturn(DataObject strategyToEval,
                                     DataObject baseStrategy)
```

ARGUMENTS

strategyToEval
Study case defining grid expansion to evaluate.

baseStrategy
Study case defining base grid configuration.

irr (out) Resulting internal rate of return.

RETURNS

Returns 0, if calculation was successful and 1 otherwise.

RemoveStudyCases

Removes all study cases from calculation.

```
None ComTecocomp.RemoveStudyCases()
```

5.4.57 ComTransfer**Overview**

[GetTransferCalcData](#)
[IsLastIterationFeasible](#)

GetTransferCalcData

The function returns the calculated transfer capacity and the total number of iteration after the transfer capacity command has been executed.

```
[float transferCapacity,
int totalIterations ] ComTransfer.GetTransferCalcData()
```


ARGUMENTS

transferCapacity (out)

Transfer capacity value at the last feasible iteration.

totalIterations (out)

Total iteration number.

IsLastIterationFeasible

The function verifies if the last transfer calculation iteration resulted in a feasible solution or not.

`int ComTransfer.IsLastIterationFeasible()`

RETURNS

- 1** Last transfer calculation iteration resulted in a feasible solution.
- 0** Last transfer calculation iteration did not result in a feasible solution.

5.4.58 ComUcte**Overview**[SetBatchMode](#)**SetBatchMode**

The batch mode allows to suppress all messages except error and warnings. This can be useful when used in scripts where additional output might be confusing.

`None ComUcte.SetBatchMode(int enabled)`

ARGUMENTS

enabled

- 0** disables batch mode, all messages are printed to output window (default).
- 1** enables batch mode, only error and warning messages are printed to output window.

5.4.59 ComUcteexp

Overview

[BuildNodeNames](#)
[DeleteCompleteQuickAccess](#)
[ExportAndInitQuickAccess](#)
[GetConnectedBranches](#)
[GetFromToNodeNames](#)
[GetOrderCode](#)
[GetUcteNodeName](#)
[InitQuickAccess](#)
[QuickAccessAvailable](#)
[ResetQuickAccess](#)
[SetGridSelection](#)

BuildNodeNames

Builds the node names as used in UCTE export and makes them accessible via :UcteNode-Name attribute. The node names will only be available as long as topology has not been changed. They must be re-build after any topology relevant modification.

Furthermore, the method fills the quick access cache given by the cache index for node names and branch topologies as used in UCTE export. The quick access cache endures also topology changes. The cache index is optional. If no cache index is given the default quick access cache is used.

```
int ComUcteexp.BuildNodeNames([int cacheIndex])
```

ARGUMENTS

cacheIndex (optional)

Index of the quick access cache (must be greater than or equals to 0)

RETURNS

- 0** On success.
- 1** On error (e.g. load flow calculation failed).

DeleteCompleteQuickAccess

Deletes all quick access caches.

```
None ComUcteexp.DeleteCompleteQuickAccess()
```

ExportAndInitQuickAccess

Performs an UCTE export and fills the quick access cache given by the cache index.

```
None ComUcteexp.ExportAndInitQuickAccess(int cacheIndex)
```

ARGUMENTS

cacheIndex

Index of the quick access cache (must be greater than or equals to 0)

GetConnectedBranches

Determines the connected branches for the given terminal from the quick access cache given by the optional cache index. If no cache index is given the default quick access cache is used.

```
list ComUcteexp.GetConnectedBranches(DataObject terminal,  
                                     [int cacheIndex])
```

ARGUMENTS

terminal Terminal to determine the connected branches from

connectedBranches (out)

Connected branches for the given terminal

cacheIndex (optional)

Index of the quick access cache (must be greater than or equals to 0)

GetFromToNodeNames

Determines the UCTE node names of the branch ends from the quick access cache given by the optional cache index. If no cache index is given the default quick access cache is used.

```
[str nodeNameFrom,  
str nodeNameTo    ] ComUcteexp.GetFromToNodeNames(DataObject branch,  
                                                  [int cacheIndex])
```

ARGUMENTS

branch Branch to find the UCTE node names from

nodeNameFrom (out)

UCTE node name of start node

nodeNameTo (out)

UCTE node name of end node

cacheIndex (optional)

Index of the quick access cache (must be greater than or equals to 0)

GetOrderCode

Determines the order code of the given branch element as used for UCTE export from the quick access cache given by the optional cache index. If no cache index is given the default quick access cache is used.

```
str ComUcteexp.GetOrderCode(DataObject branch,  
                             [int cacheIndex])
```

ARGUMENTS

branch Branch element to get the UCTE order code from

orderCode (out)

Order code of the given branch element

cacheIndex (optional)

Index of the quick access cache (must be greater than or equals to 0)

GetUcteNodeName

Determines the node name of the given terminal as used for UCTE export from the quick access cache given by the optional cache index. If no cache index is given the default quick access cache is used.

```
None ComUcteexp.GetOrderCode(DataObject terminal,  
                             [int cacheIndex])
```

ARGUMENTS

terminal Terminal to get the UCTE node name from

ucteNodeName (out)
UCTE node name of the given terminal

cacheIndex (optional)
Index of the quick access cache (must be greater than or equals to 0)

InitQuickAccess

Initializes the quick access cache given by the optional cache index. The quick access cache contains node names and branch topologies as used in UCTE export and endures topology changes. *InitQuickAccess()* requires a successful executed UCTE export as pre-condition. The cache index is optional. If no cache index is given the default quick access cache is used.

```
None ComUcteexp.InitQuickAccess([int cacheIndex])
```

ARGUMENTS

cacheIndex (optional)
Index of the quick access cache (must be greater than or equals to 0)

QuickAccessAvailable

Checks if the quick access cache given by the optional cache index is available. If no cache index is given the default quick access cache is checked for availability.

```
int ComUcteexp.QuickAccessAvailable([int cacheIndex])
```

ARGUMENTS

cacheIndex (optional)
Index of the quick access cache (must be greater than or equals to 0)

RETURNS

0 on success and 1 on error.

ResetQuickAccess

Resets the given quick access cache for node names and branch topologies as used in UCTE export. The cache index is optional. If no cache index is given the default quick access cache is reset.

```
None ComUcteexp.ResetQuickAccess([int cacheIndex])
```

ARGUMENTS

cacheIndex (optional)

Index of the quick access cache (must be greater than or equals to 0)

SetGridSelection

Configures the selected grids in the UCTE export command.

```
None ComUcteexp.SetGridSelection(list gridsToExport)
```

ARGUMENTS

gridsToExport

Grids (instances of class ElmNet) to be selected for export. All not contained grids will be de-selected.

5.4.60 ComWr**Overview**[ExportGraphicTab](#)**ExportGraphicTab**

Exports the passed graphic to the specified output file.

```
int ComWr.ExportGraphicTab(object graphic,
                           str filename
                           )
```

ARGUMENTS

graphic Object that identifies the graphic to be exported. May either be a diagram page (SetDeskpage), or a plot page (GrpPage), or a diagram (IntGrfnet).*filename* Full filesystem path of the exported file, including the file extension. Supported file formats:

- .pdf
- .emf
- .wmf
- .svg
- .png
- .jpg

RETURNS

- 0** On success.
- 1** On failure.

EXAMPLE

The following example exports all single line diagrams from the active project as PDF files:

```
import powerfactory
app = powerfactory.GetApplication()

comWr = app.GetFromStudyCase('ComWr')

diagramsFolder = app.GetProjectFolder('dia')
diagrams = diagramsFolder.GetChildren(0, '*.IntGrfnet')
for diagram in diagrams:
    diagramname = diagram.GetAttribute('loc_name')
    outputpath = f'E:/Temp/{diagramname}.pdf'
    ret = comWr.ExportGraphicTab(diagram, outputpath)
    app.PrintPlain('success' if ret == 0 else 'failed')
```

5.5 Settings

5.5.1 SetCluster

Overview

[CalcCluster](#)
[GetNumberOfClusters](#)

CalcCluster

Performs a load flow calculation for the cluster index passed to the function. To execute properly this function requires that a valid load flow result is already calculated before calling it.

```
int SetCluster.CalcCluster(int clusterIndex,
                           [int messageOn]
                           )
```

ARGUMENTS

clusterIndex

The cluster index. Zero based value, the first cluster has index 0.

messageOn (optional)

Possible values:

- | | |
|----------|--|
| 0 | Do not emit a message in the output window. |
| 1 | Emit a message in the output window in case that the function does not execute properly. |

RETURNS

- | | |
|----------|---|
| 0 | On success. |
| 1 | There are no clusters, the number of clusters is 0. |
| 2 | The cluster index exceeds the number of clusters. |
| 3 | There is no load flow in memory before running CalcCluster. |

GetNumberOfClusters

Get the number of clusters.

```
int SetCluster.GetNumberOfClusters()
```

RETURNS

The number of clusters.

5.5.2 SetColscheme

Overview

[GetAlarmColouringMode](#)
[GetColouringMode](#)
[GetEnergisingColouringMode](#)
[SetColouring](#)
[SetFilter](#)

GetAlarmColouringMode

Returns the alarm colouring number for the given or currently valid calculation.

```
int SetColscheme.GetAlarmColouringMode(str page)
```

ARGUMENTS

page

empty for currently valid calculation

set page (see [dialog page name table](#))

RETURNS

The colouring number of "Alarm" colouring or negative value if not set.

GetColouringMode

Returns the "other" colouring number for the given or currently valid calculation.

```
int SetColscheme.GetColouringMode(str page)
```

ARGUMENTS

page

empty for currently valid calculation

set page (see [dialog page name table](#))

RETURNS

The colouring number of "Other" colouring or negative value if not set.

GetEnergisingColouringMode

Returns the energising status colouring number for the given or currently valid calculation.

```
int SetColscheme.GetEnergisingColouringMode(str page)
```

ARGUMENTS

page

empty for currently valid calculation
set page (see [dialog page name table](#))

RETURNS

The colouring number of "Energising Status" colouring or negative value if not set.

SetColouring

Sets colouring for given or currently valid calculation.

```
int SetColscheme.SetColouring(str page,  
                               int energizing,  
                               [int alarm,]  
                               [int normal]  
                               )
```

ARGUMENTS

page

empty set for currently valid calculation
set page for which modes are set (see [dialog page name table](#))

energizing

Colouring for Energizing Status

-2 enable (set to previously selected mode),
-1 do not change
0 disable
>0 set to this mode (see table below)

alarm

Colouring for Alarm

-2 enable (set to previously selected mode),
-1 do not change (default)
0 disable
>0 set to this mode (see table below)

normal

Other Colouring

-2 enable (set to previously selected mode),
-1 do not change (default)
0 disable
>0 set to this mode (see table below)

Table 5.5.3

Dialog Page Name	"page" value
Basic Data	basic
Load Flow	ldf
AC Load Flow Sensitivities	acsens
AC Contingency Analysis	accont
AC Quasi-dynamic Simulation	acldfsweep
DC Load Flow	dcldf
DC Load Flow Sensitivities	dcsens
DC Contingency Analysis	dccont
DC Quasi-dynamic Simulation	dcldfsweep
VDE/IEC Short-Circuit	shc
Complete Short-Circuit	shcfull
ANSI Short-Circuit	shcansi
IEC 61363	shc61363
DC Short-Circuit	shcdc
RMS-Simulation	rms
Modal Analysis	modal
EMT-Simulation	emt
Harmonics/Power Quality	harm
Frequency Sweep	fsweep
D-A-CH-CZ Connection Request	dachcz
BDEW/VDE Connection Request	bdewvde
Optimal Power Flow	opf
DC Optimal Power Flow	dcopf
DC OPF with Contingencies	dccontopf
State Estimation	est
Reliability	rel
General Adequacy	genrel
Tie Open Point Opt.	topo
Motor Starting Calculation	motstart
Arc Flash Calculation	arcflash
Optimal Capacitor Placement	optcapo
Voltage Profile Optimisation	mvplan
Backbone Calculation	backbone
Optimal RCS Placement	optrcs
Optimal Manual Restoration	omr
Phase Balance Optimisation	balance
Hosting Capacity Analysis	hostcap
User defined calculation	usercalc

Table 5.5.4

Energizing State Name	"energizing" value
De-energized	33
Out of Calculation	37
De-energised, Planned Outage	61

Table 5.5.5

Alarm Name	"alarm" value
Voltage Violations / Overloading	29
Outages	32
Overloading of Thermal / Peak Short Circuit Current	31
Feeder Radiality Check	38

Table 5.5.6

Other Colouring Name	Group	"normal" value
Voltages / Loading	Results	1
Voltage Levels	Topology	2
Individual	Individual	4
Connected Grid Components	Topology	5
According to Filter	User-defined	see notes below table
Grids	Groupings	7
Modifications in Variations / System Stages	Variations / System Stages	8
Loading of Thermal / Peak Short-Circuit Current	Results	9
Paths	Groupings	10
System Type AC/DC and Phases	Topology	11
Relays, Current and Voltage Transformers	Secondary Equipment	12
Fault Clearing Times	Results	13
Feeders	Topology	14
Switches, Type of Usage	Secondary Equipment	15
Measurement Locations	Secondary Equipment	16
Missing graphical connections	Topology	17
Zones	Groupings	18
State Estimation	Results	19
Boundaries (Interior Region)	Topology	20
Station Connectivity	Topology	21
Outage Check	Topology	22
Energizing Status	Topology	23
Modifications in Recording Expansion Stage	Variations / System Stages	24
Areas	Groupings	25
Owners	Groupings	26
Routes	Groupings	27
Operators	Groupings	28
Layers	Groupings	66
Original Locations	Variations / System Stages	30
Boundaries (Definition)	Topology	34
Meteo Stations	Groupings	35
Station Connectivity (Beach Balls only)	Topology	36
Power Restoration	Secondary Equipment	43
Connected Components	Topology	39
Connected Components, Voltage Level	Topology	40
Year of Construction	Primary Equipment	41
Cross Section	Primary Equipment	42
Forced Outage Rate	Primary Equipment	44
Forced Outage Duration	Primary Equipment	45
Loads: Yearly interruption frequency	Results	46
Loads: Yearly interruption time	Results	47
Loads: Average Interruption Duration	Results	48
Loads: Load Point Energy Not Supplied	Results	49
Supplied by Substation	Topology	50
Supplied by Secondary Substation	Topology	51
Incident Energy	Results	52
PPE-Category	Results	53
Optimal Manual Restoration	Results	54
Connection Request: Approval Status	Results	55
Voltage Angle	Results	56
Contributions to SAIDI	Results	57
Contributions to SAIFI	Results	58
Contributions to ENS	Results	59
Contributions to EIC	Results	60

Note: User-defined filters can be set with a "normal" value of 1000 or higher. The first filter in the list has the value 1000, the next one has 1001 and so on.

RETURNS

- 0** error (at least one of the given colourings cannot be set, e.g. not available for given page). Nothing is changed.
- 1** ok

SetFilter

Sets the "other" colouring for the given or currently valid calculation if that mode is available for that calculation.

```
int SetColscheme.SetFilter(int modeNumber,  
                           [int page]  
                           )  
int SetColscheme.SetFilter(DataObject obj,  
                           [int page]  
                           )
```

ARGUMENTS

modeNumber

Colouring mode number to be set (for numbers see table listed in [SetColscheme.SetColouring\(\)](#)).

obj

User-defined filter to be set. The filter needs to be an "IntFiltset" stored inside the project colour settings.

page (optional)

Dialog page number for which colouring is set (see table below).

Table 5.5.7

Dialog Page Name	"page" value
Basic Data	101
Load Flow	102
AC Load Flow Sensitivities	120
AC Contingency Analysis	121
AC Quasi-dynamic Simulation	137
DC Load Flow	122
DC Load Flow Sensitivities	123
DC Contingency Analysis	124
DC Quasi-dynamic Simulation	138
VDE/IEC Short-Circuit	103
Complete Short-Circuit	111
ANSI Short-Circuit	112
IEC 61363	114
DC Short-Circuit	117
RMS-Simulation	104
Modal Analysis	128
EMT-Simulation	105
Harmonics/Power Quality	106
Frequency Sweep	127
D-A-CH-CZ Connection Request	139
BDEW/VDE Connection Request	142
Optimal Power Flow	108
DC Optimal Power Flow	130
DC OPF with Contingencies	135
State Estimation	113
Reliability	109
General Adequacy	115
Tie Open Point Opt.	116
Motor Starting Calculation	133
Arc Flash Calculation	129
Optimal Capacitor Placement	126
Voltage Profile Optimisation	125
Backbone Calculation	131
Optimal RCS Placement	132
Optimal Manual Restoration	136
Phase Balance Optimisation	141
User defined calculation	142

RETURNS

- 0** Ok.
- 1** Error (colouring mode or page not found).

5.5.3 SetDatabase

Overview

[EmptyCache](#)

EmptyCache

Empties characteristics cache for this database connection.

```
None SetDatabase.EmptyCache()
```

5.5.4 SetDataext

Overview

[AddConfiguration](#)
[GetConfiguration](#)
[GetConfigurations](#)
[RemoveAllConfigurations](#)
[RemoveConfiguration](#)

AddConfiguration

Adds a new IntAddonvars configuration object for the given classFilter with the descriptiveName as object name. For the classFilter expressions like Elm* or ElmTr? are possible. If there already is an object matching classFilter and descriptiveName exactly, this object is returned instead.

```
DataObject SetDataext.AddConfiguration(str classFilter,  
                                       str descriptiveName)
```

ARGUMENTS

classFilter
The class filter of the IntAddonvars object

descriptiveName
The object name of the IntAddonvars object

RETURNS

The IntAddonvars object which exactly matches the classFilter and descriptive name or a newly created one. Returns nothing if the object cannot be modified.

SEE ALSO

[IntAddonvars.AddDouble\(\)](#), [IntAddonvars.AddDoubleMatrix\(\)](#),
[IntAddonvars.AddDoubleVector\(\)](#), [IntAddonvars.AddInteger\(\)](#),
[IntAddonvars.AddIntegerVector\(\)](#), [IntAddonvars.AddObject\(\)](#),
[IntAddonvars.AddObjectVector\(\)](#), [IntAddonvars.AddString\(\)](#),
[IntAddonvars.RemoveParameter\(\)](#)

GetConfiguration

Returns the `IntAddonvars` object which exactly matches the `classFilter` and `descriptiveName`, if the latter is specified. If there are multiple matches the first object will be returned. Otherwise nothing is returned.

```
DataObject SetDataext.GetConfiguration(str classFilter,
                                       [str descriptiveName])
```

ARGUMENTS

classFilter

The class filter of the `IntAddonvars` object

descriptiveName (optional)

The object name of the `IntAddonvars` object

RETURNS

The `IntAddonvars` object which exactly matches the `classFilter` and optionally the `descriptiveName` or nothing.

SEE ALSO

[IntAddonvars.AddDouble\(\)](#), [IntAddonvars.AddDoubleMatrix\(\)](#),
[IntAddonvars.AddDoubleVector\(\)](#), [IntAddonvars.AddInteger\(\)](#),
[IntAddonvars.AddIntegerVector\(\)](#), [IntAddonvars.AddObject\(\)](#),
[IntAddonvars.AddObjectVector\(\)](#), [IntAddonvars.AddString\(\)](#),
[IntAddonvars.RemoveParameter\(\)](#)

GetConfigurations

Returns all `IntAddonvars` objects by a given `classFilter`.

```
list SetDataext.GetConfigurations(str classFilter)
list SetDataext.GetConfigurations()
```

ARGUMENTS

classFilter

The class filter for the `IntAddonvars` object

RETURNS

A list of `IntAddonvars` objects matching the `classFilter` exactly. If no filter is specified all `IntAddonvars` are returned.

SEE ALSO

[IntAddonvars.AddDouble\(\)](#), [IntAddonvars.AddDoubleMatrix\(\)](#),
[IntAddonvars.AddDoubleVector\(\)](#), [IntAddonvars.AddInteger\(\)](#),
[IntAddonvars.AddIntegerVector\(\)](#), [IntAddonvars.AddObject\(\)](#),
[IntAddonvars.AddObjectVector\(\)](#), [IntAddonvars.AddString\(\)](#),
[IntAddonvars.RemoveParameter\(\)](#)

RemoveAllConfigurations

Removes all `IntAddonvars` objects effectively removing all Data Extensions.

```
None SetDataext.RemoveAllConfigurations()
```

RemoveConfiguration

Removes the IntAddonvars object exactly matching classFilter and descriptive name.

```
None SetDataext.RemoveConfiguration(str classFilter,  
                                   [str descriptiveName])
```

ARGUMENTS

classFilter

The class filter of the IntAddonvars object

descriptiveName (optional)

The object name of the IntAddonvars object

5.5.5 SetDeskpage

Overview

[Close](#)

[Show](#)

Close

Closes the graphic page, if currently shown in the desktop.

```
int SetDeskpage.Close()
```

RETURNS

- | | |
|----------|--------------------------------|
| 0 | On success, no error occurred. |
| 1 | Otherwise |

Show

Displays the diagram page in the desktop.

```
int SetDeskpage.Show()
```

RETURNS

- | | |
|----------|--------------------------------|
| 0 | On success, no error occurred. |
| 1 | Otherwise |

5.5.6 SetDesktop

Overview

[AddPage](#)
[BeginTabGroup](#)
[Close](#)
[CloseAllTemporaryTabs](#)
[DoAutoScaleX](#)
[EndTabGroup](#)
[ExportGraphicTab](#)
[Freeze](#)
[GetActivePage](#)
[GetCanvasSize](#)
[GetPage](#)
[GetSplitOrientation](#)
[GetTabGroups](#)
[IsFrozen](#)
[IsOpened](#)
[OpenScriptInTab](#)
[OpenTextFileInTab](#)
[RemovePage](#)
[SetAdaptX](#)
[SetAutoScaleX](#)
[SetResults](#)
[SetScaleX](#)
[SetSplitOrientation](#)
[SetViewArea](#)
[SetXVar](#)
[Show](#)
[Unfreeze](#)
[WriteWMF](#)
[ZoomAll](#)

AddPage

This function is deprecated. Please use [SetDesktop.Show\(\)](#) instead.

BeginTabGroup

This function is not supported in GUI-less mode.

Collects all subsequently created or opened tabs in one new floating tab group.

After all desired tabs have been opened, the function [SetDesktop.EndTabGroup\(\)](#) should be called to end the collection mechanism and obtain a tab group object ([SetTabgroup](#)), which can be used to perform further actions on the tab group.

```
None SetDesktop.BeginTabGroup()
```

EXAMPLE

The following example demonstrates the usage of this method.

```
import powerfactory
```

```

app = powerfactory.GetApplicationExt()

# get currently opened desktop
desktop = app.GetDesktop()

desktop.BeginTabGroup()
# open/create tabs here

tabGroup = desktop.EndTabGroup()

# optionally, perform operations on returned tab group
if tabGroup:
    tabGroup.ExportAllTableReports(0)

```

SEE ALSO

[SetDesktop.EndTabGroup\(\)](#)

Close

Closes the desktop, if it is currently shown.

```
int SetDesktop.Close()
```

RETURNS

0	on success
1	on error

CloseAllTemporaryTabs

This function is not supported in GUI-less mode.

Closes all temporary tabs, i.e. tabs that are not part of the Desktop (except Data Managers).

```
None SetDesktop.CloseAllTemporaryTabs()
```

DoAutoScaleX

Scales the x-axes of all plots in the desktop which use the x-axis scale defined in the desktop.

```
None SetDesktop.DoAutoScaleX()
```

EndTabGroup

This function is not supported in GUI-less mode.

Stops collecting newly created tabs in a single tab group and returns the tab group object ([SetTabgroup](#)) of the tab group containing previously created tabs.

```
DataObject SetDesktop.EndTabGroup()
```

RETURNS

The tab group containing all tabs opened after the last [SetDesktop.BeginTabGroup\(\)](#) call or None if no tab group or no tabs were opened.

SEE ALSO

[SetDesktop.BeginTabGroup\(\)](#)

ExportGraphicTab

Convenience function that fetches or creates the ComWr from the active study case and calls [ComWr.ExportGraphicTab\(\)](#).

```
int SetDesktop.ExportGraphicTab(object graphic,
                               str filename
                               )
```

ARGUMENTS

graphic Object that identifies the graphic to be exported.
filename Full filesystem path of the exported file, including the file extension.

RETURNS

0 On success.
1 On failure.

Freeze

Enables the graphical freeze mode, preventing changes to open diagrams.

```
int SetDesktop.Freeze()
```

RETURNS

0 on success
1 on error

GetActivePage

Returns the page object of the currently shown page.

```
DataObject SetDesktop.GetActivePage()
```

RETURNS

Page object of the active page, or 0 if no page is active.

GetCanvasSize

Returns the pixel dimensions of the currently active (top-most) graphic page.

```
[int valid
int width,
int height] SetDesktop.GetCanvasSize()
```

ARGUMENTS

width (out)

Pixel width of the canvas. -1 if no graphics page is open.

height (out)

Pixel height of the canvas. -1 if no graphics page is open.

RETURNS

- 0** on success: canvas size could be determined
- 1** on error: no graphics page is open

GetPage

Searches, activates and returns a graphics page in the currently open desktop. If “create” is true, then a new page will be created and added to the desktop if no page with name was found.

```
DataObject SetDesktop.GetPage(str name,
                               [int create,]
                               [str class]
                               )
```

ARGUMENTS

name Name of the page.*create (optional)*

Possible values:

- 0** do not create new plot page (default)
- 1** create plot page if it does not exist already

class (optional)

Classname of the plot page object to create. If not specified, a 'GrpPage' will be created.

RETURNS

Plot page (GrpPage or SetVipage), or network graphic page (SetDeskpage)

GetSplitOrientation

This function is not supported in GUI-less mode.

Returns the current split orientation of the main window.

As soon as more than one tab group is open in the main window, its central area is either split horizontally (aligning tab groups from left to right) or vertically (aligning tab groups from top to bottom).

```
int SetDesktop.GetSplitOrientation()
```

RETURNS

A value representing the orientation of the main window:

- 0** Main window is split horizontally.
- 1** Main window is split vertically.

SEE ALSO

[SetDesktop.SetSplitOrientation\(\)](#)

GetTabGroups

This function is not supported in GUI-less mode.

Returns the set of the currently opened tab groups. Each tab group is represented by a `SetTabgroup` object.

The optional filter argument provides the possibility to limit the collection to only docked or only floating tab groups.

```
list SetDesktop.GetTabGroups ([int filter])
```

ARGUMENTS

<i>filter</i>	Filter specifying which kind of tab groups are returned:
0	All tab groups (default).
1	Only docked tab groups.
2	Only floating tab groups.

RETURNS

The (optionally filtered) set of the currently opened tab groups.

IsFrozen

Returns whether the graphical freeze mode is currently enabled.

```
int SetDesktop.IsFrozen()
```

RETURNS

0	freeze mode is disabled, or the desktop is not open
1	desktop is open and freeze mode is enabled

IsOpened

Returns whether the desktop is currently shown.

```
int SetDesktop.IsOpened()
```

RETURNS

1	if desktop is shown
0	otherwise

OpenScriptInTab

This function is not supported in GUI-less mode.

Opens the script associated with the given attribute of the given object. Only scripts that can also be opened in a new Editor tab using the graphical user interface can be opened this way.

Note that it is not possible to open scripts of read-only objects (e.g. objects located in an inactive project).

```
int SetDesktop.OpenScriptInEditor(DataObject sourceObject,  
                                str attribute  
                                )
```

ARGUMENTS

sourceObject

The object that contains the desired script (e.g. a ComDpl object).

attribute

The attribute of the desired script (e.g. 'xScript' for the script stored in a ComDpl object).

RETURNS

An error code. Possible values are

- 0** No error has occurred, the script has been opened successfully in a new Editor tab.
- 1** The given object is None.
- 2** The given attribute does not exist or cannot be opened in the Editor.

SEE ALSO

[SetDesktop.OpenTextFileInTab\(\)](#)

OpenTextFileInTab

This function is not supported in GUI-less mode.

Opens the given file in a new Editor tab. Only plain text files should be opened this way.

If the given file path ends in '.py' or '.pyw' the opened Editor will provide syntax highlighting for the Python scripting language.

```
int SetDesktop.OpenTextFileInTab(str path)
```

ARGUMENTS

path

The path to the text file to open.

RETURNS

An error code. Possible values are

- 0** No error has occurred, the file has been opened successfully in a new Editor tab.
- 1** The given path does not point to a valid file.

SEE ALSO

[SetDesktop.OpenScriptInTab\(\)](#)

RemovePage

Removes a graphic page. The page to be removed can be identified either by its name or by its page object.

```
int SetDesktop.RemovePage(str pageName)
int SetDesktop.RemovePage(DataObject pageObject)
```

ARGUMENTS

pageName
Name of graphics page.

pageObject
A graphics page object.

RETURNS

0 on success
1 on error

SetAdaptX

Sets the Adapt Scale option of the x-scale.

```
None SetDesktop.SetAdaptX(int mode,
                           [float trigger]
                           )
```

ARGUMENTS

mode Possible values:

0	off
1	on

trigger (optional)
Trigger value, unused if mode is off or empty

SetAutoScaleX

Sets automatic scaling mode of the x-scale. A warning is issued if an invalid mode is passed to the function.

```
None SetDesktop.SetAutoScaleX(int mode)
```

ARGUMENTS

mode Possible values:

0	never
1	after simulation
2	during simulation

SetResults

Sets default results object of desktop.

```
None SetDesktop.SetResults(DataObject res)
```

ARGUMENTS

res Result object to set or None to reset. Valid result object is any of class ElmRes, IntComtrade and IntComtradeset.

SetScaleX

Sets x-axis scale. A function call without arguments sets the Auto Scale setting to On without changing the scale itself.

```
None SetDesktop.SetScaleX()
None SetDesktop.SetScaleX(float min,
                           float max,
                           [int log]
                           )
```

ARGUMENTS

min (optional)
Minimum of x-scale.

max (optional)
Maximum of x-scale.

log (optional)
Possible values:

0	linear
1	logarithmic

SetSplitOrientation

This function is not supported in GUI-less mode.

Sets the current split orientation of the main window, see [SetDesktop.GetSplitOrientation\(\)](#) for details on split orientations.

```
None SetDesktop.SetSplitOrientation(int orientation)
```

ARGUMENTS

orientation
The desired orientation of the main window:

0	Split main window horizontally.
1	Split main window vertically.

SEE ALSO

[SetDesktop.GetSplitOrientation\(\)](#)

SetViewArea

Adjusts the view area of the currently active (top-most) graphic page. Coordinates are expected in millimetres for schematic diagrams or in geographic coordinates for geographic diagrams, respectively.

```
None SetDesktop.SetViewArea(float left,
                             float right,
                             float bottom,
                             float top)
```

SetXVar

Sets x-axis variable. If The default x-axis variable (time) is set if no argument is passed.

```
None SetDesktop.SetXVar()
None SetDesktop.SetXVar(DataObject obj,
                          str varname
                          )
```

ARGUMENTS

obj (optional)
x-axis object

varname (optional)
variable of obj

Show

Opens and activates the passed 'pageObject' or the page with name 'pageName' in the desktop. The object 'pageObject' is typically a plot page (GrpPage) or a diagram page (SetDeskpage), but it may also be a diagram object (IntGrfnet) or a model type object (BlkDef, TypMdl). Calling the function without an argument opens the desktop.

```
int SetDesktop.Show()
int SetDesktop.Show(str pageName)
int SetDesktop.Show(DataObject pageObject)
```

ARGUMENTS

pageName (optional)
Name of graphics page.

pageObject (optional)
A graphics page object.

RETURNS

0 on success
1 on error

Unfreeze

Disables the graphical freeze mode, allowing changes to open diagrams.

```
int SetDesktop.Unfreeze()
```

RETURNS

0	on success
1	on error

WriteWMF

Writes the currently open graphic to a windows metafile file (*.wmf).

Please use the Save File command (ComWr) for writing to other formats like *.pdf, *.png, *.svg, *.emf or *.bmp.

```
int SetDesktop.WriteWMF(str filename)
```

ARGUMENTS

filename Filename without extension.

RETURNS

0	On error.
1	On success.

ZoomAll

Adjusts the zoom level of the currently active (top-most) graphic page such that the entire diagram is shown.

```
int SetDesktop.ZoomAll()
```

RETURNS

0	on success
1	on error

5.5.7 SetDistrstate**Overview**

[CalcCluster](#)

CalcCluster

Calculates a load flow with a given load distribution state applied.

```
int SetDistrstate.CalcCluster(int clusterIndex,
                             [int messageOn]
                             )
```

ARGUMENTS

clusterIndex

The cluster index. Zero based value, the first cluster has index 0.

messageOn (optional)

Possible values:

- | | |
|----------|--|
| 0 | Do not emit a message in the output window. |
| 1 | Emit a message in the output window in case that the function does not execute properly. |

RETURNS

0 if ok. -1 if load flow of cluster did not converge.

5.5.8 SetFilt

Overview

[Get](#)

Get

Returns a container with the filtered objects.

```
list SetFilt.Get()
```

RETURNS

The set of filtered objects.

5.5.9 SetLevelvis

Overview

[AdaptWidth](#)
[Align](#)
[ChangeFont](#)
[ChangeLayer](#)
[ChangeRefPoints](#)
[ChangeWidthVisibilityAndColour](#)
[CreateLayer](#)
[Mark](#)
[Reset](#)

AdaptWidth

This function resizes the in the object specified group of text boxes regarding their text contents.

```
None SetLevelvis.AdaptWidth()
```

Align

This function aligns the text within a text box.

```
None SetLevelvis.Align(int iPos)
```

ARGUMENTS

<i>iPos</i>	Alignment position
0	left
1	middle
2	right

ChangeFont

This function sets the font number for the specified group of text boxes.

```
None SetLevelvis.ChangeFont (int iFont)
```

ARGUMENTS

<i>iFont</i>	Font number (default fonts range from 0 to 13)
--------------	--

ChangeLayer

This function sets the specified group of text boxes to a given layer.

```
None SetLevelvis.ChangeLayer (str sLayer)
```

ARGUMENTS

<i>sLayer</i>	Layer name (e.g. 'Object Names', 'Results', 'Invisible Objects',...)
---------------	--

ChangeRefPoints

This function sets the reference points between a text box (second parameter) and its parent object (first parameter), e.g. if the result box of a busbar shall be shown on top of a drawn bar instead of below the bar the values change from (6,4) to (4,6). The first number specifies the reference number of the text box. The integer values describe the position of the reference points within a rectangle (0=centre, 1=middle right, 2=top right,...):

```
4 3 2
5 0 1
6 7 8
```

```
None SetLevelvis.ChangeRefPoints (int iParRef,
                                   int iTBRef
                                   )
```

ARGUMENTS

<i>iParRef</i>	Defines the reference point on the parent object (e.g. busbar)
<i>iTBRef</i>	Defines the reference point on the text box

ChangeWidthVisibilityAndColour

This function sets the visibility of the frame, the width (in number of letters), the visibility and the colour of text boxes.

```
None SetLevelvis.ChangeWidthVisibilityAndColour([int iWidth,]
                                                [int iVisibility,]
                                                [int iColour]
                                                )
```

ARGUMENTS

iWidth Sets the width in number of letters

0..n width

iVisibility Sets the visibility

0 not visible

1 visible

iColour Sets the colour

0..255 colour

CreateLayer

Creation of user-defined layers.

```
DataObject SetLevelvis.CreateLayer([str name,]
                                    [int type]
                                    )
```

ARGUMENTS

name Layer name

type Sets the visibility

2 Net elements, annotations, text boxes

3 Background image

5 Filtered

RETURNS

The created layer if successful, None otherwise.

Mark

Marks the specified group of text boxes in the currently shown diagram.

```
None SetLevelvis.Mark()
```

Reset

This function resets the individually modified text box settings.

```
None SetLevelvis.Reset(int iMode)
```

ARGUMENTS

iMode

- | | |
|----------|---|
| 0 | Reset to default (changed reference points are not reset) |
| 1 | Only font |
| 2 | Shift to original layer (result boxes to layer 'Results', object names to layer 'Object Names') |

5.5.10 SetLvscale

Overview

[AddCalcRelevantCoincidenceDefinitions](#)

AddCalcRelevantCoincidenceDefinitions

Adds all calculation relevant coincidence definitions.

```
None SetLvscale.AddCalcRelevantCoincidenceDefinitions()
```

5.5.11 SetParalman

Overview

[GetNumSlave](#)
[SetNumSlave](#)
[SetTransfType](#)

GetNumSlave

To get the number of slaves which is currently configured.

```
int SetParalman.GetNumSlave()
```

RETURNS

the number of slaves which is currently configured.

SetNumSlave

To configure the number of slaves to be used for parallel computing.

```
int SetParalman.SetNumSlave(int numSlaves)
```

ARGUMENTS

numSlaves

Number of slaves to be used for parallel computing

- | | |
|-----|-----------------------------------|
| -1 | All cores available will be used. |
| > 0 | The number of slaves to be used. |

RETURNS

Always return 0.

SetTransfType

To change the data transfer type: via file or via socket communication.

```
int SetParalman.SetTransfType(int viaFile)
```

ARGUMENTS

viaFile

- | | |
|----------|--|
| 0 | The data will be transferred via socket communication. |
| 1 | The data will be transferred via file. |

RETURNS

- | | |
|----------|--|
| 0 | the data will be transferred via socket communication. |
| 1 | the data will be transferred via file. |

5.5.12 SetPath**Overview**

[AllBreakers](#)
[AllClosedBreakers](#)
[AllOpenBreakers](#)
[AllProtectionDevices](#)
[Create](#)
[CreateTimeOvercurrentPlot](#)
[GetAbsDistance](#)
[GetAll](#)
[GetBranches](#)
[GetBuses](#)
[GetImpedanceAtPos](#)
[GetNode](#)
[GetPathFolder](#)
[GetRelay](#)
[NextRelayBranch](#)

AllBreakers

Returns all breakers in the path definition.

```
list SetPath.AllBreakers()
```

RETURNS

The set of breakers.

AllClosedBreakers

Returns all closed breakers in the path definition.

```
list SetPath.AllClosedBreakers()
```

RETURNS

The set of closed breakers.

AllOpenBreakers

Returns all open breakers in the path definition.

```
list SetPath.AllOpenBreakers()
```

RETURNS

The set of open breakers.

AllProtectionDevices

Returns all protection devices in the path definition for a given direction.

```
list SetPath.AllProtectionDevices(int reverse)
```

ARGUMENTS

reverse

- | | |
|----------|--------------------------------------|
| 0 | Return devices in forward direction. |
| 1 | Return devices in reverse direction. |

RETURNS

The set of protection devices.

Create

Creates a path based on the provided elements.

```
DataObject SetPath.Create(list elements)
```

ARGUMENTS

elements Elements the path shall be created with. If two elements are provided, the returned path will be the shortest path (SP) between those. If an incomplete path $v_1, v_2, \dots, v_k$ is provided, then the result will be the concatenation of $SP(v_1, v_2)$, $SP(v_2, v_3)$, ... (it is not possible to visit the same element twice). If the elements form a complete path, this path will be returned.

RETURNS

- DataObject** Modification was successful.
- None** Modification failed. (e.g. elements can not be joined to a path.)

CreateTimeOvercurrentPlot

Generates and opens a graphic page containing a time-overcurrent plot showing the path's protection devices. In addition, the page shows a single line diagram of the path (SGL legend).

```
DataObject SetPath.CreateTimeOvercurrentPlot()
```

RETURNS

The generated graphic page (GrpPage).

GetAbsDistance

Determines the intersection of the (sub-)path and the given impedance.

```
[DataObject object,
float Rcut,
float Xcut,
float distance] SetPath.GetAbsDistance(DataObject start,
                                       DataObject end,
                                       float Zabs,
                                       int reverse)
```

ARGUMENTS

start Start element of the (sub-)path or None for the first busbar of the path.

end End element of the (sub-)path or None for the last busbar of the path.

Zabs Impedance magnitude for the intersection in Ohm.

reverse

0 Search intersection in:forward direction;

1 Search intersection in:reverse direction.

Rcut (out)

Resistance value of the intersection on the line or branch in Ohm.

Xcut (out)

Reactance value of the intersection on the line or branch in Ohm.

distance (out)

Length of the intersection on the line or branch in km.

RETURNS

The line or branch of the intersction or None if no intersection could be found.

GetAll

Returns all objects in the path definition.

```
list SetPath.GetAll()
```

RETURNS

The set of objects.

GetBranches

Returns all branches in the path definition.

```
list SetPath.GetBranches([int reverse])
```

ARGUMENTS

reverse (optional)

- | | |
|----------|---|
| 0 | Sort the branches in forward direction; |
| 1 | Sort the branches in reverse direction. |

RETURNS

The set of branches.

GetBuses

Returns all busbars and terminals in the path definition.

```
list SetPath.GetBuses()
```

RETURNS

The set of busbars and terminals.

GetImpedanceAtPos

Determines the intersection of the (sub-)path and the given relative distance.

```
[DataObject object,
float Rcut,
float Xcut,
float distance] SetPath.GetImpedanceAtPos(DataObject start,
                                           DataObject end,
                                           float cutPositionPercent,
                                           float reverse)
```

ARGUMENTS

start Start element of the (sub-)path or None for the first busbar of the path.

end End element of the (sub-)path or None for the last busbar of the path.

cutPositionPercent

Distance, relative to the (sub-)path, for the intersection in %.

reverse

- | | |
|----------|---|
| 0 | Search intersection in:forward direction; |
| 1 | Search intersection in:reverse direction. |

Rcut (out)

Resistance value of the intersection on the line or branch in Ohm.

Xcut (out)

Reactance value of the intersection on the line or branch in Ohm.

distance (out)

Length of the intersection on the line or branch in km.

RETURNS

The line or branch of the intersection or None if no intersection could be found.

GetNode

Returns the terminal for the given branch.

```
DataObject SetPath.GetNode(DataObject branch,
                             [int reverse])
```

ARGUMENTS

branch Branch to get the terminal from.

reverse (optional)

0 (default) Get terminal in forward direction;

1 Get terminal in reverse direction.

RETURNS

The terminal or None if not found.

GetPathFolder

Returns the default folder for storing path objects.

```
DataObject SetPath.GetPathFolder([int create])
```

ARGUMENTS

create (optional)

0 Return only if the folder exists.

1 Create the folder if it does not exist.

RETURNS

DataObject Default folder for storing path.

None Default folder does not exist or could not be created.

GetRelay

Returns the relay for the given branch.

```
DataObject SetPath.GetRelay(DataObject branch,
                              [int reverse,]
                              [int relType])
```

ARGUMENTS

branch Branch to get the relay from.

reverse (optional)

0 (default) Get relay in forward direction;

1 Get relay in reverse direction.

relType (optional)

- 0 (default)** Get any relay;
- 1** Get overcurrent relays only;
- 2** Get distance relays only.

RETURNS

The relay or None if no relay is present.

NextRelayBranch

Returns the next branch in the given direction with an installed relay.

```
DataObject SetPath.NextRelayBranch(DataObject branch,
                                     [int reverse,]
                                     [int relType])
```

ARGUMENTS

branch Branch to start the search from.

reverse (optional)

- 0 (default)** Search in forward direction;
- 1** Search in reverse direction.

relType (optional)

- 0 (default)** Search any relay;
- 1** Search overcurrent relays only;
- 2** Search distance relays only.

RETURNS

The found branch or None.

5.5.13 SetPrj

Overview

[GetFontID](#)
[SetFontFor](#)

GetFontID

Determines the ID for given font. The font is automatically internally registered if it has not been used before.

```
int SetPrj.GetFontID(const char* fontName,
                    int fontSize,
                    [int fontStyle = 0]
                    )
```

ARGUMENTS

<i>fontName</i>	Font name
<i>fontSize</i>	Font size
<i>fontStyle</i> (optional)	Bitfield if bold, italic and/or underline
0	Regular (no style used)
1	Bold
2	Italic
3	Bold and italic
4	Underline

RETURNS

Returns the font ID. The value is always greater than zero.

SetFontFor

Sets a font for a specified group of text boxes.

```
None SetPrj.SetFontFor(int sglOrBlock,
                        int labelResultOrTitle,
                        int nodesOrBranches,
                        string fontName,
                        int fontSize,
                        int fontStyle
                        )
```

ARGUMENTS

<i>sglOrBlock</i>	Font settings for single line or block diagrams
0	Single line diagrams
1	Block diagrams
<i>labelResultOrTitle</i>	Type of text box to be modified.
0	Labels
1	Results
2	Title and Legends
<i>nodesOrBranches</i>	Type of parent object
0	Nodes
1	Branches

<i>fontName</i>	Font name
<i>fontSize</i>	Font size
<i>fontStyle</i>	Font style

- | | |
|---|-----------------|
| 1 | Bold |
| 2 | Italic |
| 3 | Bold and italic |
| 4 | Underline |

5.5.14 SetScenario

Overview

[Check](#)
[Default](#)
[Print](#)

Check

Checks the scenario configuration. The action is identical to pressing the corresponding button in the dialog.

NB: This function is only available if called on the configuration (SetScenario) of the currently active project.

```
int IntScenario.Check()
```

RETURNS

- | | |
|---|---|
| 0 | Ok, check did not reveal any problems |
| 1 | Not ok, check found some problems. See the output window for details. |

Default

Resets the scenario configuration to the default, built-in configuration. The action is identical to pressing the corresponding button in the dialog.

NB: This function is only available if no scenario is active and called on the configuration (SetScenario) of the currently active project.

```
None IntScenario.Default()
```

Print

Prints the scenario configuration to the output window. The action is identical to pressing the corresponding button in the dialog.

NB: This function is only available if called on the configuration (SetScenario) of the currently active project.

```
None IntScenario.Print()
```

5.5.15 SetSelect

Overview

[AddRef](#)
[All](#)
[AllAsm](#)
[AllBars](#)
[AllBreakers](#)
[AllClosedBreakers](#)
[AllElm](#)
[AllLines](#)
[AllLoads](#)
[AllOpenBreakers](#)
[AllSym](#)
[AllTypLne](#)
[Clear](#)
[GetAll](#)

AddRef

Adds a reference to the objects to the existing selection.

```
None SetSelect.AddRef(DataObject O)  
None SetSelect.AddRef(list S)
```

ARGUMENTS

- | | |
|----------|-------------------|
| <i>O</i> | An object. |
| <i>S</i> | A set of objects. |

All

Returns all objects in the selection.

```
list SetSelect.All()
```

RETURNS

The set of objects

AllAsm

Returns all asynchronous machines in the selection.

```
list SetSelect.AllAsm()
```

RETURNS

The set of objects

AllBars

Returns all busbars and terminals in the selection.

```
list SetSelect.AllBars()
```

RETURNS

The set of objects

AllBreakers

Returns all breakers in the selection.

```
list SetSelect.AllBreakers()
```

RETURNS

The set of objects

AllClosedBreakers

Returns all closed breakers in the selection.

```
list SetSelect.AllClosedBreakers()
```

RETURNS

The set of objects

AllElm

Returns all elements (Elm*) in the selection.

```
list SetSelect.AllElm()
```

RETURNS

The set of containing objects

AllLines

Returns all lines and line routes in the selection.

```
list SetSelect.AllLines()
```

RETURNS

The set of objects

AllLoads

Returns all loads in the selection.

```
list SetSelect.AllLoads()
```


RETURNS

The set of objects

AllOpenBreakers

Returns all open breakers in the selection.

```
list SetSelect.AllOpenBreakers()
```

RETURNS

The set of objects

AllSym

Returns all synchronous machines in the selection.

```
list SetSelect.AllSym()
```

RETURNS

The set of objects

AllTypLne

Returns all line types in the selection.

```
list SetSelect.AllTypLne()
```

RETURNS

The set of objects

Clear

Clears (deletes) the selection.

```
None SetSelect.Clear()
```

GetAll

Returns all objects in the selection which are of the class 'ClassName'.

```
list SetSelect.GetAll(str ClassName)
```

ARGUMENTS

ClassName

The object class name.

RETURNS

The set of objects

5.5.16 SetTabgroup

Overview

[Activate](#)
[Close](#)
[CloseTab](#)
[ExportAllReportDocuments](#)
[ExportAllTableReports](#)
[GetTabCount](#)
[GetTabObject](#)
[GetTabTitle](#)
[GetTabType](#)
[IsClosed](#)
[IsInMainWindow](#)
[MoveTab](#)
[MoveTabs](#)
[MoveTabToMainWindow](#)
[MoveTabToNewFloatingGroup](#)
[MoveToMainWindow](#)
[MoveToNewFloatingWindow](#)

Activate

This function is not supported in GUI-less mode.

Activates the tab group.

Calling this method before opening Graphic or Text Editor tabs will ensure that they are opened in this group.

```
None SetTabgroup.Activate()
```

Close

This function is not supported in GUI-less mode.

Closes all tabs in the tab group, effectively closing the complete tab group.

```
None SetTabgroup.Close()
```

SEE ALSO

[SetTabgroup.IsClosed\(\)](#)

CloseTab

This function is not supported in GUI-less mode.

Closes the specified tab.

```
None SetTabgroup.CloseTab(int tabIndex)
```

ARGUMENTS

tabIndex The index of the desired tab in the group. The first tab always has index 0.

ExportAllReportDocuments

This function is not supported in GUI-less mode.

Exports all report documents (displayed by PDF Viewer tabs) in the tab group to the specified folder.

If no folder path is given, a folder selection dialog will pop up, allowing to manually select a folder.

The names of the exported files are chosen based on the name of the corresponding report document objects and are automatically adapted to avoid overwriting existing files.

```
int SetTabgroup.ExportAllReportDocuments([str folderPath])
```

ARGUMENTS

folderPath (optional)

The path to the folder the report documents should be exported to. If not given, a folder selection dialog will pop up.

RETURNS

An error code:

- 0** No error occurred, export was successful.
- 1** User cancelled the folder selection dialog.
- 2** The specified folder path does not point to an existing folder.
- 3** User has no write access to the folder specified by the folder path.
- 4** This tab group does not contain any report documents.

ExportAllTableReports

This function is not supported in GUI-less mode.

Exports all tabular reports contained in the tab group in the selected format to the specified folder.

If no folder path is given, a folder selection dialog will pop up, allowing to manually select a folder.

The names of the exported files are chosen based on the name of the corresponding tabular report objects and are automatically adapted to avoid overwriting existing files.

```
int SetTabgroup.ExportAllTableReports(int format,
                                     [str folderPath]
                                     )
```

ARGUMENTS

format The desired export format, specified by one of these values:

- 0** Excel (xlsx)
- 1** HTML

folderPath (optional)

The path to the folder the tabular reports should be exported to. If not given, a folder selection dialog will pop up.

RETURNS

An error code:

- 0** No error occurred, export was successful.
- 1** User cancelled the folder selection dialog.
- 2** The specified folder path does not point to an existing folder.
- 3** User has no write access to the folder specified by the folder path.
- 4** This tab group does not contain any tabular reports.

GetTabCount

This function is not supported in GUI-less mode.

Returns the number of tabs in this tab group.

```
int SetTabgroup.GetTabCount ()
```

RETURNS

The number of tabs in this tab group.

GetTabObject

This function is not supported in GUI-less mode.

Returns the object associated with the tab at the given index. Please note that not all tabs have an associated object.

```
DataObject SetTabgroup.GetTabObject (int tabIndex)
```

ARGUMENTS

tabIndex The index of the desired tab in the group. The first tab always has index 0.

RETURNS

If the specified tab has an associated object this method returns one of these types:

SetDeskpage Graphics Page

GrpPage Plot Page

IntTextref Text reference (used by Text Editor tabs stored in Desktop)

ComTableport Tabular Report (only if report is stored in Desktop)

IntReportdoc Report document (displayed by PDF Viewer tab)

If the tab has no associated object or the given index is out of bounds, this method returns None.

GetTabTitle

This function is not supported in GUI-less mode.

Returns the title of the tab at the given index.

```
str SetTabgroup.GetTabTitle(int tabIndex)
```

ARGUMENTS

tabIndex The index of the desired tab in the group. The first tab always has index 0.

RETURNS

The title of the specified tab (empty if index is out of bounds).

GetTabType

This function is not supported in GUI-less mode.

Returns the type of the tab at the given index.

```
int SetTabgroup.GetTabType(int tabIndex)
```

ARGUMENTS

tabIndex The index of the desired tab in the group. The first tab always has index 0.

RETURNS

The type of the specified tab:

- | | |
|-----------|---|
| -1 | Error, the given tab index is out of bounds. |
| 0 | Graphic (Diagram, Plot, etc.) |
| 1 | Text Editor |
| 2 | Tabular Report |
| 3 | Variation Manager |
| 4 | Report document (displayed by PDF Viewer tab) |
| 5 | Data Manager |
| 6 | Network Model Manager |

IsClosed

This function is not supported in GUI-less mode.

Determines whether the group is closed. Closed groups cannot be used for any operations.

Please note that opened tab groups are automatically closed as soon as they become empty, e.g. when their last remaining tab is closed or moved to another group.

```
int SetTabgroup.IsClosed()
```

RETURNS

The state of the group:

- | | |
|----------|----------------------|
| 0 | The group is open. |
| 1 | The group is closed. |

SEE ALSO

[SetTabgroup.Close\(\)](#)

IsInMainWindow

This function is not supported in GUI-less mode.

Determines whether the group is docked to the main window or if it is floating.

```
int SetTabgroup.IsInMainWindow()
```

RETURNS

The location of the group:

- 0** The group is floating.
- 1** The group is docked to the main window.

SEE ALSO

[SetTabgroup.MoveToMainWindow\(\)](#), [SetTabgroup.MoveToNewFloatingWindow\(\)](#)

MoveTab

This function is not supported in GUI-less mode.

Moves the tab at the specified index to the end of the given tab group.

```
None SetTabgroup.MoveTab(int tabIndex,  
                          DataObject otherTabGroup)
```

ARGUMENTS

tabIndex The index of the desired tab in this group. The first tab always has index 0.

otherTabGroup
 The tab group (*SetTabgroup*) the tab should be moved to.

MoveTabs

This function is not supported in GUI-less mode.

Moves all tabs of the group to the end of the specified group.

Please note that this group is automatically closed after all of its tabs are moved.

```
None SetTabgroup.MoveTabs(DataObject otherTabGroup)
```

ARGUMENTS

otherTabGroup
 The tab group (*SetTabgroup*) the tabs should be moved to.

MoveTabToMainWindow

This function is not supported in GUI-less mode.

Moves the specified tab to a new group docked in the main window.

```
DataObject SetTabgroup.MoveTabToMainWindow(int tabIndex)
```

ARGUMENTS

tabIndex The index of the desired tab in the group. The first tab always has index 0.

RETURNS

The new tab group.

MoveTabToNewFloatingGroup

This function is not supported in GUI-less mode.

Moves the specified tab to a new floating group.

```
DataObject SetTabgroup.MoveTabToNewFloatingGroup(int tabIndex)
```

ARGUMENTS

tabIndex The index of the desired tab in the group. The first tab always has index 0.

RETURNS

The new tab group.

MoveToMainWindow

This function is not supported in GUI-less mode.

Docks this group to the main window.

If the group is already docked to the main window, calling this method has no effect.

```
None SetTabgroup.MoveToMainWindow()
```

SEE ALSO

[SetTabgroup.IsInMainWindow\(\)](#), [SetTabgroup.MoveToNewFloatingWindow\(\)](#)

MoveToNewFloatingWindow

This function is not supported in GUI-less mode.

Moves this group to a new floating window.

If the group is already located in a floating window, calling this method has no effect.

```
None SetTabgroup.MoveToNewFloatingWindow()
```

SEE ALSO

[SetTabgroup.IsInMainWindow\(\)](#), [SetTabgroup.MoveToMainWindow\(\)](#)

5.5.17 SetTboxconfig

Overview

[Check](#)
[GetAvailableButtons](#)
[GetDisplayedButtons](#)
[Purge](#)
[SetDisplayedButtons](#)

Check

Checks buttons to be displayed for invalid or duplicate ids and prints error messages.

```
int SetTboxconfig.Check()
```

RETURNS

0	No errors found.
1	Errors found.

GetAvailableButtons

Gets buttons available for selected tool bar.

```
str SetTboxconfig.GetAvailableButtons()
```

RETURNS

String ids of all buttons available for selected tool bar; ids are separated by '\n'.

GetDisplayedButtons

Gets buttons configured to be displayed in selected tool bar.

```
str SetTboxconfig.GetDisplayedButtons()
```

RETURNS

String ids of all buttons configured to be displayed in selected tool bar; ids are separated by '\n'.

Purge

Purges buttons to be displayed from invalid or duplicate ids.

```
int SetTboxconfig.Purge()
```

RETURNS

0	No problems found.
1	Configuration was adapted.

SetDisplayedButtons

Sets buttons to be displayed in selected tool bar. Purges given buttons from invalid or duplicate buttons (duplicate separators or breaks are kept).

```
int SetTboxconfig.SetDisplayedButtons(str buttonIds)
```

ARGUMENTS

buttonIds String ids of all buttons to be set as displayed buttons; ids have to be separated by '\n'

RETURNS

- 0** Given buttons were stored without modification.
- 1** Given buttons were purged from invalid or duplicate ids.

5.5.18 SetTime

Overview

[Date](#)
[GetTimeUTC](#)
[SetTime](#)
[SetTimeUTC](#)
[Time](#)

Date

Sets date component to current system date.

```
None SetTime.Date()
```

SEE ALSO

[SetTime.Time\(\)](#), [SetTime.SetTimeUTC\(\)](#)

GetTimeUTC

Gets UTC time as seconds since 01.01.1970 00:00 GMT.

```
int SetTime.GetTimeUTC()
```

RETURNS

UTC time as seconds since 01.01.1970 00:00 GMT.

SEE ALSO

[SetTime.SetTimeUTC\(\)](#)

SetTime

Sets the time in the current year. There is no restriction to the values for H, M and S, except for the fact that negative values are interpreted as zero. Values higher than 24 or 60 will be processed normally by adding the hours, minutes and seconds into an absolute time, from which a new hour-of-year, hour-of-day, minutes and seconds are calculated.

```
None SetTime.SetTime(float H,  
                     [float M,]  
                     [float S]  
                     )
```

ARGUMENTS

H The hours
M (optional)
 The minutes
S (optional)
 The seconds

SetTimeUTC

Sets date and time to given time. The time must be given in UTC format as seconds since 01.01.1970 00:00 GMT.

```
None SetTime.SetTimeUTC(int time)
```

ARGUMENTS

time UTC time in seconds since 01.01.1970 00:00 GMT

SEE ALSO

[SetTime.Date\(\)](#), [SetTime.Time\(\)](#)

Time

Sets time component to current system time.

```
None SetTime.Time()
```

SEE ALSO

[SetTime.Date\(\)](#), [SetTime.SetTimeUTC\(\)](#)

5.5.19 SetUser

Overview

[GetNumProcesses](#)

GetNumProcesses

This function returns the actual number of processes for parallel computation.

```
int SetUser.GetNumProcesses()
```

RETURNS

The actual number of processes for parallel computation.

5.5.20 SetVipage

Overview

Close
DoAutoScaleX
DoAutoScaleY
GetOrInsertPlot
InsertPlot
MigratePage
SetAdaptX
SetAutoScaleX
SetResults
SetScaleX
SetStyle
SetTile
SetXVar
Show

Close

Closes the graphic page, if currently shown, and deletes it from the database.

```
int SetVipage.Close()
```

RETURNS

- 0 On success, no error occurred.
- 1 Otherwise

DoAutoScaleX

Scales the x-axes of all plots on the virtual instrument panel automatically.

```
None SetVipage.DoAutoScaleX()
```

DoAutoScaleY

Scales the y-axes of all plots on the virtual instrument panel automatically.

```
None SetVipage.DoAutoScaleY()
```

GetOrInsertPlot

Get or create a virtual instrument of the virtual instrument panel.

```
DataObject SetVipage.GetOrInsertPlot (str name,
                                     [str class,]
                                     [int create]
                                     )
```

DEPRECATED NAMES

GetVI

ARGUMENTS

name Name of virtual instrument

class='VisPlot' (optional)
 classname of virtual instrument.

create (optional)
 Possible values:

- | | |
|----------|--|
| 0 | do not create new virtual instrument |
| 1 | create virtual instrument if it does not exist already |

RETURNS

Virtual instrument

InsertPlot

Creates a copy of the virtual instrument passed and displays the copy on this panel.

```
DataObject SetVipage.InsertPlot(DataObject vi)
```

DEPRECATED NAMES

CreateVI

ARGUMENTS

vi The virtual instrument which will be copied. Only virtual instruments are allowed (classname 'Vis*').

RETURNS

Returns the created virtual instrument.

MigratePage

Converts this SetVipage to the new plot framework introduced in PowerFactory 2021, creating a GrpPage:

- The original SetVipage will remain unchanged
- The created GrpPage will initially be hidden. Use GrpPage.Show() to make it visible.

```
None SetVipage.MigratePage()
```

RETURNS

The migrated plot page (GrpPage)

SetAdaptX

Sets the Adapt Scale option of the x-scale.

```
None SetVipage.SetAdaptX(int mode,
                        [float trigger]
                        )
```

ARGUMENTS

mode Possible values:

0	off
1	on

trigger (optional)

Trigger value, unused if mode is off or empty

SetAutoScaleX

Sets automatic scaling mode of the x-scale. A warning is issued if an invalid mode is passed to the function.

```
None SetVipage.SetAutoScaleX(int mode)
```

ARGUMENTS

mode Possible values:

0	never
1	after simulation
2	during simulation

SetResults

Sets default results object of virtual instrument panel.

```
None SetVipage.SetResults(DataObject res)
```

ARGUMENTS

res Result object to set or None to reset. Valid result object is any of class ElmRes, IntComtrade and IntComtradeset.

SetScaleX

Sets x-axis scale. A function call without arguments sets the Auto Scale setting to On without changing the scale itself.

```
None SetVipage.SetScaleX()
None SetVipage.SetScaleX(float min,
                          float max,
                          [int log]
                          )
```

ARGUMENTS

min (optional)

Minimum of x-scale.

max (optional)

Maximum of x-scale.

log (optional)

Possible values:

0	linear
1	logarithmic

SetStyle

Sets style of virtual instrument panel. A warning message is issued in the case that a style with the given name does not exist.

```
None SetVipage.SetStyle(str name)
```

ARGUMENTS

name Style Name

SetTitle

Rearranges the virtual instrument on the panel.

```
None SetVipage.SetTile([int tile])
```

ARGUMENTS

tile=1 (optional) **tile =0** arrange virtual instruments automatically (like tiles)
 tile=1 arrange them horizontally

SetXVar

Sets x-axis variable. If The default x-axis variable (time) is set if no argument is passed.

```
None SetVipage.SetXVar()
None SetVipage.SetXVar(DataObject obj,
                        str varname
                        )
```

ARGUMENTS

- obj (optional)*
x-axis object
- varname (optional)*
variable of obj

Show

Displays the plot page in the desktop.

```
int SetVipage.Show()
```

RETURNS

- 0** On success, no error occurred.
- 1** Otherwise

5.6 Others

5.6.1 BlkDef

Overview

[Check](#)
[Compile](#)
[Encrypt](#)
[GetChecksum](#)
[Pack](#)
[PackAsMacro](#)
[ResetThirdPartyModule](#)
[SetThirdPartyModule](#)

Check

Verifies the DSL model equations.

```
int BlkDef.Check()
```

RETURNS

- 0** BlkDef is OK.
- 1** Error during parsing.
- 2** Compiled model, no check is possible.

Compile

Compiles the model to a DLL. Can be called on an already compiled model. A study case of a project has to be active.

```
None BlkDef.Compile([string modelPath])
```

ARGUMENTS

modelPath (optional)

Full path to a location where the model should be stored. Leave empty to use default.

Encrypt

Encrypts this block definition. It has to be packed as macro before.

```
int BlkDef.Encrypt ([int removeObjectHistory])
```

ARGUMENTS

removeObjectHistory (optional)

Handling of unencrypted object history in database, e.g. used by project versions or by undo:

- 0** Do not remove.
- 1** Do remove (default).
- 2** Show dialog and ask.

RETURNS

- 0** On success.
- 1** On error.

SEE ALSO

[BlkDef.PackAsMacro\(\)](#)

GetChecksum

```
str BlkDef.GetChecksum()
```

DEPRECATED NAMES

CalculateChecksum

RETURNS

The checksum of the block definition (0000-0000-0000-0000 for frames).

Pack

Copies all used macros (i.e. referenced BlkDef) to this block.

```
int BlkDef.Pack ([int inclGlobalLib])
```

ARGUMENTS

inclGlobalLib (optional)

Include also objects from DIgSILENT Library (default = 1)

RETURNS

- 0** On success.
- 1** On error.

PackAsMacro

Collects all equations, stores them to this model and deletes block diagram and all macro references.

```
int BlkDef.PackAsMacro()
```

RETURNS

- 0** On success.
- 1** On error.

SEE ALSO

[BlkDef.Encrypt\(\)](#)

ResetThirdPartyModule

Resets the third party licence. Only possible for non-encrypted, non-compiled blocks. Requires masterkey licence for third party module currently set.

```
int BlkDef.ResetThirdPartyModule()
```

RETURNS

- 0** On success.
- 1** On error.

SetThirdPartyModule

Sets the third party licence to a specific value. Only possible for non-encrypted, non-compiled blocks with no third party licence set so far. Requires masterkey licence for third party module to be set.

```
int BlkDef.SetThirdPartyModule(str companyCode,  
                                str moduleCode  
                                )
```

ARGUMENTS

companyCode

D isplay name or numeric value of company code.

moduleCode

D isplay name or numeric value of third party module.

RETURNS

- 0** On success.
- 1** On error.

5.6.2 BlkSig

Overview

[GetFromSigName](#)
[GetToSigName](#)

GetFromSigName

```
str BlkSig.GetFromSigName()
```

RETURNS

The name of the output from which the signal is connected. In cases of no connection, an empty string.

GetToSigName

```
str BlkSig.GetToSigName()
```

RETURNS

The name of the input to which the signal is connected. In cases of no connection, an empty string.

5.6.3 ChaVecfile

Overview

[Update](#)

Update

Reloads the file from disk. Same behaviour like button update.

```
int ChaVecfile.Update([int msgOn = 0])
```

ARGUMENTS

msgOn (optional)

Reporting of errors:

- | | |
|----------|--|
| 0 | No error message is shown in case that the file can not be loaded (default). |
| 1 | Emit an error message in case that the file can not be loaded. |

RETURNS

The number of samples (rows) read from the file.

5.6.4 CimArchive

Overview

[ConvertToBusBranch](#)

ConvertToBusBranch

Performs the conversion of *CimModels* in the selected *CimArchive* to bus-branch model representation.

Note that this function will work only on CGMES v2.4.15 *CimArchives*. Conversion of *CimArchives* to bus-branch model representation for other CGMES versions is not supported.

```
None CimArchive.ConvertToBusBranch()
```

EXAMPLE

This example converts a *CimArchive* to a Bus-Branch model. The *CimArchive* is selected in the archive variable in External objects.

```
import powerfactory
app = powerfactory.GetApplicationExt()

script = app.GetCurrentScript()
[error, archive] = script.GetExternalObject("archive")
archive.ConvertToBusBranch();
```

5.6.5 CimModel

Overview

[DeleteParameterAtIndex](#)
[GetAttributeEnumerationType](#)
[GetModelsReferencingThis](#)
[GetParameterCount](#)
[GetParameterNamespace](#)
[GetParameterValue](#)
[HasParameter](#)
[RemoveParameter](#)
[SetAssociationValue](#)
[SetAssociationValue](#)
[SetAttributeEnumeration](#)
[SetAttributeEnumeration](#)
[SetAttributeValue](#)
[SetAttributeValue](#)

DeleteParameterAtIndex

Removes the parameter (attribute, or association) value at the given index.

```
None CimModel.DeleteParameterAtIndex(str parameter, int index)
```

ARGUMENTS

parameter

Full-name specifier of the attribute, or association
(e.g. "Model.profile")

index

Index of the parameter

EXAMPLE

This example deletes the "Model.profile" parameter of the *CimModel* at index 1. The *CimModel* is selected in the model variable in External objects.

```
import powerfactory
app = powerfactory.GetApplicationExt()

script = app.GetCurrentScript()
[error, model] = script.GetExternalObject("model")
model.DeleteParameterAtIndex("Model.profile", 1)
```

GetAttributeEnumerationType

Returns the enumeration type of the attribute.

```
str CimModel.GetAttributeEnumerationType(str attribute)
```

ARGUMENTS

attribute Full-name specifier of the attribute (e.g. "GeneratingUnit.genControlSource")

GetModelsReferencingThis

Returns all CIM models (CimModel) that reference the calling model.

```
list CimModel.GetModelsReferencingThis()
```

RETURNS

CIM models that reference the calling model. The order of the set is undefined.

EXAMPLE

This example prints the profile of CIM models referencing a selected *CimModel*. The *CimModel* is selected in the model variable in External objects.

```
import powerfactory
app = powerfactory.GetApplicationExt()

script = app.GetCurrentScript()
[error, model] = script.GetExternalObject("model")
cimModels = model.GetModelsReferencingThis()
for cimModel in cimModels:
    app.PrintInfo(cimModel.GetParameterValue("Model.profile"))
```

GetParameterCount

Returns the number of parameters (attribute, or association) of given type.

```
int CimModel.GetParameterCount(str parameter)
```

ARGUMENTS

parameter

Full-name specifier of the attribute, or association
(e.g. "Model.profile")

EXAMPLE

This example prints the "Model.profile" attributes for all CIM models from the active project.

```
import powerfactory
app = powerfactory.GetApplicationExt()

project = app.GetActiveProject()
cimModels = project.GetContents("*.CimModel", 1)
for cimModel in cimModels :
    nProfiles = cimModel.GetParameterCount("Model.profile")
    app.PrintInfo("Model %s has %d profiles" % (cimModel, nProfiles))
    for i in range(nProfiles):
        profile = cimModel.GetParameterValue("Model.profile", i)
        app.PrintInfo("Profile:%d = %s" % (i, profile))
```

GetParameterNamespace

Returns the namespace of the parameter (attribute, or association).

```
str CimModel.GetParameterNamespace(str parameter)
```

ARGUMENTS

parameter

Full-name specifier of the attribute, or association
(e.g. "Model.created")

EXAMPLE

This example prints the namespace of the "Model.created" parameter for the *CimModel* that is selected in the model variable in External objects.

```
import powerfactory
app = powerfactory.GetApplicationExt()

script = app.GetCurrentScript()
[error, model] = script.GetExternalObject("model")
namespace = model.GetParameterNamespace("Model.created")
app.PrintInfo(namespace)
```

GetParameterValue

Returns the value of the parameter (attribute, or association) at the given index if available. If the parameter (attribute, or association) is not available, or the index is out of bounds the function returns an empty string.

```
str CimModel.GetParameterValue(str parameter, [int index])
```

ARGUMENTS

parameter
Full-name specifier of the attribute, or association
(e.g. "Model.modelingAuthoritySet")

index
Index of the parameter:
0 Default index

EXAMPLE

This example prints the "Model.modelingAuthoritySet" parameter for a *CimModel*. The *CimModel* is selected in the model variable in External objects.

```
import powerfactory
app = powerfactory.GetApplicationExt()

script = app.GetCurrentScript()
[error, model] = script.GetExternalObject("model")
app.PrintInfo(model.GetParameterValue("Model.modelingAuthoritySet"))
```

HasParameter

Checks whether the CimModel has the parameter (attribute, or association) specified.

```
int CimModel.HasParameter(str parameter)
```

ARGUMENTS

parameter
Full-name specifier of the attribute, or association
(e.g. "Model.modelingAuthoritySet")

RETURNS

1 if parameter is specified
0 if parameter is not specified

EXAMPLE

This example checks if a selected *CimModel* contains the "Model.scenarioTime" parameter. The *CimModel* is selected in the model variable in External objects.

```
import powerfactory
app = powerfactory.GetApplicationExt()

script = app.GetCurrentScript()
[error, model] = script.GetExternalObject("model")
hasParameter = model.HasParameter("Model.scenarioTime")
if hasParameter == 1:
    app.PrintInfo("Parameter exists.")
else:
    app.PrintInfo("Parameter does not exist.")
```

RemoveParameter

Removes all occurrences of the parameter (attribute, or association).

```
None CimModel.RemoveParameter(str parameter)
```

ARGUMENTS

parameter
Full-name specifier of the attribute, or association
(e.g. "Model.scenarioTime")

EXAMPLE

This example removes the "Model.scenarioTime" parameter from all CIM models from the active project.

```
import powerfactory
app = powerfactory.GetApplicationExt()

project = app.GetActiveProject()
cimModels = project.GetContents("*.CimModel", 1)
for cimModel in cimModels :
    cimModel.RemoveParameter("Model.scenarioTime")
```

SetAssociationValue

Adds the association if not available yet, and sets its value at the given index. If the association is already added, the function sets a new value at the given index only.

```
None CimModel.SetAssociationValue(str association,
                                   str value,
                                   [int index])
```

ARGUMENTS

association
Full-name specifier of the association (e.g. "Model.DependentOn")

value
Value of the association

index
Index of the association:
0 Default index

EXAMPLE

This example sets the "Model.DependentOn" parameter at index 1 for a selected *CimModel*. The *CimModel* is selected in the model variable in External Objects.

```
import powerfactory
app = powerfactory.GetApplicationExt()

script = app.GetCurrentScript()
[error, model] = script.GetExternalObject("model")
dependentOnId = "21df3d4d-3f82-4998-be21-772e3d2d573f"
model.SetAssociationValue("Model.DependentOn", dependentOnId, 1)
```

SetAssociationValue

Adds the association if not available yet, and sets its namespace and value. If the association is already added, the function sets its namespace and value only.

```
None CimModel.SetAssociationValue(str association,  
                                  str value,  
                                  str nspace)
```

ARGUMENTS

- attribute* Full-name specifier of the association (e.g. "Model.DependentOn")
- value* Value of the association
- nspace* Namespace of the association (e.g. "md")

EXAMPLE

This example sets the "Model.DependentOn" parameter for a selected *CimModel*. The *CimModel* is selected in the model variable in External objects.

```
import powerfactory  
app = powerfactory.GetApplicationExt()  
  
script = app.GetCurrentScript()  
[error, model] = script.GetExternalObject("model")  
dependentOnId = "21df3d4d-3f82-4998-be21-772e3d2d573f"  
model.SetAssociationValue("Model.DependentOn", dependentOnId, "md")
```

SetAttributeEnumeration

Adds the attribute if not available yet, and sets its enumeration type and value. If the attribute is already added, the function sets its enumeration type and value only.

```
None CimModel.SetAttributeEnumeration(str attribute,  
                                       str enumerationType,  
                                       str value)
```

ARGUMENTS

- attribute* Full-name specifier of the attribute (e.g. "GeneratingUnit.genControlSource")
- enumerationType* Enumeration type of the attribute (e.g. "GeneratorControlSource")
- value* Value of the enumeration (e.g. "offAGC")

SetAttributeEnumeration

Adds the attribute if not available yet, and sets its namespace, enumeration type and value. If the attribute is already added, the function sets its namespace, enumeration type and value only.

```
None CimModel.SetAttributeEnumeration(str attribute,  
                                     str enumerationType,  
                                     str value,  
                                     str nspace)
```

ARGUMENTS

attribute Full-name specifier of the attribute (e.g. "GeneratingUnit.genControlSource")

enumerationType Enumeration type of the attribute (e.g. "GeneratorControlSource")

value Value of the attribute (e.g. "offAGC")

nspace Namespace of the attribute (e.g. "cim")

SetAttributeValue

Adds the attribute if not available yet, and sets its value at the given index. If the attribute is already added, the function sets a new value at the given index only.

```
None CimModel.SetAttributeValue(str attribute,  
                               str value,  
                               [int index])
```

ARGUMENTS

attribute Full-name specifier of the attribute (e.g. "Model.modelingAuthoritySet")

value Value of the attribute

index Index of the attribute:

0 Default index

EXAMPLE

This example sets the "Model.profile" parameter at index 2 for a selected *CimModel*. The *CimModel* is selected in the *equipmentModel* variable in External objects.

```
import powerfactory  
app = powerfactory.GetApplicationExt()  
  
script = app.GetCurrentScript()  
[error, equipmentModel] = script.GetExternalObject("equipmentModel")  
equipmentShortCircuit = "http://entsoe.eu/CIM/EquipmentShortCircuit/3/1"  
equipmentModel.SetAttributeValue("Model.profile",  
                                equipmentShortCircuit,  
                                2)
```

SetAttributeValue

Adds the attribute if not available yet, and sets its namespace and value. If the attribute is already added, the function sets its namespace and value only.

```
None CimModel.SetAttributeValue(str attribute,
                                str value,
                                str nspace)
```

ARGUMENTS

attribute Full-name specifier of the attribute (e.g. "Model.modelingAuthoritySet")

value Value of the attribute

nspace Namespace of the attribute (e.g. "md")

EXAMPLE

This example sets the "Model.modelingAuthoritySet" parameter for all CIM models from the active project.

```
import powerfactory
app = powerfactory.GetApplicationExt()

project = app.GetActiveProject()
cimModels = project.GetContents("*.CimModel", 1)
for cimModel in cimModels :
    cimModel.SetAttributeValue("Model.modelingAuthoritySet", "mas", "md")
```

5.6.6 CimObject

Overview

[DeleteParameterAtIndex](#)
[GetAttributeEnumerationType](#)
[GetObjectsReferencingThis](#)
[GetObjectsWithSameId](#)
[GetParameterCount](#)
[GetParameterNamespace](#)
[GetParameterValue](#)
[GetPfObjects](#)
[HasParameter](#)
[RemoveParameter](#)
[SetAssociationValue](#)
[SetAssociationValue](#)
[SetAttributeEnumeration](#)
[SetAttributeEnumeration](#)
[SetAttributeValue](#)
[SetAttributeValue](#)

DeleteParameterAtIndex

Removes the parameter (attribute, or association) value at the given index.

```
None CimObject.DeleteParameterAtIndex(str parameter,
                                       int index)
```

ARGUMENTS

<i>parameter</i>	Full-name of the attribute, or association (e.g. "TopologicalIsland.TopologicalNodes")
<i>index</i>	Index of the parameter

EXAMPLE

This example removes all "TopologicalIsland.TopologicalNodes" parameters values from all "TopologicalIsland" CIM objects in the active project.

```
import powerfactory
app = powerfactory.GetApplicationExt()

project = app.GetActiveProject()
topoNodesParameter = "TopologicalIsland.TopologicalNodes"
cimObjects = project.GetContents("*.CimObject", 1)
for cimObject in cimObjects :
    if cimObject.GetAttribute("cimClass") == "TopologicalIsland":
        nNodes = cimObject.GetParameterCount(topoNodesParameter)
        app.PrintInfo("TP-island %s has %d TP-nodes" % (cimObject, nNodes))
        for i in range(nNodes, -1, -1):
            cimObject.DeleteParameterAtIndex(topoNodesParameter, i)
```

GetAttributeEnumerationType

Returns the enumeration type of the attribute.

```
str CimObject.GetAttributeEnumerationType(str attribute)
```

ARGUMENTS

<i>attribute</i>	Full-name of the attribute (e.g. "SynchronousMachine.shortCircuitRotorType")
------------------	--

EXAMPLE

This example prints the enumeration type of the "SynchronousMachine.shortCircuitRotorType" attribute of a "SynchronousMachine" *CimObject*. The *CimObject* is selected in the *cimObject* variable in External Objects.

```
import powerfactory
app = powerfactory.GetApplicationExt()

script = app.GetCurrentScript()
[error, cimObject] = script.GetExternalObject("cimObject")
attributeName = "SynchronousMachine.shortCircuitRotorType"
app.PrintInfo(cimObject.GetAttributeEnumerationType(attributeName))
```

GetObjectsReferencingThis

Returns all CIM objects (CimObject) that reference the calling object. The set of objects returned is also determined by the DependentOn and Supersedes references set in parent CIM model objects. In order for a CIM object to reference another CIM object, the parent CIM model of the former object has to hold a reference to the parent CIM model of the later object.

```
list CimObject.GetObjectsReferencingThis()
```

RETURNS

CIM objects that reference the calling object. The order of the set is undefined.

EXAMPLE

This example prints all CIM objects which reference the "SynchronousMachine" *CimObject*. The SynchronousMachine is selected in the machine variable in External Objects.

```
import powerfactory
app = powerfactory.GetApplicationExt()

script = app.GetCurrentScript()
[error, machine] = script.GetExternalObject("machine")
cimObjects = machine.GetObjectsReferencingThis()
for cimObject in cimObjects:
    app.PrintInfo(cimObject)
```

GetObjectsWithSameId

Returns all CIM objects (CimObject) that have the same Resource ID as this object.

```
list CimObject.GetObjectsWithSameId()
```

RETURNS

CIM objects that have the same Resource ID as this object.

EXAMPLE

This example prints all CIM objects with the same CIM RDF ID as the "SynchronousMachine" *CimObject*. The SynchronousMachine is selected in the machine variable in External Objects.

```
import powerfactory
app = powerfactory.GetApplicationExt()

script = app.GetCurrentScript()
[error, machine] = script.GetExternalObject("machine")
cimObjects = machine.GetObjectsWithSameId()
for cimObject in cimObjects:
    app.PrintInfo(cimObject)
```

GetParameterCount

Returns the number of parameters (attribute, or association) of given type.

```
int CimObject.GetParameterCount(str parameter)
```

ARGUMENTS

parameter

Full-name of the attribute, or association
(e.g. "TopologicalIsland.TopologicalNodes")

EXAMPLE

This example prints the IDs of all "TopologicalNode" CIM objects from all "TopologicalIsland" CIM objects in the active project.

```
import powerfactory
app = powerfactory.GetApplicationExt()

project = app.GetActiveProject()
topoNodesParameter = "TopologicalIsland.TopologicalNodes"
cimObjects = project.GetContents("*.CimObject", 1)
for cimObject in cimObjects :
    if cimObject.GetAttribute("cimClass") == "TopologicalIsland":
        nNodes = cimObject.GetParameterCount(topoNodesParameter)
        app.PrintInfo("TP-island %s has %d TP-nodes" % (cimObject, nNodes))
        for i in range(nNodes):
            nodeId = cimObject.GetParameterValue(topoNodesParameter, i)
            app.PrintInfo("CIM RDF ID of TP-node %d is: %s" % (i, nodeId))
```

GetParameterNamespace

Returns the namespace of the parameter (attribute, or association).

```
str CimObject.GetParameterNamespace(str parameter)
```

ARGUMENTS

parameter

Full-name of the attribute, or association
(e.g. "IdentifiedObject.name")

EXAMPLE

This example prints the namespace of the "IdentifiedObject.name" parameter of a *CimObject*. The *CimObject* is selected in the *acLineSegment* variable in External Objects.

```
import powerfactory
app = powerfactory.GetApplicationExt()

script = app.GetCurrentScript()
[error, acLineSegment] = script.GetExternalObject("acLineSegment")
app.PrintInfo(acLineSegment.GetParameterNamespace("IdentifiedObject.name"))
```

GetParameterValue

Returns the value of the parameter (attribute, or association) at the given index if available. If the parameter (attribute, or association) is not available, or the index is out of bounds the function returns an empty string.

```
str CimObject.GetParameterValue(str parameter, [int index])
```

ARGUMENTS

parameter

Full-name of the attribute, or association
(e.g. "IdentifiedObject.name")

index Index of the parameter:
 0 Default index

EXAMPLE

This example prints the "IdentifiedObject.name" parameter of a selected *CimObject*. The *CimObject* is selected in the *cimObject* variable in External Objects.

```
import powerfactory
app = powerfactory.GetApplicationExt()

script = app.GetCurrentScript()
[error, cimObject] = script.GetExternalObject("cimObject")
app.PrintInfo(cimObject.GetParameterValue("IdentifiedObject.name"))
```

GetPfObjects

Returns all PF objects that have the same Resource ID as this CIM object.

```
list CimObject.GetPfObjects()
```

RETURNS

PF objects that have the same Resource ID as this CIM object.

EXAMPLE

This example prints all PowerFactory objects with the same CIM RDF ID as the "Synchronous-Machine" *CimObject*. The SynchronousMachine is selected in the *machine* variable in External objects.

```
import powerfactory
app = powerfactory.GetApplicationExt()

script = app.GetCurrentScript()
[error, machine] = script.GetExternalObject("machine")
pfObjects = machine.GetPfObjects()
for pfObject in pfObjects:
    app.PrintInfo(pfObject)
```

HasParameter

Checks whether the *CimObject* has the parameter (attribute, or association) specified.

```
int CimObject.HasParameter(str parameter)
```

ARGUMENTS

parameter
 Full-name of the attribute, or association
 (e.g. "IdentifiedObject.name")

RETURNS

1 if parameter is specified
0 if parameter is not specified

EXAMPLE

This example checks if a *CimObject* contains the "IdentifiedObject.name" parameter. The *CimObject* is selected in the *cimObject* variable in External Objects.

```
import powerfactory
app = powerfactory.GetApplicationExt()
script = app.GetCurrentScript()
[error, cimObject] = script.GetExternalObject("cimObject")
hasParameter = cimObject.HasParameter("IdentifiedObject.name")
if hasParameter == 1:
    app.PrintInfo("Parameter exists.")
else:
    app.PrintInfo("Parameter does not exist.")
```

RemoveParameter

Removes all occurrences of the parameter (attribute, or association).

```
None CimObject.RemoveParameter(str parameter)
```

ARGUMENTS

parameter

Full-name of the attribute, or association
(e.g. "SynchronousMachine.shortCircuitRotorType")

EXAMPLE

This example removes the "SynchronousMachine.shortCircuitRotorType" parameter from all "SynchronousMachine" CIM objects in the active project.

```
import powerfactory
app = powerfactory.GetApplicationExt()

project = app.GetActiveProject()
cimObjects = project.GetContents("*.CimObject", 1)
for cimObject in cimObjects :
    if cimObject.GetAttribute("cimClass") == "SynchronousMachine":
        cimObject.RemoveParameter("SynchronousMachine.shortCircuitRotorType")
```

SetAssociationValue

Adds the association if not available yet, and sets its value at the given index. If the association is already added, the function sets a new value at the given index only.

```
None CimObject.SetAssociationValue(str association,
                                   str value,
                                   [int index]
                                   )
```

ARGUMENTS

association

Full-name of the association (e.g. "Equipment.EquipmentContainer")

value

Value of the association

index Index of the association:

0 Default index

SetAssociationValue

Adds the association if not available yet, and sets its namespace and value. If the association is already added, the function sets its namespace and value only.

```
None CimObject.SetAssociationValue(str association,
                                   str value,
                                   str nspace)
```

ARGUMENTS

attribute Full-name of the association (e.g. "NonConformLoad.LoadGroup")

value Value of the association

nspace Namespace of the association (e.g. "cim")

EXAMPLE

This example adds the missing association "NonConformLoad.LoadGroup" on "NonConformLoad" CIM objects in the active project. The association is set to the object defined in the loadGroup variable in External Objects.

```
import powerfactory
app = powerfactory.GetApplicationExt()

project = app.GetActiveProject()
script = app.GetCurrentScript()
[error, loadGroup] = script.GetExternalObject("loadGroup")
loadGroupId = loadGroup.GetAttribute("resID")
loadGroupParameter = "NonConformLoad.LoadGroup"
cimObjects = project.GetContents("*.CimObject", 1)
for cimObject in cimObjects :
    cimClass = cimObject.GetAttribute("cimClass")
    if cimClass == "NonConformLoad":
        # concrete CimObject has the about parameter set to 0
        if cimObject.GetAttribute("about") == 0:
            if cimObject.HasParameter(loadGroupParameter) == 0:
                cimObject.SetAssociationValue(loadGroupParameter,
                                              loadGroupId,
                                              "cim")
```

SetAttributeEnumeration

Adds the attribute if not available yet, and sets its enumeration type and value. If the attribute is already added, the function sets its enumeration type and value only.

```
None CimObject.SetAttributeEnumeration(str attribute,
                                       str enumerationType,
                                       str value)
```


ARGUMENTS

- attribute* Full-name of the attribute (e.g. "SynchronousMachine.shortCircuitRotorType")
- enumerationType* Enumeration type of the attribute (e.g. "ShortCircuitRotorKind")
- value* Value of the enumeration (e.g. "salientPole1")

EXAMPLE

This example adds the missing attribute "SynchronousMachine.shortCircuitRotorType" on "SynchronousMachine" CIM objects in the active project.

```
import powerfactory
app = powerfactory.GetApplicationExt()

parameter = "SynchronousMachine.shortCircuitRotorType"
type = "ShortCircuitRotorKind"
value = "salientPole1"

project = app.GetActiveProject()
cimObjects = project.GetContents("*.CimObject", 1)
for cimObject in cimObjects :
    cimClass = cimObject.GetAttribute("cimClass")
    if cimClass == "SynchronousMachine":
        # concrete CimObject has the about parameter set to 0
        if cimObject.GetAttribute("about") == 0:
            if cimObject.HasParameter(parameter) == 0:
                cimObject.SetAttributeEnumeration(parameter, type, value)
```

SetAttributeEnumeration

Adds the attribute if not available yet, and sets its namespace, enumeration type and value. If the attribute is already added, the function sets its namespace, enumeration type and value only.

```
None CimObject.SetAttributeEnumeration(str attribute,
                                       str enumerationType,
                                       str value,
                                       str nspace)
```

ARGUMENTS

- attribute* Full-name of the attribute (e.g. "SynchronousMachine.shortCircuitRotorType")
- enumerationType* Enumeration type of the attribute (e.g. "ShortCircuitRotorKind")
- value* Value of the attribute (e.g. "salientPole1")
- nspace* Namespace of the attribute (e.g. "cim")

EXAMPLE

This example adds the missing attribute "SynchronousMachine.shortCircuitRotorType" on "SynchronousMachine" CIM objects in the active project.

```
import powerfactory
app = powerfactory.GetApplicationExt()
```

```

parameter = "SynchronousMachine.shortCircuitRotorType"
type = "ShortCircuitRotorKind"
value = "salientPole1"
namespace = "cim"

project = app.GetActiveProject()
cimObjects = project.GetContents("*.CimObject", 1)
for cimObject in cimObjects :
    if cimObject.GetAttribute("cimClass") == "SynchronousMachine":
        # concrete CimObject has the about parameter set to 0
        if cimObject.GetAttribute("about") == 0:
            if cimObject.HasParameter(parameter) == 0:
                cimObject.SetAttributeEnumeration(parameter, type, value, namespace)

```

SetAttributeValue

Adds the attribute if not available yet, and sets its value at the given index. If the attribute is already added, the function sets a new value at the given index only.

```

None CimObject.SetAttributeValue(str attribute,
                                str value,
                                [int index])

```

ARGUMENTS

attribute Full-name of the attribute (e.g. "IdentifiedObject.name")

value Value of the attribute

index Index of the attribute:

0 Default index

EXAMPLE

This example adds the prefix "Load_" to the "IdentifiedObject.name" attribute for all concrete "NonConformLoad" CIM objects in the active project.

```

import powerfactory
app = powerfactory.GetApplicationExt()

project = app.GetActiveProject()
cimObjects = project.GetContents("*.CimObject", 1)
for cimObject in cimObjects :
    cimClass = cimObject.GetAttribute("cimClass")
    if cimClass == "NonConformLoad":
        # concrete CimObject has the about parameter set to 0
        if cimObject.GetAttribute("about") == 0:
            oldName = cimObject.GetParameterValue("IdentifiedObject.name")
            newName = "Load_" + oldName
            cimObject.SetAttributeValue("IdentifiedObject.name", newName)

```

SetAttributeValue

Adds the attribute if not available yet, and sets its namespace and value. If the attribute is already added, the function sets its namespace and value only.

```
None CimObject.SetAttributeValue(str attribute,
                                str value,
                                str nspace)
```

ARGUMENTS

attribute Full-name of the attribute (e.g. "Equipment.aggregate")

value Value of the attribute

nspace Namespace of the attribute (e.g. "cim")

EXAMPLE

This example sets the "Equipment.aggregate" attribute to "false" for all concrete "NonConformLoad" CIM objects in the active project.

```
import powerfactory
app = powerfactory.GetApplicationExt()

project = app.GetActiveProject()
cimObjects = project.GetContents("*.CimObject", 1)
for cimObject in cimObjects :
    cimClass = cimObject.GetAttribute("cimClass")
    if cimClass == "NonConformLoad":
        # concrete CimObject has the about parameter set to 0
        if cimObject.GetAttribute("about") == 0:
            cimObject.SetAttributeValue("Equipment.aggregate", "false", "cim")
```

5.6.7 GrpPage

Overview

[ChangeStyle](#)
[DoAutoScale](#)
[DoAutoScaleX](#)
[DoAutoScaleY](#)
[GetOrInsertCurvePlot](#)
[GetOrInsertPlot](#)
[GetPlot](#)
[RemovePage](#)
[SetAutoScaleModeX](#)
[SetAutoScaleModeY](#)
[SetLayoutMode](#)
[SetResults](#)
[SetScaleTypeX](#)
[SetScaleTypeY](#)
[SetScaleX](#)
[SetScaleY](#)
[Show](#)

ChangeStyle

Applies the plot style identified by the given name to all plots on this page.

```
int GrpPage.ChangeStyle(str styleName)
```

ARGUMENTS

styleName
Name of the style template to apply.

RETURNS

0 On success.
1 On error.

DoAutoScale

Adapts axis ranges of all plots on the page such that they show the entire data range.

```
None GrpPage.DoAutoScale([int axisDimension])
```

ARGUMENTS

axisDimension (optional)
Limits auto-scaling to one dimension. Possible values:

0 Scale only x-axes.
1 Scale only y-axes.

DoAutoScaleX

Adapts x-axis ranges of all plots on the page such that they show the entire data range.

```
None GrpPage.DoAutoScaleX()
```

DoAutoScaleY

Adapts y-axis ranges of all plots on the page such that they show the entire data range.

```
None GrpPage.DoAutoScaleY()
```

GetOrInsertCurvePlot

Finds a curve plot by name, or creates it if not found.

This function is deprecated. Please use the more general function [GrpPage.GetOrInsertPlot\(\)](#) instead.

```
DataObject GrpPage.GetOrInsertCurvePlot(str name,  
                                         [int create = 1]  
                                         )
```

ARGUMENTS

name Name of plot-

create (optional)

Possible values:

- 0** Do not create new plot if it does not exist already.
- 1** Create plot if it does not exist already (default).

RETURNS

Found or created PltLinebarplot object.

GetOrInsertPlot

Finds a plot by name, or creates it if not found.

```
DataObject GrpPage.GetOrInsertPlot(str name,
                                   int type,
                                   [int create = 1]
                                   )
```

ARGUMENTS

name Name of plot.

type Type of plot to create:

- 1** Curve plot.
- 2** XY plot: curve plot whose x-axis mode is set to 'XY'.
- 3** Discrete bar plot: curve plot whose x-axis mode is set to 'discrete'.
- 4** Vector plot.
- 6** Eigenvalue plot: scatter plot displaying modal eigenvalues.
- 7** Mode polar plot: vector plot displaying state vectors of an eigenmode.
- 8** Mode bar plot: bar plot displaying state vectors of an eigenmode.
- 10** Time-overcurrent plot.
- 11** Time-distance plot.
- 12** Impedance R-X plot.
- 13** Relay operational limits plot.
- 14** Biased current differential plot.
- 16** Short-circuit sweep plot.
- 20** Network graphic: shows a single line diagram on a plot page.

create (optional)

Possible values:

- 0** Do not create new plot if it does not exist already.
- 1** Create plot if it does not exist already (default).

RETURNS

Found or created plot object:

None No matching plot with name was found or created.

PltVectorplot Vector plot, mode polar plot.

PltNetgraphic Network graphic.

PltLinebarplot All other plot types.

GetPlot

Returns the plot on this page with the given name.

```
DataObject GrpPage.GetPlot(str name)
```

ARGUMENTS

name Name of the plot to look for.

RETURNS

Plot object if found, or None otherwise.

SEE ALSO

[GrpPage.GetOrInsertPlot\(\)](#)

RemovePage

Closes the graphic page, if currently shown, and deletes it from the database.

```
None GrpPage.RemovePage()
```

SetAutoScaleModeX

Defines whether the x-axes on the page should automatically adapt their range on data changes.

```
None GrpPage.SetAutoScaleModeX(int mode)
```

ARGUMENTS

mode Possible values:

- 0** Off (do not react to data changes).
- 1** Adapt scale after calculation has finished.
- 2** Adapt scale during live plotting.

SetAutoScaleModeY

Defines whether the y-axes on the page should automatically adapt their range on data changes.

```
None GrpPage.SetAutoScaleModeY(int mode)
```

ARGUMENTS

<i>mode</i>	Possible values:
0	Off (do not react to data changes).
1	Adapt scale after calculation has finished.
2	Adapt scale during live plotting.

SetLayoutMode

Defines the automatic arrangement of plots on the page.

```
None GrpPage.SetLayoutMode(int mode)
```

ARGUMENTS

<i>mode</i>	Possible values:
0	Off (do not arrange plots automatically).
1	Arrange plots vertically.
2	Arrange plots on grid.

SetResults

Sets the default results object of page.

```
None GrpPage.SetResults(DataObject res)
```

ARGUMENTS

<i>res</i>	Result object to set or None to reset. Valid result object is any of class ElmRes, IntComtrade and IntComtradeset.
------------	--

SetScaleTypeX

Sets the scale type (linear, logarithmic) of all x-axes on the page.

```
None GrpPage.SetScaleTypeX(int scaleType)
```

ARGUMENTS

<i>scaleType</i>	Possible values:
0	linear
1	logarithmic

SetScaleTypeY

Set the scale type (linear, logarithmic, dB) of all y-axes on the page.

```
None GrpPage.SetScaleTypeY(int scaleType)
```

ARGUMENTS

scaleType

Possible values:

0	linear
1	logarithmic
2	dB

SetScaleX

Sets the scale of all x-axes on the page.

```
None GrpPage.SetScaleX(float min,  
                        float max  
                        )
```

ARGUMENTS

<i>min</i>	Minimum of x-scale.
<i>max</i>	Maximum of x-scale.

SetScaleY

Sets the scale of all y-axes on the page.

```
None GrpPage.SetScaleY(float min,  
                        float max  
                        )
```

ARGUMENTS

<i>min</i>	Minimum of y-scale.
<i>max</i>	Maximum of y-scale.

Show

Displays the diagram page in the desktop.

```
int GrpPage.Show()
```

RETURNS

0	On success, no error occurred.
1	Otherwise.

5.6.8 IntAddonvars

Overview

[AddDouble](#)
[AddDoubleMatrix](#)
[AddDoubleVector](#)
[AddInteger](#)
[AddIntegerVector](#)
[AddObject](#)
[AddObjectVector](#)
[AddString](#)
[RemoveParameter](#)
[RenameClass](#)
[RenameParameter](#)
[SetConstraint](#)

AddDouble

Adds a new double parameter to the Data Extension configuration object.

```
int IntAddonvars.AddDouble(str parameterName,
                           str desc,
                           str unitText,
                           float initialValue
                           )
```

ARGUMENTS

parameterName The name of the new parameter
desc The description of the new parameter
unitText The unit of the new parameter
initialValue The initial value of the new parameter

RETURNS

0 attribute was successfully added
-1 error (object cannot be modified)
-2 error (parameter name contains illegal characters)
row error (parameter with same name already exists in returned row)

AddDoubleMatrix

Adds a new double vector parameter to the Data Extension configuration object.

```
int IntAddonvars.AddDoubleMatrix(str parameterName,
                                  str desc,
                                  int initialRows,
                                  int initialColumns,
                                  str unitText,
                                  float initialValue)
```

ARGUMENTS

<i>parameterName</i>	The name of the new parameter
<i>desc</i>	The description of the new parameter
<i>initialRows</i>	The initial number of rows for the matrix
<i>initialColumns</i>	The initial number of columns for the matrix
<i>unitText</i>	The unit of the new parameter
<i>initialValue</i>	The initial value for the elements

RETURNS

0	attribute was successfully added
-1	error (object cannot be modified)
-2	error (parameter name contains illegal characters)
row	error (parameter with same name already exists in returned row)

AddDoubleVector

Adds a new double vector parameter to the Data Extension configuration object.

```
int IntAddonvars.AddDoubleVector(str parameterName,
                                str desc,
                                int initialSize,
                                str unitText,
                                float initialValue
                                )
```

ARGUMENTS

<i>parameterName</i>	The name of the new parameter
<i>desc</i>	The description of the new parameter
<i>initialSize</i>	The initial size of the vector
<i>unitText</i>	The unit of the new parameter
<i>initialValue</i>	The initial value for the elements

RETURNS

0	attribute was successfully added
-1	error (object cannot be modified)
-2	error (parameter name contains illegal characters)
row	error (parameter with same name already exists in returned row)

AddInteger

Adds a new integer parameter to the Data Extension configuration object.

```
int IntAddonvars.AddInteger(str parameterName,
                           str desc,
                           str unitText,
                           int initialValue
                           )
```

ARGUMENTS

parameterName The name of the new parameter

desc The description of the new parameter

unitText The unit of the new parameter

initialValue The initial value of the new parameter

RETURNS

0 attribute was successfully added

-1 error (object cannot be modified)

-2 error (parameter name contains illegal characters)

row error (parameter with same name already exists in returned row)

AddIntegerVector

Adds a new integer vector parameter to the Data Extension configuration object.

```
int IntAddonvars.AddIntegerVector(str parameterName,
                                  str desc,
                                  int initialSize,
                                  str unitText,
                                  int initialValue)
```

ARGUMENTS

parameterName The name of the new parameter

desc The description of the new parameter

initialSize The initial size of the vector

unitText The unit of the new parameter

initialValue The initial value for the elements

RETURNS

0 attribute was successfully added

-1 error (object cannot be modified)

-2 error (parameter name contains illegal characters)

row error (parameter with same name already exists in returned row)

AddObject

Adds a new string parameter to the Data Extension configuration object.

```
int IntAddonvars.AddObject(str parameterName,
                           str desc,
                           str classFilter
                           )
```

ARGUMENTS

parameterName
The name of the new parameter

desc
The description of the new parameter

classFilter
The filter for the objects which are allowed for selection

RETURNS

Zero if attribute was successfully added. One based row number if there already is a parameter with the same name. Returns -1 if the object cannot be modified.

AddObjectVector

Adds a new object vector parameter to the Data Extension configuration object.

```
int IntAddonvars.AddObjectVector(str parameterName,
                                  str desc,
                                  int initialSize,
                                  str classFilter
                                  )
```

ARGUMENTS

parameterName
The name of the new parameter

desc
The description of the new parameter

initialSize
The initial size of the vector

classFilter
The filter for the objects which are allowed for selection

RETURNS

0 attribute was successfully added

-1 error (object cannot be modified)

-2 error (parameter name contains illegal characters)

row error (parameter with same name already exists in returned row)

AddString

Adds a new string parameter to the Data Extension configuration object.

```
int IntAddonvars.AddString(str parameterName,
                           str desc,
                           str unitText,
                           str initialValue
                           )
```

ARGUMENTS

<i>parameterName</i>	The name of the new parameter
<i>desc</i>	The description of the new parameter
<i>unitText</i>	The unit of the new parameter
<i>initialValue</i>	The initial value of the new parameter

RETURNS

0	attribute was successfully added
-1	error (object cannot be modified)
-2	error (parameter name contains illegal characters)
row	error (parameter with same name already exists in returned row)

RemoveParameter

Removes the given parameter from the Data Extension configuration.

```
None IntAddonvars.RemoveParameter(str parameterName)
```

ARGUMENTS

<i>parameterName</i>	The name of the parameter to be removed
----------------------	---

RenameClass

Renames the class from the Data Extension configuration.

```
int IntAddonvars.RenameClass(str newClassName)
```

ARGUMENTS

<i>newClassName</i>	The new name of the parameter
---------------------	-------------------------------

RETURNS

0	parameter was successfully renamed
-1	error (new class name contains illegal characters or is too long)
-2	error (current configuration object does not define a custom class)

RenameParameter

Renames the given parameter from the Data Extension configuration.

```
int IntAddonvars.RenameParameter(str oldPparameterName,
                                  str newPparameterName)
```

ARGUMENTS

oldParameterName

The old name of the parameter

newParameterName

The new name of the parameter

RETURNS

- 0** parameter was successfully renamed
- 1** error (new parameter name contains illegal characters)
- 2** error (old parameter name does not exist)
- 3** error (new parameter name already exists)

SetConstraint

Adds a constraint for the parameter to the Data Extension configuration object.

The arguments passed must be convertible into the configured data type for the parameter. Upper and lower bounds are mutually exclusive with a list of values. An empty string should be passed when a constraint should not be used or removed.

```
int IntAddonvars.SetConstraint(str parameterName,  
                               str minValue,  
                               str maxValue,  
                               str allowedValues  
                               )
```

ARGUMENTS

parameterName

The name of the parameter to be modified

minValue The minimum value*maxValue*

The maximum value

allowedValues

List of the allowed values (;-separated)

RETURNS

- 0** ok
- 1** error (parameter does not exist)
- 2** error (upper/lower bounds and list of values are mutually exclusive)
- 3** error (underlying type does not support constraints)
- 4** error (upper/lower bounds cannot be used for strings)
- 5** error (the values passed cannot be converted into the underlying type)

5.6.9 IntCase

Overview

[Activate](#)
[ApplyNetworkState](#)
[ApplyStudyTime](#)
[Consolidate](#)
[CreateMissingSetTrigger](#)
[Deactivate](#)
[SetStudyTime](#)

Activate

Activates the study case. Deactivates other study cases first.

```
int IntCase.Activate()
```

RETURNS

0 on success
1 on error

ApplyNetworkState

For a study case in a combined project, copy the network state from another case.

Copies the active grids, scenarios and network variations configuration to the current case. The data will be added to any already existing configuration.

```
int IntCase.ApplyNetworkState(DataObject other)
```

ARGUMENTS

other The source Study Case to copy data from

RETURNS

0 On success
1 Source object is not an IntCase object
2 Case where function is called on is not the active case
3 Source case is not from active project
4 Source Study Case is not from a source project in a combined project
5 Other error. Details are given in an error message

ApplyStudyTime

For a study case in a combined project, apply the study time from another study case.

```
int IntCase.ApplyStudyTime(DataObject other)
```

ARGUMENTS

other The source study case to copy study time from

RETURNS

- 0** On success
- 1** Source object is not an IntCase object
- 2** Study case where function is called on is not the active case
- 3** Source case is not from active project
- 4** Source case is not from a project part of a combined project

Consolidate

Changes that are recorded in a project's active Variations are permanently applied to the Network Data folder (like right mouse button Consolidate Network Variation)

Note: Modified scenarios are not saved!

Works only:

- For active study cases
- If a network variation is active

```
int IntCase.Consolidate()
```

RETURNS

- 0** On success
- 1** If an error has occurred

SEE ALSO

[IntScheme.Consolidate\(\)](#)

CreateMissingSetTrigger

Creates missing trigger objects (SetTrigger) in the 'Triggers' folder for all relevant scales (Tri* objects). The study case must be active for the function to take effect.

```
int IntCase.CreateMissingSetTrigger()
```

RETURNS

- 0** On success
- 1** Error, e.g. no active project or study case is not activated.

Deactivate

De-activates the study case.

```
int IntCase.Deactivate()
```

RETURNS

- 0** on success
- 1** on error

SetStudyTime

Sets the current Study Case time to seconds since 01.01.1970 00:00:00. Use IntCase.iStudyTime for getting current Study Case time.

```
None IntCase.SetStudyTime(int dateTime)
```

ARGUMENTS

dateTime Seconds since 01.01.1970 00:00:00.

5.6.10 IntComtrade

Overview

[ConvertToASCIIFormat](#)
[ConvertToBinaryFormat](#)
[FindColumn](#)
[FindMaxInColumn](#)
[FindMinInColumn](#)
[GetAnalogueDescriptions](#)
[GetColumnValues](#)
[GetDescription](#)
[GetDigitalDescriptions](#)
[GetNumberOfAnalogueSignalDescriptions](#)
[GetNumberOfColumns](#)
[GetNumberOfDigitalSignalDescriptions](#)
[GetNumberOfRows](#)
[GetObjectValue](#)
[GetSignalHeader](#)
[GetUnit](#)
[GetValue](#)
[GetVariable](#)
[Load](#)
[Release](#)
[SortAccordingToColumn](#)

ConvertToASCIIFormat

Creates new comtrade configuration and data files in ASCII format in the file system directory of the original files. The new configuration file is linked automatically to a new IntComtrade object created in the same **PowerFactory** folder like this object. An existing IntComtrade object is already in ASCII format when its parameter 'Binary' is set to 0.

```
int IntComtrade.ConvertToASCIIFormat ()
```

RETURNS

- 0** File successfully converted.
- 1** Error occurred, e.g. file is already in ASCII format.

ConvertToBinaryFormat

Creates new comtrade configuration and data files in binary format in the file system directory of the original files. The new configuration file is linked automatically to a new `IntComtrade` object created in the same **PowerFactory** folder like this object. An existing `IntComtrade` object is already in binary format when its parameter 'Binary' is set to 1.

```
int IntComtrade.ConvertToBinaryFormat()
```

RETURNS

- 0** File successfully converted.
- 1** Error occurred, e.g. file is already in binary format.

FindColumn

Returns the first column matching the variable name. `IntComtrade.Load()` must be called before using this function.

```
int IntComtrade.FindColumn(str variable,
                           [int startCol]
                           )
```

ARGUMENTS

- variable* The variable name to look for.
- startCol (optional)*
The index of the column at which to start the search.

RETURNS

- ≥ 0 The column index found.
- < 0 The column with name variable was not found.

FindMaxInColumn

Find the maximum value of the variable in the given column. `IntComtrade.Load()` must be called before using this function.

```
[int row,
float value] IntComtrade.FindMaxInColumn(int column)
```

ARGUMENTS

- column* The column index.
- value (optional, out)*
The maximum value found. The value is 0. in case that the maximum value was not found.

RETURNS

- < 0 The maximum value of column was not found.
- ≥ 0 The row with the maximum value of the column.

FindMinInColumn

Find the minimum value of the variable in the given column. [IntComtrade.Load\(\)](#) must be called before using this function.

```
[int row,
float value] IntComtrade.FindMinInColumn(int column)
```

ARGUMENTS

column The column index.

value (optional, out)

The minimum value found. The value is 0. in case that the minimum value was not found.

RETURNS

< 0 The minimum value of column was not found.

≥ 0 The row with the minimum value of the column.

GetAnalogueDescriptions

Get the descriptions of the analogue channel Please note that the comtrade info file contains proprietary data from PFM. Info files not written by DIgSILENT PFM are not supported. [IntComtrade.Load\(\)](#) must be called before using this function.

```
str IntComtrade.GetAnalogueDescriptions(int index)
```

ARGUMENTS

index Digital channel index.

RETURNS

Descriptions for analogue channel in the comtrade info file.

GetColumnValues

Get complete column values. [IntComtrade.Load\(\)](#) must be called before using this function.

```
int IntComtrade.GetColumnValues(DataObject dataVector,
                                int column)
```

ARGUMENTS

dataVector

IntVec which will be filled with column values.

column The column index. -1 for default (e.g. time).

RETURNS

= 0 Column values were found.

= 1 dataVector is None.

= 2 dataVector is not of class IntVec.

= 3 Column index is out of range.

GetDescription

Get the description of a column. [IntComtrade.Load\(\)](#) must be called before using this function.

```
str IntComtrade.GetDescription([int column],
                               [int short]
                               )
```

ARGUMENTS

column (optional)

The column index. The description name of the default variable is returned if the parameter is not passed to the function.

short (optional)

0	long desc. (default)
1	short description

RETURNS

Returns the description which is empty in case that the column index is not part of the data.

GetDigitalDescriptions

Get the descriptions of the digital channel. Please note that the comtrade info file contains proprietary data from PFM. Info files not written by DlgSILENT PFM are not supported. [IntComtrade.Load\(\)](#) must be called before using this function.

```
str IntComtrade.GetDigitalDescriptions(int index)
```

ARGUMENTS

index Digital channel index

RETURNS

Descriptions for digital channel in the comtrade info file.

GetNumberOfAnalogueSignalDescriptions

Gets the number of descriptions for analogue channels in the comtrade info file. Please note that the comtrade info file contains proprietary data from PFM. Info files not written by DlgSILENT PFM are not supported. [IntComtrade.Load\(\)](#) must be called before using this function.

```
int IntComtrade.GetNumberOfAnalogueSignalDescriptions()
```

RETURNS

Number of descriptions for analogue channels in the comtrade info file.

GetNumberOfColumns

Returns the number of variables (columns) in result file excluding the default variable (e.g. time for time domain simulation). [IntComtrade.Load\(\)](#) must be called before using this function.

```
int IntComtrade.GetNumberOfColumns()
```

RETURNS

Number of variables (columns) in result file.

GetNumberOfDigitalSignalDescriptions

Get the number of descriptions for digital channels in the comtrade info file. Please note that the comtrade info file contains proprietary data from PFM. Info files not written by DlgSILENT PFM are not supported. [IntComtrade.Load\(\)](#) must be called before using this function.

```
int IntComtrade.GetNumberOfDigitalSignalDescriptions()
```

RETURNS

Number of descriptions for digital channels in the comtrade info file.

GetNumberOfRows

Returns the number of values per column (rows) stored in result object. [IntComtrade.Load\(\)](#) must be called before using this function.

```
int IntComtrade.GetNumberOfRows()
```

RETURNS

Returns the number of values per column stored in result object.

GetObjectValue

Returns a value from a result object for row iX of curve col. [IntComtrade.Load\(\)](#) must be called before using this function.

```
[int error,
DataObject o ] IntComtrade.GetObjectValue(int iX,
                                           [int col])
```

ARGUMENTS

o (out) The object retrieved from the data.

iX The row.

col (optional)

The curve number, which equals the variable or column number, first column value (time,index, etc.) is returned when omitted.

RETURNS

- 0** when ok
- 1** when iX out of bound
- 2** when col out of bound
- 3** when invalid value is returned from a sparse file. Sparse files are written e.g. by the contingency analysis, the value is invalid in case that it was not written, because it was below the recording limit. Result files created using DPL/Python are always full and will not return invalid values.

GetSignalHeader

Get the headline of the channel section in the comtrade info file. Please note that the comtrade info file contains proprietary data from PFM. Info files not written by DlgSILENT PFM are not supported. [IntComtrade.Load\(\)](#) must be called before using this function.

```
str IntComtrade.GetSignalHeader()
```

RETURNS

Headline of signal descriptions

GetUnit

Get the unit of a column. [IntComtrade.Load\(\)](#) must be called before using this function.

```
str IntComtrade.GetUnit([int column])
```

ARGUMENTS

column (optional)

The column index. The unit of the default variable is returned if the parameter is not passed to the function.

RETURNS

Returns the unit which is empty in case that the column index is not part of the data.

GetValue

Returns a value from a result object for row *iX* of curve *col*. [IntComtrade.Load\(\)](#) must be called before using this function.

```
[int error,
float d ] IntComtrade.GetValue(int iX,
                               [int col])
```

ARGUMENTS

d (out) The value retrieved from the data.

iX The row.

col (optional)

The curve number, which equals the variable or column number, first column value (time, index, etc.) is returned when omitted.

RETURNS

- 0** when ok
- 1** when *iX* out of bound
- 2** when *col* out of bound
- 3** when invalid value is returned from a sparse file. Sparse files are written e.g. by the contingency analysis, the value is invalid in case that it was not written, because it was below the recording limit. Result files created using DPL/Python are always full and will not return invalid values.

GetVariable

Get variable name of column. `IntComtrade.Load()` must be called before using this function.

```
str IntComtrade.GetVariable([int column])
```

ARGUMENTS

column (optional)

The column index. The variable name of the default variable is returned if the parameter is not passed to the function.

RETURNS

Returns the variable name which is empty in case that the column index is not part of the data.

Load

Loads the data of a result object (**IntComtrade**) in memory for reading.

```
None IntComtrade.Load()
```

Release

Releases the data loaded to memory. This function should be used whenever several result objects are processed in a loop. Data is always released from memory automatically after execution of the current script.

```
None IntComtrade.Release()
```

SortAccordingToColumn

Sorts all rows in the data loaded according to the given column. The `IntComtrade` itself remains unchanged. `IntComtrade.Load()` must be called before using this function.

```
int IntComtrade.SortAccordingToColumn(int column)
```

ARGUMENTS

col The column number.

RETURNS

- 0** The function executed correctly, the data was sorted correctly according to the given column.
- 1** The column with index column does not exist.

5.6.11 IntComtradeset

Overview

[FindColumn](#)
[FindMaxInColumn](#)
[FindMinInColumn](#)
[GetAnalogueDescriptions](#)
[GetColumnValues](#)
[GetDescription](#)
[GetDigitalDescriptions](#)
[GetNumberOfAnalogueSignalDescriptions](#)
[GetNumberOfColumns](#)
[GetNumberOfDigitalSignalDescriptions](#)
[GetNumberOfRows](#)
[GetObjectValue](#)
[GetSignalHeader](#)
[GetUnit](#)
[GetValue](#)
[GetVariable](#)
[Load](#)
[Release](#)
[SortAccordingToColumn](#)

FindColumn

Returns the first column matching the variable name. [IntComtradeset.Load\(\)](#) must be called before using this function.

```
int IntComtradeset.FindColumn(str variable,
                             [int startCol]
                             )
```

ARGUMENTS

variable The variable name to look for.

startCol (optional)
The index of the column at which to start the search.

RETURNS

- ≥ 0 The column index found.
- < 0 The column with name variable was not found.

FindMaxInColumn

Find the maximum value of the variable in the given column. [IntComtradeset.Load\(\)](#) must be called before using this function.

```
[int row,
float value] IntComtradeset.FindMaxInColumn(int column)
```


ARGUMENTS

column The column index.

value (optional, out)

The maximum value found. The value is 0. in case that the maximum value was not found.

RETURNS

< 0 The maximum value of column was not found.

≥ 0 The row with the maximum value of the column.

FindMinInColumn

Find the minimum value of the variable in the given column. [IntComtradeset.Load\(\)](#) must be called before using this function.

```
[int row,
float value] IntComtradeset.FindMinInColumn(int column)
```

ARGUMENTS

column The column index.

value (optional, out)

The minimum value found. The value is 0. in case that the minimum value was not found.

RETURNS

< 0 The minimum value of column was not found.

≥ 0 The row with the minimum value of the column.

GetAnalogueDescriptions

Get the descriptions of the analogue channel Please note that the comtrade info file contains proprietary data from PFM. Info files not written by DiGSILENT PFM are not supported. [IntComtradeset.Load\(\)](#) must be called before using this function.

```
str IntComtradeset.GetAnalogueDescriptions(int index)
```

ARGUMENTS

index Digital channel index.

RETURNS

Descriptions for analogue channel in the comtrade info file.

GetColumnValues

Get complete column values. [IntComtradeset.Load\(\)](#) must be called before using this function.

```
int IntComtradeset.GetColumnValues(DataObject dataVector,
int column)
```

ARGUMENTS

- dataVector* IntVec which will be filled with column values.
- column* The column index. -1 for default (e.g. time).

RETURNS

- = 0 Column values were found.
- = 1 dataVector is None.
- = 2 dataVector is not of class IntVec.
- = 3 Column index is out of range.

GetDescription

Get the description of a column. [IntComtradeset.Load\(\)](#) must be called before using this function.

```
str IntComtradeset.GetDescription([int column],
                                  [int short]
                                  )
```

ARGUMENTS

- column (optional)*
The column index. The description name of the default variable is returned if the parameter is not passed to the function.
- short (optional)*
- | | |
|----------|----------------------|
| 0 | long desc. (default) |
| 1 | short description |

RETURNS

Returns the description which is empty in case that the column index is not part of the data.

GetDigitalDescriptions

Get the descriptions of the digital channel Please note that the comtrade info file contains proprietary data from PFM. Info files not written by DigSILENT PFM are not supported. [IntComtradeset.Load\(\)](#) must be called before using this function.

```
str IntComtradeset.GetDigitalDescriptions(int index)
```

ARGUMENTS

- index* Digital channel index

RETURNS

Descriptions for digital channel in the comtrade info file.

GetNumberOfAnalogueSignalDescriptions

Gets the number of descriptions for analogue channels in the comtrade info file. Please note that the comtrade info file contains proprietary data from PFM. Info files not written by DlgSILENT PFM are not supported. [IntComtradeset.Load\(\)](#) must be called before using this function.

```
int IntComtradeset.GetNumberOfAnalogueSignalDescriptions()
```

RETURNS

Number of descriptions for analogue channels in the comtrade info file.

GetNumberOfColumns

Returns the number of variables (columns) in result file excluding the default variable (e.g. time for time domain simulation). [IntComtradeset.Load\(\)](#) must be called before using this function.

```
int IntComtradeset.GetNumberOfColumns()
```

RETURNS

Number of variables (columns) in result file.

GetNumberOfDigitalSignalDescriptions

Get the number of descriptions for digital channels in the comtrade info file. Please note that the comtrade info file contains proprietary data from PFM. Info files not written by DlgSILENT PFM are not supported. [IntComtradeset.Load\(\)](#) must be called before using this function.

```
int IntComtradeset.GetNumberOfDigitalSignalDescriptions()
```

RETURNS

Number of descriptions for digital channels in the comtrade info file.

GetNumberOfRows

Returns the number of values per column (rows) stored in result object. [IntComtradeset.Load\(\)](#) must be called before using this function.

```
int IntComtradeset.GetNumberOfRows()
```

RETURNS

Returns the number of values per column stored in result object.

GetObjectValue

Returns a value from a result object for row iX of curve col. [IntComtradeset.Load\(\)](#) must be called before using this function.

```
[int error,  
DataObject o ] IntComtradeset.GetObjectValue(int iX,  
                                              [int col])
```

ARGUMENTS

- o (out)* The object retrieved from the data.
- iX* The row.
- col (optional)*
 The curve number, which equals the variable or column number, first column value (time,index, etc.) is returned when omitted.

RETURNS

- 0** when ok
- 1** when iX out of bound
- 2** when col out of bound
- 3** when invalid value is returned from a sparse file. Sparse files are written e.g. by the contingency analysis, the value is invalid in case that it was not written, because it was below the recording limit. Result files created using DPL/Python are always full and will not return invalid values.

GetSignalHeader

Get the headline of the channel section in the comtrade info file. Please note that the comtrade info file contains proprietary data from PFM. Info files not written by DlgSILENT PFM are not supported. [IntComtradeset.Load\(\)](#) must be called before using this function.

```
str IntComtradeset.GetSignalHeader()
```

RETURNS

Headline of signal descriptions

GetUnit

Get the unit of a column. [IntComtradeset.Load\(\)](#) must be called before using this function.

```
str IntComtradeset.GetUnit([int column])
```

ARGUMENTS

- column (optional)*
 The column index. The unit of the default variable is returned if the parameter is nor passed to the function.

RETURNS

Returns the unit which is empty in case that the column index is not part of the data.

GetValue

Returns a value from a result object for row iX of curve col. [IntComtradeset.Load\(\)](#) must be called before using this function.

```
[int error,
float d    ] IntComtradeset.GetValue(int iX,
                                     [int col])
```

ARGUMENTS

- d (out)* The value retrieved from the data.
- iX* The row.
- col (optional)*
 The curve number, which equals the variable or column number, first column value (time,index, etc.) is returned when omitted.

RETURNS

- 0** when ok
- 1** when iX out of bound
- 2** when col out of bound
- 3** when invalid value is returned from a sparse file. Sparse files are written e.g. by the contingency analysis, the value is invalid in case that it was not written, because it was below the recording limit. Result files created using DPL/Python are always full and will not return invalid values.

GetVariable

Get variable name of column. [IntComtradeset.Load\(\)](#) must be called before using this function.

```
str IntComtradeset.GetVariable([int column])
```

ARGUMENTS

- column (optional)*
 The column index. The variable name of the default variable is returned if the parameter is not passed to the function.

RETURNS

Returns the variable name which is empty in case that the column index is not part of the data.

Load

Loads the data of a result object (**IntComtradeset**) in memory for reading.

```
None IntComtradeset.Load()
```

Release

Releases the data loaded to memory. This function should be used whenever several result objects are processed in a loop. Data is always released from memory automatically after execution of the current script.

```
None IntComtradeset.Release()
```

SortAccordingToColumn

Sorts all rows in the data loaded according to the given column. The **IntComtradeset** itself remains unchanged. [IntComtradeset.Load\(\)](#) must be called before using this function.

```
int IntComtradeset.SortAccordingToColumn(int column)
```

ARGUMENTS

col The column number.

RETURNS

- 0** The function executed correctly, the data was sorted correctly according to the given column.
- 1** The column with index column does not exist.

5.6.12 IntDataset

Overview

[AddRef](#)
[All](#)
[Clear](#)
[GetAll](#)

AddRef

Adds new reference(s) for passed object(s) as children to the dataset object. Nothing happens if there exists already a reference for the passed object.

```
None IntDataset.AddRef(DataObject object)
None IntDataset.AddRef(list objects)
```

ARGUMENTS

obj/objects
Object(s) for which references should be created and added to the dataset object

All

Returns all children of the dataset object.

```
list IntDataset.All()
```

RETURNS

All objects contained in dataset object.

Clear

Deletes all children of the dataset object.

```
None IntDataset.Clear()
```

GetAll

Returns all children of the dataset filtered according to given class name.

```
list IntDataset.GetAll(str className)
```

ARGUMENTS

className
class name filter, e.g. ElmTerm

RETURNS

All objects of given class stored in dataset object.

5.6.13 IntDocument

Overview

[Export](#)
[Import](#)
[Reset](#)
[View](#)

Export

Exports the embedded data as new file on disk. The embedded data remains unmodified. If desired it can be removed by calling the Reset() function afterwards

```
int IntDocument.Export(str filename)
```

ARGUMENTS

filename Name of export file on disk

RETURNS

0 On success.
1 On error.

SEE ALSO

[IntDocument.Import\(\)](#)

Import

Imports the content of selected file into the PowerFactory object. The data is afterwards embedded in the PowerFactory database.

```
int IntDocument.Import()
```

RETURNS

0 On success.
1 On error.

SEE ALSO

[IntDocument.Export\(\)](#)

Reset

Resets embedded data and reference to an external file.

```
int IntDocument.Reset()
```

View

Views the file in external application. If the file is embedded, it's extracted into a temporary file that is opened afterwards. Please note, the action is only executed if access to given file (type) is enabled in the 'External Access' configuration of PowerFactory (IntExtaccess).

```
int IntDocument.View()
```

RETURNS

- 0** Success, file was opened
- 1** Error, file not opened (because of invalid address or security reasons)

SEE ALSO

[IntUrl.View\(\)](#)

5.6.14 IntDplmap

Overview

[Clear](#)
[Contains](#)
[First](#)
[GetValue](#)
[Insert](#)
[Next](#)
[Remove](#)
[Size](#)
[Update](#)

Clear

Removes all key/value pairs from the container and resets type information.

```
None IntDplmap.Clear()
```

Contains

Checks if a key/value pair with given key is contained in the container.

```
int IntDplmap.Contains(int | float | str | DataObject | list key)
```

ARGUMENTS

- key** Key of the associated pair in the container

RETURNS

1 if an entry of same key is contained, otherwise 0.

First

Outputs the first key/value pair stored in the container.

Note:

- The sequence of the returned pairs is determined by internal criteria and cannot be changed.
- It is not allowed to modify a container while iterating over it. If doing so, the next call of the Next command will return a value of 1.

Exception: Update() does not invalidate current position.

```
[int end,
int|float|str|DataObject|list key
int|float|str|DataObject|list value] IntDplmap.First()
```

ARGUMENTS

key (out) Key of the associated pair in the container

value (out)
Value of the associated pair in the container

RETURNS

1 if no next entry is available in the container (e.g. end is reached), otherwise 0.

GetValue

Returns the associated value for given key.

```
[int|float|str|DataObject|list value,
int error] IntDplmap.GetValue(int|float|str|DataObject|list key)
```

ARGUMENTS

key Key of the associated pair in the container to find.

error (optional, out)

- | | |
|----------|---------------------------------|
| 1 | Key was not found in container. |
| 0 | Key was found in the container. |

RETURNS

The value which is associated to the given key or an undefined value if key is not associated with any value.

Insert

Inserts given key and value as an associated pair into the container.

On the first insertion, the container is (automatically) typed by given data types of key and value. From now on, only keys and values of that types are accepted. (This type information is removed when `IntDplmap.Clear()` is called.)

If given key already exists in the container, its associated value will be overwritten. (Each key can only be contained once in a map (no multi-map support).)

Note:

- Type of key and value can be different, of course.
- Sets are always inserted by value, not by reference!

```
None IntDplmap.Insert (int|float|str|DataObject|list key,
                      int|float|str|DataObject|list value)
```

ARGUMENTS

key Key of the associated pair in the container.
value Value of the associated pair in the container.

Next

Outputs the next key/value pair relative to the last key/value pair in the container.

Note:

- The sequence of the returned pairs is determined by internal criteria and cannot be changed.
- It is not allowed to modify a container while iterating over it. If doing so, the next call of the Next command will return a value of 1.
 Exception: `Update()` does not invalidate current position.

```
[int end,
int|float|str|DataObject|list key
int|float|str|DataObject|list value] IntDplmap.Next ()
```

ARGUMENTS

key (out) Key of the associated pair in the container.
value (out) Value of the associated pair in the container.

RETURNS

1 if no next entry is available in the container (e.g. end is reached), otherwise 0.

Remove

Removes the key/value pair for given key from the container. No error will occur, if the key is not contained in the container.

```
None IntDplmap.Remove (int|float|str|DataObject|list key)
```

ARGUMENTS

key Key of the associated pair in the container

Size

Returns the number of key/value pairs stored in the container.

```
int IntDplmap.Size()
```

RETURNS

Number of key-value pairs stored in the container.

Update

Is a special insert function that can be used for updating key/value pairs in the map. It can only be used if the key is already contained in the map.

```
None IntDplmap.Update(int|float|str|DataObject|list key,  
                      int|float|str|DataObject|list value)
```

ARGUMENTS

key Key of the associated pair in the container
value Value of the associated pair in the container

5.6.15 IntDplvec

Overview

[Clear](#)
[Get](#)
[IndexOf](#)
[Insert](#)
[Remove](#)
[Size](#)
[Sort](#)

Clear

Removes all elements from the container and resets the typ information.

```
None IntDplvec.Clear()
```

Get

Returns the element stored at given position in the container.

```
int|float|str|DataObject|list IntDplvec.Get(int position)
```

ARGUMENTS

position Position in the container. It is zero-based and must always be lesser than the container's size.

RETURNS

Element stored at given position in the container.

IndexOf

Returns the position where the given element is stored in the container.

```
int IntDplvec.IndexOf(int|float|str|DataObject|list element,
                    [int startPosition]
                    )
```

ARGUMENTS

element Element for which the position will be searched.

startPosition

Start position from which the next occurrence greater or equal to this position is searched.

RETURNS

Position of the the given element in the container. The returned position is zero-based. If no occurrence was found, -1 is returned.

Insert

Inserts an element at given position into the container. If no position is given then the element is appended to the back. Inserting an element to an empty container fixes the type of elements which can be hold by itself. Clearing the container resets this type information.

```
None IntDplvec.Insert(int|float|str|DataObject|list element)
None IntDplvec.Insert(int position,
                    int|float|str|DataObject|list element
                    )
```

ARGUMENTS

element Element to be inserted.

position Position (zero-based) to insert the element at. Any old entry at that position will be overwritten. Note: The size of the vector is automatically increased if given position is greater than current size.

Remove

Removes the element stored at given position from the container.

```
None IntDplvec.Remove(int position)
```

ARGUMENTS

position Given position (zero-based) at which the element is to be removed.

Size

Returns the number of elements stored in the container.

```
int IntDplvec.Size()
```

RETURNS

Number of elements stored in the container.

Sort

Sorts the elements of the vector depending on the type of elements stored inside the vector:

string lexically

double/int
 according to value

object according to full name (path + name) or given attribute

```
None IntDplvec.Sort([int descending,]  
                      [str attribute]  
                      )
```

ARGUMENTS

descending (optional)

- 1** Descending sorting order
- 0** Ascending sorting order (default)

attribute (optional)

For objects only: Attribute according to which the sorting is done (default is full name)

5.6.16 IntEvt**Overview**

[CreateCBEvents](#)
[RemoveSwitchEvents](#)

CreateCBEvents

Create boundary breaker events for all shc locations which occur simultaneously in this fault case.

```
None IntEvt.CreateCBEvents([int iRemoveExisting])
```

ARGUMENTS

iRemoveExisting (optional)

- 1** Query user if circuit breaker events exist.
- 0** Do not create circuit breaker events if circuit breaker events are already defined events exist (default)
- 1** Remove existing circuit breaker events.

RemoveSwitchEvents

Remove all switch events of this fault case.

```
None IntEvt.RemoveSwitchEvents([int onlyContingency])
```

ARGUMENTS

onlyContingency (optional)

Condition to remove.

- 0** Remove all switch events regardless of the calculation type.
- 1** Remove all switch events only when this fault case is used for contingency analysis.

5.6.17 IntExtaccess**Overview**

[CheckUrl](#)

CheckUrl

Checks whether access to given url will be granted or not according to the security settings. See also [IntUrl.View\(\)](#) for accessing that url.

```
int IntExtaccess.CheckUrl(str url)
```

ARGUMENTS

url url to check

RETURNS

- 0** access granted
- 1** access denied

5.6.18 IntGate

Overview

[AddTrigger](#)

AddTrigger

Adds either a condition or a gate to the gate.

```
list IntGate.AddTrigger(DataObject newTrigger)
```

ARGUMENTS

newTrigger
The condition or gate that shall be added.

5.6.19 IntGrf

Overview

[MoveToLayer](#)
[Orthogonalise](#)
[SnapToGrid](#)

MoveToLayer

Moves an IntGrf object to the selected target layer, provided that the object is a valid object for that layer. Annotation elements stored as (obsolete) *IntGrf* objects can be moved to any annotation layer (*IntGrflayer*) or group (*IntGrfgroup*).

```
None IntGrf.MoveToLayer(DataObject layer)
```

ARGUMENTS

layer Target *IntGrflayer* or *IntGrfgroup* object.

Orthogonalise

Orthogonalises this IntGrf object. Only suitable for branch elements.

Note: The parent diagram of this object needs to be the active graphic page during execution of this function, and 'Ortho' mode needs to be enabled.

```
int IntGrf.Orthogonalise()
```

RETURNS

- 0** On success.
- 1** An error occurred. See log file for details.

SnapToGrid

Snaps this IntGrf object to grid.

Note: The parent diagram of this object needs to be the active graphic page during execution of this function, and 'Snap' mode needs to be enabled.

```
int IntGrf.SnapToGrid()
```

RETURNS

- 0** On success.
- 1** An error occurred. See log file for details.

5.6.20 IntGrfgroup

Overview

[ClearData](#)
[Export](#)
[Import](#)

ClearData

Removes all annotation elements from this group.

```
None IntGrfgroup.ClearData()
```

Export

Exports all objects of a group into svg-file.

```
None IntGrfgroup.Export(str path,  
                        [int OpenDialog])
```

ARGUMENTS

- path* Full export file path
- OpenDialog (optional)*
 Prompt for export path in dialog
 - 0** Export directly and do not show any dialog (default)
 - 1** Show dialog with path before exporting

Import

Imports svg-file into group object.

```
None IntGrfgroup.Import(str path)
```


ARGUMENTS

path Path of file to be imported.

5.6.21 IntGrflayer

Overview

[AdaptWidth](#)
[AddAnnotationElement](#)
[Align](#)
[ChangeFont](#)
[ChangeLayer](#)
[ChangeRefPoints](#)
[ChangeWidthVisibilityAndColour](#)
[CheckAnnotationString](#)
[ClearData](#)
[Export](#)
[ExportToVec](#)
[GetAnnotationElement](#)
[GetNumberOfAnnotationElements](#)
[Import](#)
[ImportFromVec](#)
[Mark](#)
[RemoveAnnotationElement](#)
[Reset](#)
[UpdateAnnotationElement](#)

AdaptWidth

Resizes the specified group of text boxes regarding their maximum text length.

```
None IntGrflayer.AdaptWidth(int objectType,
                             [str symbolName])
```

ARGUMENTS

objectType

Object type

- | | |
|----------|--------------------|
| 0 | Nodes and branches |
| 1 | Nodes |
| 2 | Branches |
| 3 | Symbol dependent |

symbolName

Symbol name (only relevant if objectType == 3)

AddAnnotationElement

Adds the element specified in `intDplMap` to the current layer. If a batch of annotation elements is processed, one should only enable `writeToDB` for the last process to increase performance. Refer to [IntGrflayer.UpdateAnnotationElement\(\)](#) for an example. Composite elements such as "Polyline with arrow" are not supported.

```
int IntGrflayer.AddAnnotationElement(object intDplMap,
                                     bool writeToDB
                                     )
```

ARGUMENTS

intDplMap

IntDplmap object which contains the element to be added

writeToDB

True by default: If set to false, the changes only occur in memory (and the validity of the inserted element is not verified)

RETURNS

0 on success
1 on failure

Align

Aligns the text within a text box.

```
None IntGrflayer.Align(int alignPos,
                       int objectType,
                       [string symbolName])
```

ARGUMENTS

alignPos Alignment within bounding box

0 left
1 middle
2 right

objectType

Object type

0 Nodes and branches
1 Nodes
2 Branches
3 Symbol dependent

symbolName

Symbol name (only relevant if `objectType == 3`)

ChangeFont

Sets the font number for the specified group of text boxes.

```
None IntGrflayer.ChangeFont (str fontName,
                             int fontSize,
                             int fontStyle,
                             int objectType,
                             [str symbolName])
```

ARGUMENTS

fontName Font name

fontSize Font size

fontStyle Font style

0	Regular
1	Bold
2	Italic
3	Bold and Italic
4	Underline

objectType Object type

0	Nodes and branches
1	Nodes
2	Branches
3	Symbol dependent

symbolName Symbol name (only relevant if objectType == 3)

ChangeLayer

Sets the specified group of text boxes to a given layer.

```
None IntGrflayer.ChangeLayer (DataObject newLayer,
                              int objectType,
                              [str symbolName])
```

ARGUMENTS

newLayer Layer object

objectType Object type

0	Nodes and branches
1	Nodes
2	Branches
3	Symbol dependent

symbolName Symbol name (only relevant if objectType == 3)

ChangeRefPoints

Sets the reference points between a text box (second parameter) and its parent object (first parameter), e.g. if the result box of a busbar shall be shown on top of a drawn bar instead of below the bar the values change from (6,4) to (4,6). The first number specifies the reference number of the text box. The integer values describe the position of the reference points within a rectangle (0=centre, 1=middle right, 2=top right,...):

```
4 3 2
5 0 1
6 7 8
```

```
None IntGrflayer.ChangeRefPoints(int parentRef,
                                   int textBoxRef,
                                   int objectType,
                                   [str symbolName])
```

ARGUMENTS

parentRef

Defines the reference point on the parent object (e.g. busbar)

textBoxRef

Defines the reference point on the text box

objectType

Object type

- | | |
|----------|--------------------|
| 0 | Nodes and branches |
| 1 | Nodes |
| 2 | Branches |
| 3 | Symbol dependent |

symbolName

Symbol name (only relevant if objectType == 3)

ChangeWidthVisibilityAndColour

Sets the visibility of the frame, the width (in number of letters), the visibility and the colour of text boxes.

```
None IntGrflayer.ChangeWidthVisibilityAndColour(int objectType,
                                                  [string symbolName],
                                                  [int columns],
                                                  [int visibility],
                                                  [int colorNumber])
```

ARGUMENTS

objectType

Object type

- | | |
|----------|--------------------|
| 0 | Nodes and branches |
| 1 | Nodes |
| 2 | Branches |
| 3 | Symbol dependent |

symbolName

Symbol name (only relevant if objectType == 3)

columns Sets the width in number of letters**0..n** columns*visibility* Sets the visibility**0** not visible**1** visible*colorNumber*

Sets the colour

0..255 colorNumber**CheckAnnotationString**

Checks if the annotation string is valid. Refer to [IntGrflayer.UpdateAnnotationElement\(\)](#) for an example.

```
int IntGrflayer.CheckAnnotationString()
```

RETURNS

0 on success**1** on failure, outputs a list of errors in the console.**ClearData**

Removes all annotation elements on this layer (keeps contained groups and annotation elements).

```
None IntGrflayer.ClearData()
```

Export

Exports all objects of a layer into svg-file or plain text (.txt), inclusive annotation objects of contained group objects.

```
None IntGrflayer.Export(str path,
                        [int OpenDialog]
                        )
```

ARGUMENTS

path Full export file path. Supported formats: .svg and .txt.

OpenDialog (optional)

Prompt for export path in dialog

0 Export directly and do not show any dialog (default)**1** Show dialog with path before exporting

ExportToVec

Fills string description of annotation elements of this layer into an *IntDplvec*. Clears *IntDplvec* before filling it.

ARGUMENTS

intDplVec *IntDplvec* object to be filled.

GetAnnotationElement

Retrieves attributes of a single annotation element and writes them into an *IntDplmap*. Clears *IntDplmap* before filling it. Refer to [IntGrflayer.UpdateAnnotationElement\(\)](#) for an example. For composite geometries (such as "Polyline with Arrow"), the first element will be retrieved.

```
int IntGrflayer.GetAnnotationElement(int index,
                                     object intDplMap
                                    )
```

ARGUMENTS

index index of the annotation element to be retrieved

intDplMap
IntDplmap) object to be filled

RETURNS

0 on success
1 on failure

GetNumberOfAnnotationElements

Returns the number of annotation elements contained by this layer. Refer to [IntGrflayer.UpdateAnnotationElement\(\)](#) for an example.

```
int IntGrflayer.GetNumberOfAnnotationElements()
```

RETURNS

≥ 0 number of annotation elements
-1 if internal annotation elements string is invalid

Import

Imports svg file or plain text (.txt) into layer.

```
None IntGrflayer.Import(str path)
```

ARGUMENTS

path Path of file to be imported. Supported formats: .svg and .txt.

ImportFromVec

Fills this layer with the string description of annotation elements from an *IntDplVec*. Clears layer before filling it.

ARGUMENTS

intDplVec *IntDplVec* containg description of annotation elements.

Mark

Marks the specified group of text boxes in the currently shown diagram.

```
None IntGrflayer.Mark(int objectType,
                      [string symbolName])
```

ARGUMENTS

objectType

Object type

- | | |
|----------|--------------------|
| 0 | Nodes and branches |
| 1 | Nodes |
| 2 | Branches |
| 3 | Symbol dependent |

symbolName

Symbol name (only relevant if objectType == 3)

RemoveAnnotationElement

Removes annotation element at position index of current layer. If a batch of annotation elements is processed, one should only enable writeToDB for the last process to increase performance. Refer to [IntGrflayer.UpdateAnnotationElement\(\)](#) for an example.

```
int IntGrflayer.RemoveAnnotationElement(int index)
```

ARGUMENTS

index Index of the element that will be removed

writeToDB

True by default: If set to false, the changes only occur in memory

RETURNS

- | | |
|----------|------------|
| 0 | on success |
| 1 | on failure |

Reset

Resets the individually modified text box settings.

```
None IntGrflayer.Reset(int mode,
                       int objectType,
                       [str symbolName])
```

ARGUMENTS

iMode

- 0** Reset to default (changed reference points are not reset)
- 1** Only font
- 2** Shift to original layer (result boxes to layer 'Results', object names to layer 'Labels')

objectType

Object type

- 0** Nodes and branches
- 1** Nodes
- 2** Branches
- 3** Symbol dependent

symbolName

Symbol name (only relevant if objectType == 3)

UpdateAnnotationElement

Updates the element at position index in the current layer with the information contained in intDplMap. For composite geometries (such as "Polyline with Arrow"), the first element will be updated.

```
int IntGrflayer.UpdateAnnotationElement(int index,
                                       object intDplMap,
                                       bool writeToDB
                                       )
```

ARGUMENTS

index The index of the element that will be updated.

intDplMap

IntDplmap object which contains the updated element.

writeToDB

True by default: If set to false, the changes only occur in memory.

RETURNS

- 0** On success.
- 1** On failure.

SEE ALSO

[IntGrflayer.AddAnnotationElement\(\)](#), [IntGrflayer.RemoveAnnotationElement\(\)](#),
[IntGrflayer.GetAnnotationElement\(\)](#)

EXAMPLE

```
import powerfactory
app = powerfactory.GetApplicationExt()
script = app.GetCurrentScript()
annotationLayer = script.annotationLayer
dplMap = script.dplMap
```



```

dplMap.Clear();
dplMap.Insert('type', 'Line');
dplMap.Insert('color', '{0,255,0}');
dplMap.Insert('points', '{{10,100},{30,200}}');
dplMap.Insert('thickness', '1');

annotationLayer.AddAnnotationElement(dplMap);

dplMap.Clear();
dplMap.Insert('type', 'Polygon');
dplMap.Insert('points', '{{20,20},{50,20},{50,50},{20,50}}');
dplMap.Insert('lineColor', '{255,0,0}');
dplMap.Insert('lineThickness', '1');

annotationLayer.AddAnnotationElement(dplMap);

dplMap.Clear();
dplMap.Insert('type', 'Line');
dplMap.Insert('color', '{255,255,0}');
dplMap.Insert('points', '{{10,100},{30,200}}');
dplMap.Insert('thickness', '1');

annotationLayer.AddAnnotationElement(dplMap);

numElements = annotationLayer.GetNumberOfAnnotationElements()
app.PrintPlain(str(annotationLayer) + ': ' + str(numElements) +
               'elements')

for i in range(numElements):
    ret = annotationLayer.GetAnnotationElement(i, dplMap)
    app.PrintPlain(
        'Attributes of annotation element at index {}:'.format(i));
    _, key, value = dplMap.First()
    app.PrintPlain('{} -> {}'.format(key, value))
    for j in range(dplMap.Size()-1):
        _, key, value = dplMap.Next()
        app.PrintPlain('{} -> {}'.format(key, value))

dplMap.Clear();
dplMap.Insert('type', 'Polygon');
dplMap.Insert('points', '{{20,20},{50,20},{50,50},{20,50}}');
dplMap.Insert('lineColor', '{0,255,0}');
dplMap.Insert('lineThickness', '1');

annotationLayer.UpdateAnnotationElement(1, dplMap)
annotationLayer.RemoveAnnotationElement(2);

numElements = annotationLayer.GetNumberOfAnnotationElements()
app.PrintPlain(str(annotationLayer) + ': ' + str(numElements) +
               'elements')

for i in range(numElements):
    ret = annotationLayer.GetAnnotationElement(i, dplMap)
    app.PrintPlain(
        'Attributes of annotation element at index {}:'.format(i));
    _, key, value = dplMap.First()

```

```
app.PrintPlain('{} -> {}'.format(key,value))
for j in range(dplMap.Size()-1):
    _,key,value = dplMap.Next()
    app.PrintPlain('{} -> {}'.format(key,value))
```

5.6.22 IntGrfnet

Overview

[Close](#)
[InsertTemplate](#)
[SetFontFor](#)
[SetLayerVisibility](#)
[SetSymbolComponentVisibility](#)
[Show](#)

Close

Closes the graphic page that displays this diagram.

```
int IntGrfnet.Close()
```

RETURNS

- 0** On success, no error occurred.
- 1** Otherwise

InsertTemplate

Inserts graphic templates from both project library and global libraries into diagram.

```
None IntGrfnet.InsertTemplate(DataObject templateObj,
                              [DataObject targetFolder],
                              [float posX],
                              [float posY],
                              [int rotate],
                              [int designViewSubstat],
                              [DataObject conNode1],
                              [DataObject conNode2])
```

ARGUMENTS

templateObj

Template object to insert (IntTemplate, substation or ElmBranch).

targetFolder

Target folder of new elements.

None Default target folder of diagram is used.

posX

x-postion in mm. Only relevant if template is not directly connected (e.g. substation templates).

posY y-postion in mm. Only relevant if template is not directly connected (e.g. substation templates).

rotate Rotate inserted object(s).

0	Do not rotate
1	Rotate by 90 degrees

designViewSubstat
Design view representation (for substation templates only).

0	Beach ball representation
1	Design view

conNode1
Relevant if template shall be connected. Any terminal or cubicle.

conNode2
Relevant if template shall be connected. Any terminal or cubicle.

SetFontFor

Sets a font for a specified group of text boxes.

```
None IntGrfnet.SetFontFor(int labelResultOrTitle,
                           int nodesOrBranches,
                           str fontName,
                           int fontSize,
                           int fontStyle)
```

ARGUMENTS

labelResultOrTitle
Type of text box to be modified.

0	Labels
1	Results
2	Title and Legends

nodesOrBranches
Type of parent object

0	Nodes
1	Branches

fontName
Font name

fontSize Font size

fontStyle Font style

1	Bold
2	Italic
3	Bold and italic
4	Underline

SetLayerVisibility

Sets a layer visible or invisible.

```
None IntGrfnet.SetLayerVisibility(str sLayer,
                                  int iVis)
```

ARGUMENTS

<i>sLayer</i>	Layer to be modified.
<i>iVis</i>	Visibility
0	Make layer invisible.
1	Make layer visible.

SetSymbolComponentVisibility

Determines which parts of net element symbols are shown in the diagram.

```
None IntGrfnet.SetSymbolComponentVisibility(int componentID,
                                             int visible)
```

ARGUMENTS

<i>componentID</i>	Component to be modified.
5	Connection points
7	Tap positions
8	Vector groups
9	Load flow arrows
11	Phases
13	Line sections
14	Connection arrows
15	Line compensations
16	Line section labels
17	Line loads
21	Connection numbers (block diagrams only)
22	Connection names (block diagrams only)
33	Remotely controlled substation markers
38	Tie open point markers
39	Open standby switch markers
40	Normally open switch markers
<i>visible</i>	Visibility
0	Make component invisible.
1	Make component visible.

Show

Opens a diagram.

```
int IntGrfnet.Show()
```

RETURNS

- | | |
|---|--------------------------------|
| 0 | On success, no error occurred. |
| 1 | Otherwise |

5.6.23 Intlcon

Overview

[Export](#)
[Import](#)

Export

Exports current icon as an image file.

```
int Intlcon.Export(str filename)
```

ARGUMENTS

filename Name of export image on disk. Extension must match the type of the stored file.

RETURNS

- | | |
|---|-------------|
| 0 | On success. |
| 1 | On error. |

SEE ALSO

[Intlcon.Import\(\)](#)

Import

Imports icon from an image file.

```
int Intlcon.Import(str filename)
```

ARGUMENTS

filename Name of image file on disk. Supported formats: BMP, PNG, TIF, GIF, ICO, WMF, EMF. Max file size is 100kb.

RETURNS

- | | |
|---|-------------|
| 0 | On success. |
| 1 | On error. |

SEE ALSO

[Intlcon.Export\(\)](#)

5.6.24 IntlLibrary

Overview

[Activate](#)

[Deactivate](#)

Activate

Activates this library. If another library is already activated it will be deactivated first.

```
int IntlLibrary.Activate()
```

RETURNS

1 if successful

0 otherwise

Deactivate

Deactivates this library.

```
int IntlLibrary.Deactivate()
```

RETURNS

1 if successful

0 otherwise

5.6.25 IntMat

Overview

[ColLbl](#)

[Get](#)

[GetColumnLabel](#)

[GetColumnLabelIndex](#)

[GetNumberOfColumns](#)

[GetNumberOfRows](#)

[GetRowLabel](#)

[GetRowLabelIndex](#)

[Init](#)

[Invert](#)

[Multiply](#)

[Resize](#)

[RowLbl](#)

[Save](#)

[Set](#)
[SetColumnLabel](#)
[SetRowLabel](#)
[SortToColumn](#)

ColLbl

Deprecated function to get or set the label of the given column. Please use [IntMat.GetColumnLabel\(\)](#) or [IntMat.SetColumnLabel\(\)](#) instead.

```
str IntMat.ColLbl(int column)
str IntMat.ColLbl(str label,
                  int column
                  )
```

Get

Returns the value at the position (row, column) of the matrix. A run-time error will occur when 'row' or 'column' is out of range.

```
float IntMat.Get(int row,
                int column
                )
```

ARGUMENTS

row Row in matrix: 1 ... GetNumberOfRows().
column column in matrix: 1 ... GetNumberOfColumn()

RETURNS

Value in matrix.

SEE ALSO

[IntMat.Set\(\)](#)

GetColumnLabel

Returns the label of a column.

```
str IntMat.GetColumnLabel(int column)
```

ARGUMENTS

column Column index (first column has index 1).

RETURNS

Column label of given column.

DEPRECATED NAMES

[ColLbl](#)

SEE ALSO

[IntMat.SetColumnLabel\(\)](#), [IntMat.GetColumnLabelIndex\(\)](#), [IntMat.GetRowLabel\(\)](#)

GetColumnLabelIndex

Gets the index of a label in all column labels.

```
int IntMat.GetColumnLabelIndex (str label)
```

ARGUMENTS

label Label to search.

RETURNS

≥ 1 The index in the column labels, if label was found.
0 Otherwise

SEE ALSO

[IntMat.GetColumnLabel\(\)](#)

GetNumberOfColumns

Returns the number of columns in the matrix.

```
int IntMat.GetNumberOfColumns ()
```

RETURNS

The number of columns of the matrix.

DEPRECATED NAMES

NCol, SizeY

SEE ALSO

[IntMat.GetNumberOfRows\(\)](#)

GetNumberOfRows

Returns the number of rows in the matrix.

```
int IntMat.GetNumberOfRows ()
```

RETURNS

The number of rows.

DEPRECATED NAMES

NRow, SizeX

SEE ALSO

[IntMat.GetNumberOfColumns\(\)](#)

GetRowLabel

Returns the label of a row.

```
str IntMat.GetRowLabel(int row)
```

ARGUMENTS

row Row index (first row has index 1).

RETURNS

Row label of given row.

DEPRECATED NAMES

RowLbl

SEE ALSO

[IntMat.SetRowLabel\(\)](#), [IntMat.GetRowLabelIndex\(\)](#), [IntMat.GetColumnLabel\(\)](#)

GetRowLabelIndex

Gets the index of a label in all row labels.

```
int IntMat.GetRowLabelIndex(str label)
```

ARGUMENTS

label Label to search.

RETURNS

≥ 1 The index in the row labels, if it was found.
0 Otherwise

SEE ALSO

[IntMat.GetRowLabel\(\)](#)

Init

Initializes the matrix with given size and values, regardless of the previous size and data.

This operation is performed in memory only. Use [IntMat.Save\(\)](#) to save the modified matrix to database.

```
int IntMat.Init(int numberOfRows,
               int numberOfColumns,
               [float initialValue = 0.0]
            )
```

ARGUMENTS

numberOfRows
The number of rows.

numberOfColumns
The number of columns.

initialValue (optional)
Initial values: All matrix entries are initialised with this value. Matrix is initialized with 0 if omitted.

RETURNS

Always 1 and can be ignored.

SEE ALSO

[IntMat.Resize\(\)](#)

Invert

Inverts the matrix.

This operation is performed in memory only. Use [IntMat.Save\(\)](#) to save the modified matrix to database.

```
int IntMat.Invert()
```

RETURNS

- 0** Success, the matrix is replaced by its inversion.
- 1** Error, inversion not possible. Original matrix was not changed.

Multiply

Multiplies 2 matrixes and stores the result in this matrix.

This operation is performed in memory only. Use [IntMat.Save\(\)](#) to save the modified matrix to database.

```
int IntMat.Multiply(DataObject M1,  
                   DataObject M2  
                   )
```

ARGUMENTS

object M1
Matrix 1 to be multiplied.

object M2
Matrix 2 to be multiplied.

RETURNS

Always 0 and can be ignored.

Resize

Resizes the matrix to a given size. Existing values will not be changed. Added values will be set to the optional value, otherwise to 0.

This operation is performed in memory only. Use [IntMat.Save\(\)](#) to save the modified matrix to database.

```
int IntMat.Resize(int numberOfRows,  
                 int numberOfColumns,  
                 [float initialValue = 0.0]  
                 )
```

ARGUMENTS

numberOfRows

The number of rows.

numberOfColumns

The number of columns.

initialValue (optional)

Initial values: Additional matrix entries are initialised with this value. Additional values are initialized with 0. if omitted.

RETURNS

Always 1 and can be ignored.

SEE ALSO

[IntMat.Init\(\)](#)**RowLbl**

Deprecated function to get or set the label of the given row. Please use [IntMat.GetRowLabel\(\)](#) or [IntMat.SetRowLabel\(\)](#) instead.

```
str IntMat.RowLbl(int row)
str IntMat.RowLbl(str label,
                  int row
                  )
```

Save

Saves the current state of this matrix to database.

If the matrix is calculation relevant, an optional parameter allows to control whether available calculation results shall be reset afterwards or not.

Note: In QDSL, the calculation results are never reset and the parameter "resetCalculation" is ignored.

```
None IntMat.Save()
None IntMat.Save(int resetCalculation)
```

ARGUMENTS

resetCalculation (optional)

1	reset calculation results (default)
0	keep calculation results

Set

Sets a value at the position (row, column) of the matrix. The matrix is resized automatically if the given coordinates exceed the size.

This operation is performed in memory only. Use [IntMat.Save\(\)](#) to save the modified matrix to database.

```
int IntMat.Set(int row,
              int column,
              float value
              )
```

ARGUMENTS

- row* Row index, 1 based. The first row has index 1. Invalid index ($leq 0$) leads to scripting error.
- column* Column index, 1 based. The first column has index 1. Invalid index ($leq 0$) leads to scripting error.
- value* Value to assign.

RETURNS

Always 1 and can be ignored.

SEE ALSO

[IntMat.Get\(\)](#)

SetColumnLabel

Sets the label of a column.

This operation is performed in memory only. Use [IntMat.Save\(\)](#) to save the modified matrix to database.

```
None IntMat.SetColumnLabel(int column,  
                           str label  
                           )
```

ARGUMENTS

- column* Column index (first column has index 1).
- label* Label to set.

SEE ALSO

[IntMat.GetColumnLabel\(\)](#), [IntMat.GetColumnLabelIndex\(\)](#), [IntMat.SetRowLabel\(\)](#)

SetRowLabel

Sets the label of a row.

This operation is performed in memory only. Use [IntMat.Save\(\)](#) to save the modified matrix to database.

```
str IntMat.SetRowLabel(int row,  
                      str label  
                      )
```

ARGUMENTS

- row* Row index (first row has index 1).
- label* Label to set.

SEE ALSO

[IntMat.GetRowLabel\(\)](#), [IntMat.GetRowLabelIndex\(\)](#), [IntMat.SetColumnLabel\(\)](#)

SortToColumn

Sorts the matrix alphanumerically according to a column, which is specified by the input parameter. The row labels are sorted accordingly (if input parameter `storeInDB` is 1).

```
int IntMat.SortToColumn(int columnIndex,
                        [float epsilon = 0.0],
                        [int storeInDB = 1])
```

DEPRECATED NAMES

`SortToColumn`

ARGUMENTS

columnIndex

The column index, 1 based. The first column has index 1.

epsilon (optional)

Accuracy for comparing equal values. Values which differ less than epsilon are treated as being equal. Default value is 0.

storeInDb (optional)

Possible Values:

- | | |
|----------|---|
| 0 | Non-persistent change. Values are not stored in database. |
| 1 | Values are stored in database. (default) |

RETURNS

- | | |
|----------|---|
| 0 | On success. |
| 1 | Error. Original matrix was not changed. |

5.6.26 IntMon

Overview

[AddVar](#)
[AddVars](#)
[ClearVars](#)
[GetVar](#)
[NVars](#)
[PrintAllVal](#)
[PrintVal](#)
[RemoveVar](#)

AddVar

Appends the variable “name” to the list of selected variable names.

```
None IntMon.AddVar(str name)
```

ARGUMENTS

name The variable name to add.

AddVars

Appends the filtered variables to the list of selected variables.

```
None IntMon.AddVars(str varFilter)
```

ARGUMENTS

varFilter The filter for variables to add. For example: 'e:*' to add all parameters of element to variable selection.

ClearVars

Clears the list of selected variable names.

```
None IntMon.ClearVars()
```

GetVar

Returns the variable name on the given row of the variable selection text on the second page of the IntMon dialogue, which should contain one variable name per line.

```
str IntMon.GetVar(int row)
```

ARGUMENTS

row Given row

RETURNS

The variable name in line row.

NVars

Returns the number of selected variables or, more exact, the number of lines in the variable selection text on the second page of the IntMon dialogue, which usually contains one variable name per line.

```
int IntMon.NVars()
```

RETURNS

The number of variables selected.

PrintAllVal

Writes all calculation results of the object assigned in obj_id to the output window. The output includes the variable name followed by the value, its unit and the description. It should be noted that the variable set itself is modified by this method.

```
None IntMon.PrintAllVal()
```

PrintVal

Prints the values of the selected variables to the output window.

```
None IntMon.PrintVal()
```

RemoveVar

Removes the variable “name” from the list of selected variable names.

```
int IntMon.RemoveVar(str name)
```

ARGUMENTS

name The variable name.

RETURNS

- 0** If variable with name was found and removed.
- 1** If the variable name was not found.

5.6.27 IntNndata

Overview

[CheckConsistency](#)

CheckConsistency

Checks whether the current power grid state matches the state with which the dataset was originally generated.

```
int IntNndata.CheckConsistency()
```

RETURNS

- 0** The power grid state matches the state the dataset was generated with.
- 1** The power grid state does not match the state the dataset was generated with.

5.6.28 IntNnet

Overview

[CheckConsistency](#)

CheckConsistency

Checks whether the current power grid state matches the state with which the neural network was originally trained.

```
int IntNnet.CheckConsistency()
```

RETURNS

- 0** The power grid state matches the state the neural network was trained with.
- 1** The power grid state does not match the state the neural network was trained with.

5.6.29 IntOutage

Overview

[Apply](#)
[ApplyAll](#)
[Check](#)
[CheckAll](#)
[IsInStudyTime](#)
[ResetAll](#)

Apply

```
None IntOutage.Apply([int reportSwitches])
```

Applies the outage object. The functionality corresponds to pressing the 'Apply' button in edit dialog with the difference that the scripting function can also be used without an active scenario.

ARGUMENTS

reportSwitches (optional)

Flag to enable the reporting of changed switches to the output window.

- 0** No output (default)
- 1** Print switches to output window

ApplyAll

```
None IntOutage.ApplyAll([int reportSwitches])
```

Applies all currently relevant (=in study time and not out-of-service) outage objects of current project. The functionality corresponds to pressing the 'ApplyAll' button in edit dialog with the difference that the scripting function can also be used without an active scenario. It applies all relevant outages independent of the one it was called on.

ARGUMENTS

reportSwitches (optional)

Flag to enable the reporting of changed switches to the output window.

- 0** No output (default)
- 1** Print switches to output window

Check

```
int IntOutage.Check([int outputMessage])
```

This function checks if the outage is correctly reflected by the network elements.

ARGUMENTS

outputMessage (optional)

Flag to enable detailed output to the output window.

- 0** No output (default)
- 1** Detailed report of mismatch to output window

RETURNS

- 0** Ok, outage is correctly reflected
- 1** Not ok, status of network elements does not reflect outage

CheckAll

This function checks if all outages are correctly reflected by the network components for current study time. It checks all outages independent of the one it was called on.

```
[list notOutaged,  
list wronglyOutaged] IntOutage.CheckAll([int emitMsg,  
[DataObject gridfilter,])
```

ARGUMENTS

int emitMsg (optional)

whether to report inconsistencies to the output window

- 1** No output
- 0** (Default) print inconsistencies but without start / end message
- 1** Full output, including start / end message

gridfilter (optional)

Possibility to restrict checking for accidentally outaged elements to given object (e.g. grid) and its children (by default, all elements for all active grids are checked).

notOutaged (optional, out)(optional)

If given, all network components that should be outaged but are not are filled into this set.

wronglyOutaged (optional, out)(optional)

If given, all network components that should be outaged but are not are filled into this set.

IsInStudyTime

```
int IntOutage.IsInStudyTime()
```

Checks if outage is relevant for current study time, i.e. the study time lies within the outage's validity period.

RETURNS

- 0** Outage is not relevant for current study time (outside validity period)
- 1** Outage is relevant for current study time (inside validity period)

DEPRECATED NAMES

IsInStudytime

ResetAll

```
None IntOutage.ResetAll([int reportSwitches])
```

Resets all currently relevant (=in study time and not out-of-service) outage objects of current project. The functionality corresponds to pressing the 'Reset' button in all outage objects with difference that the scripting function can also be used without an active scenario. It resets all relevant outages independent of the one it was called on.

ARGUMENTS

reportSwitches (optional)

Flag to enable the reporting of changed switches to the output window.

- | | |
|----------|---------------------------------|
| 0 | No output (default) |
| 1 | Print switches to output window |

5.6.30 IntPlannedout

Overview

[SetRecurrence](#)

SetRecurrence

Copies the settings of a Recurrence Pattern object to the planned outage object and enables the flag Recurrent.

```
int IntPlannedout.SetRecurrence(DataObject recurrencePattern)
```

ARGUMENTS

recurrencePattern

Recurrence pattern object, classname IntRecurrence.

RETURNS

- | | |
|----------|--|
| 0 | Ok, settings copied successful. |
| 1 | Failed, passed object is None or not of class IntRecurrence. |

5.6.31 IntPrj

Overview

Activate
AddProjectToCombined
AddProjectToRemoteDatabase
Archive
BeginDataExtensionModification
CanAddProjectToRemoteDatabase
CanSubscribeProjectReadOnly
CanSubscribeProjectReadWrite
CopyDataExtensionFrom
CopyProjectSettings
CreateVersion
Deactivate
EndDataExtensionModification
GetDerivedProjects
GetExternalReferences
GetGeoCoordinateSystem
GetLatestVersion
GetProjectDirectory
GetVersions
HasExternalReferences
LoadCimData
LoadData
MergeToBaseProject
NormaliseCombined
PackExternalReferences
Purge
PurgeObjectKeys
RemoveProjectFromCombined
Restore
SetGeoCoordinateSystem
SubscribeProjectReadOnly
SubscribeProjectReadWrite
TransformGeoCoordinates
TransformToGeographicCoordinateSystem
UnsubscribeProject
UpdateStatistics
UpdateToDefaultStructure
UpdateToMostRecentBaseVersion

Activate

Activates the project. If another project is already activated it will be deactivated first.

```
int IntPrj.Activate()
```

RETURNS

0	on success
1	on error

AddProjectToCombined

Adds a project to this using the Project Combination logic. The passed object must be an `IntVersion`. The receiving project must be activated but not have a Study Case active, otherwise this method will fail.

```
int IntPrj.AddProjectToCombined(object projectVersion,
                                [int acceptMergeErrors])
```

ARGUMENTS

projectVersion

The version of a project to add

acceptMergeErrors (optional)

0 Cancel merge on error (default)

1 Ignore conflicts, merge everything else

RETURNS

0 operation was successful

1 an error occurred

AddProjectToRemoteDatabase

Adds a project to the online database if possible.

Can only be used if the database driver is set to Offline Mode.

```
int IntPrj.AddProjectToRemoteDatabase()
```

Archive

Archives the project if the functionality is configured and activated. Does nothing otherwise.

```
int IntPrj.Archive()
```

RETURNS

0 project has been archived

1 project has not been archived

BeginDataExtensionModification

Signals the start of a Data Extension modification.

Must be terminated with `EndDataExtensionModification`, otherwise all changes will be discarded. Data Extensions can only be modified when the project is active.

```
DataObject IntPrj.BeginDataExtensionModification()
```

RETURNS

The `SetDataext` configuration object in the settings folder for further processing.

SEE ALSO

[IntPrj.EndDataExtensionModification\(\)](#), [SetDataext.AddConfiguration\(\)](#),
[SetDataext.GetConfiguration\(\)](#), [SetDataext.GetConfigurations\(\)](#),
[SetDataext.RemoveAllConfigurations\(\)](#), [SetDataext.RemoveConfiguration\(\)](#)

CanAddProjectToRemoteDatabase

Checks if the project can be pushed to the remote database.

The project must be subscribable as read and write and it must be unsubscribed. Can only be used if the database driver is set to Offline Mode.

```
int IntPrj.CanAddProjectToRemoteDatabase()
```

RETURNS

- 0 project cannot be added to the remote database
- 1 project can be added to the remote database

CanSubscribeProjectReadOnly

Checks if a project can be subscribed read-only by the user executing the script.

```
int IntPrj.CanSubscribeProjectReadOnly()
```

RETURNS

- 0 no permission to subscribe project
- 1 project can be subscribed

CanSubscribeProjectReadWrite

Checks if a project can be subscribed read-write by the user executing the script.

```
int IntPrj.CanSubscribeProjectReadWrite()
```

RETURNS

- 0 no permission to subscribe project
- 1 project can be subscribed

CopyDataExtensionFrom

Copies the Data Extension configuration from another project into this project. The configuration is applied immediately. The target project must be active.

```
int IntPrj.CopyDataExtensionFrom(object other)
```

ARGUMENTS

- other* Project to copy the Data Extension configuration from.

RETURNS

- 0 Copied successfully

- 1 Target project is not active
- 2 Source object is not a project
- 3 Error during copying, see Output Window

CopyProjectSettings

Copies project settings from another project or the default project into this project. The target project must not be active.

```
int IntPrj.CopyProjectSettings([object other])
```

ARGUMENTS

other (optional)

Project to copy the settings from. Copy settings from default project if omitted.

RETURNS

- 0 Copied successfully
- 1 Project is active
- 2 Source object is not a project

CreateVersion

Creates a new version of project it was called on.

Optionally allows to pass the version name, the timestamp, a bool for user notification, a bool to enforce project approval and a description.

```
DataObject IntPrj.CreateVersion([str name = "",]
                                [int timestamp = 0,]
                                [int notifyUsers = 0,]
                                [int approvalRequired = 0,]
                                [str description = ""])
DataObject IntPrj.CreateVersion(int notifyUsersAndApprovalRequired,
                                [str name = "",]
                                [float timestamp = 0,]
                                [str description = ""])
```

ARGUMENTS

name Version name. The default version name e.g. 'Project Version' is used on an empty string. (default: empty string)

timestamp

Seconds since 01.01.1970 00:00:00. On zero the current date and time is used. (default: 0)

notifyUsers

User notifications activated:

- 0 Create version and do not notify users (default).
- 1 Notify users.

approvalRequired

Project approval required:

- 0** Create version without approval (default).
- 1** Require approval.

notifyUsersAndApprovalRequired

Project approval required and user notifications activated:

- 0** Create version without approval and do not notify users (default).
- 1** Require approval and notify users.

description

Version description. (default: empty string)

RETURNS

- DataObject** Newly created *IntVersion* object.
- None** On failure e.g. missing permission rights.

Deactivate

De-activates the project if it is active. Does nothing otherwise.

```
int IntPrj.Deactivate()
```

RETURNS

- 0** on success
- 1** on error

EndDataExtensionModification

Terminates a Data Extension modification previously initiated with *BeginDataExtensionModification*.

This will deactivate the Study Case if the new Data Extension configuration can be applied. In case of errors the project will be deactivated and rolled back. Omitting the call to *EndDataExtensionModification* and exiting from the script will discard all changes to the Data Extension configuration.

```
None IntPrj.EndDataExtensionModification()
```

SEE ALSO

[IntPrj.BeginDataExtensionModification\(\)](#)

GetDerivedProjects

Return a set holding all versions created in the project.

```
list IntPrj.GetDerivedProjects()
```

RETURNS

- Set holding all versions of a project.

GetExternalReferences

Fills the given map with objects from this project mapping to its external references.

```
int IntPrj.GetExternalReferences(DataObject resultMap,
                                [DataObject externalReferencesSettings])
```

ARGUMENTS

resultMap

DPL map (IntDplmap) which will contain objects mapping to its external references. Objects without external references are not mapped.

externalReferencesSettings (optional)

External References settings object (SetExtref). Defines the properties for objects being external references. The External References settings object from current user is used if omitted.

RETURNS

- 0** Getting external references succeeded.
- 1** Getting external references cancelled in dialogue or failed e.g project inactive or not migrated.

SEE ALSO

[IntPrj.HasExternalReferences\(\)](#), [IntPrj.PackExternalReferences\(\)](#)

GetGeoCoordinateSystem

Returns the EPSG code of the geographic coordinate system in which the geo coordinates of the project's net elements are stored.

```
int IntPrj.GetGeoCoordinateSystem()
```

RETURNS

EPSG code of the project's geographic coordinate system, or 0 if the coordinate system is not known.

GetLatestVersion

Returns the most recent version available in the project which has the notify users option set.

Optionally allows to consider all versions, regardless of notify users option.

```
DataObject IntPrj.GetLatestVersion([int onlyregular])
```

ARGUMENTS

onlyregular (optional)

- 1** consider only regular version (default)
- 0** consider all versions

RETURNS

Latest version of the project

GetProjectDirectory

Returns the project directory for the project as full path.

```
string IntPrj.GetProjectDirectory()
```

GetVersions

Returns a set containing all versions of the project.

```
list IntPrj.GetVersions()
```

RETURNS

Set that contains all versions of the project

HasExternalReferences

Checks if any object inside the project references external non-system objects and prints a report to the Output Window.

```
int IntPrj.HasExternalReferences([int considerGlobal = 1,]
                                [int considerRemoteVariants = 0]
                                )
int IntPrj.HasExternalReferences(DataObject externalReferencesSettings)
```

ARGUMENTS

considerGlobal (optional)

- 0** References to global (non-system) objects are not considered as external references.
- 1** References to global (non-system) objects are considered as external references (default).

considerRemoteVariants (optional)

- 0** References to remote variants are not considered as external references (default).
- 1** References to remote variants are considered as external references.

externalReferencesSettings (optional)

External References settings object (SetExtref). Defines the properties for objects being external references.

RETURNS

- 0** No external reference was found.
- 1** An external reference was found.

SEE ALSO

[IntPrj.PackExternalReferences\(\)](#), [IntPrj.GetExternalReferences\(\)](#)

LoadCimData

Efficiently loads all objects of a project's CIM Model folder from the database.

Project activation loads everything but the CIM Model folder from the database. This function is useful to optimise the traversal of the CIM Model folder.

```
None IntPrj.LoadCimData()
```

SEE ALSO

[IntPrj.LoadData\(\)](#)

LoadData

Loads all objects of the project from the data base. Does nothing when called on an active project.

This function is useful to optimise searches which would traverse deep into an inactive project.

```
None IntPrj.LoadData()
```

SEE ALSO

[IntPrj.LoadCimData\(\)](#)

MergeToBaseProject

Merges the modifications of a derived project to the base project.

```
int IntPrj.MergeToBaseProject(int conflictMode)
```

ARGUMENTS

conflictMode

Assignment in case of modification conflict:

- | | |
|----------|--|
| 0 | Favour none. Diff browser is shown in case of conflicts. |
| 1 | Favour base version. |
| 2 | Favour derived project. |
| 3 | Favour base project. |

RETURNS

- | | |
|----------|---|
| 0 | Merge finished sucessfully. |
| 1 | Merge failed (no further information). |
| 2 | Merge failed due to failing assignment check. |
| 3 | Merge failed due to invalid projects (e.g. no derived project). |
| 4 | Merge was canceled by user. |
| 5 | Merge completed with errors (see output window). |

NormaliseCombined

Normalises a combined project so it appears to be a regular project. Allows also to partially normalise the project. This will remove intermediate folders which were added when creating the combined project. This might lead to naming duplications which will be resolved by the normal logic of numbering duplicates. Passing a mapping key to the function will only normalise that sub-project.

```
int IntPrj.NormaliseCombined(str mappingKey)
```

ARGUMENTS

mappingKey (optional)

The mapping key for the project that should be normalised

RETURNS

- 0** operation was successful
- 1** operation was cancelled because the project is active

PackExternalReferences

Packs external references of this project and prints a report to the Output Window.

```
int IntPrj.PackExternalReferences([DataObject externalReferencesSettings])
```

ARGUMENTS

externalReferencesSettings (optional)

External References settings object (SetExtref). Defines the properties for objects being external references. The External References settings object from current user is used if omitted.

RETURNS

- 0** Packing external references succeeded.
- 1** Packing external references cancelled in dialogue or failed e.g project inactive or not migrated.

SEE ALSO

[IntPrj.HasExternalReferences\(\)](#), [IntPrj.GetExternalReferences\(\)](#)

Purge

Purges project storage and updates storage statistics.

Requires write access to the project; the functions does nothing when the project is locked by another user.

```
None IntPrj.Purge()
```

PurgeObjectKeys

Purges project's object key table.

RETURNS

Number of purged records. -1 in case of errors.

```
int IntPrj.PurgeObjectKeys()
```

RemoveProjectFromCombined

Removes a project from a combined project. For the removal the mapping key must be specified. Mapping keys are stored in the project, parameter `project_mapped`. The project this method is called on must be activated but not have a Study Case active, otherwise this method will fail.

```
int IntPrj.RemoveProjectFromCombined(str mappingKey)
```

ARGUMENTS

mappingKey

The mapping key for the project that should be removed

RETURNS

- 0** operation was successful
- 1** an unknown error occurred
- 2** an error occurred and is documented in the output window

Restore

Restores an archived project so it can be used again. Does nothing if the project is not an archived one.

```
int IntPrj.Restore()
```

RETURNS

- 0** project has not been restored
- 1** project has been restored

SetGeoCoordinateSystem

Defines the the geographic coordinate system in which the geo coordinates of the project's net elements are stored.

```
None IntPrj.SetGeoCoordinateSystem(int epsgCode)
```

ARGUMENTS

epsgCode

EPSG code of the geographic coordinate system to be used for this project. A value of 0 denotes an unknown coordinate system.

SubscribeProjectReadOnly

Subscribes a project read only if the permission is granted.

Can only be used if the database driver is set to Offline Mode.

```
None IntPrj.SubscribeProjectReadOnly()
```

SubscribeProjectReadWrite

Subscribes a project read/write if the permission is granted.

Can only be used if the database driver is set to Offline Mode.

```
None IntPrj.SubscribeProjectReadWrite()
```

TransformGeoCoordinates

Transforms geographic coordinates from a source coordinate system to a destination coordinate system. Geodetic coordinates (longitude/latitude) are specified in decimal degrees. Projected coordinates are specified in meters.

```
[int error,
float xOut,
float yOut] IntPrj.TransformGeoCoordinates(float xIn, float yIn,
                                           int sourceEpsg, int destEpsg
                                           )
```

ARGUMENTS

- xIn* horizontal component of the input location: x position or longitude, resp.
- yIn* vertical component of the input location: y position or latitude, resp.
- xOut (out)* horizontal component of the output location: x position or longitude, resp.
- yOut (out)* vertical component of the output location: y position or latitude, resp.
- sourceEpsg* EPSG code of the source coordinate system
- destEpsg* EPSG code of the destination coordinate system

RETURNS

- 0** operation was successful
- 1** an error occurred

TransformToGeographicCoordinateSystem

Transforms geographic coordinates of all net elements contained by the project to a destination coordinate system, and updates the configured project coordinate system accordingly. Please note: The project's geographic diagram needs to be shown when this function is called. Otherwise, annotations will not be transformed.

```
[int error] IntPrj.TransformToGeographicCoordinateSystem(int destEpsg)
```

ARGUMENTS

destEpsg EPSG code of the destination coordinate system

RETURNS

- 0** operation was successful
- 1** an error occurred

UnsubscribeProject

Unsubscribes a project.

Can only be used if the database driver is set to Offline Mode.

```
None IntPrj.UnsubscribeProject()
```

UpdateStatistics

Updates the storage statistics for a project. The statistics are displayed on the page Storage of a project.

Note: This function requires write access to the project otherwise the update is not executed and an error message is printed to the output window.

```
None IntPrj.UpdateStatistics()
```

UpdateToDefaultStructure

Updates folder structure of currently active project to that of the default project (used for creation of new projects). Existing folders will be moved to a new location within the project. Folders that have no correspondence in the default project will remain untouched.

NB: Folders might get moved or additional ones might be created, but no folder is deleted by this routine.

```
int IntPrj.UpdateToDefaultStructure(int createMissingFolders,
                                   int updateForeignKeys
                                   )
```

ARGUMENTS

createMissingFolders (optional)

- 0** Missing folders will not be created. Only existing ones will be moved to new locations, if required.
- 1** Missing folders will be created (default).

updateForeignKeys (optional)

- 0** Foreign-keys of folders will not be updated.
- 1** Foreign-keys of folders will be updated (default).

RETURNS

- 0** operation was successful
- 1** operation was not successful, e.g. project not active

UpdateToMostRecentBaseVersion

Creates a new derived project from most recent version of the base project and (optionally) merges the modifications from the existing derived project into it. The existing derived project is moved to the recycle bin.

```
[ int errorCode,
DataObject newDerivedProject ]
IntPrj.UpdateToMostRecentBaseVersion(int versionWithNotification,
                                     int discardOwnModifications,
                                     [int conflictMode = 0]
                                     )
```

ARGUMENTS

newDerivedProject (out)

New derived project if no error occurred.

versionWithNotification

- 0** Update to the most recent version independent of the "Notify users" setting.
- 1** Update to the most recent version with "Notify users" enabled.

discardOwnModifications

- 0** Merge modifications of new version and derived project.
- 1** Discard modifications of derived project. The Compare and Merge Tool is not used at all.

conflictMode (optional)

Assignment in case of modification conflict (only used if not discarding derived modifications):

- 0** Favour none. Diff browser is shown in case of conflicts. (default)
- 1** Favour new base version.
- 2** Favour derived project.

RETURNS

- 0** Merge finished successfully.
- 1** Merge failed (no further information).
- 2** Merge failed due to failing assignment check.
- 3** Merge failed due to invalid projects (e.g. no derived project).
- 4** Merge was canceled by user.
- 5** Merge completed with errors (see output window).

5.6.32 IntPrjFolder

Overview

[GetProjectFolderType](#)
[IsProjectFolderType](#)

GetProjectFolderType

Returns the type of the project folder stored in attribute "iopt_type".
The following types are currently available (language independent):

- blk - User Defined Models
- cbrat - CB Ratings
- chars - Characteristics
- cstgen - Generator Cost Curves
- effgen - Generator Efficiency Curves
- rnd - Probabilistic Assessment
- cim - CIM Model
- common - Common Mode Failures
- demand - Demand Transfers
- dia - Diagrams
- equip - Equipment Type Library
- fault - Faults
- ras - Remedial Action Schemes
- valper - Validity Periods
- gen - Generic
- lib - Library
- lvdata - Coincidence Definitions
- mvar - Mvar Limit Curves
- netdat - Network Data
- netmod - Network Model
- oplib - Operational Library
- outage - Outages
- qpc - QP-Curves
- qvc - QV-Curves
- ra - Running Arrangements
- report - Reports
- docs - Document Reports
- tables - Tabular Reports
- scen - Operation Scenarios
- scheme - Variations
- script - Scripts
- study - Study Cases

- sw - StationWare
- tariff - Tariffs
- templ - Templates
- therm - Thermal Ratings
- ucc - V-Control-Curves

```
str IntPrjfolder.GetProjectFolderType()
```

RETURNS

The type of the project folder as string. For possible return values see list above.

SEE ALSO

[Application.GetProjectFolder\(\)](#)

IsProjectFolderType

This function checks if a project folder is of given type.

```
int IntPrjfolder.IsProjectFolderType(str type)
```

ARGUMENTS

type Folder type; for possible type values see [IntPrjfolder.GetProjectFolderType\(\)](#)

RETURNS

- 1** true, is of given type
- 0** false, is not of given type

SEE ALSO

[Application.GetProjectFolder\(\)](#), [IntPrjfolder.GetProjectFolderType\(\)](#)

5.6.33 IntQlim

Overview

[GetQlim](#)

GetQlim

Returns either the current maximum or the minimum reactive power limit, given the specified active power and voltage.

The active power must be given in the same units as the input mode definition of the capability curve object (parameter "inputmod" is 0 for MW/Mvar and 1 for p.u.).

```
float IntQlim.GetQlim(float p,
                     float v,
                     [float minmax]
                     )
```

ARGUMENTS

p the current value of active power in MW or p.u.

v the current value of voltage in p.u.

minmax (optional)

Returns either the maximum or minimum value. Possible values are:

-1 minimum value

1 maximum value. This is the default value

RETURNS

Returns the minimum/maximum limit. The units might be Mvar or p.u., depending on the input mode of the capability curve. Also, the limits are calculated for a single machine.

5.6.34 IntRas

Overview

[AddEvent](#)
[AddTrigger](#)
[IsValid](#)

AddEvent

Adds an event to the Remedial Action Scheme.

```
list IntRas.AddEvent(DataObject newEvent)
```

ARGUMENTS

newEvent

The event that shall be added.

AddTrigger

Adds either a condition or a gate to the Remedial Action Scheme.

```
list IntRas.AddTrigger(DataObject newTrigger)
```

ARGUMENTS

newTrigger

The condition or gate that shall be added.

IsValid

Checks if the Remedial Action Scheme is valid.

```
int IntRas.IsValid(int emitMessage = 0)
```

ARGUMENTS

emitMessage

Emit messages if not equal to zero.

RETURNS

0 If invalid.**1** If valid.

5.6.35 IntReport

Overview

[AddObject](#)
[AddObjects](#)
[CreateField](#)
[CreateTable](#)
[GetFieldCount](#)
[GetFieldDataType](#)
[GetFieldName](#)
[GetObjects](#)
[GetParameterValueAsDouble](#)
[GetParameterValueAsInteger](#)
[GetParameterValueAsString](#)
[GetRowCount](#)
[GetTableCount](#)
[GetTableName](#)
[GetValueAsDouble](#)
[GetValueAsInteger](#)
[GetValueAsObject](#)
[GetValueAsString](#)
[Reset](#)
[SetDefaultValue](#)
[SetValue](#)

AddObject

Adds the given object to the set of objects that are considered during report creation.

Typically, objects are automatically collected based on the Variable Selections in the report. In some cases, however, it might be necessary to manually add objects to the report creation mechanism.

The added object will be included in the return value of [IntReport.GetObjects\(\)](#). Moreover, if a Variable Selection for the class of the given object exists in the report, the corresponding table will include a row for the given object.

If the given object is already present in the set of collected objects (regardless if it was automatically collected or added with a previous call of this method or `IntReport.SetObjects()`), it will *not* be added a second time.

```
None IntReport.AddObject(DataObject objectToAdd)
```

ARGUMENTS

objectToAdd

The object to be added to the report generation mechanism. None is ignored.

SEE ALSO

[IntReport.AddObjects\(\)](#), [IntReport.GetObjects\(\)](#)

AddObjects

Adds the given list of objects to the set of objects that are considered during report creation.

See [IntReport.AddObject\(\)](#) for more details on adding objects.

```
None IntReport.AddObjects(list objectsToAdd)
```

ARGUMENTS

objectsToAdd

List of objects to be added to the report generation mechanism.

SEE ALSO

[IntReport.AddObject\(\)](#), [IntReport.GetObjects\(\)](#)

CreateField

Creates a new field (i.e. a column) with the specified name and data type, appending it to the specified table. The referenced table must have been previously created using the [IntReport.CreateTable\(\)](#) method.

```
int IntReport.CreateField(str tableName,
                        str fieldName,
                        int dataType)
```

ARGUMENTS

tableName

The name of a table (previously created using [IntReport.CreateTable\(\)](#)).

fieldName

The name of the new field, which must satisfy all of the following conditions:

- The name is not empty.
- The name only includes characters of the English alphabet, digits and under-scores.
- The name does not start with a digit or a capital (upper-case) character.

dataType An integer specifying the data type of the field. Possible values are

- | | |
|----------|--------------------------------|
| 0 | String |
| 1 | Integer |
| 2 | Floating point number (double) |
| 3 | Object |

RETURNS

An error code. Possible values are

- 0** No error has occurred, the field has been successfully created.
- 1** No table with the given name has been found.
- 2** The given field name is empty or blank.
- 3** Another field with the given name was already created for the specified table.
- 4** The given data type has no valid value (see argument description of *dataType*).

SEE ALSO

[IntReport.GetFieldCount\(\)](#), [IntReport.GetFieldName\(\)](#), [IntReport.GetFieldDataType\(\)](#)

CreateTable

Creates a new table with the given name.

In order to be visible in the Report Designer, a table needs to have at least one field (i.e. a column). Fields are created using the [IntReport.CreateField\(\)](#) method.

Using the [IntReport.SetValue\(\)](#) method, a table with fields can be filled with values, which are stored in rows (containing one value per table field).

Please note that the name of the table will be shown with the prefix 'Scripted' in the Report Designer (e.g. a table created with the name 'MyTable' will be shown as 'ScriptedMyTable' in the Report Designer). This mechanism helps to avoid name collisions with other, automatically generated tables (e.g. tables based on Variable Selections) and allows to quickly identify tables created by scripts in the Report Designer.

```
int IntReport.CreateTable(str name)
```

ARGUMENTS

name The name of the new table, which may only include characters of the English alphabet, digits and underscores and must not be empty.

RETURNS

An error code. Possible values are

- 0** No error has occurred, the table has been successfully created.
- 1** The given table name is empty or blank.
- 2** The given table name contains invalid characters (see description of argument *name*).
- 3** Another table with the given name was already created.

GetFieldCount

Returns the number of fields in the specified table.

```
int IntReport.GetFieldCount(str tableName)
```

ARGUMENTS

tableName
The name of the table.

RETURNS

The number of fields in the specified table or -1 if the specified table does not exist.

SEE ALSO

[IntReport.CreateField\(\)](#), [IntReport.GetFieldName\(\)](#), [IntReport.GetFieldDataType\(\)](#)

GetFieldDataType

Returns the data type (encoded as integer) of the specified field in the specified table.

```
int IntReport.GetFieldDataType(str tableName,
                              str fieldName)
```

ARGUMENTS

tableName

The name of the table.

fieldName

The name of the field.

RETURNS

An integer specifying the data type of the field or signalling an error. Possible values are

- 1** Error. The specified table or the specified field does not exist.
- 0** String
- 1** Integer
- 2** Floating point number (double)
- 3** Object

SEE ALSO

[IntReport.CreateField\(\)](#), [IntReport.GetFieldCount\(\)](#), [IntReport.GetFieldName\(\)](#)

GetFieldName

Determines the name of the field at the given field index of the specified table.

The given field index must be a non-negative number that is smaller than the field count of the specified table, which can be determined by calling [IntReport.GetFieldCount\(\)](#).

```
[int error, str name] IntReport.GetFieldName(str tableName,
                                             int fieldIndex)
```

ARGUMENTS

tableName

The name of the table.

fieldIndex

The index of the field (non-negative integer that is smaller than the field count of the specified table).

name (out)

The name of the field.

RETURNS

An error code. Possible values are:

- 0** No error has occurred, the field name has been successfully determined.
- 1** The specified table does not exist or the field index is out of bounds.

SEE ALSO

[IntReport.CreateField\(\)](#), [IntReport.GetFieldCount\(\)](#), [IntReport.GetFieldDataType\(\)](#)

GetObjects

Returns all objects that were collected by the report generation mechanism.

Besides objects that were automatically collected based the Variable Selections of a report, this set also includes objects that were added in the *AddObjects* script of the report (see [IntReport.AddObject\(\)](#) for details).

```
list IntReport.GetObjects()
```

RETURNS

A list of all collected objects.

SEE ALSO

[IntReport.AddObject\(\)](#), [IntReport.AddObjects\(\)](#)

GetParameterValueAsDouble

Returns the current value of the report parameter with the specified identifier as double.

This method is intended to be used with report parameters of data type 'Double' only.

```
[int error, float value] IntReport.GetParameterValueAsDouble(str identifier)
```

ARGUMENTS

identifier The identifier of the report parameter.

value (out)
The current value of the report parameter.

RETURNS

An error code. Possible values are

- 0** No error has occurred, the value has been successfully read.
- 1** No report parameter with the given identifier has been found.
- 2** The data type of the specified parameter is not numeric, conversion into double is not possible.

SEE ALSO

[IntReport.GetParameterValueAsString\(\)](#), [IntReport.GetParameterValueAsInteger\(\)](#)

GetParameterValueAsInteger

Returns the current value of the report parameter with the specified identifier as integer.

This method is intended to be used with report parameters of data type 'Integer' or 'Boolean' only.

Please note that the values of boolean report parameters are treated as integers, with 0 representing 'false' and 1 representing 'true'.

```
[int error, int value] IntReport.GetParameterValueAsInteger(str identifier)
```

ARGUMENTS

identifier The identifier of the report parameter.

value (out)
The current value of the report parameter.

RETURNS

An error code. Possible values are

- 0** No error has occurred, the value has been successfully read.
- 1** No report parameter with the given identifier has been found.
- 2** The data type of the specified parameter is not numeric, conversion into integer is not possible.

SEE ALSO

[IntReport.GetParameterValueAsString\(\)](#), [IntReport.GetParameterValueAsDouble\(\)](#)

GetParameterValueAsString

Returns the current value of the report parameter with the specified identifier as string.

This method is intended to be used with report parameters of data type 'String' only.

```
[int error, str value] IntReport.GetParameterValueAsString(str identifier)
```

ARGUMENTS

identifier The identifier of the report parameter.

value (out)
The current value of the report parameter.

RETURNS

An error code. Possible values are

- 0** No error has occurred, the value has been successfully read.
- 1** No report parameter with the given identifier has been found.

SEE ALSO

[IntReport.GetParameterValueAsInteger\(\)](#), [IntReport.GetParameterValueAsDouble\(\)](#)

GetRowCount

Returns the number of rows of the specified table.

The row count of a table is determined by the highest position, for which any of its field was assigned a value using the method [IntReport.SetValue\(\)](#). As positions start with zero (i.e. the first table row has position zero, the second table row has position one, and so on), the row count is always the highest position plus one. If the method [IntReport.SetValue\(\)](#) method has not been called on any field of the table, the row count will be zero. The value returned by this method can thus be used to determine the position for a new table row.

```
int IntReport.GetRowCount(str tableName)
```

ARGUMENTS

tableName

The name of the table.

RETURNS

The number of rows in the specified table or -1 if the specified table does not exist.

SEE ALSO

[IntReport.SetValue\(\)](#), [IntReport.GetValue\(\)](#)

GetTableCount

Returns the number of tables that have been created (using [IntReport.CreateTable\(\)](#)).

```
int IntReport.GetTableCount()
```

RETURNS

The number of tables that have been created (using [IntReport.CreateTable\(\)](#)).

SEE ALSO

[IntReport.GetTableName\(\)](#)

GetTableName

Determines the name of the table with the given table index.

The given table index must be a non-negative number that is smaller than the current table count, which can be determined by calling [IntReport.GetTableCount\(\)](#).

```
[int error, str name] IntReport.GetTableName(int tableIndex)
```

ARGUMENTS

tableIndex

The index of the table (a non-negative integer that is smaller than the current table count).

name (out)

The name of the table.

RETURNS

An error code. Possible values are:

- 0** No error has occurred, the table name was successfully determined.
- 1** The given table index is out of bounds.

SEE ALSO

[IntReport.GetTableCount\(\)](#)

GetValueAsDouble

Determines the double value at the given position (row) of the specified field in the specified table.

If the value at the given position of the specified field was not previously set (see [IntReport.SetValue\(\)](#)), the default value of the field is returned instead (see [IntReport.SetDefaultValue\(\)](#)).

This method is intended to be used with double fields only.

```
[int error, float value] IntReport.GetValueAsDouble(str tableName,
                                                    str fieldName,
                                                    int position)
```

ARGUMENTS

tableName

The name of the table.

fieldName

The name of the field.

position

The position (row).

value (out)

The value at the given position (row) of the specified field in the specified table.

RETURNS

An error code. Possible values are

- 0** No error has occurred, the value has been successfully read.
- 1** No table with the given name has been found.
- 2** No field with the given name has been found in the given table.
- 3** The data type of the given value argument does not match the data type of the given field.
- 4** The given position is out of bounds (negative or equal or greater than the row count of the table).

SEE ALSO

[IntReport.SetValue\(\)](#), [IntReport.SetDefaultValue\(\)](#), [IntReport.GetValueAsString\(\)](#),
[IntReport.GetValueAsInteger\(\)](#), [IntReport.GetValueAsObject\(\)](#)

GetValueAsInteger

Determines the integer value at the given position (row) of the specified field in the specified table.

If the value at the given position of the specified field was not previously set (see [IntReport.SetValue\(\)](#)), the default value of the field is returned instead (see [IntReport.SetDefaultValue\(\)](#)).

This method is intended to be used with integer fields only.

```
[int error, int value] IntReport.GetValueAsInteger(str tableName,
                                                    str fieldName,
                                                    int position)
```

ARGUMENTS

tableName

The name of the table.

fieldName

The name of the field.

position The position (row).*value (out)*

The value at the given position (row) of the specified field in the specified table.

RETURNS

An error code. Possible values are

- 0** No error has occurred, the value has been successfully read.
- 1** No table with the given name has been found.
- 2** No field with the given name has been found in the given table.
- 3** The data type of the given value argument does not match the data type of the given field.
- 4** The given position is out of bounds (negative or equal or greater than the row count of the table).

SEE ALSO

[IntReport.SetValue\(\)](#), [IntReport.SetDefaultValue\(\)](#), [IntReport.GetValueAsString\(\)](#),
[IntReport.GetValueAsDouble\(\)](#), [IntReport.GetValueAsObject\(\)](#)

GetValueAsObject

Determines the object at the given position (row) of the specified field in the specified table.

If the object at the given position of the specified field was not previously set (see [IntReport.SetValue\(\)](#)), then None is returned instead.

This method is intended to be used with object fields only.

```
[int error, DataObject value] IntReport.GetValueAsObject(str tableName,
                                                         str fieldName,
                                                         int position)
```

ARGUMENTS

tableName

The name of the table.

fieldName

The name of the field.

position The position (row).*value (out)*

The object at the given position (row) of the specified field in the specified table.

RETURNS

An error code. Possible values are

- 0** No error has occurred, the value has been successfully read.
- 1** No table with the given name has been found.
- 2** No field with the given name has been found in the given table.
- 3** The data type of the given value argument does not match the data type of the given field.
- 4** The given position is out of bounds (negative or equal or greater than the row count of the table).

SEE ALSO

[IntReport.SetValue\(\)](#), [IntReport.SetDefaultValue\(\)](#), [IntReport.GetValueAsString\(\)](#),
[IntReport.GetValueAsInteger\(\)](#), [IntReport.GetValueAsDouble\(\)](#)

GetValueAsString

Determines the string value at the given position (row) of the specified field in the specified table.

If the value at the given position of the specified field was not previously set (see [IntReport.SetValue\(\)](#)), the default value of the field is returned instead (see [IntReport.SetDefaultValue\(\)](#)).

This method is intended to be used with string fields only.

```
[int error, str value] IntReport.GetValueAsString(str tableName,
                                                str fieldName,
                                                int position)
```

ARGUMENTS

tableName

The name of the table.

fieldName

The name of the field.

position

The position (row).

value (out)

The value at the given position (row) of the specified field in the specified table.

RETURNS

An error code. Possible values are

- 0** No error has occurred, the value has been successfully read.
- 1** No table with the given name has been found.
- 2** No field with the given name has been found in the given table.
- 3** The data type of the given value argument does not match the data type of the given field.
- 4** The given position is out of bounds (negative or equal or greater than the row count of the table).

SEE ALSO

[IntReport.SetValue\(\)](#), [IntReport.SetDefaultValue\(\)](#), [IntReport.GetValueAsInteger\(\)](#),
[IntReport.GetValueAsDouble\(\)](#), [IntReport.GetValueAsObject\(\)](#)

Reset

Removes all objects and tables added by the extension script.

When an extension script is executed outside of the regular Report Generation mechanism (e.g. by pressing the 'Execute' button of the script), all added objects and tables remain in the memory of the corresponding Report Template (IntReport) object even after the script was executed. By calling this method at the beginning of the extension script, i.e. before any objects or tables are added, users can make sure that no added objects or tables from a previous, manual script execution are left.

When running the regular Report Generation command, this method is automatically called before the extension script is executed.

```
None IntReport.Reset()
```

SetDefaultValue

Stores the given value as default value for the specified field of the specified table. The specified table and field must have been previously created using [IntReport.CreateTable\(\)](#) and [IntReport.CreateField\(\)](#), respectively.

If the default value of a field is not explicitly set, its default value is either an empty string (for string fields), zero (for integer and double fields) or None (for object fields).

Please note that the default value of object fields cannot be changed.

```
int IntReport.SetDefaultValue(str tableName,
                             str fieldName,
                             int|float|str value)
```

ARGUMENTS

tableName

The name of the table.

fieldName

the name of the field.

value

The value that should be used as default value.

RETURNS

An error code. Possible values are

- 0** No error has occurred, the default value has been successfully set.
- 1** No table with the given name has been found.
- 2** No field with the given name has been found in the given table.
- 3** The data type of the given value does not match the data type of the given field.
- 4** The data type of the given value is not supported by this method.

SEE ALSO

[IntReport.SetValue\(\)](#), [IntReport.GetValue\(\)](#)

SetValue

Stores the given value at the position in the specified field of the specified table. The specified table and field must have been previously created using [IntReport.CreateTable\(\)](#) and [IntReport.CreateField\(\)](#), respectively.

If the given field is a string field, numeric values are implicitly converted into strings and if the given field is an integer field, double values are implicitly converted into integers (and vice versa). Trying to store a string value to a numeric (i.e. integer or double) will result in an error (see return value). Furthermore, objects can only be stored in object fields and object fields only accept objects.

In order to use this method effectively, it is important to understand how fields work. Each field maps positions (non-negative integers) to values of its data type, e.g. a string field maps positions to strings. When a field is created (see [IntReport.CreateField\(\)](#)), it does not map any position to a value. By calling this method (for each desired field and position), users specify what value is stored at which position. The highest position, for which at least one field in a table has a value set, determines the row count of the table (see [IntReport.GetRowCount\(\)](#)).

This means that users can conveniently set the value of a field at any desired position in any order, but need to be aware that the row count of the whole table will be the highest position they set a value for. If a valid position of a field (i.e. a non-negative integer that is smaller than the current row count of the table) has not been assigned a value, the field will return its default value whenever the value at the position is to be determined (see [IntReport.GetValue\(\)](#)). The default value of a field can be changed by calling the method [IntReport.SetDefaultValue\(\)](#).

```
int IntReport.SetValue(str tableName,
                      str fieldName,
                      int rowIndex,
                      int|float|str|DataObject value)
```

ARGUMENTS

<i>tableName</i>	The name of the table.
<i>fieldName</i>	The name of the field.
<i>position</i>	The position (a non-negative integer; negative positions are treated as zero and should not be used).
<i>value</i>	The value that should be set in the given table, field and position.

RETURNS

An error code. Possible values are

- 0** No error has occurred, the value has been successfully set.
- 1** No table with the given name has been found.
- 2** No field with the given name has been found in the given table.
- 3** The data type of the given value does not match the data type of the given field.
- 4** The data type of the given value is not supported by this method.

SEE ALSO

[IntReport.SetDefaultValue\(\)](#), [IntReport.GetValue\(\)](#), [IntReport.GetRowCount\(\)](#)

5.6.36 IntRunarrange

Overview

[GetSwitchStatus](#)

GetSwitchStatus

Determines the status of the given switch in the running arrangement, without assigning or applying the running arrangement.

```
int IntRunarrange.GetSwitchStatus(DataObject switch)
```

ARGUMENTS

switch *ElmCoupe* or *StaSwitch* from which to get the status stored in running arrangement

RETURNS

Status of the switch in the running arrangement. Possible values are

- | | |
|----|---|
| -1 | Switch is not part of the running arrangement |
| 0 | Switch is open |
| 1 | Switch is closed |

5.6.37 IntScenario

Overview

[Activate](#)
[Apply](#)
[ApplySelective](#)
[Deactivate](#)
[DiscardChanges](#)
[GetObjects](#)
[GetOperationValue](#)
[ReleaseMemory](#)
[Save](#)
[SetOperationValue](#)

Activate

Activates a scenario. If there is currently another scenario active that one will be deactivated automatically.

```
int IntScenario.Activate()
```

RETURNS

- 0** successfully activated
- 1** error, e.g. already activate, no project and study case active

Apply

Copies the values stored in a scenario to the corresponding network elements. The value transfer is identical to scenario activation, however, the scenario will not be activated. In case of having an active variation or another scenario, the values will be recorded there.

```
int IntScenario.Apply([int requestUserConfirmation])
int IntScenario.Apply(int requestUserConfirmation,
                      DataObject parentfilter
                      )
```

ARGUMENTS

requestUserConfirmation(optional)

- 0** silent, just apply the data without further confirmation requests
- 1** request a user confirmation first (default)

parentfilter (optional)

If given, scenario data is only applied for given object and all of its children (hierarchical filter)

RETURNS

- 0 on success

ApplySelective

Similar to function Apply() but copies only the set of attributes listed in the given apply configuration. An apply configuration is a folder consisting of variable selection objects (IntMon), one per class. For each class the attributes to be copied can be selected.

```
int IntScenario.ApplySelective(DataObject configuration)
int IntScenario.ApplySelective(int requestUserConfirmation,
                              DataObject applyConfiguration
                              )
```

ARGUMENTS

applyConfiguration

folder containing variable selection objects

requestUserConfirmation(optional)

- 0** silent, just apply the data without further confirmation requests
- 1** request a user confirmation first (default)

RETURNS

- 0 on succes

Deactivate

Deactivates the currently active scenario.

```
int IntScenario.Deactivate([int saveOrUndo])
```

ARGUMENTS

saveOrUndo(optional)

Determines whether changes in active scenario will be saved or discarded before the scenario is deactivated.

- | | |
|----------|--------------------------|
| 0 | discard changes(default) |
| 1 | save changes |
| 2 | ask the user |

RETURNS

0 on success

DiscardChanges

Discards all unsaved changes made to a scenario.

```
int IntScenario.DiscardChanges([int resetCalculation])
```

ARGUMENTS

resetCalculation(optional)

Determines whether calculation results should be reset afterwards.

- | | |
|----------|--------------------------|
| 0 | no reset, retain results |
| 1 | default, reset results |

RETURNS

- | | |
|----------|--|
| 0 | on success |
| 1 | error, scenario was not modified or not active |

GetObjects

Returns a set of all objects for which operational data are stored in scenario.

```
list IntScenario.GetObjects()
```

RETURNS

Set of all objects for which operational data are stored in scenario

GetOperationValue

This function offers read access to the operation data values stored in the scenario.

```
[int error,  
int|float|str|DataObject value]  
IntScenario.GetOperationValue(DataObject obj,  
                               str attribute,  
                               [int fromObject])
```

ARGUMENTS

- value (out)* variable that holds the value after call
- obj* object for which the operation to be retrieved
- attribute* name of the operation data attribute
- fromObject* only if current scenario is active:
- 0** value is taken from scenario (as stored on db)
 - 1** (default), value is taken from object (reflects un-saved modifications)

RETURNS

0 on success

ReleaseMemory

Releases the memory used by a scenario. Any further access to the scenario will reload the data from database. The function can be called on inactive scenarios only. Use this function with care!

```
int IntScenario.ReleaseMemory()
```

RETURNS

- 0** on success
- 1** error, scenario is active

Save

Saves the current active value of all operational attributes for all active network elements to database.

```
int IntScenario.Save()
```

RETURNS

- 0** successfully saved
- 1** error, scenario was not modified or not active

SetOperationValue

Offers write access to operational data stored in a scenario.

```
int IntScenario.SetOperationValue(int|float|str|DataObject newvalue,
                                  DataObject obj,
                                  str attribute,
                                  [int toObject = 1]
                                  )
```

ARGUMENTS

- newvalue* New value to store in the scenario.
- obj* Object for which the operation data to store.
- attribute* Name of the operation data attribute.
- toObject* Only if current scenario is active:
- 0** Value is only stored to scenario on db.
 - 1** As 0 but value is also updated on object in memory. (default)

RETURNS

0 on success, otherwise 1.

5.6.38 IntScensched

Overview

[Activate](#)
[Deactivate](#)
[DeleteRow](#)
[GetScenario](#)
[GetStartEndTime](#)
[SearchScenario](#)

Activate

Activates a scenario scheduler.

```
int IntScensched.Activate()
```

RETURNS

- 0** successfully activated
- 1** error, e.g. already activate, no project and study case active

Deactivate

Deactivates a scenario scheduler.

```
int IntScensched.Deactivate()
```

RETURNS

- 0** successfully deactivated
- 1** error, e.g. already deactivates, no project and study case active

DeleteRow

Delete row(s) of the scenario scheduler.

```
None IntScensched.DeleteRow(int row, [int numberOfRows])
```

ARGUMENTS

row row number (begin with 0)

numberOfRows (optional)
number of rows to delete (default = 1)

GetScenario

Get the scenario for corresponding time 'iTime'.

```
DataObject IntScensched.GetScenario(int iTime)
```

ARGUMENTS

iTime Time (UCTE) to get the corresponding scenario.

RETURNS

None No scenario at time 'iTime' defined

IntScenario Scenario will be activated at time 'iTime'

GetStartEndTime

Get start and end time of the corresponding scenario.

```
[int error  
int startTime,  
int endTime ] IntScensched.GetStartEndTime(DataObject scenario)
```

ARGUMENTS

scenario A scenario (*IntScenario*).

startTime (out)
Start time (time when the scenario is activated)).

endTime (out)
End time (time until the scenario is still activated).

RETURNS

−1 Scenario not found (not part of scenario scheduler)

≥ 0 Vector index (index of scenario)

SearchScenario

Search at which table index (row) the corresponding scenario is defined in the scheduler.

```
int IntScensched.SearchScenario(DataObject scenarioObject)
```

ARGUMENTS

scenarioObject
scenario object

RETURNS

- −1 Scenario not found (not part of scenario scheduler).
- ≥ 0 Vector index (row, index of scenario).

5.6.39 IntScheme

Overview

[Activate](#)
[Consolidate](#)
[Deactivate](#)
[GetActiveScheduler](#)
[IsActive](#)
[NewStage](#)

Activate

Activates a variation and inserts a variation reference in a 'Variation Configuration Folder'stored in the study case.

```
int IntScheme.Activate()
```

RETURNS

- 0 successfully activated
- 1 error, e.g. already activate, no project and study case active

Consolidate

Changes that are recorded in this variation will be permanently applied to the original location.
Note: Modified scenarios are not saved.

Works only:

- for non network variation e.g. used for Mvar Limit Curves, Thermal Ratings ...
- and the variation must be activated.

```
int IntScheme.Consolidate()
```

RETURNS

- 0 On success.
- 1 If an error has occurred.

Deactivate

Deactivates a variation and removes the variation reference in the 'Variation Configuration Folder'stored in the study case.

```
int IntScheme.Deactivate()
```

RETURNS

- 0** successfully deactivated
- 1** error, e.g. already deactivated, no project and study case active

GetActiveScheduler

Returns the corresponding active variation scheduler or None if no scheduler is active for this variation (IntScheme).

```
DataObject IntScheme.GetActiveScheduler()
```

IsActive

Checks if this variation is active.

```
int IntScheme.IsActive()
```

RETURNS

- 1** Variation is active.
- 0** Variation is not active.

NewStage

Adds a new expansion stage into the variation (name = sname).

```
int IntScheme.NewStage(str name,
                       int activationTime,
                       int activate
                       )
```

ARGUMENTS

name Name of the new expansion stage.

activationTime

Activation time of the new expansion stage in seconds since 01.01.1970 00:00:00.

activate

- 1** The actual study time is changed to the parameter iUTCtime and the variation will be activated. If the variation is a network variation, the new created expansion stage is used as 'recording' expansion stage. If the variation (this) is not active, the variation will be automatically activated.
- 0** Expansion stage and/or variation will not be activated.

5.6.40 IntScheduler

Overview

[Activate](#)
[Deactivate](#)
[Update](#)

Activate

Activates a variation scheduler. An already activated scheduler for same variation will be deactivated automatically.

```
int IntScheduler.Activate()
```

RETURNS

= 0 On success
≠ 0 If an error has occurred

Deactivate

Deactivates a variation scheduler.

```
int IntScheduler.Deactivate()
```

RETURNS

= 0 on success
≠ 0 If an error has occurred especially if scheduler was not active (to be consistent with scenario scheduler deactivate()).

Update

Update variation scheduler (updates internal reference stages).

```
int IntScheduler.Update()
```

RETURNS

= 0 On success
≠ 0 If an error has occurred

5.6.41 IntSstage

Overview

[Activate](#)
[ApplyChanges](#)
[CreateStageObject](#)
[EnableDiffMode](#)
[GetVariation](#)
[IsExcluded](#)
[PrintModifications](#)
[ReadValue](#)
[WriteValue](#)

Activate

Activates the expansion stage and sets the 'recording' expansion stage. The study time will be automatically set to the correponsing time of the stage.

```
int IntSstage.Activate([int iQueryOption])
```

ARGUMENTS

iQueryOption

- | | |
|----------|--|
| 0 | (default) The user must confirm the query. |
| 1 | The “Yes” button is automatically applied. |
| 2 | The “No” button is automatically applied. |

RETURNS

- | | |
|----------|-----------------------------------|
| 0 | Successfully activated. |
| 1 | Error, e.g. scheme is not active. |

ApplyChanges

Applies the changes of the expansion stage. Only possible when the stage is not active. This function is equivalent to pressing the "Apply" button in the dialog, except that no confirmation dialog is shown.

```
int IntSstage.ApplyChanges()
```

RETURNS

- | | |
|----------|------------|
| 0 | on success |
| 1 | on error |

CreateStageObject

Creates a stage object (delta or delete object) inside corresponding *IntSstage*.

```
DataObject IntSstage.CreateStageObject(int type,
                                         DataObject rootObject
                                         )
```


ARGUMENTS

<i>type</i>	Kind of object to create
1	Delete object
2	Delta object

rootObject

(Original) object for which the stage object should be created.

RETURNS

Stage object on success.

EnableDiffMode

Enables the comparison mode for the variation management system. If the mode is enabled a DELTA object is only created when the object is different.

```
None IntSstage.EnableDiffMode(int enable)
```

ARGUMENTS

<i>enable</i>	
0	disables the difference/comparison mode
1	enables the difference/comparison mode

GetVariation

Returns variation of expansion stage.

```
DataObject IntSstage.GetVariation()
```

RETURNS

Variation object corresponding to stage.

DEPRECATED NAMES

GetScheme

IsExcluded

Returns if expansion stage flag 'Exclude from Activation' is switched on (return value = 1) or not (return value = 0). The function checks also if the stage is excluded regarding the restricted validity period of the corresponding variation and considers also the settings of an variation scheduler when defined.

```
float IntSstage.IsExcluded()
```

RETURNS

1	if stage is excluded
0	if stage is considered

PrintModifications

Reports in the the output window the modification of the corresponding expansion stage. Works only if the expansion stage is the active 'recording' expansion stage.

```
int IntSstage.PrintModifications([int onlyNetworkData,]
                                [str ignoredParameter]
                                )
```

ARGUMENTS

onlyNetworkData (optional)

- 1** (default) Show only network data modifications. Graphical modifications are not report when the diagrams folder are recored.
- 0** Show all modifications

ignoredParameter (optional)

Comma separated list of parameters which are ignored for reporting.

RETURNS

- 0** on success
- 1** if the actual expansion stage is not the 'recording' expansion stage.

ReadValue

Get the value for an attribute of an ADD or DELTA object which modifies “rootObj” (root object).

```
[int error,
float|str|DataObject value] IntSstage.ReadValue(DataObject rootObj,
                                                str attributeName)
```

RETURNS

- = 0 On success.
- ≠ 0 Error e.g. wrong data type.

WriteValue

Writes a value for an attribute to an ADD or DELTA object which modifies rootObj (root object).

```
int IntSstage.WriteValue(float|str|DataObject value,
                          DataObject rootObj,
                          str attributeName)
```

RETURNS

- = 0 On success.
- ≠ 0 Error e.g. wrong data type.

5.6.42 IntSubset

Overview

[Apply](#)
[ApplySelective](#)
[Clear](#)
[GetConfiguration](#)
[GetObjects](#)

Apply

Copies the values stored in a scenario to the corresponding network elements. The value transfer is identical to scenario activation, however, the scenario will not be activated. In case of having an active variation or another scenario, the values will be recorded there.

```
int IntSubset.Apply([int requestUserConfirmation])
```

ARGUMENTS

requestUserConfirmation(optional)

- | | |
|----------|---|
| 0 | silent, just apply the data without further confirmation requests |
| 1 | request a user confirmation first (default) |

RETURNS

0 on success

ApplySelective

Similar to function Apply() but copies only the set of attributes listed in the given apply configuration. An apply configuration is a folder consisting of variable selection objects (IntMon), one per class. For each class the attributes to be copied can be selected.

```
int IntSubset.ApplySelective(DataObject applyConfiguration)
int IntSubset.ApplySelective(int requestUserConfirmation,
                             DataObject applyConfiguration
                             )
```

ARGUMENTS

applyConfiguration

folder containing variable selection objects

requestUserConfirmation(optional)

- | | |
|----------|---|
| 0 | silent, just apply the data without further confirmation requests |
| 1 | request a user confirmation first (default) |

RETURNS

0 on succes

Clear

Clears all values stored in the subset.

Please note that this function can only be called on subsets of currently in-active scenarios.

```
int IntSubset.Clear()
```

RETURNS

- 0 On success.
- 1 On error, e.g. subset belongs to a currently active scenario.

GetConfiguration

Returns class and attribute configuration for the subset.

```
str IntSubset.GetConfiguration(str subset)
```

ARGUMENTS

subset

RETURNS

Returns a list of classes and attributes for which operational data are stored in subset.

GetObjects

Returns a set of all objects for which operational data are stored in the subset.

```
list IntSubset.GetObjects()
```

RETURNS

Set of all objects for which operational data are stored in the subset

5.6.43 IntSym**Overview**

[ConvertGeometriesToMDLString](#)

ConvertGeometriesToMDLString

Converts the internal legacy geometry string to Modelica geometry description language introduced in PowerFactory version 23.

```
None IntSym.ConvertGeometriesToMDLString()
```

5.6.44 IntTemplate

Overview

[InsertTemplate](#)

[PackExternalReferences](#)

InsertTemplate

Inserts graphic templates from both project library and global libraries into the specified target folder.

```
None IntTemplate.InsertTemplate(DataObject targetFolder,
                                [DataObject conNode1],
                                [DataObject conNode2],
                                [DataObject diagram],
                                [float posX],
                                [float posY],
                                [int rotate],
                                [int designViewSubstat])
```

ARGUMENTS

targetFolder

Target folder of new elements.

None Default target folder of diagram is used.

conNode1

Relevant if template shall be connected. Any terminal or cubicle.

conNode2

Relevant if template shall be connected. Any terminal or cubicle.

diagram

Target diagram if template shall also be inserted graphically.

posX

x-position in mm. Only relevant if target diagram is specified and template is a node template or template is not directly connected (node templates, e.g. substation templates).

posY

y-position in mm. Only relevant if target diagram is specified and template is a node template or template is not directly connected (node templates, e.g. substation templates).

rotate

Rotate inserted object(s). Only relevant if target diagram is specified.

0 Do not rotate

1 Rotate by 90 degrees

designViewSubstat

Design view representation (for substation templates only). Only relevant if target diagram is specified.

0 Beach ball representation

1 Design view

PackExternalReferences

Copies all external references into the template. Equivalent to pressing the 'Pack' button in the dialog, except that no settings dialog is shown.

```
int IntTemplate.PackExternalReferences (bool includeGlobalLibrary)
```

ARGUMENTS

includeGlobalLibrary

Specifies whether references to types in the DlgSILENT library shall also be included.

RETURNS

0 on success
1 on failure

5.6.45 IntThrating

Overview

[GetCriticalTimePhase](#)
[GetRating](#)
[Resize](#)

GetCriticalTimePhase

This function returns the smallest duration (time-phase) for which the power flow is beyond the rating.

```
float IntThrating.GetCriticalTimePhase (float Flow,  
                                       float Loading  
                                       )
```

ARGUMENTS

Flow Power from the load flow calculation, in MVA.
Loading Element loading, in %.

RETURNS

>0 Smallest time-phase for which the flow is beyond the rating.
-1 In case that no rating is violated.

GetRating

This function returns the rating in MVA according to the thermal rating table, considering element overloading and its duration (time-phase).

```
float IntThrating.GetRating (float Loading,  
                             float Duration  
                             )
```

ARGUMENTS

Loading Element loading, in %.

Duration Duration or time phase for which the loading is considered, in minutes

RETURNS

Rating in MVA or 0 if not found.

Resize

Resizes the configuration vectors like configTa,condigWind,configSolar,preload or duration

```
void IntThrating.Resize(int size, str name)
```

ARGUMENTS

size size of the referenced vector

name reference to the vector ('configTa','configWind','configSolar', 'preload' or 'duration')

RETURNS

If the resize is unsuccessful the error message shall be issued.

5.6.46 IntUrl**Overview**

[View](#)

View

Requests the operating system to open given URL for viewing. The performed action depends on the default action configured in the system. For example, by default 'http://www.google.com' would be opened in standard browser.

Please note, the action is only executed if access to given URL is enabled in the 'External Access' configuration of PowerFactory (IntExtaccess).

```
int IntUrl.View()
```

RETURNS

The returned value reports the success of the operation:

- 0** Success, URL was opened
- 1** Error, URL was not opened (because of invalid address or security reasons)

5.6.47 IntUser

Overview

[Purge](#)
[SetPassword](#)
[TerminateSession](#)

Purge

Purges project storage and updates storage statistics for all projects of the user.

Requires write access to the project; the functions does nothing when the project is locked by another user.

```
None IntUser.Purge()
```

SetPassword

Sets the password for the user the function is called on.

Note: Only the administrator user is allowed to use this function. He can (re-)set the password for every user.

```
int IntUser.SetPassword(str newpassword)
```

ARGUMENTS

newpassword
Case sensitive user password to set

RETURNS

Returns whether or not the password has successfully been set. Possible values are:

0	error
1	password set successfully

TerminateSession

Allows the Administrator to log out another user. Prints an error if the current user is not the Administrator.

```
None IntUser.TerminateSession()
```


5.6.48 IntUserman

Overview

CreateGroup
CreateUser
GetGroups
GetUsers
UpdateGroups

CreateGroup

Creates a new user group of given name. If a group with given name already exists the existing one is returned instead.

Note: Only Administrator user is allowed to call this function.

```
DataObject IntUserman.CreateGroup(str name)
```

ARGUMENTS

name Given name of the user group

RETURNS

Created user group (IntGroup)

CreateUser

Creates a new user with given name. If the user already exists the existing one is returned instead.

Note: Only Administrator user is allowed to call this function.

```
DataObject IntUserman.CreateUser(str name)
```

ARGUMENTS

name Given name of the user

RETURNS

Created user (IntUser)

GetGroups

Returns a container with all user groups.

Note: Only the administrator user is allowed to call this function.

```
list IntUserman.GetGroups()
```

RETURNS

Set of all available users

GetUsers

Returns a container with all users as they are currently visible in the Data Manager tree.

Note: Only the administrator user is allowed to call this function.

```
list IntUserman.GetUsers()
```

RETURNS

Set of all available users

UpdateGroups

Updates the Everybody group so it contains all currently existing users and cleans it of removed users.

```
None IntUserman.UpdateGroups()
```

5.6.49 IntVec

Overview

[Get](#)
[Init](#)
[Max](#)
[Mean](#)
[Min](#)
[Resize](#)
[Save](#)
[Set](#)
[Size](#)
[Sort](#)

Get

Get the value in row index. Index is one based, therefore the index of the first entry is 1.

```
float IntVec.Get(int index)
```

ARGUMENTS

index Index in vector, one based.

SEE ALSO

[IntVec.Set\(\)](#)

Init

Initializes the vector. Resizes the vector and initializes all values to 0.

This operation is performed in memory only. Use [IntVec.Save\(\)](#) to save the modified vector to database.

```
None IntVec.Init(int size)
```

ARGUMENTS

size The new size of the vector.

Max

Gets the maximum value stored in the vector.

```
float IntVec.Max()
```

RETURNS

The maximum value stored in the vector. Empty vectors return 0 as maximum value.

Mean

Calculates the average value of the vector.

```
float IntVec.Mean()
```

RETURNS

The average value of the vector. A value of 0. is returned for empty vectors.

Min

Gets the minimum value stored in the vector.

```
float IntVec.Min()
```

RETURNS

The minimum value stored in the vector. Empty vectors return 0 as minimum value.

Resize

Resizes the vector. Inserted values are initialized to 0.

This operation is performed in memory only. Use [IntVec.Save\(\)](#) to save the modified vector to database.

```
None IntVec.Resize(int size)
```

ARGUMENTS

size The new size.

Save

Saves the current state of this vector to database.

If the matrix is calculation relevant, an optional parameter allows to control whether available calculation results shall be reset afterwards or not.

Note: In QDSL, the calculation results are never reset and the parameter "resetCalculation" is ignored.

```
None IntVec.Save()
None IntVec.Save(int resetCalculation)
```

ARGUMENTS

resetCalculation (optional)

- 1** reset calculation results (default)
- 0** keep calculation results

Set

Set the value in row index. Index is one based, therefore the index of the first entry is 1. The vector is resized automatically to size index in case that the index exceeds the current vector size. Values inserted are automatically initialized to a value of 0.

This operation is performed in memory only. Use [IntVec.Save\(\)](#) to save the modified vector to database.

```
None IntVec.Set(int index,
                float value)
```

ARGUMENTS

- index* Index in vector.
- value* Value to assign in row index.

SEE ALSO

[IntVec.Get\(\)](#)

Size

Returns the size of the vector.

```
int IntVec.Size()
```

RETURNS

The size of the vector.

Sort

Sorts the vector.

This operation is performed in memory only. Use [IntVec.Save\(\)](#) to save the modified vector to database.

```
None IntVec.Sort([int ascending = 0])
```

ARGUMENTS

ascending

Sort order:

- 0** Highest value first (descending, default).
- 1** Smallest value first (ascending).

5.6.50 IntVecobj

Overview

[Get](#)
[Resize](#)
[Save](#)
[Search](#)
[Set](#)
[Size](#)

Get

Get the object in row index. Index is one based, therefore the index of the first entry is 1.

```
DataObject IntVecobj.Get(int index)
```

ARGUMENTS

index Index in vector, one based.

SEE ALSO

[IntVecobj.Set\(\)](#)

Resize

Resizes the vector. Inserted new entries are initialized to None.

This operation is performed in memory only. Use [IntVecobj.Save\(\)](#) to save the modified vector to database.

```
None IntVecobj.Resize(int size)
```

ARGUMENTS

size The new size.

Save

Saves the current state of this vector to database.

If the vector is calculation relevant, an optional parameter allows to control whether available calculation results shall be reset afterwards or not.

Note: In QDSL, the calculation results are never reset and the parameter "resetCalculation" is ignored.

```
None IntVecobj.Save()  
None IntVecobj.Save(int resetCalculation)
```

ARGUMENTS

resetCalculation (optional)

1	reset calculation results (default)
0	keep calculation results

Search

Search if the object (obj) is part of the vecor and returns the corresponding index of the vector (one based).

```
int IntVecobj.Search(DataObject obj)
```

RETURNS

- 1 ... size** object found, located at index
- 0** object not part of vector

Set

Set the object (obj) in row index. Index is one based, therefore the index of the first entry is 1. The vector is resized automatically to size index in case that the index exceeds the current vector size. Object inserted are automatically initialized to a value of None.

This operation is performed in memory only. Use [IntVecobj.Save\(\)](#) to save the modified vector to database.

```
None IntVecobj.Set(int index,
                  DataObject obj)
```

ARGUMENTS

- index* Index in vector.
- obj* Object to assign in row index.

SEE ALSO

[IntVecobj.Get\(\)](#)

Size

Returns the size of the vector.

```
int IntVecobj.Size()
```

RETURNS

- The size of the vector.

5.6.51 IntVersion

Overview

[CreateDerivedProject](#)
[GetDerivedProjects](#)
[GetHistoricalProject](#)
[Rollback](#)

CreateDerivedProject

Creates a derived project from the version.

```
DataObject IntVersion.CreateDerivedProject (str name,  
                                           [DataObject parent]  
                                           )
```

ARGUMENTS

name The name of the project which will be created.

parent(optional)

The parent of the project which will be created. Default is the current user.

RETURNS

Returns the created project.

GetDerivedProjects

list of projects derived from this version

```
list IntVersion.GetDerivedProjects()
```

RETURNS

list of derived projects

GetHistoricalProject

Returns historic project within version

```
DataObject IntVersion.GetHistoricalProject()
```

RETURNS

Returns the historic project object

Rollback

Roll backs the project to this version. No project have to be active. Furthermore no script from the project of the version have to be running.

```
int IntVersion.Rollback()
```

RETURNS

0 on success
1 otherwise

5.6.52 IntViewbookmark

Overview

[JumpTo](#)
[UpdateFromCurrentView](#)

JumpTo

Opens the referenced diagram (if not already open) and sets the viewing area.

```
None IntViewbookmark.JumpTo()
```

UpdateFromCurrentView

Updates the bookmark's diagram and view area from the current drawing window.

```
None IntViewbookmark.UpdateFromCurrentView()
```

5.6.53 PltAxis

Overview

[DoAutoScale](#)
[SetFont](#)

DoAutoScale

Adapts the axis range such that it includes the entire data range. Note: Only works if the plot this axis belongs to is currently shown.

```
None PltAxis.DoAutoScale()
```

SetFont

Sets the font for this axis

```
None PltAxis.SetFont(str fontName,  
                     int fontSize,  
                     int fontStyle)
```

ARGUMENTS

fontName Font name

fontSize Font size

fontStyle Font style

1 Bold

- 2 Italic
- 3 Bold and italic
- 4 Underline

5.6.54 PltBiasdiff

Overview

[AddCurve](#)
[AddCurves](#)
[ClearCurves](#)

AddCurve

Adds an element to the plot and optionally sets the drawing style.

```
None PltBiasdiff.AddCurve(DataObject element,  
                           [int colour,]  
                           [int lineStyle,]  
                           [float lineWidth])
```

ARGUMENTS

- element* The protection device to be added.
- colour (optional)*
 Encoded colour value to be used. See: [Application.EncodeColour\(\)](#)
- lineStyle (optional)*
 The line style to be used.
- lineWidth (optional)*
 The line width to be used.

AddCurves

Adds elements to the plot.

```
None PltBiasdiff.AddCurves(list elements)
```

ARGUMENTS

- elements* The protection devices to be added.

ClearCurves

Removes all elements from the plot.

```
None PltBiasdiff.ClearCurves()
```

5.6.55 PltComplexdata

Overview

[AddVector](#)
[ChangeColourPalette](#)
[ClearVectors](#)

AddVector

Appends a vector to the plot.

```
None PltComplexdata.AddVector(DataObject element,  
                               string complexVariable)
```

ARGUMENTS

element Element to display

complexVariable

Complex variable to display, e.g.: 'm:ur:bus1 + j * m:ui:bus1'

ChangeColourPalette

Colours the vectors according to the colour palette identified by the given name. Additionally, the colour palette is set as the object's default palette.

```
None PltComplexdata.ChangeColourPalette(str paletteName)
```

ARGUMENTS

paletteName

Name of the colour palette to apply

RETURNS

0 on success

1 on error

ClearVectors

Removes all vectors from the plot.

```
None PltComplexdata.ClearVectors()
```

5.6.56 PltDataseries

Overview

[AddCurve](#)
[AddXYCurve](#)
[ChangeColourPalette](#)
[ClearCurves](#)
[GetDataSource](#)
[GetIntCalces](#)
[RemoveCurve](#)
[SetLabelFont](#)

AddCurve

Appends a curve to the plot.

```
None PltDataseries.AddCurve(DataObject element,  
                             str varname,  
                             [DataObject datasource]  
                             )
```

ARGUMENTS

element Element to display

varname Name of the element variable to display

datasource (optional)

Data source to assign to the curve (ElmRes or IntComtrade). If not specified, the plot's default result file will be used for the curve.

SEE ALSO

[GrpPage.GetOrInsertPlot\(\)](#)

AddXYCurve

Appends a curve to a XY plot.

```
None PltDataseries.AddXYCurve(DataObject elementX,  
                               str varnameX,  
                               DataObject elementY,  
                               str varnameY,  
                               [DataObject datasource]  
                               )
```

ARGUMENTS

elementX Element to display on x-axis

varnameX

Name of the element variable to display on x-axis

elementY Element to display on y-axis

varnameY

Name of the element variable to display on y-axis

datasource (optional)

Data source to assign to the curve (ElmRes or IntComtrade). If not specified, the plot's default result file will be used for the curve.

ChangeColourPalette

Colours the curves according to the colour palette identified by the given name. Additionally, the colour palette is set as the dataseries' default palette.

```
None PltDataseries.ChangeColourPalette(str paletteName)
```

ARGUMENTS

paletteName

Name of the colour palette to apply

RETURNS

0 on success
1 on error

ClearCurves

Removes all curves from the plot.

```
None PltDataseries.ClearCurves()
```

GetDataSource

Returns the data source that is used for the curve with given index.

```
DataObject PltDataseries.GetDataSource(int curveIndex)
```

ARGUMENTS

int curveIndex

curve index in table, must be ≥ 0

RETURNS

DataObject Data source
None No data source found

GetIntCalcres

Gets all user Calculated Result objects (IntCalcres) stored inside the data series.

```
list PltDataseries.GetIntCalcres()
```

RETURNS

All Calculated Result objects (IntCalcres) stored inside the data series.

RemoveCurve

Removes a single curve from the plot.

```
None PltDataserie.RemoveCurve(int curveIndex)
```

ARGUMENTS

int curveIndex
curve index in table, must be ≥ 0

SetLabelFont

Sets the curve label font for this data series.

```
None PltDataserie.SetLabelFont(str fontName,  
                                int fontSize,  
                                int fontStyle)
```

ARGUMENTS

fontName
Font name

fontSize Font size

fontStyle Font style

- | | |
|---|-----------------|
| 1 | Bold |
| 2 | Italic |
| 3 | Bold and italic |
| 4 | Underline |

5.6.57 PltImpedancerx

Overview

[AddRelayCurve](#)
[AddRelayCurves](#)
[ClearRelayCurves](#)

AddRelayCurve

Adds a relay to the plot and optionally sets the drawing style.

```
None PltImpedancerx.AddRelayCurve(DataObject element,  
                                   [int colour,]  
                                   [int lineStyle,]  
                                   [float lineWidth])
```

ARGUMENTS

element The relay to be added.

colour (optional)

Encoded colour value to be used. See: [Application.EncodeColour\(\)](#)

lineStyle (optional)

The line style to be used.

lineWidth (optional)

The line width to be used.

AddRelayCurves

Adds relays to the plot.

```
None PltImpedancerx.AddRelayCurves(list elements)
```

ARGUMENTS

elements The relays to be added.

ClearRelayCurves

Removes all relays from the plot.

```
None PltImpedancerx.ClearRelayCurves()
```

5.6.58 PltLegend

Overview

[SetFont](#)

SetFont

Sets the font for this axis

```
None PltAxis.SetFont(str fontName,
                      int fontSize,
                      int fontStyle)
```

ARGUMENTS

fontName

Font name

fontSize

Font size

fontStyle

Font style

1 Bold

2 Italic

- 3** Bold and italic
- 4** Underline

5.6.59 PltLinebarplot

Overview

[ChangeStyle](#)
[DoAutoScale](#)
[DoAutoScaleX](#)
[DoAutoScaleY](#)
[GetAxisX](#)
[GetAxisY](#)
[GetDataSet](#)
[GetDataSource](#)
[GetLegend](#)
[GetTitleObject](#)
[SetAutoScaleModeX](#)
[SetAutoScaleModeY](#)
[SetAxisSharingLevelX](#)
[SetAxisSharingLevelY](#)
[SetScaleTypeX](#)
[SetScaleTypeY](#)
[SetScaleX](#)
[SetScaleY](#)

ChangeStyle

Applies the plot style identified by the given name to this plot.

```
None PltLinebarplot.ChangeStyle(str styleName)
```

ARGUMENTS

styleName
Name of the style template to apply

RETURNS

0 on success
1 on error

DoAutoScale

Adapts the plot's axes ranges such that they show the entire data range.

```
None PltLinebarplot.DoAutoScale([int axisDimension])
```

ARGUMENTS

axisDimension (optional)
Limits auto-scaling to one dimension. Possible values:

0	scale only x-axes
1	scale only y-axes

DoAutoScaleX

Adapts the plot's x-axes ranges such that they show the entire data range.

```
None PltLinebarplot.DoAutoScaleX()
```

DoAutoScaleY

Adapts the plot's y-axes ranges such that they show the entire data range.

```
None PltLinebarplot.DoAutoScaleY()
```

GetAxisX

Returns one of the plot's x-axes.

```
DataObject PltLinebarplot.GetAxisX([int axisIndex])
```

ARGUMENTS

axisIndex=0 (optional)

Determines which x-axis should be returned:

0	main x-axis
1	second x-axis (will be created if not yet present)

RETURNS

PltAxis object

GetAxisY

Returns one of the plot's y-axes.

```
DataObject PltLinebarplot.GetAxisY([int axisIndex])
```

ARGUMENTS

axisIndex=0 (optional)

Determines which y-axis should be returned:

0	main y-axis
1	second y-axis (will be created if not yet present)

RETURNS

PltAxis object

GetDataSeries

Returns the plot's data series object (PltDataserries).

```
DataObject PltLinebarplot.GetDataSeries()
```


RETURNS

Data series object (PltDataseries)

GetDataSource

Returns the plot's data source object.

```
DataObject PltLinebarplot.GetDataSource()
```

RETURNS

Data source object. Object type depends on type of the plot:

- PltDataseries** Curve plot
- PltEigenvalues** Eigenvalue plot
- PltEigenmode** Mode bar plot
- PltOvercurrent** Time-overcurrent plot
- PltBiasdiff** Biased current differential plot

GetLegend

Returns the plot's legend object (PltLegend).

```
DataObject PltLinebarplot.GetLegend()
```

RETURNS

Legend object (PltLegend)

GetTitleObject

Returns the plot's title object (PltTitle).

```
DataObject PltLinebarplot.GetTitleObject()
```

RETURNS

Title object (PltTitle)

SetAutoScaleModeX

Defines whether the plot should automatically adapt its main x-axis range on data changes.

```
None PltLinebarplot.SetAutoScaleModeX(int mode)
```

ARGUMENTS

- | | |
|-------------|--|
| <i>mode</i> | Possible values: |
| 0 | off (do not react to data changes) |
| 1 | adapt scale after calculation has finished |
| 2 | adapt scale during live plotting |

SetAutoScaleModeY

Defines whether the plot should automatically adapt its main y-axis range on data changes.

```
None PltLinebarplot.SetAutoScaleModeY(int mode)
```

ARGUMENTS

<i>mode</i>	Possible values:
0	off (do not react to data changes)
1	adapt scale after calculation has finished
2	adapt scale during live plotting

SetAxisSharingLevelX

Defines whether the plot has its own x-axis or should share its x-axis across the page or the entire desktop.

```
None PltLinebarplot.SetAxisSharingLevelX(int level)
```

ARGUMENTS

<i>level</i>	Possible values:
0	local (do not share x-axis)
1	use x-axis from page
2	use x-axis from desktop

SetAxisSharingLevelY

Defines whether the plot has its own y-axis or should share its y-axis across the page or the entire desktop.

```
None PltLinebarplot.SetAxisSharingLevelY(int level)
```

ARGUMENTS

<i>level</i>	Possible values:
0	local (do not share y-axis)
1	use y-axis from page
2	use y-axis from desktop

SetScaleTypeX

Sets the scale type of the plot's main x-axis.

```
None PltLinebarplot.SetScaleTypeX(int scaleType)
```

ARGUMENTS

scaleType

Possible values:

0	linear
1	logarithmic

SetScaleTypeY

Set the scale type of the plot's main y-axis.

```
None PltLinebarplot.SetScaleTypeY(int scaleType)
```

ARGUMENTS

scaleType

Possible values:

0	linear
1	logarithmic
2	dB

SetScaleX

Sets the scale of the plot's main x-axis.

```
None PltLinebarplot.SetScaleX(float min,  
                                float max  
                                )
```

ARGUMENTS

<i>min</i>	Minimum of x-scale.
<i>max</i>	Maximum of x-scale.

SetScaleY

Sets the scale of the plot's main y-axis.

```
None PltLinebarplot.SetScaleY(float min,  
                                float max  
                                )
```

ARGUMENTS

<i>min</i>	Minimum of y-scale.
<i>max</i>	Maximum of y-scale.

5.6.60 PltNetgraphic

Overview

[ChangeStyle](#)

ChangeStyle

Applies the plot style identified by the given name to this plot.

```
None PltNetgraphic.ChangeStyle(str styleName)
```

ARGUMENTS

styleName
Name of the style template to apply

RETURNS

0 on success
1 on error

5.6.61 PltOvercurrent

Overview

[AddCurve](#)
[AddCurves](#)
[ClearCurves](#)
[IsSubCurveVisible](#)
[SetSubCurveVisible](#)

AddCurve

Adds an element to the plot and optionally sets the drawing style.

```
None PltOvercurrent.AddCurve(DataObject element,  
                               [int colour,]  
                               [int lineStyle,]  
                               [float lineWidth])
```

ARGUMENTS

element The protection device or net element to be added.

colour (optional)
Encoded colour value to be used. See: [Application.EncodeColour\(\)](#)

lineStyle (optional)
The line style to be used.

lineWidth (optional)
The line width to be used.

AddCurves

Adds elements to the plot.

```
None PltOvercurrent.AddCurves(list elements)
```

ARGUMENTS

elements The protection devices or net elements to be added.

ClearCurves

Removes all elements from the plot.

```
None PltOvercurrent.ClearCurves()
```

IsSubCurveVisible

Returns whether a sub curve of a curve is shown.

```
int Application.IsSubCurveVisible(int curveIndex, int subCurveType)
```

ARGUMENTS

curveIndex
Index of the curve to query

subCurveType
Sub curve to query. See: SetSubCurveVisible.

RETURNS

0 Sub curve is not shown.
1 Sub curve is shown.

SetSubCurveVisible

Sets the visibility of a sub curve for one or all curves in the plot.

```
None Application.SetSubCurveVisible(int curveIndex, int subCurveType, int visible)
```

ARGUMENTS

curveIndex
Index of the curve to modify. Use -1 for modifying all curves.

subCurveType
Sub curve to modify:

-1	All sub curves
1	Transformer nominal current
2	Transformer inrush current
3	Transformer cold load curve
4	Transformer damage curve (IEC)
5	Transformer damage curve (Ansi)

	10	Line/cable nominal current
	11	Line/cable inrush current
	12	Line/cable overload curve
	15	Motor damage curve
	16	Motor inrush current
<i>visible</i>	0	Do not show sub curve.
	1	Show sub curve.

5.6.62 PltPowerpq

Overview

[AddRelayCurve](#)
[AddRelayCurves](#)
[ClearRelayCurves](#)

AddRelayCurve

Adds a relay to the plot and optionally sets the drawing style.

```
None PltPowerpq.AddRelayCurve(DataObject element,
                               [int colour,]
                               [int lineStyle,]
                               [int lineWidth])
```

ARGUMENTS

element The relay to be added.

colour (optional)

Encoded colour value to be used. See: [Application.EncodeColour\(\)](#)

lineStyle (optional)

The line style to be used.

lineWidth (optional)

The line width to be used.

AddRelayCurves

Adds relays to the plot.

```
None PltPowerpq.AddRelayCurves(list elements)
```

ARGUMENTS

elements The relays to be added.

ClearRelayCurves

Removes all relays from the plot.

```
None PltPowerpq.ClearRelayCurves()
```

5.6.63 PltShcsweep

Overview

[AddCurve](#)
[ClearCurves](#)

AddCurve

Adds a curve to the plot and optionally sets the drawing style.

```
None PltShcsweep.AddCurve(DataObject element,  
                           str variableName,  
                           [int colour,]  
                           [int lineStyle,]  
                           [float lineWidth])
```

ARGUMENTS

element The relay to be added.

varname Name of the element variable to display

colour (optional)

Encoded colour value to be used. See: [Application.EncodeColour\(\)](#)

lineStyle (optional)

The line style to be used.

lineWidth (optional)

The line width to be used.

ClearCurves

Removes all curves from the plot.

```
None PltShcsweep.ClearCurves()
```

5.6.64 PltTimedistance

Overview

[AddRelayCurve](#)
[AddRelayCurves](#)
[ClearRelayCurves](#)

AddRelayCurve

Adds a relay to the plot and optionally sets the drawing style.

```
None PltTimedistance.AddRelayCurve(DataObject element,
                                   [int colour,]
                                   [int lineStyle,]
                                   [float lineWidth])
```

ARGUMENTS

element The relay to be added.

colour (optional)

Encoded colour value to be used. See: [Application.EncodeColour\(\)](#)

lineStyle (optional)

The line style to be used.

lineWidth (optional)

The line width to be used.

AddRelayCurves

Adds relays to the plot.

```
None PltTimedistance.AddRelayCurves(list elements)
```

ARGUMENTS

elements The relays to be added.

ClearRelayCurves

Removes all relays from the plot.

```
None PltTimedistance.ClearRelayCurves()
```

5.6.65 PltTitle

Overview

[SetFont](#)

SetFont

Sets the font for this axis

```
None PltAxis.SetFont(str fontName,
                     int fontSize,
                     int fontStyle)
```


ARGUMENTS

<i>fontName</i>	Font name
<i>fontSize</i>	Font size
<i>fontStyle</i>	Font style
1	Bold
2	Italic
3	Bold and italic
4	Underline

5.6.66 PltVectorplot

Overview

[ChangeStyle](#)
[DoAutoScale](#)
[GetAxisX](#)
[GetAxisY](#)
[GetComplexData](#)
[GetLegend](#)
[GetTitleObject](#)
[SetAutoScaleModeX](#)
[SetAutoScaleModeY](#)
[SetScaleX](#)
[SetScaleY](#)

ChangeStyle

Applies the plot style identified by the given name to this plot.

```
None PltVectorplot.ChangeStyle(str styleName)
```

ARGUMENTS

<i>styleName</i>	Name of the style template to apply
------------------	-------------------------------------

RETURNS

0	on success
1	on error

DoAutoScale

Adapts the plot's axes ranges such that they show the entire data range.

```
None PltVectorplot.DoAutoScale()
```

GetAxisX

Returns the plot's x-axis.

```
DataObject PltVectorplot.GetAxisX()
```

RETURNS

PltAxis object

GetAxisY

Returns the plot's y-axes.

```
DataObject PltVectorplot.GetAxisY()
```

RETURNS

PltAxis object

GetComplexData

Returns the plot's complex data definition object (PltComplexdata).

```
DataObject PltVectorplot.GetComplexData()
```

RETURNS

Complex data definition object (PltComplexdata)

GetLegend

Returns the plot's legend object (PltLegend).

```
DataObject PltVectorplot.GetLegend()
```

RETURNS

Legend object (PltLegend)

GetTitleObject

Returns the plot's title object (PltTitle).

```
DataObject PltVectorplot.GetTitleObject()
```

RETURNS

Title object (PltTitle)

SetAutoScaleModeX

Defines whether the plot should automatically adapt its main x-axis range on data changes.

```
None PltVectorplot.SetAutoScaleModeX(int mode)
```

ARGUMENTS

<i>mode</i>	Possible values:
0	off (do not react to data changes)
1	adapt scale after calculation has finished

SetAutoScaleModeY

Defines whether the plot should automatically adapt its main y-axis range on data changes.

```
None PltVectorplot.SetAutoScaleModeY(int mode)
```

ARGUMENTS

<i>mode</i>	Possible values:
0	off (do not react to data changes)
1	adapt scale after calculation has finished

SetScaleX

Sets the scale of the plot's x-axis.

```
None PltVectorplot.SetScaleX(float min,  
                             float max  
                             )
```

ARGUMENTS

<i>min</i>	Minimum of x-scale.
<i>max</i>	Maximum of x-scale.

SetScaleY

Sets the scale of the plot's y-axis.

```
None PltVectorplot.SetScaleY(float min,  
                             float max  
                             )
```

ARGUMENTS

<i>min</i>	Minimum of y-scale.
<i>max</i>	Maximum of y-scale.

5.6.67 RelChar

Overview

[SetCurve](#)

SetCurve

Assign a tripping curve by name. The curve must be defined in the associated type object.

```
int RelChar.SetCurve(str name)
```

ARGUMENTS

name Name of the curve to assign (may contain wildcards).

RETURNS

- 0** The curve was found and assigned.
- 1** No curve with the given name is defined or multiple curves matched the name.

5.6.68 RelFuse

Overview

[Close](#)
[GetOperatedSwitches](#)
[IsClosed](#)
[IsOpen](#)
[Open](#)

Close

Closes the fuse by changing its status to 'close'. Only explicitly modelled fuses can be operated.

```
int RelFuse.Close()
```

RETURNS

- 0** On success
- ≠ 0** On error

SEE ALSO

[RelFuse.Open\(\)](#)

GetOperatedSwitches

Returns the switch operated by the fuse. Explicitly modelled fuses will return themselves.

```
list RelFuse.GetOperatedSwitches()
```

RETURNS

Switches operated by this fuse.

SEE ALSO

[ElmRelay.GetOperatedSwitches\(\)](#),
[RelLogic.GetOperatedSwitches\(\)](#),
[RelLogdip.GetOperatedSwitches\(\)](#)

IsClosed

Returns information about the current switch state. Fuses in cubicles will return the state of the operated switch instead.

```
int RelFuse.IsClosed()
```

RETURNS

1	Fuse/Switch is closed
0	Fuse/Switch is open

SEE ALSO

[RelFuse.IsOpen\(\)](#)

IsOpen

Returns information about the current switch state. Fuses in cubicles will return the state of the operated switch instead.

```
int RelFuse.IsOpen()
```

RETURNS

1	Fuse/Switch is open
0	Fuse/Switch is closed

SEE ALSO

[RelFuse.IsClosed\(\)](#)

Open

Opens the fuse by changing its status to 'open'. Only explicitly modelled fuses can be operated.

```
int RelFuse.Open()
```

RETURNS

0	On success
≠ 0	On error

SEE ALSO

[RelFuse.Close\(\)](#)

5.6.69 RelLogdip

Overview

[GetOperatedSwitches](#)

GetOperatedSwitches

Returns the operated switches if the unit is a tripping logic, including the automatically determined switches.

```
list RelLogdip.GetOperatedSwitches()
```

RETURNS

Switches operated by this logic unit.

SEE ALSO

[ElmRelay.GetOperatedSwitches\(\)](#),
[RelLogic.GetOperatedSwitches\(\)](#),
[RelFuse.GetOperatedSwitches\(\)](#)

5.6.70 RelLogic

Overview

[GetOperatedSwitches](#)

GetOperatedSwitches

Returns the operated switches if the unit is a tripping logic, including the automatically determined switches.

```
list RelLogic.GetOperatedSwitches()
```

RETURNS

Switches operated by this logic unit.

SEE ALSO

[ElmRelay.GetOperatedSwitches\(\)](#),
[RelLogdip.GetOperatedSwitches\(\)](#),
[RelFuse.GetOperatedSwitches\(\)](#)

5.6.71 RelToc

Overview

[SetCurve](#)

SetCurve

Assign a tripping curve by name. The curve must be defined in the associated type object.

```
int RelToc.SetCurve(str name)
```

ARGUMENTS

name Name of the curve to assign (may contain wildcards).

RETURNS

- 0** The curve was found and assigned.
- 1** No curve with the given name is defined or multiple curves matched the name.

5.6.72 RelZpol

Overview

[AssumeCompensationFactor](#)
[AssumeReRl](#)
[AssumeXeXI](#)

AssumeCompensationFactor

Triggers a calculation of the complex compensation factor and stores the result.

```
int RelZpol.AssumeCompensationFactor()
```

RETURNS

- 0** The compensation factor was successfully calculated.
- 1** An error occurred (e.g. connected branch was not found).

AssumeReRl

Triggers a calculation of the real part of the decoupled compensation factor and stores the result.

```
int RelZpol.AssumeReRl()
```

RETURNS

- 0** The compensation factor was successfully calculated.
- 1** An error occurred (e.g. connected branch was not found).

AssumeXeXl

Triggers a calculation of the imaginary part of the decoupled compensation factor and stores the result.

```
int RelZpol.AssumeXeXl()
```

RETURNS

- 0** The compensation factor was successfully calculated.
- 1** An error occurred (e.g. connected branch was not found).

5.6.73 ScnFreq**Overview**

[GetLimit](#)
[GetNumberOfViolations](#)
[GetRecoveryTime](#)
[GetValue](#)
[GetVariable](#)
[GetViolatedElement](#)
[GetViolationTime](#)

GetLimit

Returns the limit value (in p.u.) of the i^{th} violation, given by vldx.

```
float ScnFreq.GetLimit(int vIdx)
```

ARGUMENTS

vldx $vldx > 0$

RETURNS

The limit value (in p.u.) of the i^{th} violation, given by vldx. If vldx is negative, zero or greater than the number of violations, then the function returns 'nan'.

GetNumberOfViolations

Returns the number of violations.

```
int ScnFreq.GetNumberOfViolations()
```


RETURNS

The number of violations.

GetRecoveryTime

Returns the time (in seconds) of the recovery for the i^{th} violation, given by vIdx.

```
float ScnFreq.GetRecoveryTime(int vIdx)
```

ARGUMENTS

vIdx vIdx > 0

RETURNS

The time (in seconds) of the recovery for the i^{th} violation, given by vIdx. If vIdx is negative, zero or greater than the number of violations, then the function returns 'nan'. If no recovery occurred for the i^{th} violation, the function returns '-inf'.

GetValue

Returns the i^{th} value (in p.u.), given by vIdx, which causes the violation.

```
float ScnFreq.GetValue(int vIdx)
```

ARGUMENTS

vIdx vIdx > 0

RETURNS

The i^{th} value (in p.u.), given by vIdx, which causes the violation. If vIdx is negative, zero or greater than the number of violations, then the function returns 'nan'.

GetVariable

Returns the name of the variable of the i^{th} violation, given by vIdx.

```
str ScnFreq.GetVariable(int vIdx)
```

ARGUMENTS

vIdx vIdx > 0

RETURNS

The name of the variable of the i^{th} violation, given by vIdx. If vIdx is negative, zero or greater than the number of violations, then the function returns "NoVariable".

GetViolatedElement

Returns the element of the i^{th} violation, given by vIdx.

```
DataObject ScnFreq.GetViolatedElement(int vIdx)
```

ARGUMENTS

vIdx $vIdx > 0$

RETURNS

The element of the i^{th} violation, given by *vIdx*. If *vIdx* is negative, zero or greater than the number of violations, then the function returns None.

GetViolationTime

Returns the time (in seconds) of the i^{th} violation, given by *vIdx*.

```
float ScnFreq.GetViolationTime(int vIdx)
```

ARGUMENTS

vIdx $vIdx > 0$

RETURNS

The time (in seconds) of the i^{th} violation, given by *vIdx*. If *vIdx* is negative, zero or greater than the number of violations, then the function returns 'nan'.

5.6.74 ScnFrt**Overview**

[GetLimit](#)
[GetNumberOfViolations](#)
[GetRecoveryTime](#)
[GetValue](#)
[GetVariable](#)
[GetViolatedElement](#)
[GetViolationTime](#)

GetLimit

Returns the limit value of the i^{th} violation, given by *vIdx*.

```
float ScnFrt.GetLimit(int vIdx)
```

ARGUMENTS

vIdx $vIdx > 0$

RETURNS

The limit value of the i^{th} violation, given by *vIdx*. If *vIdx* is negative, zero or greater than the number of violations, then the function returns 'nan'.

GetNumberOfViolations

Returns the number of violations.

```
int ScnFrt.GetNumberOfViolations()
```

RETURNS

The number of violations.

GetRecoveryTime

Returns the time (in seconds) of the recovery for the i^{th} violation, given by vIdx.

```
float ScnFrt.GetRecoveryTime(int vIdx)
```

ARGUMENTS

vIdx vIdx > 0

RETURNS

The time (in seconds) of the recovery for the i^{th} violation, given by vIdx. If vIdx is negative, zero or greater than the number of violations, then the function returns 'nan'. If no recovery occurred for the i^{th} violation, the function returns '-inf'.

GetValue

Returns the i^{th} value, given by vIdx, which causes the violation.

```
float ScnFrt.GetValue(int vIdx)
```

ARGUMENTS

vIdx vIdx > 0

RETURNS

The i^{th} value, given by vIdx, which causes the violation. If vIdx is negative, zero or greater than the number of violations, then the function returns 'nan'.

GetVariable

Returns the name of the variable of the i^{th} violation, given by vIdx.

```
str ScnFrt.GetVariable(int vIdx)
```

ARGUMENTS

vIdx vIdx > 0

RETURNS

The name of the variable of the i^{th} violation, given by vIdx. If vIdx is negative, zero or greater than the number of violations, then the function returns "NoVariable".

GetViolatedElement

Returns the element of the i^{th} violation, given by vIdx.

```
DataObject ScnFrt.GetViolatedElement(int vIdx)
```

ARGUMENTS

vIdx $vIdx > 0$

RETURNS

The element of the i^{th} violation, given by *vIdx*. If *vIdx* is negative, zero or greater than the number of violations, then the function returns None.

GetViolationTime

Returns the time (in seconds) of the i^{th} violation, given by *vIdx*.

```
float ScnFrt.GetViolationTime(int vIdx)
```

ARGUMENTS

vIdx $vIdx > 0$

RETURNS

The time (in seconds) of the i^{th} violation, given by *vIdx*. If *vIdx* is negative, zero or greater than the number of violations, then the function returns 'nan'.

5.6.75 ScnSpeed**Overview**

[GetLimit](#)
[GetNumberOfViolations](#)
[GetRecoveryTime](#)
[GetValue](#)
[GetVariable](#)
[GetViolatedElement](#)
[GetViolationTime](#)

GetLimit

Returns the limit value (in p.u.) of the i^{th} violation, given by *vIdx*.

```
float ScnSpeed.GetLimit(int vIdx)
```

ARGUMENTS

vIdx $vIdx > 0$

RETURNS

The limit value (in p.u.) of the i^{th} violation, given by *vIdx*. If *vIdx* is negative, zero or greater than the number of violations, then the function returns 'nan'.

GetNumberOfViolations

Returns the number of violations.

```
int ScnSpeed.GetNumberOfViolations()
```

RETURNS

The number of violations.

GetRecoveryTime

Returns the time (in seconds) of the recovery for the i^{th} violation, given by vIdx.

```
float ScnSpeed.GetRecoveryTime(int vIdx)
```

ARGUMENTS

vIdx vIdx > 0

RETURNS

The time (in seconds) of the recovery for the i^{th} violation, given by vIdx. If vIdx is negative, zero or greater than the number of violations, then the function returns 'nan'. If no recovery occurred for the i^{th} violation, the function returns '-inf'.

GetValue

Returns the i^{th} value (in p.u.), given by vIdx, which causes the violation.

```
float ScnSpeed.GetValue(int vIdx)
```

ARGUMENTS

vIdx vIdx > 0

RETURNS

The i^{th} value (in p.u.), given by vIdx, which causes the violation. If vIdx is negative, zero or greater than the number of violations, then the function returns 'nan'.

GetVariable

Returns the name of the variable of the i^{th} violation, given by vIdx.

```
str ScnSpeed.GetVariable(int vIdx)
```

ARGUMENTS

vIdx vIdx > 0

RETURNS

The name of the variable of the i^{th} violation, given by vIdx. If vIdx is negative, zero or greater than the number of violations, then the function returns "NoVariable".

GetViolatedElement

Returns the element of the i^{th} violation, given by vIdx.

```
DataObject ScnSpeed.GetViolatedElement(int vIdx)
```

ARGUMENTS

vldx $vldx > 0$

RETURNS

The element of the i^{th} violation, given by *vldx*. If *vldx* is negative, zero or greater than the number of violations, then the function returns None.

GetViolationTime

Returns the time (in seconds) of the i^{th} violation, given by *vldx*.

```
float ScnSpeed.GetViolationTime(int vIdx)
```

ARGUMENTS

vldx $vldx > 0$

RETURNS

The time (in seconds) of the i^{th} violation, given by *vldx*. If *vldx* is negative, zero or greater than the number of violations, then the function returns 'nan'.

5.6.76 ScnSync**Overview**

[GetLimit](#)
[GetNumberOfViolations](#)
[GetRecoveryTime](#)
[GetValue](#)
[GetVariable](#)
[GetViolatedElement](#)
[GetViolationTime](#)

GetLimit

Returns the limit value of the i^{th} violation, given by *vldx*.

```
float ScnSync.GetLimit(int vIdx)
```

ARGUMENTS

vldx $vldx > 0$

RETURNS

The limit value of the i^{th} violation, given by *vldx*. If *vldx* is negative, zero or greater than the number of violations, then the function returns 'nan'.

GetNumberOfViolations

Returns the number of violations.

```
int ScnSync.GetNumberOfViolations()
```

RETURNS

The number of violations.

GetRecoveryTime

Returns the time (in seconds) of the recovery for the i^{th} violation, given by vIdx.

```
float ScnSync.GetRecoveryTime(int vIdx)
```

ARGUMENTS

vIdx vIdx > 0

RETURNS

The time (in seconds) of the recovery for the i^{th} violation, given by vIdx. If vIdx is negative, zero or greater than the number of violations, then the function returns 'nan'. If no recovery occurred for the i^{th} violation, the function returns '-inf'.

GetValue

Returns the i^{th} value, given by vIdx, which causes the violation.

```
float ScnSync.GetValue(int vIdx)
```

ARGUMENTS

vIdx vIdx > 0

RETURNS

The i^{th} value, given by vIdx, which causes the violation. If vIdx is negative, zero or greater than the number of violations, then the function returns 'nan'.

GetVariable

Returns the name of the variable of the i^{th} violation, given by vIdx.

```
str ScnSync.GetVariable(int vIdx)
```

ARGUMENTS

vIdx vIdx > 0

RETURNS

The name of the variable of the i^{th} violation, given by vIdx. If vIdx is negative, zero or greater than the number of violations, then the function returns "NoVariable".

GetViolatedElement

Returns the element of the i^{th} violation, given by vIdx.

```
DataObject ScnSync.GetViolatedElement(int vIdx)
```

ARGUMENTS

vIdx $vIdx > 0$

RETURNS

The element of the i^{th} violation, given by *vIdx*. If *vIdx* is negative, zero or greater than the number of violations, then the function returns None.

GetViolationTime

Returns the time (in seconds) of the i^{th} violation, given by *vIdx*.

```
float ScnSync.GetViolationTime(int vIdx)
```

ARGUMENTS

vIdx $vIdx > 0$

RETURNS

The time (in seconds) of the i^{th} violation, given by *vIdx*. If *vIdx* is negative, zero or greater than the number of violations, then the function returns 'nan'.

5.6.77 ScnVar**Overview**

[GetLimit](#)
[GetNumberOfViolations](#)
[GetRecoveryTime](#)
[GetValue](#)
[GetVariable](#)
[GetViolatedElement](#)
[GetViolationTime](#)

GetLimit

Returns the limit value of the i^{th} violation, given by *vIdx*.

```
float ScnVar.GetLimit(int vIdx)
```

ARGUMENTS

vIdx $vIdx > 0$

RETURNS

The limit value of the i^{th} violation, given by *vIdx*. If *vIdx* is negative, zero or greater than the number of violations, then the function returns 'nan'.

GetNumberOfViolations

Returns the number of violations.

```
int ScnVar.GetNumberOfViolations()
```


RETURNS

The number of violations.

GetRecoveryTime

Returns the time (in seconds) of the recovery for the i^{th} violation, given by vIdx.

```
float ScnVar.GetRecoveryTime(int vIdx)
```

ARGUMENTS

vIdx vIdx > 0

RETURNS

The time (in seconds) of the recovery for the i^{th} violation, given by vIdx. If vIdx is negative, zero or greater than the number of violations, then the function returns 'nan'. If no recovery occurred for the i^{th} violation, the function returns '-inf'.

GetValue

Returns the i^{th} value, given by vIdx, which causes the violation.

```
float ScnVar.GetValue(int vIdx)
```

ARGUMENTS

vIdx vIdx > 0

RETURNS

The i^{th} value, given by vIdx, which causes the violation. If vIdx is negative, zero or greater than the number of violations, then the function returns 'nan'.

GetVariable

Returns the name of the variable of the i^{th} violation, given by vIdx.

```
str ScnVar.GetVariable(int vIdx)
```

ARGUMENTS

vIdx vIdx > 0

RETURNS

The name of the variable of the i^{th} violation, given by vIdx. If vIdx is negative, zero or greater than the number of violations, then the function returns "NoVariable".

GetViolatedElement

Returns the element of the i^{th} violation, given by vIdx.

```
DataObject ScnVar.GetViolatedElement(int vIdx)
```

ARGUMENTS

vIdx $vIdx > 0$

RETURNS

The element of the i^{th} violation, given by *vIdx*. If *vIdx* is negative, zero or greater than the number of violations, then the function returns None.

GetViolationTime

Returns the time (in seconds) of the i^{th} violation, given by *vIdx*.

```
float ScnVar.GetViolationTime(int vIdx)
```

ARGUMENTS

vIdx $vIdx > 0$

RETURNS

The time (in seconds) of the i^{th} violation, given by *vIdx*. If *vIdx* is negative, zero or greater than the number of violations, then the function returns 'nan'.

5.6.78 ScnVolt**Overview**

[GetLimit](#)
[GetNumberOfViolations](#)
[GetRecoveryTime](#)
[GetValue](#)
[GetVariable](#)
[GetViolatedElement](#)
[GetViolationTime](#)

GetLimit

Returns the limit value (in p.u.) of the i^{th} violation, given by *vIdx*.

```
float ScnVolt.GetLimit(int vIdx)
```

ARGUMENTS

vIdx $vIdx > 0$

RETURNS

The limit value (in p.u.) of the i^{th} violation, given by *vIdx*. If *vIdx* is negative, zero or greater than the number of violations, then the function returns 'nan'.

GetNumberOfViolations

Returns the number of violations.

```
int ScnVolt.GetNumberOfViolations()
```

RETURNS

The number of violations.

GetRecoveryTime

Returns the time (in seconds) of the recovery for the i^{th} violation, given by vIdx.

```
float ScnVolt.GetRecoveryTime(int vIdx)
```

ARGUMENTS

vIdx vIdx > 0

RETURNS

The time (in seconds) of the recovery for the i^{th} violation, given by vIdx. If vIdx is negative, zero or greater than the number of violations, then the function returns 'nan'. If no recovery occurred for the i^{th} violation, the function returns '-inf'.

GetValue

Returns the i^{th} value (in p.u.), given by vIdx, which causes the violation.

```
float ScnVolt.GetValue(int vIdx)
```

ARGUMENTS

vIdx vIdx > 0

RETURNS

The i^{th} value (in p.u.), given by vIdx, which causes the violation. If vIdx is negative, zero or greater than the number of violations, then the function returns 'nan'.

GetVariable

Returns the name of the variable of the i^{th} violation, given by vIdx.

```
str ScnVolt.GetVariable(int vIdx)
```

ARGUMENTS

vIdx vIdx > 0

RETURNS

The name of the variable of the i^{th} violation, given by vIdx. If vIdx is negative, zero or greater than the number of violations, then the function returns "NoVariable".

GetViolatedElement

Returns the element of the i^{th} violation, given by vIdx.

```
DataObject ScnVolt.GetViolatedElement(int vIdx)
```

ARGUMENTS

vIdx $vIdx > 0$

RETURNS

The element of the i^{th} violation, given by *vIdx*. If *vIdx* is negative, zero or greater than the number of violations, then the function returns None.

GetViolationTime

Returns the time (in seconds) of the i^{th} violation, given by *vIdx*.

```
float ScnVolt.GetViolationTime(int vIdx)
```

ARGUMENTS

vIdx $vIdx > 0$

RETURNS

The time (in seconds) of the i^{th} violation, given by *vIdx*. If *vIdx* is negative, zero or greater than the number of violations, then the function returns 'nan'.

5.6.79 StoMaint**Overview**

[SetElms](#)

SetElms

Sets the maintenance elements.

```
None StoMaint.SetElms(DataObject singleElement)
None StoMaint.SetElms(list multipleElements)
```

ARGUMENTS

singleElement
single Element for Maintenance

multipleElements
multiple Elements for Maintenance

5.6.80 TriCont

Overview

[GetOrCreateTrigger](#)

GetOrCreateTrigger

Creates a trigger object (SetTrigger) in the 'Triggers' folder of the active study case or return the already assigned one.

```
DataObject TriCont.GetOrCreateTrigger()
```

RETURNS

The actual trigger (SetTrigger) object

5.6.81 TriDisc

Overview

[GetOrCreateTrigger](#)

GetOrCreateTrigger

Creates a trigger object (SetTrigger) in the 'Triggers' folder of the active study case or return the already assigned one.

```
DataObject TriDisc.GetOrCreateTrigger()
```

RETURNS

The actual trigger (SetTrigger) object

5.6.82 TriFile

Overview

[GetOrCreateTrigger](#)

GetOrCreateTrigger

Creates a trigger object (SetTrigger) in the 'Triggers' folder of the active study case or return the already assigned one. If a time trigger is required, the function returns None. Use the study time (SetTime) object from the study case instead.

```
DataObject TriFile.GetOrCreateTrigger()
```

RETURNS

The actual trigger (SetTrigger) object

5.6.83 TriVal

Overview

[GetOrCreateTrigger](#)

GetOrCreateTrigger

Creates a trigger object (SetTrigger) in the 'Triggers' folder of the active study case or return the already assigned one.

```
DataObject TriVal.GetOrCreateTrigger()
```

RETURNS

The actual trigger (SetTrigger) object

5.6.84 TypAsmo

Overview

[CalcElParams](#)

CalcElParams

Calculates the electrical parameters from the input data. Behaves as the calculate button on the basic data page was pressed and the parameter estimation is executed. Shall be applied only if the Input mode is set to 'Slip-Torque/Current Characteristic' or 'Measurement curves'.

```
int TypAsmo.CalcElParams([float acceptSqError = 1.e-03],
                        [int solverType = 0],
                        [int useLinConst = 1],
                        [int considerEff = 1],
                        [float kx = 0.5],
                        [float kr = 1.])
```

ARGUMENTS

acceptSqError (optional)

If calculated squared error is below this value, calculation is successfull.

solverType (optional)

Solver used in the parameter estimation. Possible values are:

- | | |
|----------|------------------------------|
| 0 | LBFGS (default). |
| 1 | Particle swarm optimisation. |
| 2 | Conjugate gradient descent. |
| 3 | Newton (old, deprecated). |

useLinConst (optional)

0: Xs from type is used, 1: linear constraints used.

considerEff (optional)

If = 1, efficiency is considered in the estimation.

kx (optional)

value for kx (only if linear constraints selected).

kr (optional)

value for kr (only if linear constraints selected and efficiency not considered).

RETURNS

- 0** Calculation successfully (squared error less than acceptSqError).
- 1** Error.

5.6.85 TypCtcore

Overview

[AddRatio](#)

[RemoveRatio](#)

[RemoveRatioByIndex](#)

AddRatio

Adds the given ratio to the core. The ratio is added so that the sorting remains in ascending order. The accuracy parameters will be copied from the previous row. If the new ratio is to be the first ratio, the accuracy parameters will be copied from the next row instead.

```
int TypCtcore.AddRatio(float ratio)
```

ARGUMENTS

ratio New ratio to add.

RETURNS

- 0** New ratio was added.
- 1** An error occurred.

RemoveRatio

Removes the given ratio from the core. The last remaining ratio can never be removed.

```
int TypCtcore.RemoveRatio(float ratio)
```

ARGUMENTS

ratio Ratio to remove.

RETURNS

- | | |
|----------|--------------------|
| 0 | Ratio was removed. |
| 1 | An error occurred. |

RemoveRatioByIndex

Removes the ratio with the given index from the core. The index is zero based. The last remaining ratio can never be removed.

```
int TypCtcore.RemoveRatio(int index)
```

ARGUMENTS

index Index to remove.

RETURNS

- | | |
|----------|--------------------|
| 0 | Index was removed. |
| 1 | An error occurred. |

5.6.86 TypLne**Overview**

[IsCable](#)

IsCable

Checks if the line type is a cable type.

```
int TypLne.IsCable()
```

RETURNS

- | | |
|----------|---------------------|
| 1 | Type is a cable |
| 0 | Type is not a cable |

5.6.87 TypMdl**Overview**

[Check](#)
[Compile](#)
[ConvertToBlackbox](#)
[Pack](#)

Check

Checks the model for errors e.g during parsing of interpreted model, during loading of compiled model.

```
int TypMdl.Check()
```


RETURNS

- 0** TypMdl is OK.
- 1** Error during parsing of interpreted model.
- 2** Error during loading of compiled model.

Compile

Compile the model.

```
int TypMdl.Compile([const char* modelPath], [int overrideModel])
```

ARGUMENTS

modelPath (optional)

Full path to a location where the model should be stored. Leave empty to use default.

overrideModel (optional)

The model will be overridden if already present at the selected location and if the value is set to 1. (default = 0)

RETURNS

- 0** Compilation is Ok.
- 1** Compilation failed

ConvertToBlackbox

Blackbox the model.

```
int TypMdl.ConvertToBlackbox([const char* modelPath],
                             [int overrideModel],
                             [int addDiagramAndIcon])
```

ARGUMENTS

modelPath (optional)

Full path to a location where the model should be stored. Leave empty to use default.

overrideModel (optional)

The model will be overwritten if already present at the selected location and if the value is set to 1. (default = 0)

addDiagramAndIcon (optional)

The diagram and Icon will be added to the ".pfmu" if set to 1. (default = 1)

RETURNS

- 0** Blackboxing is Ok.
- 1** Blackboxing failed

Pack

Copies all used Modelica model types (i.e. referenced *TypMdl*) to a child folder "Externals".

```
int TypMdl.Pack([int inclGlobalLib])
```

ARGUMENTS

inclGlobalLib (optional)

Include also objects from DIgSILENT Library (default = 1)

RETURNS

0 On success.**1** On error.

5.6.88 TypQdsl

Overview

[Encrypt](#)[IsEncrypted](#)[ResetThirdPartyModule](#)[SetThirdPartyModule](#)

Encrypt

Encrypts a type. An encrypted type can be used without password but decrypted only with password. If no password is given a 'Choose Password' dialog appears.

```
int TypQdsl.Encrypt([str password = "",
                    [int removeObjectHistory = 1],
                    [int masterCode = 0])
```

ARGUMENTS

password (optional)

Password for decryption. If no password is given a 'Choose Password' dialog appears.

removeObjectHistory (optional)

Handling of unencrypted object history in database, e.g. used by project versions or by undo:

0 Do not remove.**1** Do remove (default).**2** Show dialog and ask.*masterCode (optional)*

Used for re-selling types. Third party licence codes already set in the type will be overwritten by this value (default = 0).

RETURNS

0 On success.**1** On error.

SEE ALSO

[TypQdsl.IsEncrypted\(\)](#)

IsEncrypted

Returns the encryption state of the type.

```
int TypQdsl.IsEncrypted()
```

RETURNS

- 1** Type is encrypted.
- 0** Type is not encrypted.

SEE ALSO

[TypQdsl.Encrypt\(\)](#)

ResetThirdPartyModule

Resets the third party licence. Only possible for non-encrypted models. Requires masterkey licence for third party module currently set.

```
int TypQdsl.ResetThirdPartyModule()
```

RETURNS

- 0** On success.
- 1** On error.

SetThirdPartyModule

Sets the third party licence to a specific value. Only possible for non-encrypted models with no third party licence set so far. Requires masterkey licence for third party module to be set.

```
int TypQdsl.SetThirdPartyModule(str companyCode,  
                                str moduleCode  
                                )
```

ARGUMENTS

companyCode

D isplay name or numeric value of company code.

moduleCode

D isplay name or numeric value of third party module.

RETURNS

- 0** On success.
- 1** On error.

5.6.89 TypTr2

Overview

[GetZeroSequenceHVLVT](#)

GetZeroSequenceHVLVT

Returns the calculated star equivalent of the zero sequence impedances.

```
[int error,
float hvReal,
float hvImag,
float lvReal,
float lvImag,
float tReal ,
float tImag ] TypTr2.GetZeroSequenceHVLVT()
```

ARGUMENTS

hvReal (out)

Real part of the HV impedance in %.

hvImag (out)

Imaginary part of the HV impedance in %.

lvReal (out)

Real part of the LV impedance in %.

lvImag (out)

Imaginary part of the LV impedance in %.

tReal (out)

Real part of the tertiary (delta) impedance in %.

tImag (out)

Imaginary part of the tertiary (delta) impedance in %.

RETURNS

0 No error occurred.

1 An error occurred; the values are invalid.

5.6.90 VisPath

Overview

[Clear](#)
[DoAutoScaleX](#)
[DoAutoScaleY](#)
[SetAdaptX](#)
[SetAdaptY](#)
[SetScaleX](#)
[SetScaleY](#)

Clear

Removes all curves by clearing table named 'Variables' on page 'Curves'.

```
None VisPath.Clear()
```

DoAutoScaleX

Scales x-axis automatically.

```
int VisPath.DoAutoScaleX()
```

RETURNS

Always 0

DoAutoScaleY

Scales y-axis automatically.

```
int VisPath.DoAutoScaleY()
```

RETURNS

Always 0

SetAdaptX

Sets the Adapt Scale option of the x-scale.

```
None VisPath.SetAdaptX(int mode)
```

ARGUMENTS

<i>mode</i>	Possible values:
0	off
1	on

SetAdaptY

Sets the Adapt Scale option of the x-scale.

```
None VisPath.SetAdaptY(int mode)
```

ARGUMENTS

<i>mode</i>	Possible values:
0	off
1	on

SetScaleX

Sets x-axis scale.

```
None VisPath.SetScaleX(float min,
                       float max
                       )
```

ARGUMENTS

min Minimum of x-scale.

max Maximum of x-scale.

SetScaleY

Sets y-axis scale limits.

```
None VisPath.SetScaleY(float min,
                       float max,
                       [int log]
                       )
```

ARGUMENTS

min Minimum of y-scale.

max Maximum of y-scale.

log (optional)

Possible values:

0 linear

1 logarithmic

5.6.91 VisPcompdiffplt

Overview

[AddRelay](#)

[AddRelays](#)

[CentreOrigin](#)

[Clear](#)

[DoAutoScaleX](#)

[DoAutoScaleY](#)

AddRelay

Adds a relay to the plot and optionally sets the drawing style.

```
None VisPcompdiffplt.AddRelay(DataObject relay,
                               [float colour,]
                               [float style,]
                               [float width])
```

ARGUMENTS

- relay* The protection device to be added.
- colour (optional)*
 The colour to be used.
- style (optional)*
 The line style to be used.
- width (optional)*
 The line width to be used.

AddRelays

Adds relays to the plot.

```
None VisPcompdiffplt.AddRelays(list relays)
```

ARGUMENTS

- relays* The protection devices (ElmRelay or RelFuse) to be added.

CentreOrigin

Centre the origin of the plot

```
None VisPcompdiffplt.CentreOrigin()
```

Clear

Removes all protection devices from the plot.

```
None VisPcompdiffplt.Clear()
```

DoAutoScaleX

Scales the x-axis of the plot automatically. The function works for local x-scales only. If the x-scale is not local a warning is shown in the output window and 1 is returned by the function.

```
int VisPcompdiffplt.DoAutoScaleX()
```

RETURNS

- 0** Automatic scaling was executed.
- 1** An Error occurred.

DoAutoScaleY

Scales the y-axis of the plot automatically. The function works for local y-scales only. If the x-scale is not local a warning is shown in the output window and 1 is returned by the function.

```
int VisPcompdiffplt.DoAutoScaleY()
```

RETURNS

- 0** Automatic scaling was executed.
- 1** An Error occurred.

5.6.92 VisPlottz

Overview

[AddRelay](#)
[AddRelays](#)
[Clear](#)
[DoAutoScaleX](#)
[DoAutoScaleY](#)

AddRelay

Adds a relay to the plot and optionally sets the drawing style.

```
None VisPlottz.AddRelay(DataObject relay,  
                        [float colour,]  
                        [float style,]  
                        [float width])
```

ARGUMENTS

- relay* The protection device to be added.
- colour (optional)*
The colour to be used.
- style (optional)*
The line style to be used.
- width (optional)*
The line width to be used.

AddRelays

Adds relays to the plot.

```
None VisPlottz.AddRelays(list relays)
```

ARGUMENTS

- relays* The protection devices (ElmRelay or RelFuse) to be added.

Clear

Removes all protection devices from the plot.

```
None VisPlottz.Clear()
```


DoAutoScaleX

Scales the x-axis of the plot automatically. The function works for local x-scales only. If the x-scale is not local a warning is shown in the output window and 1 is returned by the function.

```
int VisPlottz.DoAutoScaleX()
```

RETURNS

- 0** Automatic scaling was executed.
- 1** An Error occurred.

DoAutoScaleY

Scales the y-axis of the plot automatically. The function works for local y-scales only. If the x-scale is not local a warning is shown in the output window and 1 is returned by the function.

```
int VisPlottz.DoAutoScaleY()
```

RETURNS

- 0** Automatic scaling was executed.
- 1** An Error occurred.

5.6.93 VisValue

Overview

[SetUserDefined](#)

SetUserDefined

Converts an auto-generated label (impedance marker, result legend) into a user-defined one.

```
None VisValue.SetUserDefined()
```

6 Callback functions

Overview

[_PowerFactory_OnUserInterrupt](#)

[_PowerFactory_OnUserInterrupt](#)

It is possible to define a callback function `_PowerFactory_OnUserInterrupt()` in a Python script which is executed when the user presses the “Break” button on the main tool bar while the Python script (ComPython) is executed. It can be used for clean-up. One example is a Python script that opens dialogue boxes. The callback can then be used to close all open dialogue boxes that were launched via the Python script.

```
None _PowerFactory_OnUserInterrupt()
```

EXAMPLE

The following example prints an information to the output window when the user presses the “Break” button:

```
import powerfactory
app = powerfactory.GetApplicationExt()

def _PowerFactory_OnUserInterrupt():
    app.PrintInfo('User pressed the break button.')
    # do some clean-up here

while True:
    pass # replace by long-running task
```

SEE ALSO

[Application.SetUserBreakEnabled\(\)](#)
[Application.IsUserBreakPressed\(\)](#)

Index

- [_PowerFactory_OnUserInterrupt](#)
 - [Callbacks, 689](#)
 - [__version__](#)
 - [Module Functions, 2](#)
- [Activate](#)
 - [ElmNet, 133](#)
 - [IntCase, 534](#)
 - [IntLibrary, 573](#)
 - [IntPrj, 586](#)
 - [IntScenario, 614](#)
 - [IntScensched, 618](#)
 - [IntScheme, 620](#)
 - [IntSscheduler, 622](#)
 - [IntSstage, 623](#)
 - [SetTabgroup, 489](#)
- [ActivateProject](#)
 - [Application Methods, 6](#)
- [AdaptWidth](#)
 - [IntGrflayer, 560](#)
 - [SetLevelvis, 474](#)
- [AddAnnotationElement](#)
 - [IntGrflayer, 561](#)
- [AddButton](#)
 - [ComTablereport, 397](#)
- [AddCalcRelevantCoincidenceDefinitions](#)
 - [SetLvscale, 477](#)
- [AddCellAction](#)
 - [ComTablereport, 398](#)
- [AddCntcy](#)
 - [ComSimoutage, 389](#)
- [AddColumn](#)
 - [ComTablereport, 399](#)
- [AddConfiguration](#)
 - [SetDataext, 461](#)
- [AddContingencies](#)
 - [ComSimoutage, 389](#)
- [AddCopy](#)
 - [General Object Methods, 67](#)
- [AddCubicle](#)
 - [ElmBoundary, 108](#)
- [AddCurve](#)
 - [PltBiasdiff, 640](#)
 - [PltDataserie, 642](#)
 - [PltOvercurrent, 651](#)
 - [PltShcsweep, 654](#)
- [AddCurves](#)
 - [PltBiasdiff, 640](#)
 - [PltOvercurrent, 652](#)
- [AddDouble](#)
 - [IntAddonvars, 528](#)
- [AddDoubleMatrix](#)
 - [IntAddonvars, 528](#)
- [AddDoubleVector](#)
 - [IntAddonvars, 529](#)
- [AddEvent](#)
 - [IntRas, 601](#)
- [AddHeader](#)
 - [ComTablereport, 400](#)
- [AddInteger](#)
 - [IntAddonvars, 530](#)
- [AddIntegerVector](#)
 - [IntAddonvars, 530](#)
- [AddInvisibleFilter](#)
 - [ComTablereport, 400](#)
- [AddListFilter](#)
 - [ComTablereport, 400](#)
- [AddListFilterEntries](#)
 - [ComTablereport, 401](#)
- [AddMultiListFilter](#)
 - [ComTablereport, 401](#)
- [AddObject](#)
 - [IntAddonvars, 531](#)
 - [IntReport, 602](#)
- [AddObjects](#)
 - [IntReport, 603](#)
- [AddObjectVector](#)
 - [IntAddonvars, 531](#)
- [AddPage](#)
 - [SetDesktop, 464](#)
- [AddProjectToCombined](#)
 - [IntPrj, 587](#)
- [AddProjectToRemoteDatabase](#)
 - [IntPrj, 587](#)
- [AddRas](#)
 - [ComSimoutage, 389](#)
- [AddRatio](#)
 - [TypCtcore, 678](#)
- [AddRef](#)
 - [ComNmink, 363](#)

- IntDataset, 549
- SetSelect, 486
- AddRelay
 - VisPcompdiffplt, 685
 - VisPlottz, 687
- AddRelayCurve
 - PltImpedancex, 644
 - PltPowerpq, 653
 - PltTimedistance, 655
- AddRelayCurves
 - PltImpedancex, 645
 - PltPowerpq, 653
 - PltTimedistance, 655
- AddRelays
 - VisPcompdiffplt, 686
 - VisPlottz, 687
- AddRow
 - ComTablereport, 402
- AddString
 - IntAddonvars, 531
- AddTable
 - ComTablereport, 403
- AddTabularFilter
 - ComTablereport, 403
- AddTextFilter
 - ComTablereport, 404
- AddToUpdatePages
 - ComProtgraphic, 369
- AddTrigger
 - IntGate, 558
 - IntRas, 601
- AddVar
 - IntMon, 580
- AddVariable
 - ElmRes, 146
- AddVars
 - ElmRes, 146
 - IntMon, 581
- AddVector
 - PltComplexdata, 641
- AddXYCurve
 - PltDatseries, 642
- Align
 - IntGrflayer, 561
 - SetLevelvis, 474
- All
 - IntDataset, 549
 - SetSelect, 486
- AllAsm
 - SetSelect, 486
- AllBars
 - SetSelect, 487
- AllBreakers
 - SetPath, 478
 - SetSelect, 487
- AllClosedBreakers
 - SetPath, 479
 - SetSelect, 487
- AllElm
 - SetSelect, 487
- AllLines
 - SetSelect, 487
- AllLoads
 - SetSelect, 487
- AllOpenBreakers
 - SetPath, 479
 - SetSelect, 488
- AllProtectionDevices
 - SetPath, 479
- AllSym
 - SetSelect, 488
- AllTypLne
 - SetSelect, 488
- AnalyseElmRes
 - ComRel3, 374
- AppendCommand
 - ComTasks, 438
- AppendMessage
 - ComCimtogrid, 302
 - ComGridtocim, 343
- AppendStudyCase
 - ComTasks, 438
 - ComTececocmp, 445
- Application Methods, 4
 - ActivateProject, 6
 - ClearRecycleBin, 6
 - CommitTransaction, 6
 - ConvertGeometryStringToMDL, 6
 - CreateFaultCase, 7
 - CreateProject, 7
 - DecodeColour, 8
 - DefineTransferAttributes, 8
 - DeleteUntouchedObjects, 9
 - EncodeColour, 9
 - ExecuteCmd, 9
 - GetActiveCalculationStr, 10
 - GetActiveNetworkVariations, 10
 - GetActiveProject, 10
 - GetActiveScenario, 10
 - GetActiveScenarioScheduler, 10
 - GetActiveStages, 11
 - GetActiveStudyCase, 11
 - GetAllUsers, 11
 - GetAttributeDescription, 11
 - GetAttributeUnit, 12
 - GetAvailableAttributes, 12
 - GetAvailableAttributesAsJson, 13
 - GetBorderCubicles, 17
 - GetBrowserSelection, 17
 - GetCalcRelevantObjects, 18
 - GetCalculationBalancedMode, 18
 - GetCalculationDescription, 19

- GetCalculations, [19](#)
- GetCalculationsAsJson, [21](#)
- GetClassDescription, [22](#)
- GetClassId, [22](#)
- GetCurrentDiagram, [22](#)
- GetCurrentScript, [22](#)
- GetCurrentSelection, [23](#)
- GetCurrentUser, [23](#)
- GetCurrentZoomScaleLevel, [23](#)
- GetDataFolder, [23](#)
- GetDesktop, [24](#)
- GetDiagramSelection, [24](#)
- GetFlowOrientation, [24](#)
- GetFromStudyCase, [25](#)
- GetGlobalLibrary, [25](#)
- GetInterfaceVersion, [25](#)
- GetLanguage, [26](#)
- GetLocalLibrary, [26](#)
- GetMem, [26](#)
- GetObjectByDbObjectKey, [27](#)
- GetProjectFolder, [27](#)
- GetRecordingStage, [27](#)
- GetSettings, [28](#)
- GetSummaryGrid, [28](#)
- GetTouchedObjects, [28](#)
- GetTouchingExpansionStages, [29](#)
- GetTouchingStageObjects, [29](#)
- GetTouchingVariations, [29](#)
- GetUnitPrefixFactor, [30](#)
- GetUserManager, [30](#)
- GetUserSettings, [30](#)
- Hide, [31](#)
- ImportDz, [31](#)
- ImportSnapshot, [31](#)
- IsAttributeModelInternal, [31](#)
- IsLdfValid, [32](#)
- IsNAN, [32](#)
- IsRmsValid, [32](#)
- IsScenarioAttribute, [32](#)
- IsShcValid, [33](#)
- IsSimValid, [33](#)
- IsWriteCacheEnabled, [33](#)
- LicenceHasModule, [33](#)
- LoadProfile, [35](#)
- MarkInGraphics, [35](#)
- MigrateAllProjects, [36](#)
- OutputFlexibleData, [36](#)
- PostCommand, [36](#)
- PrepForUntouchedDelete, [37](#)
- Rebuild, [37](#)
- ReloadProfile, [37](#)
- ResetCalculation, [37](#)
- ResGetData, [37](#)
- ResGetDescription, [38](#)
- ResGetFirstValidObject, [38](#)
- ResGetFirstValidObjectVariable, [38](#)
- ResGetFirstValidVariable, [38](#)
- ResGetIndex, [38](#)
- ResGetMax, [39](#)
- ResGetMin, [39](#)
- ResGetNextValidObject, [39](#)
- ResGetNextValidObjectVariable, [39](#)
- ResGetNextValidVariable, [39](#)
- ResGetObject, [39](#)
- ResGetUnit, [40](#)
- ResGetValueCount, [40](#)
- ResGetVariable, [40](#)
- ResGetVariableCount, [40](#)
- ResLoadData, [40](#)
- ResReleaseData, [40](#)
- ResSortToVariable, [40](#)
- SaveAsScenario, [41](#)
- SearchObjectByForeignKey, [41](#)
- SearchObjectsByCimId, [41](#)
- SelectToolbox, [42](#)
- SetAttributeInRootAndStageObjects, [42](#)
- SetAttributeModelInternal, [42](#)
- SetInterfaceVersion, [43](#)
- SetShowAllUsers, [43](#)
- SetVariationRecordingMode, [43](#)
- SetWriteCacheEnabled, [44](#)
- Show, [44](#)
- SplitLine, [44](#)
- StatFileGetXrange, [45](#)
- StatFileResetXrange, [45](#)
- StatFileSetXrange, [46](#)
- WriteChangesToDb, [46](#)
- Apply
 - ElmBmu, [108](#)
 - IntOutage, [583](#)
 - IntScenario, [615](#)
 - IntSubset, [626](#)
- ApplyAll
 - IntOutage, [583](#)
- ApplyAndResetRA
 - ElmSubstat, [163](#)
- ApplyChanges
 - IntSstage, [623](#)
- ApplyNetworkState
 - IntCase, [534](#)
- ApplySelective
 - IntScenario, [615](#)
 - IntSubset, [626](#)
- ApplyStudyTime
 - IntCase, [534](#)
- Archive
 - IntPrj, [587](#)
- AreDistParamsPossible
 - ElmLne, [126](#)
- AssignCimRdfIds
 - ComGridtocim, [344](#)
- AssumeCompensationFactor

- RelZpol, 662
- AssumeReRI
 - RelZpol, 662
- AssumeXeXI
 - RelZpol, 663
- BeginDataExtensionModification
 - IntPrj, 587
- BeginTabGroup
 - SetDesktop, 464
- BlkDef, 502
 - CalculateChecksum, 503
 - Check, 502
 - Compile, 502
 - Encrypt, 503
 - GetChecksum, 503
 - Pack, 503
 - PackAsMacro, 504
 - ResetThirdPartyModule, 504
 - SetThirdPartyModule, 504
- BlkSig, 505
 - GetFromSigName, 505
 - GetToSigName, 505
- BlockSwitch
 - ComShctrace, 382
- BuildNodeNames
 - ComUcteexp, 449
- CalcAggrVarsInRadFeed
 - ElmFeeder, 116
- CalcCluster
 - SetCluster, 453
 - SetDistrstate, 473
- CalcContributions
 - ComRelpost, 376
- CalcDiscountedEstimatedPaybackPeriod
 - ComTececocmp, 446
- CalcEfficiency
 - ElmAsm, 100
 - ElmGenstat, 121
 - ElmPvsys, 136
 - ElmSym, 168
 - ElmXnet, 203
- CalcEIParams
 - TypAsmo, 677
- CalcEstimatedPaybackPeriod
 - ComTececocmp, 446
- CalcInternalRateOfReturn
 - ComTececocmp, 447
- CalcMaxHostedPower
 - ComHostcap, 348
- CalcShiftedReversedBoundary
 - ElmBoundary, 108
- CalculateChecksum
 - BlkDef, 503
- CalculateInterchangeTo
 - ElmArea, 97
 - ElmNet, 134
 - ElmZone, 205
- CalculateMaxFaultCurrents
 - ElmRelay, 140
- CalculateVoltageLevel
 - ElmArea, 97
 - ElmNet, 134
 - ElmZone, 205
- CalculateVoltInterVolt
 - ElmArea, 98
 - ElmNet, 134
 - ElmZone, 206
- Callbacks, 689
 - _PowerFactory_OnUserInterrupt, 689
- CanAddProjectToRemoteDatabase
 - IntPrj, 588
- CanSubscribeProjectReadOnly
 - IntPrj, 588
- CanSubscribeProjectReadWrite
 - IntPrj, 588
- CentreOrigin
 - VisPcompdiffplt, 686
- ChangeColourPalette
 - PltComplexdata, 641
 - PltDataseries, 643
- ChangeFont
 - IntGrflayer, 562
 - SetLevelvis, 475
- ChangeLayer
 - IntGrflayer, 562
 - SetLevelvis, 475
- ChangeRefPoints
 - IntGrflayer, 563
 - SetLevelvis, 475
- ChangeStyle
 - GrpPage, 523
 - PltLinebarplot, 646
 - PltNetgraphic, 651
 - PltVectorplot, 656
- ChangeWidthVisibilityAndColour
 - IntGrflayer, 563
 - SetLevelvis, 476
- ChaVecfile, 505
 - Update, 505
- Check
 - BlkDef, 502
 - ComAuditlog, 296
 - ElmMdl, 131
 - IntOutage, 584
 - SetScenario, 485
 - SetTboxconfig, 495
 - TypMdl, 679
- CheckAll
 - IntOutage, 584
- CheckAnnotationString

- IntGrflayer, 564
- CheckAssignments
 - ComMerge, 356
- CheckBbPath
 - ElmBbone, 105
- CheckConsistency
 - IntNdata, 582
 - IntNnet, 582
- CheckControllers
 - ComLdf, 352
- CheckRanges
 - ElmRelay, 140
- CheckSyntax
 - ComDpl, 336
- CheckUrl
 - IntExtaccess, 557
- CimArchive, 506
 - ConvertToBusBranch, 506
- CimModel, 506
 - DeleteParameterAtIndex, 506
 - GetAttributeEnumerationType, 507
 - GetModelsReferencingThis, 507
 - GetParameterCount, 508
 - GetParameterNamespace, 508
 - GetParameterValue, 509
 - HasParameter, 509
 - RemoveParameter, 510
 - SetAssociationValue, 510, 511
 - SetAttributeEnumeration, 511, 512
 - SetAttributeValue, 512, 513
- CimObject, 513
 - DeleteParameterAtIndex, 513
 - GetAttributeEnumerationType, 514
 - GetObjectsReferencingThis, 514
 - GetObjectsWithSameld, 515
 - GetParameterCount, 515
 - GetParameterNamespace, 516
 - GetParameterValue, 516
 - GetPfObjects, 517
 - HasParameter, 517
 - RemoveParameter, 518
 - SetAssociationValue, 518, 519
 - SetAttributeEnumeration, 519, 520
 - SetAttributeValue, 521, 522
- Clear
 - ComNmink, 363
 - ElmBoundary, 109
 - ElmRes, 146
 - IntDataset, 549
 - IntDplmap, 551
 - IntDplvec, 554
 - IntSubset, 627
 - Output Window Methods, 64
 - SetSelect, 488
 - VisPath, 684
 - VisPcompdiffplt, 686
 - VisPlottz, 687
- ClearAll
 - ComTablereport, 404
- ClearCont
 - ComSimoutage, 389
- ClearCurves
 - PltBiasdiff, 640
 - PltDataseries, 643
 - PltOvercurrent, 652
 - PltShcsweep, 654
- ClearData
 - IntGrfgroup, 559
 - IntGrflayer, 564
- ClearGroundingAreas
 - ComCheck, 299
- ClearOutputWindow
 - Output Window Functions, 61
- ClearRecycleBin
 - Application Methods, 6
- ClearRelayCurves
 - PltImpedancex, 645
 - PltPowerpq, 654
 - PltTimedistance, 655
- ClearUpdatePages
 - ComProtgraphic, 369
- ClearVars
 - IntMon, 581
- ClearVectors
 - PltComplexdata, 641
- Close
 - ElmCoup, 112
 - ElmGndswt, 124
 - ElmRes, 150
 - IntGrfnets, 569
 - RelFuse, 659
 - SetDeskpage, 463
 - SetDesktop, 465
 - SetTabgroup, 489
 - SetVipage, 498
 - StaSwitch, 280
- CloseAllTemporaryTabs
 - SetDesktop, 465
- CloseTab
 - SetTabgroup, 489
- CloseTableReports
 - Dialogue Boxes Functions, 48
- ColLbl
 - IntMat, 574
- ComAddlabel, 282
 - Execute, 282
- ComAddon, 282
 - CreateModule, 283
 - DefineDouble, 283
 - DefineDoubleMatrix, 284
 - DefineDoublePerConnection, 284
 - DefineDoubleVector, 285

- DefineDoubleVectorPerConnection, 286
- DefineInteger, 286
- DefineIntegerPerConnection, 287
- DefineIntegerVector, 288
- DefineIntegerVectorPerConnection, 288
- DefineObject, 289
- DefineObjectPerConnection, 290
- DefineObjectVector, 290
- DefineObjectVectorPerConnection, 291
- DefineString, 291
- DefineStringPerConnection, 292
- DeleteModule, 293
- FinaliseModule, 293
- GetActiveModule, 293
- ModuleExists, 293
- SetActiveModule, 294
- ComAmpacity, 294
 - ExecuteAmpacityCalc, 294
- ComArcreport, 294
 - GetLocationsToReport, 294
 - GetUnitFor, 295
 - GetValueFor, 295
 - IsDguv, 295
 - IsEpri, 296
- ComAuditlog, 296
 - Check, 296
- ComBoundary, 296
 - GetCreatedBoundaries, 296
- ComCapo, 297
 - ConnectShuntToBus, 297
 - LossCostAtBusTech, 297
 - TotalLossCost, 298
- ComCheck, 298
 - ClearGroundingAreas, 299
 - GetGroundingAreaCouplings, 299
 - GetGroundingAreaElements, 299
 - GetGroundingAreaGroundings, 299
 - GetNumberOfGroundingAreas, 299
 - InitGroundingAreas, 300
- ComCimdbexp, 300
 - Execute, 300
- ComCimdbimp, 301
 - Execute, 301
 - ImportAndConvert, 301
- ComCimtogrid, 302
 - AppendMessage, 302
 - GetMessageDescription, 303
 - GetMessageObject, 303
 - GetMessageSeverity, 304
 - GetNumberOfMessages, 304
- ComCimvalidate, 305
 - Execute, 305
 - GetClassType, 306
 - GetDescriptionText, 306
 - GetInputObject, 307
 - GetModel, 307
 - GetModelId, 308
 - GetNumberOfValidationMessages, 308
 - GetObject, 308
 - GetObjectId, 309
 - GetProfile, 309
 - GetSeverity, 310
 - GetType, 310
- ComConreq, 311
 - Execute, 311
- ComContingency, 311
 - ContinueTrace, 311
 - CreateRecoveryInformation, 312
 - GetGeneratorEvent, 312
 - GetInterruptedPowerAndCustomersForStage, 313
 - GetInterruptedPowerAndCustomersForTimeStep, 313
 - GetLoadEvent, 314
 - GetNumberOfGeneratorEventsForTimeStep, 314
 - GetNumberOfLoadEventsForTimeStep, 314
 - GetNumberOfSwitchEventsForTimeStep, 315
 - GetNumberOfTimeSteps, 315
 - GetObj, 315
 - GetSwitchEvent, 315
 - GetTimeOfStepInSeconds, 316
 - GetTotalInterruptedPower, 316
 - JumpToLastStep, 316
 - RemoveEvents, 317
 - StartTrace, 317
 - StopTrace, 317
- ComCoordreport, 318
 - DevicesToReport, 318
 - HasResultsForDirectionalBackup, 318
 - HasResultsForFuse, 319
 - HasResultsForInstantaneous, 319
 - HasResultsForNonDirectionalBackup, 319
 - HasResultsForOverload, 320
 - HasResultsForOverreach, 320
 - HasResultsForShortCircuit, 320
 - HasResultsForZone, 321
 - MaxZoneNumberFor, 321
 - ResultForDirectionalBackupVariable, 321
 - ResultForFuseVariable, 322
 - ResultForInstantaneousVariable, 323
 - ResultForMaxCurrent, 323
 - ResultForNonDirectionalBackupVariable, 324
 - ResultForOverloadVariable, 325
 - ResultForOverreachVariable, 325
 - ResultForShortCircuitVariable, 326
 - ResultForZoneVariable, 327
 - TopologyForDirectionalBackupVariable, 327
 - TopologyForFuseVariable, 328
 - TopologyForInstantaneousVariable, 328
 - TopologyForMaxCurrent, 329

- TopologyForNonDirectionalBackupVariable, 329
- TopologyForOverloadVariable, 329
- TopologyForOverreachVariable, 330
- TopologyForShortCircuitVariable, 330
- TopologyForZoneVariable, 331
- TransferDirectionalBackupResultsTo, 331
- TransferNonDirectionalBackupResultsTo, 332
- TransferOverreachResultsTo, 332
- TransferResultsTo, 333
- TransferZoneResultsTo, 334
- ComCosim, 334
 - GetAdmissibleLines, 335
 - GetAllBoundaryBranches, 335
 - PartitionNetwork, 335
- ComDiffoutage, 335
 - Start, 335
- ComDllmanager, 336
 - Report, 336
- ComDpl, 336
 - CheckSyntax, 336
 - Encrypt, 337
 - Execute, 337
 - GetExternalObject, 338
 - GetInputParameterDouble, 338
 - GetInputParameterInt, 339
 - GetInputParameterString, 339
 - IsEncrypted, 339
 - ResetThirdPartyModule, 340
 - SetExternalObject, 340
 - SetInputParameterDouble, 340
 - SetInputParameterInt, 341
 - SetInputParameterString, 341
 - SetThirdPartyModule, 341
- ComFlickermeter, 342
 - Execute, 342
- ComGenrelin, 342
 - GetCurrentIteration, 342
 - GetMaxNumIterations, 343
- ComGridtocim, 343
 - AppendMessage, 343
 - AssignCimRdfIds, 344
 - ConvertAndExport, 344
 - GetMessageDescription, 345
 - GetMessageObject, 345
 - GetMessageSeverity, 346
 - GetNumberOfMessages, 346
 - SetAuthorityUri, 347
 - SetBoundaries, 347
 - SetGridsToExport, 348
- ComHostcap, 348
 - CalcMaxHostedPower, 348
- ComImport, 349
 - GetCreatedObjects, 349
 - GetModifiedObjects, 349
- ComInc, 350
 - CompileDynamicModelTypes, 350
 - CreateRemainingRegion, 350
 - GetAdmissibleLines, 351
 - GetAllBoundaryLines, 351
 - PartitionNetwork, 351
 - ZeroDerivative, 351
- ComLdf, 352
 - CheckControllers, 352
 - DoNotResetCalc, 352
 - EstimateOutage, 352
 - Execute, 353
 - IsAC, 353
 - IsBalanced, 353
 - IsDC, 353
 - PrintCheckResults, 354
 - SetOldDistributeLoadMode, 354
- ComLink, 354
 - LoadMicroSCADAFile, 354
 - ReceiveData, 355
 - SendData, 355
 - SentDataStatus, 355
 - SetOPCReceiveQuality, 355
 - SetSwitchShcEventMode, 356
- Commands Methods, 281
 - Execute, 281
- ComMerge, 356
 - CheckAssignments, 356
 - Compare, 357
 - CompareActive, 357
 - CompareRecording, 357
 - ExecuteRecording, 358
 - ExecuteWithActiveProject, 358
 - GetCorrespondingObject, 358
 - GetModification, 358
 - GetModificationResult, 359
 - GetModifiedObjects, 359
 - Merge, 360
 - PrintComparisonReport, 360
 - PrintModifications, 360
 - Reset, 361
 - SetAutoAssignmentForAll, 361
 - SetObjectsToCompare, 361
 - ShowBrowser, 361
 - WereModificationsFound, 361
- CommitTransaction
 - Application Methods, 6
- ComMot, 362
 - GetMotorConnections, 362
 - GetMotorSwitch, 362
 - GetMotorTerminal, 362
- ComNmink, 363
 - AddRef, 363
 - Clear, 363
 - GenerateContingenciesForAnalysis, 363
 - GetAll, 363
- ComOmr, 364

- GetFeeders, 364
- GetOMR, 364
- GetRegionCount, 364
- ComOpc, 365
 - GetCertificatePath, 365
 - ReceiveData, 365
 - SendData, 366
- ComOutage, 366
 - ContinueTrace, 366
 - ExecuteTime, 366
 - GetObject, 367
 - RemoveEvents, 367
 - SetObjs, 367
 - StartTrace, 368
 - StopTrace, 368
- Compare
 - ComMerge, 357
- CompareActive
 - ComMerge, 357
- CompareRecording
 - ComMerge, 357
- ComPfdimport, 368
 - GetImportedObjects, 368
- Compile
 - BlkDef, 502
 - TypMdl, 680
- CompileDynamicModelTypes
 - ComInc, 350
- ComPrjconnector, 369
 - GetSuccessfullyConnectedItems, 369
 - GetUnsuccessfullyConnectedItems, 369
- ComProtgraphic, 369
 - AddToUpdatePages, 369
 - ClearUpdatePages, 369
- ComPvcurves, 369
 - FindCriticalBus, 370
- ComPython, 370
 - GetExternalObject, 370
 - GetInputParameterDouble, 370
 - GetInputParameterInt, 371
 - GetInputParameterString, 371
 - SetExternalObject, 372
 - SetInputParameterDouble, 372
 - SetInputParameterInt, 372
 - SetInputParameterString, 373
- ComRed, 373
 - LdfEquivalentVerification, 373
 - ReductionInMemory, 374
 - ResetReductionInMemory, 374
 - SimEquivalentVerification, 374
- ComRel3, 374
 - AnalyseElmRes, 374
 - ExeEvt, 375
 - OvlAlleviate, 375
 - RemoveEvents, 375
 - RemoveOutages, 375
- ValidateConstraints, 376
- ComRelpost, 376
 - CalcContributions, 376
 - GetContributionOfComponent, 376
- ComRelreport, 377
 - GetContingencies, 377
 - GetContributionOfComponent, 377
- ComReltabreport, 377
 - GetContingencies, 378
 - GetContributionOfComponent, 378
- ComReport, 378
 - ExecuteWithCustomSelection, 378
 - SetParameter, 379
- ComRes, 379
 - ExportFullRange, 379
 - FileNmResNm, 379
- ComShc, 380
 - ExecuteRXSweep, 380
 - GetFaultType, 380
 - GetOverLoadedBranches, 381
 - GetOverLoadedBuses, 381
- ComShctrace, 382
 - BlockSwitch, 382
 - ExecuteAllSteps, 382
 - ExecuteInitialStep, 383
 - ExecuteNextStep, 383
 - GetBlockedSwitches, 383
 - GetCurrentTimeStep, 383
 - GetDeviceSequence, 383
 - GetDeviceSwitches, 384
 - GetDeviceTime, 384
 - GetFaultLocations, 384
 - GetNonStartedDevices, 384
 - GetPreviousDeviceTime, 384
 - GetStartedDevices, 385
 - GetSwitchSequence, 385
 - GetSwitchTime, 385
 - GetTrippedDevices, 385
 - IsSwitchScheduledToOpen, 386
 - NextStepAvailable, 386
- ComSim, 386
 - GetSimulationTime, 386
 - GetTotalWarnA, 386
 - GetTotalWarnB, 387
 - GetTotalWarnC, 387
 - GetViolatedScanModules, 387
 - LoadSimulationState, 387
 - LoadSnapshot, 387
 - SaveSimulationState, 388
 - SaveSnapshot, 388
- ComSimoutage, 388
 - AddCntcy, 389
 - AddContingencies, 389
 - AddRas, 389
 - ClearCont, 389
 - CreateFaultCase, 390

- Execute, 390
- ExecuteAndCheck, 390
- MarkRegions, 392
- RemoveAllRas, 392
- RemoveContingencies, 392
- RemoveRas, 392
- Reset, 392
- SetLimits, 393
- Update, 393
- ComStationware, 393
 - Connect, 393
 - Disconnect, 393
 - GetAuthenticationTicket, 394
 - IsConnected, 394
- ComSvgexport, 394
 - SetFileName, 394
 - SetObject, 394
 - SetObjects, 395
- ComSvgimport, 395
 - SetFileName, 395
 - SetObject, 395
- ComTablereport, 396
 - AddButton, 397
 - AddCellAction, 398
 - AddColumn, 399
 - AddHeader, 400
 - AddInvisibleFilter, 400
 - AddListFilter, 400
 - AddListFilterEntries, 401
 - AddMultiListFilter, 401
 - AddRow, 402
 - AddTable, 403
 - AddTabularFilter, 403
 - AddTextFilter, 404
 - ClearAll, 404
 - DisableAutomaticRowNumbering, 404
 - DisableSingleFilterRefresh, 405
 - DisplayButtonsCollapsible, 405
 - DisplayFiltersCollapsible, 405
 - DisplayFiltersIn2Columns, 405
 - DisplayHeadersCollapsible, 405
 - EnableAutomaticRowNumbering, 406
 - ExportToExcel, 406
 - ExportToHTML, 406
 - FindNextCell, 407
 - FindNextRow, 407
 - FindPreviousCell, 408
 - FindPreviousRow, 408
 - GetCellAccessObject, 409
 - GetCellAlignment, 409
 - GetCellBackgroundColor, 410
 - GetCellColor, 410
 - GetCellEditObjects, 410
 - GetCellFontStyle, 411
 - GetCellFormat, 411
 - GetCellHelpText, 412
 - GetCellValueType, 412
 - GetCheckboxCellValue, 413
 - GetColumnFilter, 413
 - GetColumnHeader, 414
 - GetColumnId, 414
 - GetDateCellValue, 415
 - GetDoubleCellValue, 415
 - GetIntCellValue, 416
 - GetNumberOfColumns, 416
 - GetNumberOfRows, 416
 - GetNumberOfSelectedCells, 417
 - GetObjectCellValue, 417
 - GetRowCaption, 418
 - GetRowId, 418
 - GetSelectedCell, 418
 - GetSelectedElements, 419
 - GetSelection, 419
 - GetStringCellValue, 419
 - GoToCell, 420
 - HasCell, 420
 - HasColumnAutoFilter, 420
 - IsColumnScrollable, 421
 - IsColumnSortable, 421
 - IsRowVisible, 422
 - NCol, 416
 - NRow, 416
 - RemoveRow, 422
 - SetBarLimits, 423
 - SetCellAccess, 423
 - SetCellAlignment, 423
 - SetCellBackgroundColor, 424
 - SetCellColor, 424
 - SetCellEdit, 425
 - SetCellFontStyle, 425
 - SetCellFormat, 426
 - SetCellStyle, 426
 - SetCellValueToBar, 427
 - SetCellValueToCheckbox, 428
 - SetCellValueToDate, 429
 - SetCellValueToDouble, 430
 - SetCellValueToInt, 431
 - SetCellValueToObject, 432
 - SetCellValueToString, 433
 - SetColumnHeader, 434
 - SetDialogSize, 435
 - SetExportHtml, 435
 - SetExportXls, 435
 - SetListFilterSelection, 436
 - SetRefresh, 436
 - SetSorting, 436
 - SetStatusText, 437
 - SetTitle, 437
 - SizeX, 416
 - SizeY, 416
- ComTasks, 437
 - AppendCommand, 438

- AppendStudyCase, 438
- GetCommandsForStudyCase, 438
- GetNumberOfCommandsForStudyCase, 439
- GetNumberOfStudyCases, 439
- GetStudyCases, 439
- IsAdditionalResultsFlagSetForCommand, 440
- IsCommandIgnored, 440
- IsStudyCaseIgnored, 441
- RemoveCmdsForStudyCaseRow, 441
- RemoveCommand, 441
- RemoveStudyCase, 442
- RemoveStudyCases, 442
- SetAdditionalResultsFlagForCommand, 443
- SetIgnoreFlagForCommand, 443
- SetIgnoreFlagForStudyCase, 444
- SetResultsFolder, 444
- ComTececo, 445
 - UpdateTablesByCalcPeriod, 445
- ComTececocmp, 445
 - AppendStudyCase, 445
 - CalcDiscountedEstimatedPaybackPeriod, 446
 - CalcEstimatedPaybackPeriod, 446
 - CalcInternalRateOfReturn, 447
 - RemoveStudyCases, 447
- ComTransfer, 447
 - GetTransferCalcData, 447
 - IsLastIterationFeasible, 448
- ComUcte, 448
 - SetBatchMode, 448
- ComUcteexp, 449
 - BuildNodeNames, 449
 - DeleteCompleteQuickAccess, 449
 - ExportAndInitQuickAccess, 449
 - GetConnectedBranches, 450
 - GetFromToNodeNames, 450
 - GetOrderCode, 450
 - GetUcteNodeName, 451
 - InitQuickAccess, 451
 - QuickAccessAvailable, 451
 - ResetQuickAccess, 451
 - SetGridSelection, 452
- ComWr, 452
 - ExportGraphicTab, 452
- Connect
 - ComStationware, 393
- ConnectShuntToBus
 - ComCapo, 297
- Consolidate
 - IntCase, 535
 - IntScheme, 620
- Contains
 - IntDplmap, 551
- ContinueTrace
 - ComContingency, 311
 - ComOutage, 366
- ConvertAndExport
 - ComGridtocim, 344
 - ConvertGeometriesToMDLString
 - IntSym, 627
 - ConvertGeometryStringToMDL
 - Application Methods, 6
 - ConvertToASCIIFormat
 - IntComtrade, 536
 - ConvertToBinaryFormat
 - IntComtrade, 537
 - ConvertToBlackbox
 - TypMdl, 680
 - ConvertToBusBranch
 - CimArchive, 506
 - CopyData
 - General Object Methods, 68
 - CopyDataExtensionFrom
 - IntPrj, 588
 - CopyExtMeaStatusToStatusTmp
 - StaExtbrkmea, 213
 - StaExtcmdmea, 217
 - StaExtatmea, 222
 - StaExtfmea, 227
 - StaExtfuelmea, 232
 - StaExttimea, 237
 - StaExtpfmea, 243
 - StaExtpmea, 248
 - StaExtqmea, 253
 - StaExtsmea, 259
 - StaExttapmea, 263
 - StaExtv3mea, 269
 - StaExtvmea, 274
 - CopyProjectSettings
 - IntPrj, 589
 - Create
 - SetPath, 479
 - CreateCBEvents
 - IntEvt, 556
 - CreateDerivedProject
 - IntVersion, 638
 - CreateEvent
 - ElmTr2, 181
 - ElmTr3, 184
 - ElmTr4, 189
 - ElmTrmult, 197
 - ElmVoltreg, 201
 - StaExtcmdmea, 217
 - StaExtatmea, 222
 - StaExttapmea, 263
 - CreateFaultCase
 - Application Methods, 7
 - ComSimoutage, 390
 - CreateFeederWithRoutes
 - ElmLne, 126
 - CreateField
 - IntReport, 603
 - CreateGroup

- IntUserman, 632
- CreateLayer
 - SetLevelvis, 476
- CreateMissingSetTrigger
 - IntCase, 535
- CreateModule
 - ComAddon, 283
- CreateObject
 - General Object Methods, 69
- CreateProject
 - Application Methods, 7
- CreateRecoveryInformation
 - ComContingency, 312
- CreateRemainingRegion
 - ComInc, 350
- CreateStageObject
 - IntSstage, 623
- CreateTable
 - IntReport, 604
- CreateTimeOvercurrentPlot
 - SetPath, 480
- CreateUser
 - IntUserman, 632
- CreateVersion
 - IntPrj, 589
- CreateVI
 - SetVipage, 499
- Date/Time Functions, 48
 - GetStudyTimeObject, 48
- Date
 - SetTime, 496
- Deactivate
 - ElmNet, 135
 - IntCase, 535
 - IntLibrary, 573
 - IntPrj, 590
 - IntScenario, 616
 - IntScensched, 618
 - IntScheme, 620
 - IntSscheduler, 622
- DecodeColour
 - Application Methods, 8
- Default
 - SetScenario, 485
- DefineBoundary
 - ElmArea, 98
 - ElmNet, 135
 - ElmZone, 206
- DefineDouble
 - ComAddon, 283
- DefineDoubleMatrix
 - ComAddon, 284
- DefineDoublePerConnection
 - ComAddon, 284
- DefineDoubleVector
 - ComAddon, 285
- DefineDoubleVectorPerConnection
 - ComAddon, 286
- DefineInteger
 - ComAddon, 286
- DefineIntegerPerConnection
 - ComAddon, 287
- DefineIntegerVector
 - ComAddon, 288
- DefineIntegerVectorPerConnection
 - ComAddon, 288
- DefineObject
 - ComAddon, 289
- DefineObjectPerConnection
 - ComAddon, 290
- DefineObjectVector
 - ComAddon, 290
- DefineObjectVectorPerConnection
 - ComAddon, 291
- DefineString
 - ComAddon, 291
- DefineStringPerConnection
 - ComAddon, 292
- DefineTransferAttributes
 - Application Methods, 8
- Delete
 - General Object Methods, 69
- DeleteCompleteQuickAccess
 - ComUctexp, 449
- DeleteModule
 - ComAddon, 293
- DeleteParameterAtIndex
 - CimModel, 506
 - CimObject, 513
- DeleteRow
 - IntScensched, 618
- DeleteUntouchedObjects
 - Application Methods, 9
- Derate
 - ElmGenstat, 121
 - ElmPvsys, 136
 - ElmSym, 168
- DevicesToReport
 - ComCoordreport, 318
- Dialogue Boxes Functions, 48
 - CloseTableReports, 48
 - GetTableReports, 48
 - ShowModalBrowser, 49
 - ShowModalSelectBrowser, 49
 - ShowModelessBrowser, 50
 - UpdateTableReports, 50
- DisableAutomaticRowNumbering
 - ComTablereport, 404
- DisableSingleFilterRefresh
 - ComTablereport, 405
- DiscardChanges

- IntScenario, 616
- Disconnect
 - ComStationware, 393
 - ElmGenstat, 121
 - ElmPvsys, 136
 - ElmSym, 168
 - ElmXnet, 203
- DisplayButtonsCollapsible
 - ComTablereport, 405
- DisplayFiltersCollapsible
 - ComTablereport, 405
- DisplayFiltersIn2Columns
 - ComTablereport, 405
- DisplayHeadersCollapsible
 - ComTablereport, 405
- DoAutoScale
 - GrpPage, 523
 - PltAxis, 639
 - PltLinebarplot, 646
 - PltVectorplot, 656
- DoAutoScaleX
 - GrpPage, 523
 - PltLinebarplot, 647
 - SetDesktop, 465
 - SetVipage, 498
 - VisPath, 684
 - VisPcompdiffplt, 686
 - VisPlottz, 688
- DoAutoScaleY
 - GrpPage, 523
 - PltLinebarplot, 647
 - SetVipage, 498
 - VisPath, 684
 - VisPcompdiffplt, 686
 - VisPlottz, 688
- DoNotResetCalc
 - ComLdf, 352
- EchoOff
 - Environment Functions, 51
- EchoOn
 - Environment Functions, 51
- ElmArea, 97
 - CalculateInterchangeTo, 97
 - CalculateVoltageLevel, 97
 - CalculateVoltInterVolt, 98
 - DefineBoundary, 98
 - GetAll, 98
 - GetBranches, 99
 - GetBuses, 99
 - GetObjs, 99
- ElmAsm, 99
 - CalcEfficiency, 100
 - GetAvailableGenPower, 100
 - GetElecTorque, 100
 - GetGroundingImpedance, 101
 - GetMechTorque, 101
 - GetMotorStartingFlag, 102
 - GetStepupTransformer, 102
 - IsPQ, 102
- ElmAsmsc, 103
 - GetAvailableGenPower, 103
 - GetGroundingImpedance, 103
 - GetStepupTransformer, 104
- ElmBattery, 104
 - GetGroundingImpedance, 104
- ElmBbone, 105
 - CheckBbPath, 105
 - GetBbOrder, 105
 - GetCompleteBbPath, 106
 - GetFOR, 106
 - GetMeanCs, 106
 - GetMinCs, 106
 - GetTieOpenPoint, 107
 - GetTotLength, 107
 - HasGnrlMod, 107
- ElmBmu, 107
 - Apply, 108
 - Update, 108
- ElmBoundary, 108
 - AddCubicle, 108
 - CalcShiftedReversedBoundary, 108
 - Clear, 109
 - GetInterior, 109
 - IsSplitting, 109
 - Resize, 109
 - Update, 110
- ElmBranch, 110
 - InsertTemplate, 110
 - Update, 111
- ElmCabsys, 111
 - FitParams, 111
 - GetLineCable, 111
 - Update, 111
- ElmComp, 112
 - slotupd, 112
 - SlotUpdate, 112
- ElmCoup, 112
 - Close, 112
 - GetRemoteBreakers, 113
 - IsBreaker, 113
 - IsClosed, 113
 - IsOpen, 114
 - Open, 114
- ElmDcu, 114
 - GetGroundingImpedance, 114
- ElmDsl, 115
 - ExportToClipboard, 115
 - ExportToFile, 115
 - InterfaceUpdate, 116
- ElmFeeder, 116
 - CalcAggrVarsInRadFeed, 116

- GetAll, 116
 - GetBranches, 117
 - GetBuses, 117
 - GetNodesBranches, 117
 - GetObjs, 118
- ElmFile, 118
 - LoadFile, 118
 - SaveFile, 119
- ElmFilter, 119
 - GetGroundingImpedance, 119
- ElmFsrc, 120
 - Init, 120
 - SetAmpl, 120
 - SetPhase, 120
- ElmGenstat, 121
 - CalcEfficiency, 121
 - Derate, 121
 - Disconnect, 121
 - GetAvailableGenPower, 122
 - GetGroundingImpedance, 122
 - GetStepupTransformer, 123
 - IsConnected, 123
 - Reconnect, 123
 - ResetDerating, 123
- ElmGndswt, 124
 - Close, 124
 - GetGroundingImpedance, 124
 - IsClosed, 124
 - IsOpen, 125
 - Open, 125
- ElmLne, 125
 - AreDistParamsPossible, 126
 - CreateFeederWithRoutes, 126
 - FitParams, 127
 - GetIthr, 127
 - GetType, 127
 - GetY0m, 127
 - GetY1m, 128
 - GetZ0m, 128
 - GetZ1m, 129
 - GetZmatDist, 129
 - HasRoutes, 130
 - HasRoutesOrSec, 130
 - IsCable, 130
 - IsNetCoupling, 130
 - MeasureLength, 130
 - SetDetailed, 131
- ElmLnesec, 131
 - IsCable, 131
- ElmMdl, 131
 - Check, 131
 - ExportToClipboard, 132
 - ExportToFile, 132
- ElmNec, 133
 - GetGroundingImpedance, 133
- ElmNet, 133
 - Activate, 133
 - CalculateInterchangeTo, 134
 - CalculateVoltageLevel, 134
 - CalculateVoltInterVolt, 134
 - Deactivate, 135
 - DefineBoundary, 135
- ElmPvsys, 136
 - CalcEfficiency, 136
 - Derate, 136
 - Disconnect, 136
 - GetAvailableGenPower, 137
 - GetGroundingImpedance, 137
 - GetStepupTransformer, 138
 - IsConnected, 138
 - Reconnect, 138
 - ResetDerating, 138
- ElmRecmono, 139
 - GetGroundingImpedance, 139
- ElmRelay, 139
 - CalculateMaxFaultCurrents, 140
 - CheckRanges, 140
 - GetCalcRX, 140
 - GetMaxFdetectCalcl, 140
 - GetOperatedSwitches, 141
 - GetSlot, 141
 - GetUnom, 141
 - IsStarted, 142
 - SetImpedance, 142
 - SetMaxI, 143
 - SetMaxlearth, 143
 - SetMinI, 143
 - SetMinlearth, 143
 - SetOutOfService, 143
 - SetTime, 144
 - slotupd, 145
 - SlotUpdate, 145
- ElmRes, 145
 - AddVariable, 146
 - AddVars, 146
 - Clear, 146
 - Close, 150
 - ExecuteLoadingCommand, 146
 - FindColumn, 146
 - FindMaxInColumn, 147
 - FindMaxOfVariableInRow, 147
 - FindMaxOfVariableInRowEx, 148
 - FindMaxRowsInColumns, 148
 - FindMinInColumn, 149
 - FindMinOfVariableInRow, 149
 - FindMinOfVariableInRowEx, 149
 - FindMinRowsInColumns, 150
 - FinishWriting, 150
 - Flush, 150
 - GetColumnValues, 151
 - GetDescription, 151
 - GetFirstValidObject, 151

- GetFirstValidObjectVariable, 153
- GetFirstValidVariable, 153
- GetNextValidObject, 153
- GetNextValidObjectVariable, 154
- GetNextValidVariable, 155
- GetNumberOfColumns, 155
- GetNumberOfRows, 155
- GetObj, 156
- GetObject, 156
- GetObjectValue, 156
- GetRelCase, 157
- GetSubElmRes, 157
- GetUnit, 157
- GetValue, 157
- GetVariable, 158
- Init, 158
- InitialiseWriting, 158
- Load, 159
- NCol, 155
- NRow, 155
- Release, 159
- SetAsDefault, 159
- SetObj, 159
- SetSubElmResKey, 160
- SizeX, 155
- SizeY, 155
- SortAccordingToColumn, 160
- Write, 160
- WriteDraw, 160
- ElmShnt, 161
 - GetGroundingImpedance, 161
- ElmStactrl, 161
 - GetControlledHVNNode, 161
 - GetControlledLVNode, 162
 - GetStepupTransformer, 162
 - Info, 162
- ElmSubstat, 163
 - ApplyAndResetRA, 163
 - GetSplit, 163
 - GetSplitCal, 164
 - GetSplitIndex, 165
 - GetSuppliedElements, 165
 - OverwriteRA, 166
 - ResetRA, 166
 - SaveAsRA, 166
 - SaveAsSwSc, 166
 - SetRA, 167
- ElmSvs, 167
 - GetStepupTransformer, 167
- ElmSym, 168
 - CalcEfficiency, 168
 - Derate, 168
 - Disconnect, 168
 - GetAvailableGenPower, 169
 - GetGroundingImpedance, 169
 - GetMotorStartingFlag, 170
 - GetStepupTransformer, 170
 - IsConnected, 170
 - Reconnect, 170
 - ResetDerating, 171
- ElmTerm, 171
 - GetBusType, 171
 - GetCalcRelevantCubicles, 172
 - GetConnectedBrkCubicles, 172
 - GetConnectedCubicles, 172
 - GetConnectedMainBuses, 172
 - GetConnectionInfo, 173
 - GetEquivalentTerminals, 173
 - GetMinDistance, 174
 - GetNextHVBUS, 174
 - GetNodeName, 175
 - GetSepStationAreas, 175
 - GetShortestPath, 175
 - GetShortestPathWithIndex, 176
 - HasCreatedCalBus, 177
 - InitAllShortestPaths, 177
 - IsElectrEquivalent, 178
 - IsEquivalent, 178
 - IsInternalNodeInStation, 179
 - UpdateSubstationTerminals, 179
- ElmTow, 179
 - FitParams, 180
 - PrintFreqDepParams, 180
 - Update, 180
- ElmTr2, 180
 - CreateEvent, 181
 - GetGroundingImpedance, 181
 - GetSuppliedElements, 181
 - GetTapPhi, 182
 - GetTapRatio, 182
 - GetZ0pu, 183
 - GetZpu, 183
 - IsQuadBooster, 184
 - NTap, 184
- ElmTr3, 184
 - CreateEvent, 184
 - GetGroundingImpedance, 185
 - GetSuppliedElements, 185
 - GetTapPhi, 186
 - GetTapRatio, 186
 - GetTapZDependentSide, 186
 - GetZ0pu, 187
 - GetZpu, 187
 - IsQuadBooster, 188
 - NTap, 188
- ElmTr4, 188
 - CreateEvent, 189
 - GetGroundingImpedance, 189
 - GetSuppliedElements, 189
 - GetTapPhi, 190
 - GetTapRatio, 190
 - GetTapZDependentSide, 191

- GetZ0pu, 191
- GetZpu, 192
- IsQuadBooster, 192
- NTap, 192
- ElmTrain, 193
 - SetPosition, 193
- ElmTrb, 193
 - GetGroundingImpedance, 193
- ElmTrfstat, 194
 - GetSplit, 194
 - GetSplitCal, 195
 - GetSplitIndex, 195
 - GetSuppliedElements, 196
 - SaveAsSwSc, 196
- ElmTrmult, 197
 - CreateEvent, 197
 - GetGroundingImpedance, 197
 - GetSuppliedElements, 198
 - GetTapPhi, 198
 - GetTapRatio, 199
 - GetZpu, 199
 - IsQuadBooster, 199
 - NTap, 200
- ElmVac, 200
 - GetGroundingImpedance, 200
- ElmVoltreg, 201
 - CreateEvent, 201
 - GetGroundingImpedance, 201
 - GetZpu, 201
 - NTap, 202
- ElmVscmono, 202
 - GetGroundingImpedance, 202
- ElmXnet, 203
 - CalcEfficiency, 203
 - Disconnect, 203
 - GetGroundingImpedance, 203
 - GetStepupTransformer, 204
 - Reconnect, 204
- ElmZone, 205
 - CalculateInterchangeTo, 205
 - CalculateVoltageLevel, 205
 - CalculateVoltInterVolt, 206
 - DefineBoundary, 206
 - GetAll, 206
 - GetBranches, 207
 - GetBuses, 207
 - GetObjs, 207
 - SetLoadScaleAbsolute, 207
- EmptyCache
 - SetDatabase, 461
- EnableAutomaticRowNumbering
 - ComTablereport, 406
- EnableDiffMode
 - IntSstage, 624
- EncodeColour
 - Application Methods, 9
- Encrypt
 - BlkDef, 503
 - ComDpl, 337
 - TypQdsl, 681
- EndDataExtensionModification
 - IntPrj, 590
- EndTabGroup
 - SetDesktop, 465
- Energize
 - General Object Methods, 69
- Environment Functions, 51
 - EchoOff, 51
 - EchoOn, 51
 - GetApplicationColourScheme, 51
 - IsAutomaticCalculationResetEnabled, 52
 - IsFinalEchoOnEnabled, 52
 - IsUserBreakPressed, 52
 - SetAutomaticCalculationResetEnabled, 53
 - SetEnableUserBreak, 55
 - SetFinalEchoOnEnabled, 53
 - SetGraphicUpdate, 53
 - SetGuiUpdateEnabled, 54
 - SetProgressBarUpdatesEnabled, 54
 - SetRescheduleFlag, 54
 - SetUserBreakEnabled, 55
- EstimateOutage
 - ComLdf, 352
- Execute
 - ComAddlabel, 282
 - ComCimdbexp, 300
 - ComCimdbimp, 301
 - ComCimvalidate, 305
 - ComConreq, 311
 - ComDpl, 337
 - ComFlickermeter, 342
 - ComLdf, 353
 - Commands Methods, 281
 - ComSimoutage, 390
- ExecuteAllSteps
 - ComShctrace, 382
- ExecuteAmpacityCalc
 - ComAmpacity, 294
- ExecuteAndCheck
 - ComSimoutage, 390
- ExecuteCmd
 - Application Methods, 9
- ExecuteInitialStep
 - ComShctrace, 383
- ExecuteLoadingCommand
 - ElmRes, 146
- ExecuteNextStep
 - ComShctrace, 383
- ExecuteRecording
 - ComMerge, 358
- ExecuteRXSweep
 - ComShc, 380

- ExecuteTime
 - ComOutage, 366
- ExecuteWithActiveProject
 - ComMerge, 358
- ExecuteWithCustomSelection
 - ComReport, 378
- ExeEvt
 - ComRel3, 375
- Export
 - IntDocument, 550
 - IntGrfgroup, 559
 - IntGrflayer, 564
 - IntIcon, 572
- ExportAllReportDocuments
 - SetTabgroup, 490
- ExportAllTableReports
 - SetTabgroup, 490
- ExportAndInitQuickAccess
 - ComUcteexp, 449
- ExportFullRange
 - ComRes, 379
- ExportGraphicTab
 - ComWr, 452
 - SetDesktop, 466
- ExportToClipboard
 - ElmDsl, 115
 - ElmMdl, 132
- ExportToExcel
 - ComTablereport, 406
- ExportToFile
 - ElmDsl, 115
 - ElmMdl, 132
- ExportToHTML
 - ComTablereport, 406
- ExportToVec
 - IntGrflayer, 565
- File System Functions, 46
 - GetAbsolutePath, 46
 - GetInstallationDirectory, 47
 - GetInstallDir, 47
 - GetTempDir, 47
 - GetTemporaryDirectory, 47
 - GetWorkingDir, 47
 - GetWorkspaceDirectory, 47
- FileNmResNm
 - ComRes, 379
- FinaliseModule
 - ComAddon, 293
- FindColumn
 - ElmRes, 146
 - IntComtrade, 537
 - IntComtradeset, 543
- FindCriticalBus
 - ComPvcures, 370
- FindMaxInColumn
 - ElmRes, 147
 - IntComtrade, 537
 - IntComtradeset, 543
- FindMaxOfVariableInRow
 - ElmRes, 147
- FindMaxOfVariableInRowEx
 - ElmRes, 148
- FindMaxRowsInColumns
 - ElmRes, 148
- FindMinInColumn
 - ElmRes, 149
 - IntComtrade, 538
 - IntComtradeset, 544
- FindMinOfVariableInRow
 - ElmRes, 149
- FindMinOfVariableInRowEx
 - ElmRes, 149
- FindMinRowsInColumns
 - ElmRes, 150
- FindNextCell
 - ComTablereport, 407
- FindNextRow
 - ComTablereport, 407
- FindPreviousCell
 - ComTablereport, 408
- FindPreviousRow
 - ComTablereport, 408
- FinishWriting
 - ElmRes, 150
- First
 - IntDplmap, 552
- FitParams
 - ElmCabsys, 111
 - ElmLne, 127
 - ElmTow, 180
- Flush
 - ElmRes, 150
 - Output Window Methods, 64
- FlushOutputWindow
 - Output Window Functions, 61
- Freeze
 - SetDesktop, 466
- General Description, 1
- General Object Methods, 66
 - AddCopy, 67
 - CopyData, 68
 - CreateObject, 69
 - Delete, 69
 - Energize, 69
 - GetAttribute, 70
 - GetAttributeDescription, 70
 - GetAttributeDisplayed, 71
 - GetAttributeLength, 71
 - GetAttributes, 71
 - GetAttributeShape, 72

- GetAttributeType, 72
- GetAttributeUnit, 72
- GetAttributeUnitPrefix, 73
- GetAttributeUnitPrefixFactor, 73
- GetChildren, 74
- GetClassName, 74
- GetCombinedProjectSource, 75
- GetConnectedElements, 75
- GetConnectionCount, 75
- GetContents, 76
- GetControlledNode, 76
- GetCubicle, 77
- GetDbObjectId, 77
- GetDbObjectKey, 77
- GetDbProjectId, 78
- GetFullName, 78
- GetFullPath, 78
- GetImpedance, 79
- GetInom, 79
- GetNode, 80
- GetObjectId_, 77
- GetObjectPid_, 78
- GetOperator, 80
- GetOwner, 80
- GetParent, 81
- GetReferences, 81
- GetRegion, 82
- GetShortPath, 82
- GetSupplyingSubstations, 82
- GetSupplyingTransformers, 83
- GetSupplyingTrfstations, 83
- GetSystemGrounding, 83
- GetUnom, 83
- GetZeroImpedance, 84
- HasAttribute, 84
- HasReferences, 85
- HasResults, 85
- IsCalcRelevant, 85
- IsDeleted, 86
- IsEarthed, 86
- IsEnergized, 86
- IsHidden, 86
- IsInFeeder, 87
- IsNetworkDataFolder, 87
- IsNode, 88
- IsObjectActive, 88
- IsObjectModifiedByVariation, 88
- Isolate, 89
- IsOutOfService, 89
- IsReducible, 90
- IsShortCircuited, 90
- MarkInGraphics, 90
- Move, 91
- PasteCopy, 91
- PurgeUnusedObjects, 92
- ReportUnusedObjects, 92
- SearchObject, 92
- SetAttribute, 93
- SetAttributeInRootAndStageObjects, 93
- SetAttributeLength, 93
- SetAttributes, 94
- SetAttributeShape, 94
- ShowEditDialog, 94
- ShowModalSelectTree, 95
- SwitchOff, 95
- SwitchOn, 96
- WriteChangesToDb, 96
- GenerateContingenciesForAnalysis
 - ComNmink, 363
- Get
 - IntDplvec, 554
 - IntMat, 574
 - IntVec, 633
 - IntVecobj, 636
 - SetFilt, 474
- GetAbsDistance
 - SetPath, 480
- GetAbsolutePath
 - File System Functions, 46
- GetActiveCalculationStr
 - Application Methods, 10
- GetActiveModule
 - ComAddon, 293
- GetActiveNetworkVariations
 - Application Methods, 10
- GetActivePage
 - SetDesktop, 466
- GetActiveProject
 - Application Methods, 10
- GetActiveScenario
 - Application Methods, 10
- GetActiveScenarioScheduler
 - Application Methods, 10
- GetActiveScheduler
 - IntScheme, 621
- GetActiveStages
 - Application Methods, 11
- GetActiveStudyCase
 - Application Methods, 11
- GetAdmissibleLines
 - ComCosim, 335
 - ComInc, 351
- GetAlarmColouringMode
 - SetColscheme, 454
- GetAll
 - ComNmink, 363
 - ElmArea, 98
 - ElmFeeder, 116
 - ElmZone, 206
 - IntDataset, 549
 - SetPath, 480
 - SetSelect, 488

- StaCubic, [209](#)
- GetAllBoundaryBranches
 - ComCosim, [335](#)
- GetAllBoundaryLines
 - ComInc, [351](#)
- GetAllUsers
 - Application Methods, [11](#)
- GetAnalogueDescriptions
 - IntComtrade, [538](#)
 - IntComtradeset, [544](#)
- GetAnnotationElement
 - IntGrflayer, [565](#)
- GetApplication
 - Module Functions, [2](#)
- GetApplicationColourScheme
 - Environment Functions, [51](#)
- GetApplicationExt
 - Module Functions, [3](#)
- GetAttribute
 - General Object Methods, [70](#)
- GetAttributeDescription
 - Application Methods, [11](#)
 - General Object Methods, [70](#)
- GetAttributeDisplayed
 - General Object Methods, [71](#)
- GetAttributeEnumerationType
 - CimModel, [507](#)
 - CimObject, [514](#)
- GetAttributeLength
 - General Object Methods, [71](#)
- GetAttributes
 - General Object Methods, [71](#)
- GetAttributeShape
 - General Object Methods, [72](#)
- GetAttributeType
 - General Object Methods, [72](#)
- GetAttributeUnit
 - Application Methods, [12](#)
 - General Object Methods, [72](#)
- GetAttributeUnitPrefix
 - General Object Methods, [73](#)
- GetAttributeUnitPrefixFactor
 - General Object Methods, [73](#)
- GetAuthenticationTicket
 - ComStationware, [394](#)
- GetAvailableAttributes
 - Application Methods, [12](#)
- GetAvailableAttributesAsJson
 - Application Methods, [13](#)
- GetAvailableButtons
 - SetTboxconfig, [495](#)
- GetAvailableGenPower
 - ElmAsm, [100](#)
 - ElmAsmsc, [103](#)
 - ElmGenstat, [122](#)
 - ElmPvsys, [137](#)
- ElmSym, [169](#)
- GetAxisX
 - PltLinebarplot, [647](#)
 - PltVectorplot, [657](#)
- GetAxisY
 - PltLinebarplot, [647](#)
 - PltVectorplot, [657](#)
- GetBbOrder
 - ElmBbone, [105](#)
- GetBlockedSwitches
 - ComShctrace, [383](#)
- GetBorderCubicles
 - Application Methods, [17](#)
- GetBranch
 - StaCubic, [210](#)
- GetBranches
 - ElmArea, [99](#)
 - ElmFeeder, [117](#)
 - ElmZone, [207](#)
 - SetPath, [481](#)
- GetBrowserSelection
 - Application Methods, [17](#)
- GetBuses
 - ElmArea, [99](#)
 - ElmFeeder, [117](#)
 - ElmZone, [207](#)
 - SetPath, [481](#)
- GetBusType
 - ElmTerm, [171](#)
- GetCalcRelevantCubicles
 - ElmTerm, [172](#)
- GetCalcRelevantObjects
 - Application Methods, [18](#)
- GetCalcRX
 - ElmRelay, [140](#)
- GetCalculationBalancedMode
 - Application Methods, [18](#)
- GetCalculationDescription
 - Application Methods, [19](#)
- GetCalculations
 - Application Methods, [19](#)
- GetCalculationsAsJson
 - Application Methods, [21](#)
- GetCanvasSize
 - SetDesktop, [466](#)
- GetCellAccessObject
 - ComTablereport, [409](#)
- GetCellAlignment
 - ComTablereport, [409](#)
- GetCellBackgroundColor
 - ComTablereport, [410](#)
- GetCellColor
 - ComTablereport, [410](#)
- GetCellEditObjects
 - ComTablereport, [410](#)
- GetCellFontStyle

- ComTablereport, 411
- GetCellFormat
 - ComTablereport, 411
- GetCellHelpText
 - ComTablereport, 412
- GetCellValueType
 - ComTablereport, 412
- GetCertificatePath
 - ComOpc, 365
- GetCheckboxCellValue
 - ComTablereport, 413
- GetChecksum
 - BlkDef, 503
- GetChildren
 - General Object Methods, 74
- GetClassDescription
 - Application Methods, 22
- GetClassId
 - Application Methods, 22
- GetClassName
 - General Object Methods, 74
- GetClassType
 - ComCimvalidate, 306
- GetColouringMode
 - SetColscheme, 454
- GetColumnFilter
 - ComTablereport, 413
- GetColumnHeader
 - ComTablereport, 414
- GetColumnId
 - ComTablereport, 414
- GetColumnLabel
 - IntMat, 574
- GetColumnLabelIndex
 - IntMat, 575
- GetColumnValues
 - ElmRes, 151
 - IntComtrade, 538
 - IntComtradeset, 544
- GetCombinedProjectSource
 - General Object Methods, 75
- GetCommandsForStudyCase
 - ComTasks, 438
- GetCompleteBbPath
 - ElmBbone, 106
- GetComplexData
 - PltVectorplot, 657
- GetConfiguration
 - IntSubset, 627
 - SetDataext, 462
- GetConfigurations
 - SetDataext, 462
- GetConnectedBranches
 - ComUcteexp, 450
- GetConnectedBrkCubicles
 - ElmTerm, 172
- GetConnectedCubicles
 - ElmTerm, 172
- GetConnectedElements
 - General Object Methods, 75
- GetConnectedMainBuses
 - ElmTerm, 172
- GetConnectedMajorNodes
 - StaCubic, 210
- GetConnectionCount
 - General Object Methods, 75
- GetConnectionInfo
 - ElmTerm, 173
- GetConnections
 - StaCubic, 210
- GetContent
 - Output Window Methods, 64
- GetContents
 - General Object Methods, 76
- GetContingencies
 - ComRelreport, 377
 - ComReltabreport, 378
- GetContributionOfComponent
 - ComRelpost, 376
 - ComRelreport, 377
 - ComReltabreport, 378
- GetControlledHVNode
 - ElmStactrl, 161
- GetControlledLVNode
 - ElmStactrl, 162
- GetControlledNode
 - General Object Methods, 76
- GetCorrespondingObject
 - ComMerge, 358
- GetCreatedBoundaries
 - ComBoundary, 296
- GetCreatedObjects
 - ComImport, 349
- GetCriticalTimePhase
 - IntThrating, 629
- GetCubicle
 - General Object Methods, 77
- GetCurrentDiagram
 - Application Methods, 22
- GetCurrentIteration
 - ComGenrelinc, 342
- GetCurrentScript
 - Application Methods, 22
- GetCurrentSelection
 - Application Methods, 23
- GetCurrentTimeStep
 - ComShctrace, 383
- GetCurrentUser
 - Application Methods, 23
- GetCurrentZoomScaleLevel
 - Application Methods, 23
- GetDataFolder

- Application Methods, 23
- GetDataSeries
 - PltLinebarplot, 647
- GetDataSource
 - PltDataseries, 643
 - PltLinebarplot, 648
- GetDateCellValue
 - ComTablereport, 415
- GetDbObjectId
 - General Object Methods, 77
- GetDbObjectKey
 - General Object Methods, 77
- GetDbProjectId
 - General Object Methods, 78
- GetDerivedProjects
 - IntPrj, 590
 - IntVersion, 638
- GetDescription
 - ElmRes, 151
 - IntComtrade, 539
 - IntComtradeset, 545
- GetDescriptionText
 - ComCimvalidate, 306
- GetDesktop
 - Application Methods, 24
- GetDeviceSequence
 - ComShctrace, 383
- GetDeviceSwitches
 - ComShctrace, 384
- GetDeviceTime
 - ComShctrace, 384
- GetDiagramSelection
 - Application Methods, 24
- GetDigitalDescriptions
 - IntComtrade, 539
 - IntComtradeset, 545
- GetDisplayedButtons
 - SetTboxconfig, 495
- GetDoubleCellValue
 - ComTablereport, 415
- GetElecTorque
 - ElmAsm, 100
- GetEnergisingColouringMode
 - SetColscheme, 455
- GetEquivalentTerminals
 - ElmTerm, 173
- GetExternalObject
 - ComDpl, 338
 - ComPython, 370
- GetExternalReferences
 - IntPrj, 591
- GetFaultLocations
 - ComShctrace, 384
- GetFaultType
 - ComShc, 380
- GetFeeders
 - ComOmr, 364
- GetFieldCount
 - IntReport, 604
- GetFieldDataType
 - IntReport, 605
- GetFieldName
 - IntReport, 605
- GetFirstValidObject
 - ElmRes, 151
- GetFirstValidObjectVariable
 - ElmRes, 153
- GetFirstValidVariable
 - ElmRes, 153
- GetFlowOrientation
 - Application Methods, 24
- GetFontID
 - SetPrj, 483
- GetFOR
 - ElmBbone, 106
- GetFromSigName
 - BlkSig, 505
- GetFromStudyCase
 - Application Methods, 25
- GetFromToNodeNames
 - ComUcteexp, 450
- GetFullName
 - General Object Methods, 78
- GetFullPath
 - General Object Methods, 78
- GetGeneratorEvent
 - ComContingency, 312
- GetGeoCoordinateSystem
 - IntPrj, 591
- GetGlobalLibrary
 - Application Methods, 25
- GetGroundingAreaCouplings
 - ComCheck, 299
- GetGroundingAreaElements
 - ComCheck, 299
- GetGroundingAreaGroundings
 - ComCheck, 299
- GetGroundingImpedance
 - ElmAsm, 101
 - ElmAsmsc, 103
 - ElmBattery, 104
 - ElmDcu, 114
 - ElmFilter, 119
 - ElmGenstat, 122
 - ElmGndswt, 124
 - ElmNec, 133
 - ElmPvsys, 137
 - ElmRecmono, 139
 - ElmShnt, 161
 - ElmSym, 169
 - ElmTr2, 181
 - ElmTr3, 185

- ElmTr4, [189](#)
- ElmTrb, [193](#)
- ElmTrmult, [197](#)
- ElmVac, [200](#)
- ElmVoltreg, [201](#)
- ElmVscmono, [202](#)
- ElmXnet, [203](#)
- GetGroups
 - IntUserman, [632](#)
- GetHistoricalProject
 - IntVersion, [638](#)
- GetImpedance
 - General Object Methods, [79](#)
- GetImpedanceAtPos
 - SetPath, [481](#)
- GetImportedObjects
 - ComPfdimport, [368](#)
- GetInom
 - General Object Methods, [79](#)
- GetInputObject
 - ComCimvalidate, [307](#)
- GetInputParameterDouble
 - ComDpl, [338](#)
 - ComPython, [370](#)
- GetInputParameterInt
 - ComDpl, [339](#)
 - ComPython, [371](#)
- GetInputParameterString
 - ComDpl, [339](#)
 - ComPython, [371](#)
- GetInstallationDirectory
 - File System Functions, [47](#)
- GetInstallDir
 - File System Functions, [47](#)
- GetIntCalcre
 - PltDataserie, [643](#)
- GetIntCellValue
 - ComTablereport, [416](#)
- GetInterfaceVersion
 - Application Methods, [25](#)
- GetInterior
 - ElmBoundary, [109](#)
- GetInterruptedPowerAndCustomersForStage
 - ComContingency, [313](#)
- GetInterruptedPowerAndCustomersForTimeStep
 - ComContingency, [313](#)
- GetIthr
 - ElmLne, [127](#)
- GetLanguage
 - Application Methods, [26](#)
- GetLatestVersion
 - IntPrj, [591](#)
- GetLegend
 - PltLinebarplot, [648](#)
 - PltVectorplot, [657](#)
- GetLimit
 - ScnFreq, [663](#)
 - ScnFrt, [665](#)
 - ScnSpeed, [667](#)
 - ScnSync, [669](#)
 - ScnVar, [671](#)
 - ScnVolt, [673](#)
- GetLineCable
 - ElmCabsys, [111](#)
- GetLoadEvent
 - ComContingency, [314](#)
- GetLocalLibrary
 - Application Methods, [26](#)
- GetLocationsToReport
 - ComArcreport, [294](#)
- GetMaxFdetectCalcl
 - ElmRelay, [140](#)
- GetMaxNumIterations
 - ComGenreline, [343](#)
- GetMeanCs
 - ElmBbone, [106](#)
- GetMeaValue
 - StaExtbrkmea, [213](#)
 - StaExtcmdmea, [218](#)
 - StaExtatmea, [223](#)
 - StaExtfmea, [227](#)
 - StaExtfuelmea, [232](#)
 - StaExttimea, [237](#)
 - StaExtpfmea, [243](#)
 - StaExtpmea, [248](#)
 - StaExtqmea, [253](#)
 - StaExttapmea, [264](#)
 - StaExtv3mea, [269](#)
 - StaExtvmea, [274](#)
- GetMechTorque
 - ElmAsm, [101](#)
- GetMem
 - Application Methods, [26](#)
- GetMessageDescription
 - ComCimtogrid, [303](#)
 - ComGridtocim, [345](#)
- GetMessageObject
 - ComCimtogrid, [303](#)
 - ComGridtocim, [345](#)
- GetMessageSeverity
 - ComCimtogrid, [304](#)
 - ComGridtocim, [346](#)
- GetMinCs
 - ElmBbone, [106](#)
- GetMinDistance
 - ElmTerm, [174](#)
- GetModel
 - ComCimvalidate, [307](#)
- GetModelId
 - ComCimvalidate, [308](#)
- GetModelsReferencingThis

- CimModel, 507
- GetModification
 - ComMerge, 358
- GetModificationResult
 - ComMerge, 359
- GetModifiedObjects
 - ComImport, 349
 - ComMerge, 359
- GetMotorConnections
 - ComMot, 362
- GetMotorStartingFlag
 - ElmAsm, 102
 - ElmSym, 170
- GetMotorSwitch
 - ComMot, 362
- GetMotorTerminal
 - ComMot, 362
- GetNearestBusbars
 - StaCubic, 211
- GetNextHVBus
 - ElmTerm, 174
- GetNextValidObject
 - ElmRes, 153
- GetNextValidObjectVariable
 - ElmRes, 154
- GetNextValidVariable
 - ElmRes, 155
- GetNode
 - General Object Methods, 80
 - SetPath, 482
- GetNodeName
 - ElmTerm, 175
- GetNodesBranches
 - ElmFeeder, 117
- GetNonStartedDevices
 - ComShctrace, 384
- GetNumberOfAnalogueSignalDescriptions
 - IntComtrade, 539
 - IntComtradeset, 546
- GetNumberOfAnnotationElements
 - IntGrflayer, 565
- GetNumberOfClusters
 - SetCluster, 454
- GetNumberOfColumns
 - ComTablereport, 416
 - ElmRes, 155
 - IntComtrade, 539
 - IntComtradeset, 546
 - IntMat, 575
- GetNumberOfCommandsForStudyCase
 - ComTasks, 439
- GetNumberOfDigitalSignalDescriptions
 - IntComtrade, 540
 - IntComtradeset, 546
- GetNumberOfGeneratorEventsForTimeStep
 - ComContingency, 314
- GetNumberOfGroundingAreas
 - ComCheck, 299
- GetNumberOfLoadEventsForTimeStep
 - ComContingency, 314
- GetNumberOfMessages
 - ComCimtogrid, 304
 - ComGridtocim, 346
- GetNumberOfRows
 - ComTablereport, 416
 - ElmRes, 155
 - IntComtrade, 540
 - IntComtradeset, 546
 - IntMat, 575
- GetNumberOfSelectedCells
 - ComTablereport, 417
- GetNumberOfStudyCases
 - ComTasks, 439
- GetNumberOfSwitchEventsForTimeStep
 - ComContingency, 315
- GetNumberOfTimeSteps
 - ComContingency, 315
- GetNumberOfValidationMessages
 - ComCimvalidate, 308
- GetNumberOfViolations
 - ScnFreq, 663
 - ScnFrt, 665
 - ScnSpeed, 667
 - ScnSync, 669
 - ScnVar, 671
 - ScnVolt, 673
- GetNumProcesses
 - SetUser, 498
- GetNumSlave
 - SetParalman, 477
- GetObj
 - ComContingency, 315
 - ElmRes, 156
- GetObject
 - ComCimvalidate, 308
 - ComOutage, 367
 - ElmRes, 156
- GetObjectByDbObjectKey
 - Application Methods, 27
- GetObjectCellValue
 - ComTablereport, 417
- GetObjectId
 - ComCimvalidate, 309
- GetObjectId_
 - General Object Methods, 77
- GetObjectPid_
 - General Object Methods, 78
- GetObjects
 - IntReport, 606
 - IntScenario, 616
 - IntSubset, 627
- GetObjectsReferencingThis

- CimObject, 514
- GetObjectsWithSameld
 - CimObject, 515
- GetObjectValue
 - ElmRes, 156
 - IntComtrade, 540
 - IntComtradeset, 546
- GetObjs
 - ElmArea, 99
 - ElmFeeder, 118
 - ElmZone, 207
- GetOMR
 - ComOmr, 364
- GetOperatedSwitches
 - ElmRelay, 141
 - RelFuse, 659
 - RelLogdip, 661
 - RelLogic, 661
- GetOperationValue
 - IntScenario, 616
- GetOperator
 - General Object Methods, 80
- GetOrCreateTrigger
 - TriCont, 676
 - TriDisc, 676
 - TriFile, 676
 - TriVal, 677
- GetOrderCode
 - ComUcteexp, 450
- GetOrInsertCurvePlot
 - GrpPage, 523
- GetOrInsertPlot
 - GrpPage, 524
 - SetVipage, 499
- GetOutputWindow
 - Output Window Functions, 62
- GetOverLoadedBranches
 - ComShc, 381
- GetOverLoadedBuses
 - ComShc, 381
- GetOwner
 - General Object Methods, 80
- GetPage
 - SetDesktop, 467
- GetParameterCount
 - CimModel, 508
 - CimObject, 515
- GetParameterNamespace
 - CimModel, 508
 - CimObject, 516
- GetParameterValue
 - CimModel, 509
 - CimObject, 516
- GetParameterValueAsDouble
 - IntReport, 606
- GetParameterValueAsInteger
 - IntReport, 607
- GetParameterValueAsString
 - IntReport, 607
- GetParent
 - General Object Methods, 81
- GetPathFolder
 - SetPath, 482
- GetPathToNearestBusbar
 - StaCubic, 211
- GetPfObjects
 - CimObject, 517
- GetPlot
 - GrpPage, 525
- GetPreviousDeviceTime
 - ComShctrace, 384
- GetProfile
 - ComCimvalidate, 309
- GetProjectDirectory
 - IntPrj, 592
- GetProjectFolder
 - Application Methods, 27
- GetProjectFolderType
 - IntPrjfolder, 599
- GetQlim
 - IntQlim, 600
- GetRandomNumber
 - Mathematical Functions, 56
- GetRandomNumberEx
 - Mathematical Functions, 56
- GetRating
 - IntThrating, 629
- GetRecordingStage
 - Application Methods, 27
- GetRecoveryTime
 - ScnFreq, 664
 - ScnFrt, 666
 - ScnSpeed, 668
 - ScnSync, 670
 - ScnVar, 672
 - ScnVolt, 674
- GetReferences
 - General Object Methods, 81
- GetRegion
 - General Object Methods, 82
- GetRegionCount
 - ComOmr, 364
- GetRelay
 - SetPath, 482
- GetRelCase
 - ElmRes, 157
- GetRemoteBreakers
 - ElmCoup, 113
- GetRowCaption
 - ComTablereport, 418
- GetRowCount
 - IntReport, 608

- GetRowId
 - ComTablereport, 418
- GetRowLabel
 - IntMat, 576
- GetRowLabelIndex
 - IntMat, 576
- GetScenario
 - IntScensched, 619
- GetScheme
 - IntSstage, 624
- GetSelectedCell
 - ComTablereport, 418
- GetSelectedElements
 - ComTablereport, 419
- GetSelection
 - ComTablereport, 419
- GetSepStationAreas
 - ElmTerm, 175
- GetSettings
 - Application Methods, 28
- GetSeverity
 - ComCimvalidate, 310
- GetShortestPath
 - ElmTerm, 175
- GetShortestPathWithIndex
 - ElmTerm, 176
- GetShortPath
 - General Object Methods, 82
- GetSignalHeader
 - IntComtrade, 541
 - IntComtradeset, 547
- GetSimulationTime
 - ComSim, 386
- GetSlot
 - ElmRelay, 141
- GetSplit
 - ElmSubstat, 163
 - ElmTrfstat, 194
- GetSplitCal
 - ElmSubstat, 164
 - ElmTrfstat, 195
- GetSplitIndex
 - ElmSubstat, 165
 - ElmTrfstat, 195
- GetSplitOrientation
 - SetDesktop, 467
- GetStartedDevices
 - ComShctrace, 385
- GetStartEndTime
 - IntScensched, 619
- GetStatus
 - StaExtbrkmea, 213
 - StaExtcmdmea, 218
 - StaExtmdatmea, 223
 - StaExtfmea, 228
 - StaExtfuelmea, 233
 - StaExttimea, 238
 - StaExtpfmea, 243
 - StaExtpmea, 248
 - StaExtqmea, 254
 - StaExtsmea, 259
 - StaExttapmea, 264
 - StaExtv3mea, 270
 - StaExtvmea, 275
- GetStatusTmp
 - StaExtbrkmea, 213
 - StaExtcmdmea, 218
 - StaExtmdatmea, 223
 - StaExtfmea, 228
 - StaExtfuelmea, 233
 - StaExttimea, 238
 - StaExtpfmea, 243
 - StaExtpmea, 249
 - StaExtqmea, 254
 - StaExtsmea, 259
 - StaExttapmea, 264
 - StaExtv3mea, 270
 - StaExtvmea, 275
- GetStepupTransformer
 - ElmAsm, 102
 - ElmAsmsc, 104
 - ElmGenstat, 123
 - ElmPvsys, 138
 - ElmStactrl, 162
 - ElmSvs, 167
 - ElmSym, 170
 - ElmXnet, 204
- GetStringCellValue
 - ComTablereport, 419
- GetStudyCases
 - ComTasks, 439
- GetStudyTimeObject
 - Date/Time Functions, 48
- GetSubElmRes
 - ElmRes, 157
- GetSuccessfullyConnectedItems
 - ComPrjconnector, 369
- GetSummaryGrid
 - Application Methods, 28
- GetSuppliedElements
 - ElmSubstat, 165
 - ElmTr2, 181
 - ElmTr3, 185
 - ElmTr4, 189
 - ElmTrfstat, 196
 - ElmTrmult, 198
- GetSupplyingSubstations
 - General Object Methods, 82
- GetSupplyingTransformers
 - General Object Methods, 83
- GetSupplyingTrfstations
 - General Object Methods, 83

- GetSwitchEvent
 - ComContingency, 315
- GetSwitchSequence
 - ComShctrace, 385
- GetSwitchStatus
 - IntRunarrange, 614
- GetSwitchTime
 - ComShctrace, 385
- GetSystemGrounding
 - General Object Methods, 83
- GetTabCount
 - SetTabgroup, 491
- GetTabGroups
 - SetDesktop, 468
- GetTableCount
 - IntReport, 608
- GetTableName
 - IntReport, 608
- GetTableReports
 - Dialogue Boxes Functions, 48
- GetTabObject
 - SetTabgroup, 491
- GetTabTitle
 - SetTabgroup, 492
- GetTabType
 - SetTabgroup, 492
- GetTapPhi
 - ElmTr2, 182
 - ElmTr3, 186
 - ElmTr4, 190
 - ElmTrmult, 198
- GetTapRatio
 - ElmTr2, 182
 - ElmTr3, 186
 - ElmTr4, 190
 - ElmTrmult, 199
- GetTapZDependentSide
 - ElmTr3, 186
 - ElmTr4, 191
- GetTempDir
 - File System Functions, 47
- GetTemporaryDirectory
 - File System Functions, 47
- GetTieOpenPoint
 - ElmBbone, 107
- GetTimeOfStepInSeconds
 - ComContingency, 316
- GetTimeUTC
 - SetTime, 496
- GetTitleObject
 - PltLinebarplot, 648
 - PltVectorplot, 657
- GetToSigName
 - BlkSig, 505
- GetTotalInterruptedPower
 - ComContingency, 316
- GetTotalWarnA
 - ComSim, 386
- GetTotalWarnB
 - ComSim, 387
- GetTotalWarnC
 - ComSim, 387
- GetTotLength
 - ElmBbone, 107
- GetTouchedObjects
 - Application Methods, 28
- GetTouchingExpansionStages
 - Application Methods, 29
- GetTouchingStageObjects
 - Application Methods, 29
- GetTouchingVariations
 - Application Methods, 29
- GetTransferCalcData
 - ComTransfer, 447
- GetTrippedDevices
 - ComShctrace, 385
- GetType
 - ComCimvalidate, 310
 - ElmLne, 127
- GetUcteNodeName
 - ComUcteexp, 451
- GetUnit
 - ElmRes, 157
 - IntComtrade, 541
 - IntComtradeset, 547
- GetUnitFor
 - ComArcreport, 295
- GetUnitPrefixFactor
 - Application Methods, 30
- GetUnom
 - ElmRelay, 141
 - General Object Methods, 83
- GetUnsuccessfullyConnectedItems
 - ComPrjconnector, 369
- GetUserManager
 - Application Methods, 30
- GetUsers
 - IntUserman, 633
- GetUserSettings
 - Application Methods, 30
- GetValue
 - ElmRes, 157
 - IntComtrade, 541
 - IntComtradeset, 547
 - IntDplmap, 552
 - ScnFreq, 664
 - ScnFrt, 666
 - ScnSpeed, 668
 - ScnSync, 670
 - ScnVar, 672
 - ScnVolt, 674
- GetValueAsDouble

- IntReport, 609
- GetValueAsInteger
 - IntReport, 609
- GetValueAsObject
 - IntReport, 610
- GetValueAsString
 - IntReport, 611
- GetValueFor
 - ComArcreport, 295
- GetVar
 - IntMon, 581
- GetVariable
 - ElmRes, 158
 - IntComtrade, 542
 - IntComtradeset, 548
 - ScnFreq, 664
 - ScnFrt, 666
 - ScnSpeed, 668
 - ScnSync, 670
 - ScnVar, 672
 - ScnVolt, 674
- GetVariation
 - IntSstage, 624
- GetVersions
 - IntPrj, 592
- GetViolatedElement
 - ScnFreq, 664
 - ScnFrt, 666
 - ScnSpeed, 668
 - ScnSync, 670
 - ScnVar, 672
 - ScnVolt, 674
- GetViolatedScanModules
 - ComSim, 387
- GetViolationTime
 - ScnFreq, 665
 - ScnFrt, 667
 - ScnSpeed, 669
 - ScnSync, 671
 - ScnVar, 673
 - ScnVolt, 675
- GetWorkingDir
 - File System Functions, 47
- GetWorkspaceDirectory
 - File System Functions, 47
- GetY0m
 - ElmLne, 127
- GetY1m
 - ElmLne, 128
- GetZ0m
 - ElmLne, 128
- GetZ0pu
 - ElmTr2, 183
 - ElmTr3, 187
 - ElmTr4, 191
- GetZ1m
 - ElmLne, 129
- GetZeroImpedance
 - General Object Methods, 84
- GetZeroSequenceHVLVT
 - TypTr2, 683
- GetZmatDist
 - ElmLne, 129
- GetZpu
 - ElmTr2, 183
 - ElmTr3, 187
 - ElmTr4, 192
 - ElmTrmult, 199
 - ElmVoltreg, 201
- GoToCell
 - ComTablereport, 420
- GrpPage, 522
 - ChangeStyle, 523
 - DoAutoScale, 523
 - DoAutoScaleX, 523
 - DoAutoScaleY, 523
 - GetOrInsertCurvePlot, 523
 - GetOrInsertPlot, 524
 - GetPlot, 525
 - RemovePage, 525
 - SetAutoScaleModeX, 525
 - SetAutoScaleModeY, 525
 - SetLayoutMode, 526
 - SetResults, 526
 - SetScaleTypeX, 526
 - SetScaleTypeY, 526
 - SetScaleX, 527
 - SetScaleY, 527
 - Show, 527
- HasAttribute
 - General Object Methods, 84
- HasCell
 - ComTablereport, 420
- HasColumnAutoFilter
 - ComTablereport, 420
- HasCreatedCalBus
 - ElmTerm, 177
- HasExternalReferences
 - IntPrj, 592
- HasGnrlMod
 - ElmBbone, 107
- HasParameter
 - CimModel, 509
 - CimObject, 517
- HasReferences
 - General Object Methods, 85
- HasResults
 - General Object Methods, 85
- HasResultsForDirectionalBackup
 - ComCoordreport, 318
- HasResultsForFuse

- ComCoordreport, 319
- HasResultsForInstantaneous
 - ComCoordreport, 319
- HasResultsForNonDirectionalBackup
 - ComCoordreport, 319
- HasResultsForOverload
 - ComCoordreport, 320
- HasResultsForOverreach
 - ComCoordreport, 320
- HasResultsForShortCircuit
 - ComCoordreport, 320
- HasResultsForZone
 - ComCoordreport, 321
- HasRoutes
 - ElmLne, 130
- HasRoutesOrSec
 - ElmLne, 130
- Hide
 - Application Methods, 31
- Import
 - IntDocument, 550
 - IntGrfgroup, 559
 - IntGrflayer, 565
 - IntIcon, 572
- ImportAndConvert
 - ComCimdbimp, 301
- ImportDz
 - Application Methods, 31
- ImportFromVec
 - IntGrflayer, 566
- ImportSnapshot
 - Application Methods, 31
- IndexOf
 - IntDplvec, 555
- Info
 - ElmStactrl, 162
- Init
 - ElmFsrc, 120
 - ElmRes, 158
 - IntMat, 576
 - IntVec, 633
- InitAllShortestPaths
 - ElmTerm, 177
- InitGroundingAreas
 - ComCheck, 300
- InitialiseWriting
 - ElmRes, 158
- InitQuickAccess
 - ComUcteexp, 451
- InitTmp
 - StaExtbrkmea, 213
 - StaExtcmdmea, 218
 - StaExtmdatmea, 223
 - StaExtfmea, 228
 - StaExtfuelmea, 233
 - StaExttimea, 238
 - StaExtpfmea, 244
 - StaExtpmea, 249
 - StaExtqmea, 254
 - StaExtsmea, 259
 - StaExttapmea, 265
 - StaExtv3mea, 270
 - StaExtvmea, 275
- Insert
 - IntDplmap, 553
 - IntDplvec, 555
- InsertPlot
 - SetVipage, 499
- InsertTemplate
 - ElmBranch, 110
 - IntGrfnet, 569
 - IntTemplate, 628
- IntAddonvars, 528
 - AddDouble, 528
 - AddDoubleMatrix, 528
 - AddDoubleVector, 529
 - AddInteger, 530
 - AddIntegerVector, 530
 - AddObject, 531
 - AddObjectVector, 531
 - AddString, 531
 - RemoveParameter, 532
 - RenameClass, 532
 - RenameParameter, 532
 - SetConstraint, 533
- IntCase, 534
 - Activate, 534
 - ApplyNetworkState, 534
 - ApplyStudyTime, 534
 - Consolidate, 535
 - CreateMissingSetTrigger, 535
 - Deactivate, 535
 - SetStudyTime, 536
- IntComtrade, 536
 - ConvertToASCIIFormat, 536
 - ConvertToBinaryFormat, 537
 - FindColumn, 537
 - FindMaxInColumn, 537
 - FindMinInColumn, 538
 - GetAnalogueDescriptions, 538
 - GetColumnValues, 538
 - GetDescription, 539
 - GetDigitalDescriptions, 539
 - GetNumberOfAnalogueSignalDescriptions, 539
 - GetNumberOfColumns, 539
 - GetNumberOfDigitalSignalDescriptions, 540
 - GetNumberOfRows, 540
 - GetObjectValue, 540
 - GetSignalHeader, 541
 - GetUnit, 541

- GetValue, 541
- GetVariable, 542
- Load, 542
- NCol, 539
- NRow, 540
- Release, 542
- SizeX, 540
- SizeY, 539
- SortAccordingToColumn, 542
- IntComtradeset, 543
 - FindColumn, 543
 - FindMaxInColumn, 543
 - FindMinInColumn, 544
 - GetAnalogueDescriptions, 544
 - GetColumnValues, 544
 - GetDescription, 545
 - GetDigitalDescriptions, 545
 - GetNumberOfAnalogueSignalDescriptions, 546
 - GetNumberOfColumns, 546
 - GetNumberOfDigitalSignalDescriptions, 546
 - GetNumberOfRows, 546
 - GetObjectValue, 546
 - GetSignalHeader, 547
 - GetUnit, 547
 - GetValue, 547
 - GetVariable, 548
 - Load, 548
 - NCol, 546
 - NRow, 546
 - Release, 548
 - SizeX, 546
 - SizeY, 546
 - SortAccordingToColumn, 548
- IntDataset, 549
 - AddRef, 549
 - All, 549
 - Clear, 549
 - GetAll, 549
- IntDocument, 550
 - Export, 550
 - Import, 550
 - Reset, 551
 - View, 551
- IntDplmap, 551
 - Clear, 551
 - Contains, 551
 - First, 552
 - GetValue, 552
 - Insert, 553
 - Next, 553
 - Remove, 553
 - Size, 554
 - Update, 554
- IntDplvec, 554
 - Clear, 554
- Get, 554
- IndexOf, 555
- Insert, 555
- Remove, 555
- Size, 556
- Sort, 556
- InterfaceUpdate
 - ElmDsl, 116
- IntEvt, 556
 - CreateCBEvents, 556
 - RemoveSwitchEvents, 557
- IntExtaccess, 557
 - CheckUrl, 557
- IntGate, 558
 - AddTrigger, 558
- IntGrf, 558
 - MoveToLayer, 558
 - Orthogonalise, 558
 - SnapToGrid, 559
- IntGrfgroup, 559
 - ClearData, 559
 - Export, 559
 - Import, 559
- IntGrflayer, 560
 - AdaptWidth, 560
 - AddAnnotationElement, 561
 - Align, 561
 - ChangeFont, 562
 - ChangeLayer, 562
 - ChangeRefPoints, 563
 - ChangeWidthVisibilityAndColour, 563
 - CheckAnnotationString, 564
 - ClearData, 564
 - Export, 564
 - ExportToVec, 565
 - GetAnnotationElement, 565
 - GetNumberOfAnnotationElements, 565
 - Import, 565
 - ImportFromVec, 566
 - Mark, 566
 - RemoveAnnotationElement, 566
 - Reset, 566
 - UpdateAnnotationElement, 567
- IntGrfnet, 569
 - Close, 569
 - InsertTemplate, 569
 - SetFontFor, 570
 - SetLayerVisibility, 571
 - SetSymbolComponentVisibility, 571
 - Show, 572
- IntIcon, 572
 - Export, 572
 - Import, 572
- IntLibrary, 573
 - Activate, 573
 - Deactivate, 573

- IntMat, 573
 - ColLbl, 574
 - Get, 574
 - GetColumnLabel, 574
 - GetColumnLabelIndex, 575
 - GetNumberOfColumns, 575
 - GetNumberOfRows, 575
 - GetRowLabel, 576
 - GetRowLabelIndex, 576
 - Init, 576
 - Invert, 577
 - Multiply, 577
 - NCol, 575
 - NRow, 575
 - Resize, 577
 - RowLbl, 576, 578
 - Save, 578
 - Set, 578
 - SetColumnLabel, 579
 - SetRowLabel, 579
 - SizeX, 575
 - SizeY, 575
 - SortToColum, 580
 - SortToColumn, 580
- IntMon, 580
 - AddVar, 580
 - AddVars, 581
 - ClearVars, 581
 - GetVar, 581
 - NVars, 581
 - PrintAllVal, 581
 - PrintVal, 582
 - RemoveVar, 582
- IntNdata, 582
 - CheckConsistency, 582
- IntNnet, 582
 - CheckConsistency, 582
- IntOutage, 583
 - Apply, 583
 - ApplyAll, 583
 - Check, 584
 - CheckAll, 584
 - IsInStudyTime, 584
 - IsInStudytime, 584
 - ResetAll, 585
- IntPlannedout, 585
 - SetRecurrence, 585
- IntPrj, 586
 - Activate, 586
 - AddProjectToCombined, 587
 - AddProjectToRemoteDatabase, 587
 - Archive, 587
 - BeginDataExtensionModification, 587
 - CanAddProjectToRemoteDatabase, 588
 - CanSubscribeProjectReadOnly, 588
 - CanSubscribeProjectReadWrite, 588
 - CopyDataExtensionFrom, 588
 - CopyProjectSettings, 589
 - CreateVersion, 589
 - Deactivate, 590
 - EndDataExtensionModification, 590
 - GetDerivedProjects, 590
 - GetExternalReferences, 591
 - GetGeoCoordinateSystem, 591
 - GetLatestVersion, 591
 - GetProjectDirectory, 592
 - GetVersions, 592
 - HasExternalReferences, 592
 - LoadCimData, 593
 - LoadData, 593
 - MergeToBaseProject, 593
 - NormaliseCombined, 594
 - PackExternalReferences, 594
 - Purge, 594
 - PurgeObjectKeys, 594
 - RemoveProjectFromCombined, 595
 - Restore, 595
 - SetGeoCoordinateSystem, 595
 - SubscribeProjectReadOnly, 596
 - SubscribeProjectReadWrite, 596
 - TransformGeoCoordinates, 596
 - TransformToGeographicCoordinateSystem, 596
 - UnsubscribeProject, 597
 - UpdateStatistics, 597
 - UpdateToDefaultStructure, 597
 - UpdateToMostRecentBaseVersion, 598
- IntPrjfolder, 598
 - GetProjectFolderType, 599
 - IsProjectFolderType, 600
- IntQlim, 600
 - GetQlim, 600
- IntRas, 601
 - AddEvent, 601
 - AddTrigger, 601
 - IsValid, 601
- IntReport, 602
 - AddObject, 602
 - AddObjects, 603
 - CreateField, 603
 - CreateTable, 604
 - GetFieldCount, 604
 - GetFieldDataType, 605
 - GetFieldName, 605
 - GetObjects, 606
 - GetParameterValueAsDouble, 606
 - GetParameterValueAsInteger, 607
 - GetParameterValueAsString, 607
 - GetRowCount, 608
 - GetTableCount, 608
 - GetTableName, 608
 - GetValueAsDouble, 609

- GetValueAsInteger, 609
 - GetValueAsObject, 610
 - GetValueAsString, 611
 - Reset, 612
 - SetDefaultValue, 612
 - SetValue, 613
- IntRunarrange, 614
 - GetSwitchStatus, 614
- IntScenario, 614
 - Activate, 614
 - Apply, 615
 - ApplySelective, 615
 - Deactivate, 616
 - DiscardChanges, 616
 - GetObjects, 616
 - GetOperationValue, 616
 - ReleaseMemory, 617
 - Save, 617
 - SetOperationValue, 617
- IntScsended, 618
 - Activate, 618
 - Deactivate, 618
 - DeleteRow, 618
 - GetScenario, 619
 - GetStartEndTime, 619
 - SearchScenario, 619
- IntScheme, 620
 - Activate, 620
 - Consolidate, 620
 - Deactivate, 620
 - GetActiveScheduler, 621
 - IsActive, 621
 - NewStage, 621
- IntSscheduler, 622
 - Activate, 622
 - Deactivate, 622
 - Update, 622
- IntSstage, 623
 - Activate, 623
 - ApplyChanges, 623
 - CreateStageObject, 623
 - EnableDiffMode, 624
 - GetScheme, 624
 - GetVariation, 624
 - IsExcluded, 624
 - PrintModifications, 625
 - ReadValue, 625
 - WriteValue, 625
- IntSubset, 626
 - Apply, 626
 - ApplySelective, 626
 - Clear, 627
 - GetConfiguration, 627
 - GetObjects, 627
- IntSym, 627
 - ConvertGeometriesToMDLString, 627
- IntTemplate, 628
 - InsertTemplate, 628
 - PackExternalReferences, 629
- IntThrating, 629
 - GetCriticalTimePhase, 629
 - GetRating, 629
 - Resize, 630
- IntUrl, 630
 - View, 630
- IntUser, 631
 - Purge, 631
 - SetPassword, 631
 - TerminateSession, 631
- IntUserman, 632
 - CreateGroup, 632
 - CreateUser, 632
 - GetGroups, 632
 - GetUsers, 633
 - UpdateGroups, 633
- IntVec, 633
 - Get, 633
 - Init, 633
 - Max, 634
 - Mean, 634
 - Min, 634
 - Resize, 634
 - Save, 634
 - Set, 635
 - Size, 635
 - Sort, 635
- IntVecobj, 636
 - Get, 636
 - Resize, 636
 - Save, 636
 - Search, 637
 - Set, 637
 - Size, 637
- IntVersion, 637
 - CreateDerivedProject, 638
 - GetDerivedProjects, 638
 - GetHistoricalProject, 638
 - Rollback, 638
- IntViewbookmark, 639
 - JumpTo, 639
 - UpdateFromCurrentView, 639
- Invert
 - IntMat, 577
- InvertMatrix
 - Mathematical Functions, 57
- IsAC
 - ComLdf, 353
- IsActive
 - IntScheme, 621
- IsAdditionalResultsFlagSetForCommand
 - ComTasks, 440
- IsAttributeModelInternal

- Application Methods, 31
- IsAutomaticCalculationResetEnabled
 - Environment Functions, 52
- IsBalanced
 - ComLdf, 353
- IsBreaker
 - ElmCoup, 113
- IsCable
 - ElmLne, 130
 - ElmLneSec, 131
 - TypLne, 679
- IsCalcRelevant
 - General Object Methods, 85
- IsClosed
 - ElmCoup, 113
 - ElmGndswt, 124
 - RelFuse, 660
 - SetTabgroup, 492
 - StaCubic, 212
 - StaSwitch, 280
- IsColumnScrollable
 - ComTablereport, 421
- IsColumnSortable
 - ComTablereport, 421
- IsCommandIgnored
 - ComTasks, 440
- IsConnected
 - ComStationware, 394
 - ElmGenstat, 123
 - ElmPvsys, 138
 - ElmSym, 170
 - StaCubic, 212
- IsDC
 - ComLdf, 353
- IsDeleted
 - General Object Methods, 86
- IsDguv
 - ComArcreport, 295
- IsEarthed
 - General Object Methods, 86
- IsElectrEquivalent
 - ElmTerm, 178
- IsEncrypted
 - ComDpl, 339
 - TypQdsl, 682
- IsEnergized
 - General Object Methods, 86
- IsEpri
 - ComArcreport, 296
- IsEquivalent
 - ElmTerm, 178
- IsExcluded
 - IntSstage, 624
- IsFinalEchoOnEnabled
 - Environment Functions, 52
- IsFrozen
 - SetDesktop, 468
- IsHidden
 - General Object Methods, 86
- IsInFeeder
 - General Object Methods, 87
- IsInMainWindow
 - SetTabgroup, 493
- IsInStudyTime
 - IntOutage, 584
- IsInStudytime
 - IntOutage, 584
- IsInternalNodeInStation
 - ElmTerm, 179
- IsLastIterationFeasible
 - ComTransfer, 448
- IsLdfValid
 - Application Methods, 32
- IsNAN
 - Application Methods, 32
- IsNetCoupling
 - ElmLne, 130
- IsNetworkDataFolder
 - General Object Methods, 87
- IsNode
 - General Object Methods, 88
- IsObjectActive
 - General Object Methods, 88
- IsObjectModifiedByVariation
 - General Object Methods, 88
- Isolate
 - General Object Methods, 89
- IsOpen
 - ElmCoup, 114
 - ElmGndswt, 125
 - RelFuse, 660
 - StaSwitch, 280
- IsOpened
 - SetDesktop, 468
- IsOutOfService
 - General Object Methods, 89
- IsPQ
 - ElmAsm, 102
- IsProjectFolderType
 - IntPrjfolder, 600
- IsQuadBooster
 - ElmTr2, 184
 - ElmTr3, 188
 - ElmTr4, 192
 - ElmTrmult, 199
- IsReducible
 - General Object Methods, 90
- IsRmsValid
 - Application Methods, 32
- IsRowVisible
 - ComTablereport, 422
- IsScenarioAttribute

- Application Methods, 32
- IsShcValid
 - Application Methods, 33
- IsShortCircuited
 - General Object Methods, 90
- IsSimValid
 - Application Methods, 33
- IsSplitting
 - ElmBoundary, 109
- IsStarted
 - ElmRelay, 142
- IsStatusBitSet
 - StaExtbrkmea, 214
 - StaExtcmdmea, 218
 - StaExtdatmea, 224
 - StaExtfmea, 228
 - StaExtfuelmea, 233
 - StaExtimea, 238
 - StaExtpfmea, 244
 - StaExtpmea, 249
 - StaExtqmea, 254
 - StaExtsmea, 259
 - StaExttapmea, 265
 - StaExtv3mea, 270
 - StaExtvmea, 276
- IsStatusBitSetTmp
 - StaExtbrkmea, 214
 - StaExtcmdmea, 219
 - StaExtdatmea, 224
 - StaExtfmea, 229
 - StaExtfuelmea, 234
 - StaExtimea, 239
 - StaExtpfmea, 244
 - StaExtpmea, 249
 - StaExtqmea, 255
 - StaExtsmea, 260
 - StaExttapmea, 265
 - StaExtv3mea, 271
 - StaExtvmea, 276
- IsStudyCaseIgnored
 - ComTasks, 441
- IsSubCurveVisible
 - PltOvercurrent, 652
- IsSwitchScheduledToOpen
 - ComShctrace, 386
- IsUserBreakPressed
 - Environment Functions, 52
- IsValid
 - IntRas, 601
- IsWriteCacheEnabled
 - Application Methods, 33
- JumpTo
 - IntViewbookmark, 639
- JumpToLastStep
 - ComContingency, 316
- LdfEquivalentVerification
 - ComRed, 373
- LicenceHasModule
 - Application Methods, 33
- Load
 - ElmRes, 159
 - IntComtrade, 542
 - IntComtradeset, 548
- LoadCimData
 - IntPrj, 593
- LoadData
 - IntPrj, 593
- LoadFile
 - ElmFile, 118
- LoadMicroSCADAFile
 - ComLink, 354
- LoadProfile
 - Application Methods, 35
- LoadSimulationState
 - ComSim, 387
- LoadSnapshot
 - ComSim, 387
- LossCostAtBusTech
 - ComCapo, 297
- Mark
 - IntGrflayer, 566
 - SetLevelvis, 476
- MarkInGraphics
 - Application Methods, 35
 - General Object Methods, 90
- MarkRegions
 - ComSimoutage, 392
- Mathematical Functions, 55
 - GetRandomNumber, 56
 - GetRandomNumberEx, 56
 - InvertMatrix, 57
 - RndExp, 57
 - RndGetMethod, 58
 - RndGetSeed, 58
 - RndNormal, 58
 - RndSetup, 59
 - RndUnifInt, 60
 - RndUnifReal, 60
 - RndWeibull, 60
 - SetRandomSeed, 61
- Max
 - IntVec, 634
- MaxZoneNumberFor
 - ComCoordreport, 321
- Mean
 - IntVec, 634
- MeasureLength
 - ElmLne, 130
- Merge
 - ComMerge, 360

- MergeToBaseProject
 - IntPrj, [593](#)
- MigrateAllProjects
 - Application Methods, [36](#)
- MigratePage
 - SetVipage, [499](#)
- Min
 - IntVec, [634](#)
- Module Functions, [2](#)
 - __version__, [2](#)
 - GetApplication, [2](#)
 - GetApplicationExt, [3](#)
- ModuleExists
 - ComAddon, [293](#)
- Move
 - General Object Methods, [91](#)
- MoveTab
 - SetTabgroup, [493](#)
- MoveTabs
 - SetTabgroup, [493](#)
- MoveTabToMainWindow
 - SetTabgroup, [494](#)
- MoveTabToNewFloatingGroup
 - SetTabgroup, [494](#)
- MoveToLayer
 - IntGrf, [558](#)
- MoveToMainWindow
 - SetTabgroup, [494](#)
- MoveToNewFloatingWindow
 - SetTabgroup, [494](#)
- Multiply
 - IntMat, [577](#)
- NCol
 - ComTablereport, [416](#)
 - ElmRes, [155](#)
 - IntComtrade, [539](#)
 - IntComtradeset, [546](#)
 - IntMat, [575](#)
- Network Elements Methods, [97](#)
- NewStage
 - IntScheme, [621](#)
- Next
 - IntDplmap, [553](#)
- NextRelayBranch
 - SetPath, [483](#)
- NextStepAvailable
 - ComShctrace, [386](#)
- NormaliseCombined
 - IntPrj, [594](#)
- NRow
 - ComTablereport, [416](#)
 - ElmRes, [155](#)
 - IntComtrade, [540](#)
 - IntComtradeset, [546](#)
 - IntMat, [575](#)
- NTap
 - ElmTr2, [184](#)
 - ElmTr3, [188](#)
 - ElmTr4, [192](#)
 - ElmTrmult, [200](#)
 - ElmVltreg, [202](#)
- NVars
 - IntMon, [581](#)
- Object Methods, [66](#)
- Open
 - ElmCou, [114](#)
 - ElmGndswt, [125](#)
 - RelFuse, [660](#)
 - StaSwitch, [280](#)
- OpenScriptInTab
 - SetDesktop, [469](#)
- OpenTextFileInTab
 - SetDesktop, [469](#)
- Orthogonalise
 - IntGrf, [558](#)
- Other Objects Methods, [502](#)
- Output Window Functions, [61](#)
 - ClearOutputWindow, [61](#)
 - FlushOutputWindow, [61](#)
 - GetOutputWindow, [62](#)
 - PrintError, [62](#)
 - PrintInfo, [62](#)
 - PrintPlain, [62](#)
 - PrintWarn, [62](#)
 - SetOutputWindowState, [63](#)
- Output Window Methods, [64](#)
 - Clear, [64](#)
 - Flush, [64](#)
 - GetContent, [64](#)
 - Print, [65](#)
 - Save, [65](#)
 - SetState, [65](#)
- OutputFlexibleData
 - Application Methods, [36](#)
- OverwriteRA
 - ElmSubstat, [166](#)
- OvlAlleviate
 - ComRel3, [375](#)
- Pack
 - BlkDef, [503](#)
 - TypMdl, [680](#)
- PackAsMacro
 - BlkDef, [504](#)
- PackExternalReferences
 - IntPrj, [594](#)
 - IntTemplate, [629](#)
- PartitionNetwork
 - ComCosim, [335](#)
 - ComInc, [351](#)

- PasteCopy
 - General Object Methods, 91
- PltAxis, 639
 - DoAutoScale, 639
 - SetFont, 639
- PltBiasdiff, 640
 - AddCurve, 640
 - AddCurves, 640
 - ClearCurves, 640
- PltComplexdata, 641
 - AddVector, 641
 - ChangeColourPalette, 641
 - ClearVectors, 641
- PltDataseries, 642
 - AddCurve, 642
 - AddXYCurve, 642
 - ChangeColourPalette, 643
 - ClearCurves, 643
 - GetDataSource, 643
 - GetIntCalcsres, 643
 - RemoveCurve, 644
 - SetLabelFont, 644
- PltImpedancex, 644
 - AddRelayCurve, 644
 - AddRelayCurves, 645
 - ClearRelayCurves, 645
- PltLegend, 645
 - SetFont, 645
- PltLinebarplot, 646
 - ChangeStyle, 646
 - DoAutoScale, 646
 - DoAutoScaleX, 647
 - DoAutoScaleY, 647
 - GetAxisX, 647
 - GetAxisY, 647
 - GetDataSeries, 647
 - GetDataSource, 648
 - GetLegend, 648
 - GetTitleObject, 648
 - SetAutoScaleModeX, 648
 - SetAutoScaleModeY, 649
 - SetAxisSharingLevelX, 649
 - SetAxisSharingLevelY, 649
 - SetScaleTypeX, 649
 - SetScaleTypeY, 650
 - SetScaleX, 650
 - SetScaleY, 650
- PltNetgraphic, 651
 - ChangeStyle, 651
- PltOvercurrent, 651
 - AddCurve, 651
 - AddCurves, 652
 - ClearCurves, 652
 - IsSubCurveVisible, 652
 - SetSubCurveVisible, 652
- PltPowerpq, 653
 - AddRelayCurve, 653
 - AddRelayCurves, 653
 - ClearRelayCurves, 654
- PltShcsweep, 654
 - AddCurve, 654
 - ClearCurves, 654
- PltTimedistance, 654
 - AddRelayCurve, 655
 - AddRelayCurves, 655
 - ClearRelayCurves, 655
- PltTitle, 655
 - SetFont, 655
- PltVectorplot, 656
 - ChangeStyle, 656
 - DoAutoScale, 656
 - GetAxisX, 657
 - GetAxisY, 657
 - GetComplexData, 657
 - GetLegend, 657
 - GetTitleObject, 657
 - SetAutoScaleModeX, 657
 - SetAutoScaleModeY, 658
 - SetScaleX, 658
 - SetScaleY, 658
- PostCommand
 - Application Methods, 36
- PrepForUntouchedDelete
 - Application Methods, 37
- Print
 - Output Window Methods, 65
 - SetScenario, 485
- PrintAllVal
 - IntMon, 581
- PrintCheckResults
 - ComLdf, 354
- PrintComparisonReport
 - ComMerge, 360
- PrintError
 - Output Window Functions, 62
- PrintFreqDepParams
 - ElmTow, 180
- PrintInfo
 - Output Window Functions, 62
- PrintModifications
 - ComMerge, 360
 - IntSstage, 625
- PrintPlain
 - Output Window Functions, 62
- PrintVal
 - IntMon, 582
- PrintWarn
 - Output Window Functions, 62
- Purge
 - IntPrj, 594
 - IntUser, 631
 - SetTboxconfig, 495

- PurgeObjectKeys
 - IntPrj, [594](#)
- PurgeUnusedObjects
 - General Object Methods, [92](#)
- QuickAccessAvailable
 - ComUcteexp, [451](#)
- ReadValue
 - IntSstage, [625](#)
- Rebuild
 - Application Methods, [37](#)
- ReceiveData
 - ComLink, [355](#)
 - ComOpc, [365](#)
- Reconnect
 - ElmGenstat, [123](#)
 - ElmPvsys, [138](#)
 - ElmSym, [170](#)
 - ElmXnet, [204](#)
- ReductionInMemory
 - ComRed, [374](#)
- RelChar, [659](#)
 - SetCurve, [659](#)
- Release
 - ElmRes, [159](#)
 - IntComtrade, [542](#)
 - IntComtradeset, [548](#)
- ReleaseMemory
 - IntScenario, [617](#)
- RelFuse, [659](#)
 - Close, [659](#)
 - GetOperatedSwitches, [659](#)
 - IsClosed, [660](#)
 - IsOpen, [660](#)
 - Open, [660](#)
- RelLogdip, [661](#)
 - GetOperatedSwitches, [661](#)
- RelLogic, [661](#)
 - GetOperatedSwitches, [661](#)
- ReloadProfile
 - Application Methods, [37](#)
- RelToc, [662](#)
 - SetCurve, [662](#)
- RelZpol, [662](#)
 - AssumeCompensationFactor, [662](#)
 - AssumeReRI, [662](#)
 - AssumeXeXI, [663](#)
- Remove
 - IntDplmap, [553](#)
 - IntDplvec, [555](#)
- RemoveAllConfigurations
 - SetDataext, [462](#)
- RemoveAllRas
 - ComSimoutage, [392](#)
- RemoveAnnotationElement
 - IntGrflayer, [566](#)
- RemoveCmdsForStudyCaseRow
 - ComTasks, [441](#)
- RemoveCommand
 - ComTasks, [441](#)
- RemoveConfiguration
 - SetDataext, [463](#)
- RemoveContingencies
 - ComSimoutage, [392](#)
- RemoveCurve
 - PltDataseries, [644](#)
- RemoveEvents
 - ComContingency, [317](#)
 - ComOutage, [367](#)
 - ComRel3, [375](#)
- RemoveOutages
 - ComRel3, [375](#)
- RemovePage
 - GrpPage, [525](#)
 - SetDesktop, [470](#)
- RemoveParameter
 - CimModel, [510](#)
 - CimObject, [518](#)
 - IntAddonvars, [532](#)
- RemoveProjectFromCombined
 - IntPrj, [595](#)
- RemoveRas
 - ComSimoutage, [392](#)
- RemoveRatio
 - TypCtcore, [678](#)
- RemoveRatioByIndex
 - TypCtcore, [679](#)
- RemoveRow
 - ComTablereport, [422](#)
- RemoveStudyCase
 - ComTasks, [442](#)
- RemoveStudyCases
 - ComTasks, [442](#)
 - ComTececocmp, [447](#)
- RemoveSwitchEvents
 - IntEvt, [557](#)
- RemoveVar
 - IntMon, [582](#)
- RenameClass
 - IntAddonvars, [532](#)
- RenameParameter
 - IntAddonvars, [532](#)
- Report
 - ComDllmanager, [336](#)
- ReportUnusedObjects
 - General Object Methods, [92](#)
- Reset
 - ComMerge, [361](#)
 - ComSimoutage, [392](#)
 - IntDocument, [551](#)
 - IntGrflayer, [566](#)

- IntReport, 612
- SetLevelvis, 476
- ResetAll
 - IntOutage, 585
- ResetCalculation
 - Application Methods, 37
- ResetDerating
 - ElmGenstat, 123
 - ElmPvsys, 138
 - ElmSym, 171
- ResetQuickAccess
 - ComUcteexp, 451
- ResetRA
 - ElmSubstat, 166
- ResetReductionInMemory
 - ComRed, 374
- ResetStatusBit
 - StaExtbrkmea, 214
 - StaExtcmdmea, 219
 - StaExtdatmea, 224
 - StaExtfmea, 229
 - StaExtfuelmea, 234
 - StaExtimea, 239
 - StaExtpfmea, 244
 - StaExtpmea, 249
 - StaExtqmea, 255
 - StaExtsmea, 260
 - StaExttapmea, 265
 - StaExtv3mea, 271
 - StaExtvmea, 276
- ResetStatusBitTmp
 - StaExtbrkmea, 214
 - StaExtcmdmea, 219
 - StaExtdatmea, 224
 - StaExtfmea, 229
 - StaExtfuelmea, 234
 - StaExtimea, 239
 - StaExtpfmea, 245
 - StaExtpmea, 250
 - StaExtqmea, 255
 - StaExtsmea, 260
 - StaExttapmea, 266
 - StaExtv3mea, 271
 - StaExtvmea, 276
- ResetThirdPartyModule
 - BlkDef, 504
 - ComDpl, 340
 - TypQdsl, 682
- ResGetData
 - Application Methods, 37
- ResGetDescription
 - Application Methods, 38
- ResGetFirstValidObject
 - Application Methods, 38
- ResGetFirstValidObjectVariable
 - Application Methods, 38
- ResGetFirstValidVariable
 - Application Methods, 38
- ResGetIndex
 - Application Methods, 38
- ResGetMax
 - Application Methods, 39
- ResGetMin
 - Application Methods, 39
- ResGetNextValidObject
 - Application Methods, 39
- ResGetNextValidObjectVariable
 - Application Methods, 39
- ResGetNextValidVariable
 - Application Methods, 39
- ResGetObject
 - Application Methods, 39
- ResGetUnit
 - Application Methods, 40
- ResGetValueCount
 - Application Methods, 40
- ResGetVariable
 - Application Methods, 40
- ResGetVariableCount
 - Application Methods, 40
- Resize
 - ElmBoundary, 109
 - IntMat, 577
 - IntThrating, 630
 - IntVec, 634
 - IntVecobj, 636
- ResLoadData
 - Application Methods, 40
- ResReleaseData
 - Application Methods, 40
- ResSortToVariable
 - Application Methods, 40
- Restore
 - IntPrj, 595
- ResultForDirectionalBackupVariable
 - ComCoordreport, 321
- ResultForFuseVariable
 - ComCoordreport, 322
- ResultForInstantaneousVariable
 - ComCoordreport, 323
- ResultForMaxCurrent
 - ComCoordreport, 323
- ResultForNonDirectionalBackupVariable
 - ComCoordreport, 324
- ResultForOverloadVariable
 - ComCoordreport, 325
- ResultForOverreachVariable
 - ComCoordreport, 325
- ResultForShortCircuitVariable
 - ComCoordreport, 326
- ResultForZoneVariable
 - ComCoordreport, 327

- RndExp
 - Mathematical Functions, 57
- RndGetMethod
 - Mathematical Functions, 58
- RndGetSeed
 - Mathematical Functions, 58
- RndNormal
 - Mathematical Functions, 58
- RndSetup
 - Mathematical Functions, 59
- RndUnifInt
 - Mathematical Functions, 60
- RndUnifReal
 - Mathematical Functions, 60
- RndWeibull
 - Mathematical Functions, 60
- Rollback
 - IntVersion, 638
- RowLbl
 - IntMat, 576, 578
- Save
 - IntMat, 578
 - IntScenario, 617
 - IntVec, 634
 - IntVecobj, 636
 - Output Window Methods, 65
- SaveAsRA
 - ElmSubstat, 166
- SaveAsScenario
 - Application Methods, 41
- SaveAsSwSc
 - ElmSubstat, 166
 - ElmTrfstat, 196
- SaveFile
 - ElmFile, 119
- SaveSimulationState
 - ComSim, 388
- SaveSnapshot
 - ComSim, 388
- ScnFreq, 663
 - GetLimit, 663
 - GetNumberOfViolations, 663
 - GetRecoveryTime, 664
 - GetValue, 664
 - GetVariable, 664
 - GetViolatedElement, 664
 - GetViolationTime, 665
- ScnFrt, 665
 - GetLimit, 665
 - GetNumberOfViolations, 665
 - GetRecoveryTime, 666
 - GetValue, 666
 - GetVariable, 666
 - GetViolatedElement, 666
 - GetViolationTime, 667
- ScnSpeed, 667
 - GetLimit, 667
 - GetNumberOfViolations, 667
 - GetRecoveryTime, 668
 - GetValue, 668
 - GetVariable, 668
 - GetViolatedElement, 668
 - GetViolationTime, 669
- ScnSync, 669
 - GetLimit, 669
 - GetNumberOfViolations, 669
 - GetRecoveryTime, 670
 - GetValue, 670
 - GetVariable, 670
 - GetViolatedElement, 670
 - GetViolationTime, 671
- ScnVar, 671
 - GetLimit, 671
 - GetNumberOfViolations, 671
 - GetRecoveryTime, 672
 - GetValue, 672
 - GetVariable, 672
 - GetViolatedElement, 672
 - GetViolationTime, 673
- ScnVolt, 673
 - GetLimit, 673
 - GetNumberOfViolations, 673
 - GetRecoveryTime, 674
 - GetValue, 674
 - GetVariable, 674
 - GetViolatedElement, 674
 - GetViolationTime, 675
- Search
 - IntVecobj, 637
- SearchObject
 - General Object Methods, 92
- SearchObjectByForeignKey
 - Application Methods, 41
- SearchObjectsByCimId
 - Application Methods, 41
- SearchScenario
 - IntScensched, 619
- SelectToolbox
 - Application Methods, 42
- SendData
 - ComLink, 355
 - ComOpc, 366
- SentDataStatus
 - ComLink, 355
- Set
 - IntMat, 578
 - IntVec, 635
 - IntVecobj, 637
- SetActiveModule
 - ComAddon, 294
- SetAdaptX

- SetDesktop, 470
- SetVipage, 500
- VisPath, 684
- SetAdaptY
 - VisPath, 684
- SetAdditionalResultsFlagForCommand
 - ComTasks, 443
- SetAmpl
 - ElmFsrc, 120
- SetAsDefault
 - ElmRes, 159
- SetAssociationValue
 - CimModel, 510, 511
 - CimObject, 518, 519
- SetAttribute
 - General Object Methods, 93
- SetAttributeEnumeration
 - CimModel, 511, 512
 - CimObject, 519, 520
- SetAttributeInRootAndStageObjects
 - Application Methods, 42
 - General Object Methods, 93
- SetAttributeLength
 - General Object Methods, 93
- SetAttributeModelInternal
 - Application Methods, 42
- SetAttributes
 - General Object Methods, 94
- SetAttributeShape
 - General Object Methods, 94
- SetAttributeValue
 - CimModel, 512, 513
 - CimObject, 521, 522
- SetAuthorityUri
 - ComGridtocim, 347
- SetAutoAssignmentForAll
 - ComMerge, 361
- SetAutomaticCalculationResetEnabled
 - Environment Functions, 53
- SetAutoScaleModeX
 - GrpPage, 525
 - PltLinebarplot, 648
 - PltVectorplot, 657
- SetAutoScaleModeY
 - GrpPage, 525
 - PltLinebarplot, 649
 - PltVectorplot, 658
- SetAutoScaleX
 - SetDesktop, 470
 - SetVipage, 500
- SetAxisSharingLevelX
 - PltLinebarplot, 649
- SetAxisSharingLevelY
 - PltLinebarplot, 649
- SetBarLimits
 - ComTablereport, 423
- SetBatchMode
 - ComUcte, 448
- SetBoundaries
 - ComGridtocim, 347
- SetCellAccess
 - ComTablereport, 423
- SetCellAlignment
 - ComTablereport, 423
- SetCellBackgroundColor
 - ComTablereport, 424
- SetCellColor
 - ComTablereport, 424
- SetCellEdit
 - ComTablereport, 425
- SetCellFontStyle
 - ComTablereport, 425
- SetCellFormat
 - ComTablereport, 426
- SetCellStyle
 - ComTablereport, 426
- SetCellValueToBar
 - ComTablereport, 427
- SetCellValueToCheckbox
 - ComTablereport, 428
- SetCellValueToDate
 - ComTablereport, 429
- SetCellValueToDouble
 - ComTablereport, 430
- SetCellValueToInt
 - ComTablereport, 431
- SetCellValueToObject
 - ComTablereport, 432
- SetCellValueToString
 - ComTablereport, 433
- SetCluster, 453
 - CalcCluster, 453
 - GetNumberOfClusters, 454
- SetColouring
 - SetColscheme, 455
- SetColscheme, 454
 - GetAlarmColouringMode, 454
 - GetColouringMode, 454
 - GetEnergisingColouringMode, 455
 - SetColouring, 455
 - SetFilter, 459
- SetColumnHeader
 - ComTablereport, 434
- SetColumnLabel
 - IntMat, 579
- SetConstraint
 - IntAddonvars, 533
- SetCurve
 - RelChar, 659
 - RelToc, 662
- SetDatabase, 461
 - EmptyCache, 461

- SetDataext, 461
 - AddConfiguration, 461
 - GetConfiguration, 462
 - GetConfigurations, 462
 - RemoveAllConfigurations, 462
 - RemoveConfiguration, 463
- SetDefaultValue
 - IntReport, 612
- SetDeskpage, 463
 - Close, 463
 - Show, 463
- SetDesktop, 464
 - AddPage, 464
 - BeginTabGroup, 464
 - Close, 465
 - CloseAllTemporaryTabs, 465
 - DoAutoScaleX, 465
 - EndTabGroup, 465
 - ExportGraphicTab, 466
 - Freeze, 466
 - GetActivePage, 466
 - GetCanvasSize, 466
 - GetPage, 467
 - GetSplitOrientation, 467
 - GetTabGroups, 468
 - IsFrozen, 468
 - IsOpened, 468
 - OpenScriptInTab, 469
 - OpenTextFileInTab, 469
 - RemovePage, 470
 - SetAdaptX, 470
 - SetAutoScaleX, 470
 - SetResults, 471
 - SetScaleX, 471
 - SetSplitOrientation, 471
 - SetViewArea, 472
 - SetXVar, 472
 - Show, 472
 - Unfreeze, 472
 - WriteWMF, 473
 - ZoomAll, 473
- SetDetailed
 - ElmLne, 131
- SetDialogSize
 - ComTablereport, 435
- SetDisplayedButtons
 - SetTboxconfig, 496
- SetDistrstate, 473
 - CalcCluster, 473
- SetElms
 - StoMaint, 675
- SetEnableUserBreak
 - Environment Functions, 55
- SetExportHtml
 - ComTablereport, 435
- SetExportXls
 - ComTablereport, 435
- SetExternalObject
 - ComDpl, 340
 - ComPython, 372
- SetFileName
 - ComSvgexport, 394
 - ComSvgimport, 395
- SetFilt, 474
 - Get, 474
- SetFilter
 - SetColscheme, 459
- SetFinalEchoOnEnabled
 - Environment Functions, 53
- SetFont
 - PltAxis, 639
 - PltLegend, 645
 - PltTitle, 655
- SetFontFor
 - IntGrfnet, 570
 - SetPrj, 484
- SetGeoCoordinateSystem
 - IntPrj, 595
- SetGraphicUpdate
 - Environment Functions, 53
- SetGridSelection
 - ComUctexp, 452
- SetGridsToExport
 - ComGridtocim, 348
- SetGuiUpdateEnabled
 - Environment Functions, 54
- SetIgnoreFlagForCommand
 - ComTasks, 443
- SetIgnoreFlagForStudyCase
 - ComTasks, 444
- SetImpedance
 - ElmRelay, 142
- SetInputParameterDouble
 - ComDpl, 340
 - ComPython, 372
- SetInputParameterInt
 - ComDpl, 341
 - ComPython, 372
- SetInputParameterString
 - ComDpl, 341
 - ComPython, 373
- SetInterfaceVersion
 - Application Methods, 43
- SetLabelFont
 - PltDataseries, 644
- SetLayerVisibility
 - IntGrfnet, 571
- SetLayoutMode
 - GrpPage, 526
- SetLevelvis, 474
 - AdaptWidth, 474
 - Align, 474

- ChangeFont, 475
- ChangeLayer, 475
- ChangeRefPoints, 475
- ChangeWidthVisibilityAndColour, 476
- CreateLayer, 476
- Mark, 476
- Reset, 476
- SetLimits
 - ComSimoutage, 393
- SetListFilterSelection
 - ComTablereport, 436
- SetLoadScaleAbsolute
 - ElmZone, 207
- SetLvscale, 477
 - AddCalcRelevantCoincidenceDefinitions, 477
- SetMaxl
 - ElmRelay, 143
- SetMaxlearth
 - ElmRelay, 143
- SetMeaValue
 - StaExtbrkmea, 214
 - StaExtcmdmea, 219
 - StaExtdatmea, 224
 - StaExtfmea, 229
 - StaExtfuelmea, 234
 - StaExttimea, 239
 - StaExtpfmea, 245
 - StaExtpmea, 250
 - StaExtqmea, 255
 - StaExttapmea, 266
 - StaExtv3mea, 271
 - StaExtvmea, 277
- SetMinl
 - ElmRelay, 143
- SetMinlearth
 - ElmRelay, 143
- SetNumSlave
 - SetParalman, 477
- SetObj
 - ElmRes, 159
- SetObject
 - ComSvgexport, 394
 - ComSvgimport, 395
- SetObjects
 - ComSvgexport, 395
- SetObjectsToCompare
 - ComMerge, 361
- SetObjs
 - ComOutage, 367
- SetOldDistributeLoadMode
 - ComLdf, 354
- SetOPCReceiveQuality
 - ComLink, 355
- SetOperationValue
 - IntScenario, 617
- SetOutOfService
 - ElmRelay, 143
- SetOutputWindowState
 - Output Window Functions, 63
- SetParalman, 477
 - GetNumSlave, 477
 - SetNumSlave, 477
 - SetTransfType, 478
- SetParameter
 - ComReport, 379
- SetPassword
 - IntUser, 631
- SetPath, 478
 - AllBreakers, 478
 - AllClosedBreakers, 479
 - AllOpenBreakers, 479
 - AllProtectionDevices, 479
 - Create, 479
 - CreateTimeOvercurrentPlot, 480
 - GetAbsDistance, 480
 - GetAll, 480
 - GetBranches, 481
 - GetBuses, 481
 - GetImpedanceAtPos, 481
 - GetNode, 482
 - GetPathFolder, 482
 - GetRelay, 482
 - NextRelayBranch, 483
- SetPhase
 - ElmFsrc, 120
- SetPosition
 - ElmTrain, 193
- SetPrimaryCtTap
 - StaCombi, 208
- SetPrimaryTap
 - StaCt, 209
 - StaVt, 281
- SetPrimaryVtTap
 - StaCombi, 208
- SetPrj, 483
 - GetFontID, 483
 - SetFontFor, 484
- SetProgressBarUpdatesEnabled
 - Environment Functions, 54
- SetRA
 - ElmSubstat, 167
- SetRandomSeed
 - Mathematical Functions, 61
- SetRecurrence
 - IntPlannedout, 585
- SetRefresh
 - ComTablereport, 436
- SetRescheduleFlag
 - Environment Functions, 54
- SetResults
 - GrpPage, 526
 - SetDesktop, 471

- SetVipage, 500
- SetResultsFolder
 - ComTasks, 444
- SetRowLabel
 - IntMat, 579
- SetScaleTypeX
 - GrpPage, 526
 - PltLinebarplot, 649
- SetScaleTypeY
 - GrpPage, 526
 - PltLinebarplot, 650
- SetScaleX
 - GrpPage, 527
 - PltLinebarplot, 650
 - PltVectorplot, 658
 - SetDesktop, 471
 - SetVipage, 501
 - VisPath, 685
- SetScaleY
 - GrpPage, 527
 - PltLinebarplot, 650
 - PltVectorplot, 658
 - VisPath, 685
- SetScenario, 485
 - Check, 485
 - Default, 485
 - Print, 485
- SetSelect, 486
 - AddRef, 486
 - All, 486
 - AllAsm, 486
 - AllBars, 487
 - AllBreakers, 487
 - AllClosedBreakers, 487
 - AllElm, 487
 - AllLines, 487
 - AllLoads, 487
 - AllOpenBreakers, 488
 - AllSym, 488
 - AllTypLne, 488
 - Clear, 488
 - GetAll, 488
- SetShowAllUsers
 - Application Methods, 43
- SetSorting
 - ComTablereport, 436
- SetSplitOrientation
 - SetDesktop, 471
- SetState
 - Output Window Methods, 65
- SetStatus
 - StaExtbrkmea, 215
 - StaExtcmdmea, 220
 - StaExtdatmea, 225
 - StaExtfmea, 230
 - StaExtfuelmea, 235
- StaExtimea, 240
- StaExtpfmea, 245
- StaExtpmea, 251
- StaExtqmea, 256
- StaExtsmea, 260
- StaExttapmea, 266
- StaExtv3mea, 272
- StaExtvmea, 277
- SetStatusBit
 - StaExtbrkmea, 215
 - StaExtcmdmea, 220
 - StaExtdatmea, 225
 - StaExtfmea, 230
 - StaExtfuelmea, 235
 - StaExtimea, 241
 - StaExtpfmea, 246
 - StaExtpmea, 251
 - StaExtqmea, 257
 - StaExtsmea, 261
 - StaExttapmea, 267
 - StaExtv3mea, 272
 - StaExtvmea, 278
- SetStatusBitTmp
 - StaExtbrkmea, 216
 - StaExtcmdmea, 221
 - StaExtdatmea, 226
 - StaExtfmea, 231
 - StaExtfuelmea, 236
 - StaExtimea, 241
 - StaExtpfmea, 246
 - StaExtpmea, 252
 - StaExtqmea, 257
 - StaExtsmea, 261
 - StaExttapmea, 267
 - StaExtv3mea, 273
 - StaExtvmea, 278
- SetStatusText
 - ComTablereport, 437
- SetStatusTmp
 - StaExtbrkmea, 216
 - StaExtcmdmea, 221
 - StaExtdatmea, 226
 - StaExtfmea, 231
 - StaExtfuelmea, 236
 - StaExtimea, 241
 - StaExtpfmea, 246
 - StaExtpmea, 252
 - StaExtqmea, 257
 - StaExtsmea, 262
 - StaExttapmea, 268
 - StaExtv3mea, 273
 - StaExtvmea, 278
- SetStudyTime
 - IntCase, 536
- SetStyle
 - SetVipage, 501

- SetSubCurveVisible
 - PltOvercurrent, 652
- SetSubElmResKey
 - ElmRes, 160
- SetSwitchShcEventMode
 - ComLink, 356
- SetSymbolComponentVisibility
 - IntGrfnet, 571
- SetTabgroup, 489
 - Activate, 489
 - Close, 489
 - CloseTab, 489
 - ExportAllReportDocuments, 490
 - ExportAllTableReports, 490
 - GetTabCount, 491
 - GetTabObject, 491
 - GetTabTitle, 492
 - GetTabType, 492
 - IsClosed, 492
 - IsInMainWindow, 493
 - MoveTab, 493
 - MoveTabs, 493
 - MoveTabToMainWindow, 494
 - MoveTabToNewFloatingGroup, 494
 - MoveToMainWindow, 494
 - MoveToNewFloatingWindow, 494
- SetTboxconfig, 495
 - Check, 495
 - GetAvailableButtons, 495
 - GetDisplayedButtons, 495
 - Purge, 495
 - SetDisplayedButtons, 496
- SetThirdPartyModule
 - BlkDef, 504
 - ComDpl, 341
 - TypQdsl, 682
- SetTile
 - SetVipage, 501
- SetTime, 496
 - Date, 496
 - GetTimeUTC, 496
 - SetTime, 497
 - SetTimeUTC, 497
 - Time, 497
- SetTime
 - ElmRelay, 144
 - SetTime, 497
- SetTimeUTC
 - SetTime, 497
- Settings Methods, 453
- SetTitle
 - ComTablereport, 437
- SetTransfType
 - SetParalman, 478
- SetUser, 497
 - GetNumProcesses, 498
- SetUserBreakEnabled
 - Environment Functions, 55
- SetUserDefined
 - VisValue, 688
- SetValue
 - IntReport, 613
- SetVariationRecordingMode
 - Application Methods, 43
- SetViewArea
 - SetDesktop, 472
- SetVipage, 498
 - Close, 498
 - CreateVI, 499
 - DoAutoScaleX, 498
 - DoAutoScaleY, 498
 - GetOrInsertPlot, 499
 - InsertPlot, 499
 - MigratePage, 499
 - SetAdaptX, 500
 - SetAutoScaleX, 500
 - SetResults, 500
 - SetScaleX, 501
 - SetStyle, 501
 - SetTile, 501
 - SetXVar, 501
 - Show, 502
- SetWriteCacheEnabled
 - Application Methods, 44
- SetXVar
 - SetDesktop, 472
 - SetVipage, 501
- Show
 - Application Methods, 44
 - GrpPage, 527
 - IntGrfnet, 572
 - SetDeskpage, 463
 - SetDesktop, 472
 - SetVipage, 502
- ShowBrowser
 - ComMerge, 361
- ShowEditDialog
 - General Object Methods, 94
- ShowModalBrowser
 - Dialogue Boxes Functions, 49
- ShowModalSelectBrowser
 - Dialogue Boxes Functions, 49
- ShowModalSelectTree
 - General Object Methods, 95
- ShowModelessBrowser
 - Dialogue Boxes Functions, 50
- SimEquivalentVerification
 - ComRed, 374
- Size
 - IntDplmap, 554
 - IntDplvec, 556
 - IntVec, 635

- IntVecobj, 637
- SizeX
 - ComTablereport, 416
 - ElmRes, 155
 - IntComtrade, 540
 - IntComtradeset, 546
 - IntMat, 575
- SizeY
 - ComTablereport, 416
 - ElmRes, 155
 - IntComtrade, 539
 - IntComtradeset, 546
 - IntMat, 575
- slotupd
 - ElmComp, 112
 - ElmRelay, 145
- SlotUpdate
 - ElmComp, 112
 - ElmRelay, 145
- SnapToGrid
 - IntGrf, 559
- Sort
 - IntDplvec, 556
 - IntVec, 635
- SortAccordingToColumn
 - ElmRes, 160
 - IntComtrade, 542
 - IntComtradeset, 548
- SortToColum
 - IntMat, 580
- SortToColumn
 - IntMat, 580
- SplitLine
 - Application Methods, 44
- StaCombi, 208
 - SetPrimaryCtTap, 208
 - SetPrimaryVtTap, 208
- StaCt, 208
 - SetPrimaryTap, 209
- StaCubic, 209
 - GetAll, 209
 - GetBranch, 210
 - GetConnectedMajorNodes, 210
 - GetConnections, 210
 - GetNearestBusbars, 211
 - GetPathToNearestBusbar, 211
 - IsClosed, 212
 - IsConnected, 212
- StaExtbrkmea, 212
 - CopyExtMeaStatusToStatusTmp, 213
 - GetMeaValue, 213
 - GetStatus, 213
 - GetStatusTmp, 213
 - InitTmp, 213
 - IsStatusBitSet, 214
 - IsStatusBitSetTmp, 214
 - ResetStatusBit, 214
 - ResetStatusBitTmp, 214
 - SetMeaValue, 214
 - SetStatus, 215
 - SetStatusBit, 215
 - SetStatusBitTmp, 216
 - SetStatusTmp, 216
 - UpdateControl, 216
 - UpdateCtrl, 217
- StaExtcmdmea, 217
 - CopyExtMeaStatusToStatusTmp, 217
 - CreateEvent, 217
 - GetMeaValue, 218
 - GetStatus, 218
 - GetStatusTmp, 218
 - InitTmp, 218
 - IsStatusBitSet, 218
 - IsStatusBitSetTmp, 219
 - ResetStatusBit, 219
 - ResetStatusBitTmp, 219
 - SetMeaValue, 219
 - SetStatus, 220
 - SetStatusBit, 220
 - SetStatusBitTmp, 221
 - SetStatusTmp, 221
 - UpdateControl, 221
 - UpdateCtrl, 222
- StaExtmdatmea, 222
 - CopyExtMeaStatusToStatusTmp, 222
 - CreateEvent, 222
 - GetMeaValue, 223
 - GetStatus, 223
 - GetStatusTmp, 223
 - InitTmp, 223
 - IsStatusBitSet, 224
 - IsStatusBitSetTmp, 224
 - ResetStatusBit, 224
 - ResetStatusBitTmp, 224
 - SetMeaValue, 224
 - SetStatus, 225
 - SetStatusBit, 225
 - SetStatusBitTmp, 226
 - SetStatusTmp, 226
 - UpdateControl, 226
 - UpdateCtrl, 227
- StaExtfmea, 227
 - CopyExtMeaStatusToStatusTmp, 227
 - GetMeaValue, 227
 - GetStatus, 228
 - GetStatusTmp, 228
 - InitTmp, 228
 - IsStatusBitSet, 228
 - IsStatusBitSetTmp, 229
 - ResetStatusBit, 229
 - ResetStatusBitTmp, 229
 - SetMeaValue, 229

- SetStatus, 230
- SetStatusBit, 230
- SetStatusBitTmp, 231
- SetStatusTmp, 231
- UpdateControl, 231
- UpdateCtrl, 231
- StaExtfuelmea, 232
 - CopyExtMeaStatusToStatusTmp, 232
 - GetMeaValue, 232
 - GetStatus, 233
 - GetStatusTmp, 233
 - InitTmp, 233
 - IsStatusBitSet, 233
 - IsStatusBitSetTmp, 234
 - ResetStatusBit, 234
 - ResetStatusBitTmp, 234
 - SetMeaValue, 234
 - SetStatus, 235
 - SetStatusBit, 235
 - SetStatusBitTmp, 236
 - SetStatusTmp, 236
 - UpdateControl, 236
 - UpdateCtrl, 236
- StaExtimea, 237
 - CopyExtMeaStatusToStatusTmp, 237
 - GetMeaValue, 237
 - GetStatus, 238
 - GetStatusTmp, 238
 - InitTmp, 238
 - IsStatusBitSet, 238
 - IsStatusBitSetTmp, 239
 - ResetStatusBit, 239
 - ResetStatusBitTmp, 239
 - SetMeaValue, 239
 - SetStatus, 240
 - SetStatusBit, 241
 - SetStatusBitTmp, 241
 - SetStatusTmp, 241
 - UpdateControl, 241
 - UpdateCtrl, 242
- StaExtpfmea, 242
 - CopyExtMeaStatusToStatusTmp, 243
 - GetMeaValue, 243
 - GetStatus, 243
 - GetStatusTmp, 243
 - InitTmp, 244
 - IsStatusBitSet, 244
 - IsStatusBitSetTmp, 244
 - ResetStatusBit, 244
 - ResetStatusBitTmp, 245
 - SetMeaValue, 245
 - SetStatus, 245
 - SetStatusBit, 246
 - SetStatusBitTmp, 246
 - SetStatusTmp, 246
 - UpdateControl, 247
- UpdateCtrl, 247
- StaExtpmea, 247
 - CopyExtMeaStatusToStatusTmp, 248
 - GetMeaValue, 248
 - GetStatus, 248
 - GetStatusTmp, 249
 - InitTmp, 249
 - IsStatusBitSet, 249
 - IsStatusBitSetTmp, 249
 - ResetStatusBit, 249
 - ResetStatusBitTmp, 250
 - SetMeaValue, 250
 - SetStatus, 251
 - SetStatusBit, 251
 - SetStatusBitTmp, 252
 - SetStatusTmp, 252
 - UpdateControl, 252
 - UpdateCtrl, 252
- StaExtqmea, 253
 - CopyExtMeaStatusToStatusTmp, 253
 - GetMeaValue, 253
 - GetStatus, 254
 - GetStatusTmp, 254
 - InitTmp, 254
 - IsStatusBitSet, 254
 - IsStatusBitSetTmp, 255
 - ResetStatusBit, 255
 - ResetStatusBitTmp, 255
 - SetMeaValue, 255
 - SetStatus, 256
 - SetStatusBit, 257
 - SetStatusBitTmp, 257
 - SetStatusTmp, 257
 - UpdateControl, 258
 - UpdateCtrl, 258
- StaExtsmea, 258
 - CopyExtMeaStatusToStatusTmp, 259
 - GetStatus, 259
 - GetStatusTmp, 259
 - InitTmp, 259
 - IsStatusBitSet, 259
 - IsStatusBitSetTmp, 260
 - ResetStatusBit, 260
 - ResetStatusBitTmp, 260
 - SetStatus, 260
 - SetStatusBit, 261
 - SetStatusBitTmp, 261
 - SetStatusTmp, 262
 - UpdateControl, 262
 - UpdateCtrl, 262
- StaExttapmea, 263
 - CopyExtMeaStatusToStatusTmp, 263
 - CreateEvent, 263
 - GetMeaValue, 264
 - GetStatus, 264
 - GetStatusTmp, 264

- InitTmp, [265](#)
- IsStatusBitSet, [265](#)
- IsStatusBitSetTmp, [265](#)
- ResetStatusBit, [265](#)
- ResetStatusBitTmp, [266](#)
- SetMeaValue, [266](#)
- SetStatus, [266](#)
- SetStatusBit, [267](#)
- SetStatusBitTmp, [267](#)
- SetStatusTmp, [268](#)
- UpdateControl, [268](#)
- UpdateCtrl, [268](#)
- StaExtv3mea, [269](#)
 - CopyExtMeaStatusToStatusTmp, [269](#)
 - GetMeaValue, [269](#)
 - GetStatus, [270](#)
 - GetStatusTmp, [270](#)
 - InitTmp, [270](#)
 - IsStatusBitSet, [270](#)
 - IsStatusBitSetTmp, [271](#)
 - ResetStatusBit, [271](#)
 - ResetStatusBitTmp, [271](#)
 - SetMeaValue, [271](#)
 - SetStatus, [272](#)
 - SetStatusBit, [272](#)
 - SetStatusBitTmp, [273](#)
 - SetStatusTmp, [273](#)
 - UpdateControl, [273](#)
 - UpdateCtrl, [274](#)
- StaExtvmea, [274](#)
 - CopyExtMeaStatusToStatusTmp, [274](#)
 - GetMeaValue, [274](#)
 - GetStatus, [275](#)
 - GetStatusTmp, [275](#)
 - InitTmp, [275](#)
 - IsStatusBitSet, [276](#)
 - IsStatusBitSetTmp, [276](#)
 - ResetStatusBit, [276](#)
 - ResetStatusBitTmp, [276](#)
 - SetMeaValue, [277](#)
 - SetStatus, [277](#)
 - SetStatusBit, [278](#)
 - SetStatusBitTmp, [278](#)
 - SetStatusTmp, [278](#)
 - UpdateControl, [279](#)
 - UpdateCtrl, [279](#)
- Start
 - ComDiffoutage, [335](#)
- StartTrace
 - ComContingency, [317](#)
 - ComOutage, [368](#)
- StaSwitch, [279](#)
 - Close, [280](#)
 - IsClosed, [280](#)
 - IsOpen, [280](#)
 - Open, [280](#)
- StatFileGetXrange
 - Application Methods, [45](#)
- StatFileResetXrange
 - Application Methods, [45](#)
- StatFileSetXrange
 - Application Methods, [46](#)
- Station Elements Methods, [208](#)
- StaVt, [281](#)
 - SetPrimaryTap, [281](#)
- StoMaint, [675](#)
 - SetElms, [675](#)
- StopTrace
 - ComContingency, [317](#)
 - ComOutage, [368](#)
- SubscribeProjectReadOnly
 - IntPrj, [596](#)
- SubscribeProjectReadWrite
 - IntPrj, [596](#)
- SwitchOff
 - General Object Methods, [95](#)
- SwitchOn
 - General Object Methods, [96](#)
- TerminateSession
 - IntUser, [631](#)
- Time
 - SetTime, [497](#)
- TopologyForDirectionalBackupVariable
 - ComCoordreport, [327](#)
- TopologyForFuseVariable
 - ComCoordreport, [328](#)
- TopologyForInstantaneousVariable
 - ComCoordreport, [328](#)
- TopologyForMaxCurrent
 - ComCoordreport, [329](#)
- TopologyForNonDirectionalBackupVariable
 - ComCoordreport, [329](#)
- TopologyForOverloadVariable
 - ComCoordreport, [329](#)
- TopologyForOverreachVariable
 - ComCoordreport, [330](#)
- TopologyForShortCircuitVariable
 - ComCoordreport, [330](#)
- TopologyForZoneVariable
 - ComCoordreport, [331](#)
- TotalLossCost
 - ComCapo, [298](#)
- TransferDirectionalBackupResultsTo
 - ComCoordreport, [331](#)
- TransferNonDirectionalBackupResultsTo
 - ComCoordreport, [332](#)
- TransferOverreachResultsTo
 - ComCoordreport, [332](#)
- TransferResultsTo
 - ComCoordreport, [333](#)
- TransferZoneResultsTo

- ComCoordreport, 334
- TransformGeoCoordinates
 - IntPrj, 596
- TransformToGeographicCoordinateSystem
 - IntPrj, 596
- TriCont, 676
 - GetOrCreateTrigger, 676
- TriDisc, 676
 - GetOrCreateTrigger, 676
- TriFile, 676
 - GetOrCreateTrigger, 676
- TriVal, 677
 - GetOrCreateTrigger, 677
- TypAsmo, 677
 - CalcElParams, 677
- TypCtcore, 678
 - AddRatio, 678
 - RemoveRatio, 678
 - RemoveRatioByIndex, 679
- TypLne, 679
 - IsCable, 679
- TypMdl, 679
 - Check, 679
 - Compile, 680
 - ConvertToBlackbox, 680
 - Pack, 680
- TypQdsl, 681
 - Encrypt, 681
 - IsEncrypted, 682
 - ResetThirdPartyModule, 682
 - SetThirdPartyModule, 682
- TypTr2, 683
 - GetZeroSequenceHVLVT, 683
- Unfreeze
 - SetDesktop, 472
- UnsubscribeProject
 - IntPrj, 597
- Update
 - ChaVecfile, 505
 - ComSimoutage, 393
 - ElmBmu, 108
 - ElmBoundary, 110
 - ElmBranch, 111
 - ElmCabsys, 111
 - ElmTow, 180
 - IntDplmap, 554
 - IntSscheduler, 622
- UpdateAnnotationElement
 - IntGrflayer, 567
- UpdateControl
 - StaExtbrkmea, 216
 - StaExtcmdmea, 221
 - StaExtmdatmea, 226
 - StaExtfmea, 231
 - StaExtfuelmea, 236
 - StaExttimea, 241
 - StaExtpfmea, 247
 - StaExtpmea, 252
 - StaExtqmea, 258
 - StaExtsmea, 262
 - StaExttapmea, 268
 - StaExtv3mea, 273
 - StaExtvmea, 279
- UpdateCtrl
 - StaExtbrkmea, 217
 - StaExtcmdmea, 222
 - StaExtmdatmea, 227
 - StaExtfmea, 231
 - StaExtfuelmea, 236
 - StaExttimea, 242
 - StaExtpfmea, 247
 - StaExtpmea, 252
 - StaExtqmea, 258
 - StaExtsmea, 262
 - StaExttapmea, 268
 - StaExtv3mea, 274
 - StaExtvmea, 279
- UpdateFromCurrentView
 - IntViewbookmark, 639
- UpdateGroups
 - IntUserman, 633
- UpdateStatistics
 - IntPrj, 597
- UpdateSubstationTerminals
 - ElmTerm, 179
- UpdateTableReports
 - Dialogue Boxes Functions, 50
- UpdateTablesByCalcPeriod
 - ComTececo, 445
- UpdateToDefaultStructure
 - IntPrj, 597
- UpdateToMostRecentBaseVersion
 - IntPrj, 598
- ValidateConstraints
 - ComRel3, 376
- View
 - IntDocument, 551
 - IntUrl, 630
- VisPath, 683
 - Clear, 684
 - DoAutoScaleX, 684
 - DoAutoScaleY, 684
 - SetAdaptX, 684
 - SetAdaptY, 684
 - SetScaleX, 685
 - SetScaleY, 685
- VisPcompdiffplt, 685
 - AddRelay, 685
 - AddRelays, 686
 - CentreOrigin, 686

- Clear, [686](#)
- DoAutoScaleX, [686](#)
- DoAutoScaleY, [686](#)
- VisPlottz, [687](#)
 - AddRelay, [687](#)
 - AddRelays, [687](#)
 - Clear, [687](#)
 - DoAutoScaleX, [688](#)
 - DoAutoScaleY, [688](#)
- VisValue, [688](#)
 - SetUserDefined, [688](#)
- WereModificationsFound
 - ComMerge, [361](#)
- Write
 - ElmRes, [160](#)
- WriteChangesToDb
 - Application Methods, [46](#)
 - General Object Methods, [96](#)
- WriteDraw
 - ElmRes, [160](#)
- WriteValue
 - IntSstage, [625](#)
- WriteWMF
 - SetDesktop, [473](#)
- ZeroDerivative
 - ComInc, [351](#)
- ZoomAll
 - SetDesktop, [473](#)