





- 1. To get the specified scale, select 100% in print settings.
- 2. Drill location tolerance: ±0.1 [±5].
- 3. Board edge tolerance: ±0.3 [±10].





