Adresse mémoire	Programme assembleur	Programme machine
0x0000	LDSPi 0x0030	8000 30
0x0002	DECSP	9400
0x0003	LDAi 0x0007	1000 7
0x0005	PUSHA	b000
0x0006	LDAi 0x0008	1000 8
0x0008	PUSHA	b000
0x0009	CALL 0x0020	a000 20