Maintenance Schedule

1. Maintenance Schedule

When inspecting the following items, also inspect regular inspection items.

Abbreviations used
I: Inspect then clean, adjust, repair, or replace as necessary.
A: Adjust.
R: Replace.
T: Tighten to the specified torque.
L: Lubricate.

1. For Europe

Service item	Service content	Service interval (Odometer reading or months, whichever comes first)
Coolant concentration	I	Every 20,000 km (12,000 miles) or 24 months
EV system (drive motor) coolant	R	Initial 160,000 km (96,000 miles) or 96 months
		Every 160,000 km (96,000 miles) or 96 months (when Isuzu genuine coolant is used)
		Every 24 months (when Isuzu recommended coolant is used)
High-volatage battery coolant	R	Initial 160,000 km (96,000 miles) or 96 months
		Every 160,000 km (96,000 miles) or 96 months (when Isuzu genuine coolant is used)
		Every 24 months (when Isuzu recommended coolant is used)
Cabin heater coolant	R	Initial 160,000 km (96,000 miles) or 96 months
		Every 160,000 km (96,000 miles) or 96 months (when Isuzu genuine coolant is used)
		Every 24 months (when Isuzu recommended coolant is used)
EV system (drive motor) coolant leakage	I	Every 20,000 km (12,000 miles) or 24 months
High-voltage battery coolant leakage	I	Every 20,000 km (12,000 miles) or 24 months
Cabin heater coolant leakage	I	Every 20,000 km (12,000 miles) or 24 months
Front and rear axle shaft rubber boot for damage	I	Every 20,000 km (12,000 miles) or 24 months
Rear axle de dion for distortion and damage	I	Every 20,000 km (12,000 miles) or 24 months
* Steering system for looseness or damage	I	Every 20,000 km (12,000 miles) or 24 months
Steering wheel play	I	Every 20,000 km (12,000 miles) or 24 months
Steering function	I	Every 20,000 km (12,000 miles) or 24 months
Wheel alignment	I	Every 20,000 km (12,000 miles) or 24 months
Steering joint ball for oil leakage or damage	I	Every 20,000 km (12,000 miles) or 24 months
Brake fluid	I	Every 20,000 km (12,000 miles) or 24 months
	R	Every 40,000 km (24,000 miles) or 48 months
Brake system for fluid leakage	I	Every 20,000 km (12,000 miles) or 24 months
Brake function	I	Every 20,000 km (12,000 miles) or 24 months
* Front disc brake pad and disc wear	I	Every 20,000 km (12,000 miles) or 24 months

RTWS0BXF000401

Service item	Service content	Service interval (Odometer reading or months, whichever comes first)
* Rear brake lining and drum wear	I	Every 20,000 km (12,000 miles) or 24 months
Brake pedal travel and play	I	Every 20,000 km (12,000 miles) or 24 months
Brake pipes and hoses for loose connections or damage	I	Every 20,000 km (12,000 miles) or 24 months
Parking brake function	I	Every 20,000 km (12,000 miles) or 24 months
Parking brake lever travel	I	Every 20,000 km (12,000 miles) or 24 months
Parking brake cables for looseness or damage and guide for damage	I	Every 20,000 km (12,000 miles) or 24 months
Parking brake ratchet for wear or damage	I	Every 20,000 km (12,000 miles) or 24 months
Leaf/coil springs for damage	I	Every 20,000 km (12,000 miles) or 24 months
Suspension mount for looseness or damage	I	Every 20,000 km (12,000 miles) or 24 months
Shock absorbers for oil leakage	I	Every 20,000 km (12,000 miles) or 24 months
Shock absorbers mount for looseness	I	Every 20,000 km (12,000 miles) or 24 months
Rubber bushes of suspension wear or damage	I	Every 20,000 km (12,000 miles) or 24 months
Suspension joint ball rubber boot for damage	I	Every 20,000 km (12,000 miles) or 24 months
Wheel nuts	T	Every 20,000 km (12,000 miles) or 24 months
Wheel disc for damage	I	Every 20,000 km (12,000 miles) or 24 months
Front and rear hub bearing for looseness	I	Every 20,000 km (12,000 miles) or 24 months
Tire air pressure and damage	I	Every 20,000 km (12,000 miles) or 24 months
Tire rotation	Rotate as required	
Other bolts and nuts on chassis and body	I	Every 20,000 km (12,000 miles) or 24 months
Air conditioning filter	R	Every 60,000 km (36,000 miles) or 24 months

RTWS0BXF000501

*: Under severe driving conditions, additional maintenance is required. Refer to "Maintenance Schedule for Severe-condition Operations".

2. Except for Europe and New Zealand

Service item	Service content	Service interval (Odometer reading or months, whichever comes first)
Coolant concentration	I	Every 10,000 km (6,000 miles) or 12 months
EV system (drive motor) coolant	R	Every 24 months (When Isuzu genuine or recommended coolant is used.)
High-volatage battery coolant	R	Every 24 months (When Isuzu genuine or recommended coolant is used.)
Cabin heater coolant	R	Every 24 months (When Isuzu genuine or recommended coolant is used.)
EV system (drive motor) coolant leakage	I	Every 10,000 km (6,000 miles) or 12 months
High-voltage battery coolant leakage	I	Every 10,000 km (6,000 miles) or 12 months
Cabin heater coolant leakage	I	Every 10,000 km (6,000 miles) or 12 months
Front and rear axle shaft rubber boot for damage	I	Every 20,000 km (12,000 miles) or 24 months
Rear axle dedion for distortion or damage	I	Every 20,000 km (12,000 miles) or 24 months
* Steering system for looseness or damage	I	Every 10,000 km (6,000 miles) or 12 months
Steering wheel play	I	Every 10,000 km (6,000 miles) or 12 months
Steering function	I	Every 10,000 km (6,000 miles) or 12 months
Wheel alignment	I	Every 20,000 km (12,000 miles) or 24 months
Steering joint ball for oil leakage or damage	I	Every 10,000 km (6,000 miles) or 12 months
Brake fluid	I R	Every 20,000 km (12,000 miles) or 24 months Every 40,000 km (24,000 miles) or 48 months
Brake system for fluid leakage	I	Every 10,000 km (6,000 miles) or 12 months
Brake function	I	Every 10,000 km (6,000 miles) or 12 months
* Front disc brake pad and disc wear	I	Every 10,000 km (6,000 miles) or 12 months
* Rear brake lining and drum wear	I	Every 10,000 km (6,000 miles) or 12 months
Brake pedal travel and play	I	Every 10,000 km (6,000 miles) or 12 months
Brake pipes and hoses for loose connections or damage	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months

RTWS0BXF001201

Service item	Service content	Service interval (Odometer reading or months, whichever comes first)
Parking brake function	I	Every 10,000 km (6,000 miles) or 12 months
Parking brake lever travel	I	Every 10,000 km (6,000 miles) or 12 months
Parking brake cables for looseness or damage and guide for damage	I	Every 10,000 km (6,000 miles) or 12 months
Parking brake ratchet for wear or damage	I	Every 10,000 km (6,000 miles) or 12 months
Leaf/coil springs for damage	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Suspension mount for looseness or damage	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Shock absorbers for oil leakage	I	Every 10,000 km (6,000 miles) or 12 months
Shock absorbers mount for looseness	I	Every 10,000 km (6,000 miles) or 12 months
Rubber bushes of suspension wear or damage	I	Every 10,000 km (6,000 miles) or 12 months
Suspension joint ball rubber boot for damage	I	Every 10,000 km (6,000 miles) or 12 months
Wheel nuts	T	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Wheel disc for damage	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Front and rear hub bearings for looseness	I	Every 10,000 km (6,000 miles) or 12 months
Tire air pressure and damage	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Tire rotation	Rotate as required	
Other bolts and nuts on chassis and body	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Air conditioning filter	R	Every 15,000 km (9,000 miles) or 12 months

RTWS0BXF001301

*: Under severe driving conditions, additional maintenance is required. Refer to "Maintenance Schedule for Severe-condition Operations".

3. For New Zealand

Service item	Service content	Service interval (Odometer reading or months, whichever comes first)
Coolant concentration	I	Every 15,000 km (9,000 miles) or 12 months
EV system (drive motor) coolant	R	Initial 120,000 km (72,000 miles) or 96 months
		Every 120,000 km (72,000 miles) or 96 months (when BESCO (coolant) is used)**
		Every 24 months (when other coolant is used)
High-volatage battery coolant	R	Initial 120,000 km (72,000 miles) or 96 months
		Every 120,000 km (72,000 miles) or 96 months (when BESCO (coolant) is used)**
		Every 24 months (when other coolant is used)
Cabin heater coolant	R	Initial 120,000 km (72,000 miles) or 96 months
		Every 120,000 km (72,000 miles) or 96 months (when BESCO (coolant) is used)**
		Every 24 months (when other coolant is used)
EV system (drive motor) coolant leakage	I	Every 15,000 km (9,000 miles) or 12 months
High-voltage battery coolant leakage	I	Every 15,000 km (9,000 miles) or 12 months
Cabin heater coolant leakage	I	Every 15,000 km (9,000 miles) or 12 months
Front and rear axle shaft rubber boot for damage	I	Every 30,000 km (18,000 miles) or 24 months
Rear axle dedion for distortion or damage	I	Every 30,000 km (18,000 miles) or 24 months
* Steering system for looseness or damage	I	Every 15,000 km (9,000 miles) or 12 months
Steering wheel play	I	Every 15,000 km (9,000 miles) or 12 months
Steering function	I	Every 15,000 km (9,000 miles) or 12 months
Wheel alignment	I	Every 30,000 km (18,000 miles) or 24 months
Steering joint ball for oil leakage or damage	I	Every 15,000 km (9,000 miles) or 12 months
Brake fluid	I	Every 15,000 km (9,000 miles) or 12 months
	R	Every 45,000 km (27,000 miles) or 36 months
Brake system for fluid leakage	I	Every 15,000 km (9,000 miles) or 12 months

RTWS0BXF001001

Service item	Service content	Service interval (Odometer reading or months, whichever comes first)
Brake function	I	Every 15,000 km (9,000 miles) or 12 months
* Front disc brake pad and disc wear	I	Every 15,000 km (9,000 miles) or 12 months
* Rear brake lining and drum wear	I	Every 15,000 km (9,000 miles) or 12 months
Brake pedal travel and play	I	Every 15,000 km (9,000 miles) or 12 months
Brake pipes and hoses for loose connections or damage	I	Every 15,000 km (9,000 miles) or 12 months
Parking brake function	I	Every 15,000 km (9,000 miles) or 12 months
Parking brake lever travel	I	Every 15,000 km (9,000 miles) or 12 months
Parking brake cables for looseness or damage and guide for damage	I	Every 15,000 km (9,000 miles) or 12 months
Parking brake ratchet for wear or damage	I	Every 15,000 km (9,000 miles) or 12 months
Leaf/coil springs for damage	I	Every 15,000 km (9,000 miles) or 12 months
Suspension mount for looseness or damage	I	Every 15,000 km (9,000 miles) or 12 months
Shock absorbers for oil leakage	I	Every 15,000 km (9,000 miles) or 12 months
Shock absorbers mount for looseness	I	Every 15,000 km (9,000 miles) or 12 months
Rubber bushes of suspension wear or damage	I	Every 15,000 km (9,000 miles) or 12 months
Suspension joint ball rubber boot for damage	I	Every 15,000 km (9,000 miles) or 12 months
Wheel nuts	T	Every 15,000 km (9,000 miles) or 12 months
Wheel disc for damage	I	Every 15,000 km (9,000 miles) or 12 months
Front and rear hub bearings for looseness	I	Every 15,000 km (9,000 miles) or 12 months
Tire air pressure and damage	I	Every 15,000 km (9,000 miles) or 12 months
Tire rotation	Rotate as required	
Other bolts and nuts on chassis and body	I	Every 15,000 km (9,000 miles) or 12 months
Air conditioning filter	R	Every 30,000 km (18,000 miles) or 24 months

RTWS0BXF001101

*Under severe driving conditions, additional maintenance is required. Refer to "Maintenance Schedule for Severe-condition Operations".

**For details about BESCO (coolant), please refer to "Recommended Fluids, Lubricants and Diesel Fuels".

2. Maintenance Schedule for Severe-Condition

Vehicles used under severe conditions need more frequent maintenance than those receiving ordinary use.

A: Repeated short trips
B: Driving on rough roads
C: Driving on dusty roads

Service item	Service interval	Condition
Steering system for looseness or damage	Inspect every 5,000 km (3,000 miles)	B
Front disc brake pad and disc wear	Inspect every 5,000 km (3,000 miles)	A, B, C
Rear brake lining and drum wear	Inspect every 5,000 km (3,000 miles)	A, B, C

RTWS0BSF000201

Copyright ISUZU MOTORS LIMITED. All rights reserved.