Maintenance Schedule

1. Maintenance Schedule

When inspecting the following items, also inspect regular inspection items.

Abbreviations used
I: Inspect, clean, or repair, or replace as necessary.
A: Adjust.
R: Replace.
T: Tighten to the specified torque.
L: Add lubricant.

*: Additional maintenance is required under severe driving conditions. Refer to Maintenance Schedule for Severe-condition Operations.

Service item	Service content	Service interval (Odometer reading or months (years), whichever comes first)
*Engine oil	R	Every 20,000 km (12,000 miles) or 24 months
*Engine oil filter	R	Every 20,000 km (12,000 miles) or 24 months
Engine oil leakage and contamination	I	Every 20,000 km (12,000 miles) or 24 months
Engine idling speed and acceleration	I	Every 20,000 km (12,000 miles) or 24 months
Accessory belt tension and damage	I	Every 20,000 km (12,000 miles) or 24 months
Exhaust system	I	Every 20,000 km (12,000 miles) or 24 months
All hoses and pipes in engine compartment for clog or damage	I	Every 20,000 km (12,000 miles) or 24 months
*Air cleaner element	I R	Every 20,000 km (12,000 miles) or 24 months Every 40,000 km (24,000 miles) or 48 months
Fuel filter	R	Replace the fuel filter when the fuel filter warning light comes on.
Fuel tank	I	Every 20,000 km (12,000 miles) or 24 months
Fuel hoses and pipes for clog or damage	I	Every 20,000 km (12,000 miles) or 24 months
Draining of water separator	Drain the fuel filter when the water separator warning light comes on	
Engine coolant concentration	I	Every 20,000 km (12,000 miles) or 24 months
Engine coolant	R	Every 40,000 km (24,000 miles) or 24 months (when Isuzu recommended coolant is used)
Cooling system for water leakage	I	Every 20,000 km (12,000 miles) or 24 months
Clutch fluid	I R	Every 20,000 km (12,000 miles) or 24 months Every 40,000 km (24,000 miles) or 48 months
Clutch pedal travel and play	I	Every 20,000 km (12,000 miles) or 24 months
*Manual transmission oil (MT)	I R	Every 20,000 km (12,000 miles) or 24 months Every 40,000 km (24,000 miles) or 48 months
*Transfer case oil (MT)	I	Every 20,000 km (12,000 miles) or 24 months
Manual transmission and transfer case oil leakage	I	Every 20,000 km (12,000 miles) or 24 months

Gear control mechanism for looseness	I	Every 20,000 km (12,000 miles) or 24 months
*Automatic transmission fluid (AT)	I	Every 100,000 km (60,000 miles) or 60 months
*Transfer case oil (AT)	I	Every 20,000 km (12,000 miles) or 24 months
Automatic transmission oil leakage	I	Every 20,000 km (12,000 miles) or 24 months
Propeller shaft loose connections	I	Every 10,000 km (6,000 miles) or 12 months
*Propeller shaft universal joints and splines for wear	I	Every 10,000 km (6,000 miles) or 12 months
Propeller shaft universal joints and splines sleeve (4WD)	L	Every 10,000 km (6,000 miles) or 12 months
*Differential gear oil - Front and rear	R I R	Initial 10,000 km (6,000 miles) or 12 months Every 20,000 km (12,000 miles) or 24 months Every 40,000 km (24,000 miles) or 48 months
Front and rear axle oil leakage	I	Every 20,000 km (12,000 miles) or 24 months
Shift on the fly system gear oil	I	Every 20,000 km (12,000 miles) or 24 months
Front axle shaft rubber boot for damage	I	Every 20,000 km (12,000 miles) or 24 months
Axle case for distortion or damage	I	Every 20,000 km (12,000 miles) or 24 months
Axle shafts for distortion or damage	I	Every 20,000 km (12,000 miles) or 24 months
Power steering fluid	I R	Every 20,000 km (12,000 miles) or 24 months Every 80,000 km (48,000 miles) or 96 months
Power steering fluid leakage	I	Every 20,000 km (12,000 miles) or 24 months
*Steering system for looseness or damage	I	Every 20,000 km (12,000 miles) or 24 months
Power steering hose	I R	Every 20,000 km (12,000 miles) or 24 months Every 100,000 km (60,000 miles) or 120 months
Steering wheel play	I	Every 20,000 km (12,000 miles) or 24 months
Steering function	I	Every 20,000 km (12,000 miles) or 24 months
Right and left turning radius	I	Every 20,000 km (12,000 miles) or 24 months
Wheel alignment	I	Every 20,000 km (12,000 miles) or 24 months
Steering joint ball for oil leakage or damage	I	Every 20,000 km (12,000 miles) or 24 months
Steering joint ball rubber boot for damage	I	Every 20,000 km (12,000 miles) or 24 months
Brake fluid	I R	Every 20,000 km (12,000 miles) or 24 months Every 40,000 km (24,000 miles) or 48 months
Brake system for fluid leakage	I	Every 10,000 km (6,000 miles) or 12 months
Brake function	I	Every 10,000 km (6,000 miles) or 12 months
*Front disc brake pad and disc wear	I	Every 10,000 km (6,000 miles) or 12 months
	I	Every 10,000 km (6,000 miles) or 12 months

*Rear brake lining and drum wear		
Brake pedal travel and play	I	Every 10,000 km (6,000 miles) or 12 months
Brake pipes and hoses for loose connections or damage	I	Every 10,000 km (6,000 miles) or 12 months
Parking brake function	I	Every 10,000 km (12,000 miles) or 12 months
Parking brake lever travel	I	Every 10,000 km (6,000 miles) or 12 months
Parking brake cables for looseness or damage and guide for damage	I	Every 20,000 km (12,000 miles) or 24 months
Parking brake ratchet for wear or damage	I	Every 10,000 km (6,000 miles) or 12 months
Leaf/coil springs for damage	I	Every 20,000 km (12,000 miles) or 24 months
Suspension mount for looseness or damage	I	Every 20,000 km (12,000 miles) or 24 months
Shock absorbers for oil leakage	I	Every 20,000 km (12,000 miles) or 24 months
Shock absorbers mount for looseness	I	Every 20,000 km (12,000 miles) or 24 months
Rubber bushes of suspension wear or damage	I	Every 20,000 km (12,000 miles) or 24 months
Spring action for loss of balance due to weakening	I	Every 20,000 km (12,000 miles) or 24 months
Suspension joint ball rubber boot for damage	I	Every 20,000 km (12,000 miles) or 24 months
Wheel nuts	T	Every 10,000 km (6,000 miles) or 12 months
Wheel disc for damage	I	Every 20,000 km (12,000 miles) or 24 months
Front hub bearing grease	R	Every 30,000 km (18,000 miles) or 36 months
Front and rear hub bearing for looseness	I	Every 10,000 km (6,000 miles) or 12 months
Tire air pressure and damage	I	Every 20,000 km (12,000 miles) or 24 months
Tire rotation	Rotate as required	
Other bolts and nuts on chassis and body	I	Every 20,000 km (12,000 miles) or 24 months
Air conditioning filter	R	Every 20,000 km (12,000 miles) or 24 months

2. Maintenance Schedule for Severe-Condition

Vehicles used under severe conditions need more frequent maintenance than ordinary use.

A: Operations involving frequent starts and stops
B: Driving on rough, mountain, or uphill roads
C: Driving in dusty areas
D: Driving on snowy or coastal roads

E: Towing a trailer or frequent uphill driving
F: Continuous driving in low speed and/or with a low load
G: Frequently turning the engine off during DPD regeneration

Item	Distance range	Condition							
		A	B	C	D	E	F	G	A+D
Engine oil	Replace every 5,000 km (3,000 miles)			○		○	○	○	○
Engine oil filter	Replace every 10,000 km (6,000 miles)			○		○	○	○	○
Exhaust pipes and mounting	Inspect every 10,000 km (6,000 miles)	○	○		○				
Air cleaner element	Inspect every 5,000 km (3,000 miles) Replace every 20,000 km (12,000 miles)			○					
Steering system for looseness or damage	Inspect every 5,000 km (3,000 miles)		○						
Universal joints and sleeves	Inspect for wear and lubricate every 5,000 km (3,000 miles)		○	○					
Manual transmission oil	Replace every 20,000 km (12,000 miles) after replacing at initial 10,000 km (6,000 miles)		○						
Automatic transmission fluid	Inspect every 40,000 km (24,000 miles) Replace every 80,000 km (48,000 miles)		○			○			○
Transfer case oil	Replace every 20,000 km (12,000 miles) after replacing at initial 10,000 km (6,000 miles)		○						
Differential gear oil	Replace every 20,000 km (12,000 miles) after replacing at initial 10,000 km (6,000 miles)		○						
Front disc brake pad and disc wear	Inspect every 5,000 km (3,000 miles)	○	○	○					
Rear brake lining and drum wear	Inspect every 5,000 km (3,000 miles)	○	○	○					

Copyright ISUZU MOTORS LIMITED. All rights reserved.