Maintenance Schedule

1. Maintenance Schedule

When inspecting the following items, also check regular inspection items.

Letters used to Indicate Maintenance Service Types
I: Inspect then clean, repair or replace as necessary
A: Adjust
R: Replace
T: Tighten to the specified torque
L: Add lubricant

I : Inspect then clean, repair or replace as necessary A : Adjust R : Replace T : Tighten to the specified torque L : Add lubricate

Service Interval x1,000 km	1.1	5.5	11	16.5	22	27.5	33	38.5	44	49.5	55	60.5	66	71.5	77	82.5	88	93.5	99	104.5	110	115.5	Odometer reading or months, whichever comes first
x1,000 miles	0.6	3.4	6.8	10.2	13.6	17.0	20.5	23.9	27.3	30.7	34.1	37.5	41.0	44.4	47.8	51.2	54.6	58.1	61.5	64.9	68.3	71.7	
Engine startability and abnormal noise	-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
Idling speed and acceleration	-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
* Air cleaner element	-	-	-	-	-	-	-	-	-	R	-	-	-	-	-	-	-	-	R	-	-	-	or every 15 months or after 6th cleaning : R every 6 months : I
Intake and exhaust manifolds	T	-	-	-	-	-	-	-	-	T	-	-	-	-	-	-	-	-	T	-	-	-	or every 15 months
Valve clearance	A	-	-	-	-	-	-	-	-	A	-	-	-	-	-	-	-	-	A	-	-	-	or every 12 months
Compression pressure for each cylinder	-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	I	-	-	-	or every 15 months
Oil contamination	-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
* Engine oil	R	-	I	-	R	-	I	-	R	-	I	-	R	-	I	-	R	-	I	-	R	-	or every 3 months : I or every 6 months : R
* Engine oil (main and partial) filter (combined type)	-	-	-	-	R	-	-	-	R	-	-	-	R	-	-	-	R	-	-	-	R	-	or every 6 months
* Engine oil main filter (separate type)	-	-	-	-	R	-	-	-	R	-	-	-	R	-	-	-	R	-	-	-	R	-	or every 6 months
* Engine oil partial filter (separate type)	-	-	-	-	R	-	-	-	R	-	-	-	R	-	-	-	R	-	-	-	R	-	or every 6 months
* Engine oil separator	-	-	-	-	R	-	-	-	R	-	-	-	R	-	-	-	R	-	-	-	R	-	
Fuel filter	-	-	-	-	-	-	-	-	R	-	-	-	-	-	-	-	R	-	-	-	-	-	or every 9 months
Fuel hose	Every 3 months : I Every 48 months : R																						
Fuel tank strainer	-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
Inside fuel tank	-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
Air compressor, governor and unloader valve functions	-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	I	-	-	-	or every 15 months
Radiator cap or radiator sub-tank cap function	Every 48 months : I																						
Damage to fan belt	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
* Loose or otherwise improper installation of exhaust pipe	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
Exhaust pipe injection nozzle (if so equipped)	Every 120,000km (74,000 miles): I																						
Cooling circuit and radiator	Every 24 months : I																						
Engine coolant	Every 24 months : R																						
Turbocharger to air duct connection and gasket	-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
* Clutch fluid (manual transmission)	-	-	I	-	I	-	I	-	I	-	R	-	I	-	I	-	I	-	I	-	R	-	or every 3 months : I every 15 months : R
Clutch system function (manual transmission)	-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
Clutch pedal free play and stroke (manual transmission)	-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
Clutch booster exhaust cover (manual transmission)	-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
Clutch hose (manual transmission)	Every 3 months : I Every 48 months : R																						
Rubber parts and gaskets of clutch booster (manual transmission)	Every 48 months : R																						

* : The vehicle needs to be maintained more often if it is driven in severe condition. Refer to "Maintenance Schedule for Severe-condition" in this section.

MFWE0BLF000201

I : Inspect then clean, repair or replace as necessary A : Adjust R : Replace T : Tighten to the specified torque L : Add lubricate

Service Interval	x1,000 km	1.1	5.5	11	16.5	22	27.5	33	38.5	44	49.5	55	60.5	66	71.5	77	82.5	88	93.5	99	104.5	110	115.5	Odometer reading or months, whichever comes first
	x1,000 miles	0.6	3.4	6.8	10.2	13.6	17.0	20.5	23.9	27.3	30.7	34.1	37.5	41.0	44.4	47.8	51.2	54.6	58.1	61.5	64.9	68.3	71.7	
* Transmission oil		R	-	I	-	I	-	I	-	I	-	R	-	I	-	I	-	I	-	I	-	R	-	or every 3 months : I every 15 months : R
* Smoother clutch oil (Vehicle equipped with the Smoother system)		R	-	I	-	I	-	I	-	I	-	R	-	I	-	I	-	I	-	I	-	R	-	or every 3 months : I every 15 months : R
Loose gear control mechanism		-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
Loose propeller shaft joints		-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	I	-	-	-	or every 15 months
* Worn propeller shaft universal joint and splines		-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	I	-	-	-	or every 15 months
Loose propeller shaft bearing and related parts		-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	I	-	-	-	or every 15 months
* Rear axle differential gear oil		R	-	I	-	I	-	I	-	I	R	I	-	I	-	I	-	I	-	R	-	I	-	or every 3 months : I every 15 months : R
Rear wheel hub bearing grease		-	-	-	-	-	-	-	-	-	-	R	-	-	-	-	-	-	-	-	-	R	-	or every 15 months
Damaged or distorted rear axle case		-	-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	-	I	-	or every 15 months
Front wheel hub bearing grease		-	-	-	-	-	-	-	-	-	-	R	-	-	-	-	-	-	-	-	-	R	-	or every 15 months
Damaged or distorted front axle case		-	-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	-	I	-	or every 15 months
* Leaf spring U-bolt nuts (Leaf suspension models)		T	-	-	-	-	-	-	-	-	-	T	-	-	-	-	-	-	-	-	-	T	-	or every 15 months
* Air suspension's beam bolt nuts/U-bolt nuts (Air suspension models)		T	-	-	-	-	-	-	-	-	-	T	-	-	-	-	-	-	-	-	-	T	-	or every 15 months
Damaged leaf spring (Leaf suspension models)		-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
Uneven suspension due to leaf spring fatigue (Leaf suspension models)		-	-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	-	I	-	or every 15 months
Loose or damaged leaf spring mounting (Leaf suspension models)		-	-	-	-	-	-	I	-	-	-	-	-	I	-	-	-	-	-	I	-	-	-	or every 9 months
Spring leaves for misalignment (Air suspension models)		-	-	-	-	-	-	I	-	-	-	-	-	I	-	-	-	-	-	I	-	-	-	or every 9 months
Oil leaks from or damage to shock absorbers		-	-	-	-	-	-	I	-	-	-	-	-	I	-	-	-	-	-	I	-	-	-	or every 9 months
Loose shock absorber mounting		-	-	-	-	-	-	I	-	-	-	-	-	I	-	-	-	-	-	I	-	-	-	or every 9 months

* : The vehicle needs to be maintained more often if it is driven in severe condition. Refer to "Maintenance Schedule for Severe-condition" in this section.

MFWE0BLF000301

I : Inspect then clean, repair or replace as necessary A : Adjust R : Replace T : Tighten to the specified torque L : Add lubricate

Service Interval	x1,000 km	1.1	5.5	11	16.5	22	27.5	33	38.5	44	49.5	55	60.5	66	71.5	77	82.5	88	93.5	99	104.5	110	115.5	Odometer reading or months, whichever comes first
	x1,000 miles	0.6	3.4	6.8	10.2	13.6	17.0	20.5	23.9	27.3	30.7	34.1	37.5	41.0	44.4	47.8	51.2	54.6	58.1	61.5	64.9	68.3	71.7	
Damaged air spring (Air suspension models)		-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
Air leaks from air suspension (Air suspension models)		-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
Loose or damaged air suspension mounting (Air suspension models)		-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
Air spring height (Air suspension models)		-	-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	-	I	-	or every 15 months
Loose or damaged V-rod (Air suspension models)		-	-	-	-	I	-	-	-	I	-	-	-	I	-	-	-	I	-	-	-	I	-	or every 6 months
Foreign object in wheels		-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
Wheel nuts		T	-	T	-	T	-	T	-	T	-	T	-	T	-	T	-	T	-	T	-	T	-	or every 3 months
Damaged disc wheels		-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
Loose front wheel hub bearings		-	-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	-	I	-	or every 15 months
Loose rear wheel hub bearings		-	-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	-	I	-	or every 15 months
Power steering fluid		-	-	I	-	I	-	I	-	I	-	R	-	I	-	I	-	I	-	I	-	R	-	or every 3 months : I every 15 months : R
Power steering fluid filter		-	-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	-	I	-	or every 15 months
Power steering hose		Every 3 months : I Every 48 months : R																						
Loose power steering system mounting		-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
Excessive play in power steering bearing		-	-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	-	I	-	or every 15 months
* Damage to, loose or excessive play in power steering joints		I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
Knuckle-to-front axle clearance		-	-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	-	I	-	or every 15 months
Wheel alignment		-	-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	-	I	-	or every 15 months
Steering angle range for right and left turns		-	-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	-	I	-	or every 15 months
Kingpin-to-bearing clearance		-	-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	-	I	-	or every 15 months
Brake fluid (Vehicle equipped with the air-over hydraulic brake system)		-	-	I	-	I	-	I	-	I	-	R	-	I	-	I	-	I	-	I	-	R	-	or every 3 months : I every 12 months : R
* Brake lining wear		-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
* Brake drum wear or damage		-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	I	-	-	-	or every 12 months

* : The vehicle needs to be maintained more often if it is driven in severe condition. Refer to "Maintenance Schedule for Severe-condition" in this section.

MFWE0BLF000401

I : Inspect then clean, repair or replace as necessary A : Adjust R : Replace T : Tighten to the specified torque L : Add lubricate

Service Interval	x1,000 km	1.1	5.5	11	16.5	22	27.5	33	38.5	44	49.5	55	60.5	66	71.5	77	82.5	88	93.5	99	104.5	110	115.5	Odometer reading or months, whichever comes first
	x1,000 miles	0.6	3.4	6.8	10.2	13.6	17.0	20.5	23.9	27.3	30.7	34.1	37.5	41.0	44.4	47.8	51.2	54.6	58.1	61.5	64.9	68.3	71.7	
Brake hose		-	I	I	I	I	I	I	I	I	R	I	I	I	I	I	I	I	I	R	I	I	I	or every 3 months : I every 24 months : R
Function of brake valves		-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	I	-	-	-	or every 12 months
Brake booster exhaust cover		-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 12 months
Electronic hydraulic control unit (EHCU)		Every 10 years : R																						
Leaks from, damage to, or loose connection of brake hose or pipe		-	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	or every 3 months
Desiccant, filter and rubber parts of air dryer		-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	R	-	-	-	or every 12 months
Rubber parts of wheel cylinder		Every 12 months : R																						
Rubber parts of HSA valve (Vehicle equipped with HSA)		Every 24 months : R																						
Rubber parts of brake valve, relay valve, parking brake valve, quick release valve, reducing valve, double check valve,multi-protection valve, Air master, TCV		Every 24 months : R																						
Rubber parts of brake chamber		Every 3 months : I Every 24 months : R																						
Brake chamber piggy-bag		Every 36 months : R																						
Brake expander		Every 12 months : I Every 36 months : overhaul																						
Worn parking brake lining (center parking brake model)		-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	I	-	-	-	or every 12 months
Worn or damaged parking brake drum (center parking brake model)		-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	I	-	-	-	or every 12 months
Loose parking brake system mounting		-	-	I	-	-	-	I	-	-	-	-	I	-	-	-	-	I	-	-	-	-	I	or every 3 months
Damaged or loosely connected rod or cable		-	I	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months

MFWE0BLF000501

I : Inspect then clean, repair or replace as necessary A : Adjust R : Replace T : Tighten to the specified torque L : Add lubricate

Service Interval x1,000 km	1.1	5.5	11	16.5	22	27.5	33	38.5	44	49.5	55	60.5	66	71.5	77	82.5	88	93.5	99	104.5	110	115.5	Odometer reading or months, whichever comes first
x1,000 miles	0.6	3.4	6.8	10.2	13.6	17.0	20.5	23.9	27.3	30.7	34.1	37.5	41.0	44.4	47.8	51.2	54.6	58.1	61.5	64.9	68.3	71.7	
Function of parking brake control valve system (wheel parking brake model)	-	I	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
Function of brake chamber (wheel parking brake model)	-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	I	-	-	-	or every 12 months
Brake chamber rod stroke (wheel parking brake model)	-	I	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
Electro-hydraulic cab tilt pump oil (Electro-hydraulic cab tilt model)	-	-	-	-	-	-	I	-	-	-	-	-	I	-	-	-	-	-	I	-	-	-	or every 9 months : I every 24 months : R
Specific gravity of battery fluid	-	-	-	-	-	-	I	-	-	-	-	-	I	-	-	-	-	-	I	-	-	-	or every 9 months
Function of starter motor	-	-	-	-	-	I	-	-	-	-	I	-	-	-	-	I	-	-	-	-	I	-	or every 9 months
Wear of starter motor brushes	-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	I	-	-	-	or every 15 months
Function of generator	-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
Damage to or loose connection of wiring harness terminals	-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 3 months
Exhaust pressure check or filter cleaning	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	I	-	-	-	or every 12 months
Exhaust differential pressure sensor rubber piece	-	-	-	-	-	-	-	-	R	-	-	-	-	-	-	-	R	-	-	-	-	-	or every 12 months
AdBlue® filter	Every 200,000km (124,000 miles): R																						
Front spring pins	-	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	or every month
Front spring shackle pins	-	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	or every month
Kingpins	-	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	or every month
Drag link (maintenance type)	-	-	-	-	-	L	-	-	-	-	L	-	-	-	-	L	-	-	-	-	L	-	or every 6 months
Propeller shaft universal joints and sliding sleeves	-	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	or every month
Propeller shaft center bearing	-	-	-	-	-	-	-	-	-	L	-	-	-	-	-	-	-	-	L	-	-	-	or every month
Rear spring pins (Leaf suspension models)	-	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	or every month
Rear spring sliding shackles (Leaf suspension models)	-	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	or every month
Steering shaft sliding sleeve	-	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	or every month
Clutch booster joint pin (manual transmission)	-	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	or every month
Function of cab tilt system	-	-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	-	I	-	or every 15 months
Cab mounting (if so equipped)	-	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	or every month

MFWE0BLF000601

2. Maintenance Schedule for Severe-Condition

Vehicles used under severe conditions need more frequent maintenance than ordinary use.

A: Trailer driving
B. Operations involving frequent starts and stops
C: Driving on rough, mountain, or uphill roads
D: Driving in dusty areas
E: Driving on snowy or coast roads

Item	Distance covered	Condition					
		A	B	C	D	E	B+E
Air cleaner element	Replace every 24,000 km (15,000 miles) or after 6th cleaning.				●		
Engine oil	Change every 10,000 km (6,000 miles).	●			●		●
Engine oil filter	Change every 10,000 km (6,000 miles).	●			●		●
Engine oil separator (4HK1 engine model)	Change every 10,000 km (6,000 miles).	●			●		●
Loose or otherwise improper installation of exhaust pipe	Inspect every 2,000 km (1,250 miles).	●	●	●		●	

Transmission oil	Replace every 24,000 km (15,000 miles).	●		●			
Clutch fluid (Manual transmission models)	Change every 24,000 km (15,000 miles).		●				
Smoother clutch oil (Models equipped with Smoother)	Change every 24,000 km (15,000 miles).	●		●			
Worn propeller shaft universal joints and splines	Inspect every 24,000 km (15,000 miles).			●			
Rear axle differential gear oil (Models equipped with ISUZU produced axle)	Change every 24,000 km (15,000 miles).	●		●			
Leaf spring U-bolt nuts	Tighten to the specified torque every 24,000 km (15,000 miles).			●			
Air suspension beam bolt nuts/U-bolt nuts (Air suspension models)	Tighten to the specified torque every 24,000 km (15,000 miles).			●			
Damaged, loose or excessive play of power steering joints	Inspect every 2,500 km (1,500 miles).			●			
Brake lining wear	Inspect every 2,500 km (1,500 miles).	●	●	●	●		
Brake drum wear or damage	Inspect every 20,000 km (12,000 miles).	●	●	●	●		
Brake disc wear or damage (Models equipped with disc brakes)	Inspect every 20,000 km (12,000 miles) or every 6 months.	●	●	●	●		

Copyright ISUZU MOTORS LIMITED. All rights reserved.