Maintenance Schedule

1. Maintenance Schedule

When inspecting the following items, also inspect regular inspection items.

Abbreviations used:
I: Inspect then clean, adjust, repair, or replace as necessary
A: Adjust
R: Replace
T: Tighten to the specified torque
L: Lubricate

- [V] : Market-/type-specific equipment (Your vehicle may not have the equipment with this symbol.)
- [M/T] : Manual transmission vehicle
- [A/T] : Automatic transmission vehicle
- [SA] : Vehicle equipped with the Smoother system
- [AHB] : Vehicle equipped with the air-over hydraulic brake system
- [FAB] : Vehicle equipped with the full-air brake system
- [ISZ] : Vehicle equipped with Isuzu production transmission or axle
- [MER] : Vehicle equipped with Meritor production axle

1. For Italy, Israel, Portugal, United Kingdom, Ireland (4HK1 Engine Model)

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	20	40	60	80	100	120	140	160		
x1,000 miles	12	24	37	49	62	75	87	99		
ENGINE										
Engine oil	*2 When "engine oil and filter indicator light" is displayed on the multi-information display: R									X
Engine oil (main and partial) filter	*2 When "engine oil and filter indicator light" is displayed on the multi-information display: R									X
Fuel filter (engine-side and chassis-side)	*2 When "fuel filter indicator light" is displayed on the multi-information display: R									-
Air cleaner element	*2 When "air cleaner inspection indicator light" is displayed on the multi-information display: I									-
Damage to fan belt	Every 12 months: I									-
Engine coolant	Every 12 months: I Every 24 months: R (when Isuzu recommended coolant is used)									-
Radiator cap function, cooling circuit and radiator	Every 24 months: I									-
Oil separator element	Every 12 months: R									-
Fuel hose	Every 48 months: R									-
Leaks from, damage to, or loose connection of fuel hose or pipe	Every 12 months: I									-
Leaks from, damage to, or loose connection of radiator hose	Every 12 months: I									-
EXHAUST SYSTEM										
AdBlue® filter (4HK1-TCH engine model)	Every 80,000 km (50,000 miles): R									X
DPD exhaust pressure check or filter cleaning	-	-	-	-	I	-	-	-	or every 12 months	-
DPD differential pressure sensor rubber hose	-	I	-	I	-	I	-	I	or every 12 months	-
PM sensor	Every 240,000 km (149,000 miles): R									-

MFWP00LF000101

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	20	40	60	80	100	120	140	160		
x1,000 miles	12	24	37	49	62	75	87	99		
Leaks from, damage to, or loose connection of SCR hose or tube	Every 12 months: I									-
Nitrogen oxides (NOx) sensor	Every 280,000 km (174,000 miles): R									-
BRAKE										
Brake fluid	I	R	I	R	I	R	I	R	or every 12 months	-
Brake drum wear or damage	-	I	-	I	-	I	-	I	or every 12 months	X
Leaks from, damage to, or loose connection of brake hose or pipe	I	I	I	I	I	I	I	I	or every 12 months	-
Function of parking brake control valve system	I	I	I	I	I	I	I	I	or every 12 months	-
Loose parking brake system mounting	I	I	I	I	I	I	I	I	or every 12 months	-
Rubber parts of brake valve, relay valve, parking brake valve, quick release valve, reducing valve, double check valve, multi-protection valve, AIR MASTER, TCV, HSA valve	Every 24 months: R									-
ABS modulator	Every 24 months: R									-
Brake booster exhaust cover	I	I	I	I	I	I	I	I	or every 12 months	-
Brake chamber piggy-bag	Every 36 months: R									-
Brake chamber rod stroke	I	I	I	I	I	I	I	I	or every 12 months	-
Brake expander	Every 12 months: I Every 36 months: overhaul									-
Brake hose	-	-	-	R	-	-	-	R	or every 24 months	-
Brake lining wear	I	I	I	I	I	I	I	I	or every 12 months	X
Brake valve, EPM-1ch, EPM-2ch	Every 10 years: R									-
Damaged or loosely connected rod or cable	I	I	I	I	I	I	I	I	or every 12 months	-

MFWS00LF000301

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	20	40	60	80	100	120	140	160		
x1,000 miles	12	24	37	49	62	75	87	99		
Desiccant, filter and rubber parts of air dryer	-	-	-	R	-	-	-	R	or every 12 months	-
Electronic hydraulic control unit (EHCU)	Every 10 years: R									-
Function of brake chamber, brake valve and relay valve	-	I	-	I	-	I	-	I	or every 12 months	-
Proportional valve	Every 24 months: R									-
Rubber parts of brake chamber	Every 12 months: I Every 24 months: R									-
Rubber parts of wheel cylinder	Every 12 months: R									-
Resin parts of relay valve with double check valve	Every 24 months: R									-
TRANSMISSION/CLUTCH										
Transmission oil (MZW models)*3	I	R	I	R	I	R	I	R	or every 12 months: R	X
[SA] Smoother clutch oil	-	R	-	R	-	R	-	R	or every 12 months	X
Leak from, damage to, or loose connection of transmission fluid cooling system hose or pipe	Every 12 months: I									-
Transmission fluid cooling system hose	Every 48 months: R									-
[M/T] Clutch fluid	I	R	I	R	I	R	I	R	or every 12 months: R	X
Clutch booster exhaust cover	I	I	I	I	I	I	I	I	or every 12 months	-
Clutch hose	Every 48 months: R									-
Leaks from, damage to, or loose connection of clutch hose or pipe	Every 12 months: I									-
Rubber parts and gaskets of clutch booster	Every 48 months: R									-
Clutch system function	I	I	I	I	I	I	I	I	or every 12 months	-
DRIVELINE/AXLE/TIRE										
Rear axle differential gear oil	I	R	I	R	I	R	I	R	or every 12 months: R	X

MFWP00LF000301

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	20	40	60	80	100	120	140	160		
x1,000 miles	12	24	37	49	62	75	87	99		
Damaged or distorted axle case (front and rear)	-	-	I	-	-	I	-	-	or every 12 months	-
Propeller shaft universal joint and spline wear	-	I	-	I	-	I	-	I	or every 12 months	X
Loose propeller shaft joints, propeller shaft bearings, and other related components (both at the front and rear)	Every 12 months: I									-
Loose king pin	Every 12 months: I									-
Wheel nuts and wheel bolts	T	T	T	T	T	T	T	T	or every 12 months	-
Front and rear wheel hub bearing grease	-	-	-	R	-	-	-	R	or every 12 months	-
Loose front and rear wheel hub bearings	-	-	I	-	-	I	-	-	or every 12 months	-
Disc wheel damage	I	I	I	I	I	I	I	I	or every 12 months	-
Foreign object in wheels	I	I	I	I	I	I	I	I	or every 12 months	-
STEERING										
Leaks from, damage to, or loose connection of power steering hose or pipe	Every 12 months: I									-
Power steering fluid	I	R	I	R	I	R	I	R	or every 12 months: R	-
Power steering fluid filter	-	-	I	-	-	I	-	-	or every 12 months	-
Loose power steering system mounting	I	I	I	I	I	I	I	I	or every 12 months	-
Excessive play in power steering bearing	-	-	I	-	-	I	-	-	or every 12 months	-
Power steering hose	Every 48 months: R									-
Damage to loose or excessive play in power steering joints and tie rod	I	I	I	I	I	I	I	I	or every 12 months	X
SUSPENSION										
Shock absorber mounting looseness	-	I	-	I	-	I	-	I	or every 12 months	-
Loose or damaged leaf spring mounting	-	I	-	I	-	I	-	I	or every 12 months	-

MFWP00LF000401

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	20	40	60	80	100	120	140	160		
x1,000 miles	12	24	37	49	62	75	87	99		
Loose or damaged air suspension mounting	I	I	I	I	I	I	I	I	or every 12 months	-
Air suspension's beam bolt nuts	-	-	T	-	-	T	-	-	or every 12 months	X
Function of height sensor or leveling valve	-	I	-	I	-	I	-	I	or every 12 months	-
Leaf spring U-bolt nuts	-	-	T	-	-	T	-	-	or every 12 months	X
Loose or damaged V-rod	I	I	I	I	I	I	I	I	or every 12 months	-
Oil leaks from or damage to shock absorbers	-	I	-	I	-	I	-	I	or every 12 months	-
Spring leaves for misalignment	-	I	-	I	-	I	-	I	or every 12 months	-
Uneven suspension due to leaf spring fatigue	-	-	I	-	-	I	-	-	or every 12 months	-
Air leaks from air suspension	I	I	I	I	I	I	I	I	or every 12 months	-
AIR CONDITIONER										
Air conditioner blower filter	Every 12 months: I									-
OTHER										
Electro-hydraulic cab tilt pump oil	-	I	-	I	-	I	-	I	or every 12 months	-
Electro-hydraulic cab tilt pump oil	Every 24 months: R									-
Function of cab tilt system	-	-	I	-	-	I	-	-	or every 12 months	-

MFWP00MF000301

Note:

- ***1 Your vehicle needs to be maintained more often if it is driven in severe conditions.**
- ***2 The illumination timing depends on the usage of the vehicle.**
- ***3 Change the transmission oil for the first time after driving initial 5,000 km (3,000 miles).**

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km x1,000 miles	20 12	40 24	60 37	80 49	100 62	120 75	140 87	160 99		
Drag link (not required for types without grease fittings)	L	L	L	L	L	L	L	L	or every 12 months	-
Clutch booster joint pin	Every 5,000 km (3,000 miles): L									-
Propeller shaft universal joints and sliding sleeves	Every 5,000 km (3,000 miles): L									-
Steering shaft sliding sleeve	Every 5,000 km (3,000 miles): L									-
Front spring pins and shackles	Every 5,000 km (3,000 miles): L									-
Rear spring shackle pins or rear spring sliding shackles	Every 5,000 km (3,000 miles): L									-
King pin	Every 5,000 km (3,000 miles): L									-
Tie rod ends	Every 5,000 km (3,000 miles): L									-
Cab mounting	L	L	L	L	L	L	L	L	or every 12 months	-

MFWP00MF000401

2. For Australia and New Zealand (4HK1 Engine Model)

1) When fuel consumption is 18.2 L/100 km or more (less than 5.5 km/L)

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	20	40	60	80	100	120	140	160		
x1,000 miles	12	24	37	49	62	75	87	99		
ENGINE										
Valve clearance	Every 12 months: I									-
Engine oil	R	R	R	R	R	R	R	R	or every 12 months	X
Engine oil (main and partial) filter	R	R	R	R	R	R	R	R	or every 12 months	X
Fuel filter (engine-side and chassis-side)	-	R	-	R	-	R	-	R	or every 12 months	X
Air cleaner element	*2 When "air cleaner inspection indicator light" is displayed on the multi-information display: I									-
Damage to fan belt	Every 12 months: I									-
Engine coolant	Every 12 months: I Every 24 months: R (when Isuzu recommended coolant is used)									-
Radiator cap function, cooling circuit and radiator	Every 24 months: I									-
Oil separator element	R	R	R	R	R	R	R	R	or every 12 months	-
Fuel hose	Every 48 months: R									-
Leaks from, damage to, or loose connection of fuel hose or pipe	Every 12 months: I									-
Leaks from, damage to, or loose connection of radiator hose	Every 12 months: I									-
EXHAUST SYSTEM										
AdBlue® filter (4HK1-TCH engine model)	Every 180,000 km (111,000 miles): R									X
AdBlue® filter (4HK1-TCS engine model)	Every 280,000 km (173,000 miles): R									X

MFWS0BLF006701

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	20	40	60	80	100	120	140	160		
x1,000 miles	12	24	37	49	62	75	87	99		
DPD exhaust pressure check or filter cleaning	-	-	-	-	-	I	-	-	or every 12 months	-
DPD differential pressure sensor rubber hose	-	I	-	I	-	I	-	I	or every 12 months	-
PM sensor	Every 240,000 km (149,000 miles): R									-
Leaks from, damage to, or loose connection of SCR hose or tube	Every 12 months: I									-
Nitrogen oxides (NOx) sensor	Every 300,000 km (185,000 miles): R									-
BRAKE										
Brake fluid	I	R	I	R	I	R	I	R	or every 12 months	-
Brake drum wear or damage	-	I	-	I	-	I	-	I	or every 12 months	X
Leaks from, damage to, or loose connection of brake hose or pipe	I	I	I	I	I	I	I	I	or every 12 months	-
Function of parking brake control valve system	I	I	I	I	I	I	I	I	or every 12 months	-
Loose parking brake system mounting	I	I	I	I	I	I	I	I	or every 12 months	-
Rubber parts of brake valve, relay valve, parking brake valve, quick release valve, reducing valve, double check valve, multi-protection valve, AIR MASTER, TCV, HSA valve	Every 24 months: R									-
ABS modulator	Every 24 months: R									-
Brake booster exhaust cover	I	I	I	I	I	I	I	I	or every 12 months	-
Brake chamber piggy-bag	Every 36 months: R									-
Brake chamber rod stroke	I	I	I	I	I	I	I	I	or every 12 months	-
Brake expander	Every 12 months: I Every 36 months: overhaul									-
Brake hose	-	-	R	-	-	R	-	-	or every 48 months	-
Brake lining wear	I	I	I	I	I	I	I	I	or every 12 months	X

MFWS0BLF006801

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	20	40	60	80	100	120	140	160		
x1,000 miles	12	24	37	49	62	75	87	99		
Brake valve, EPM-1ch, EPM-2ch	Every 10 years: R									-
Damaged or loosely connected rod or cable	I	I	I	I	I	I	I	I	or every 12 months	-
Desiccant, filter and rubber parts of air dryer	-	-	-	-	R	-	-	-	or every 12 months	-
Electronic hydraulic control unit (EHCU)	Every 10 years: R									-
Function of brake chamber, brake valve and relay valve	-	I	-	I	-	I	-	I	or every 12 months	-
Proportional valve	Every 24 months: R									-
Rubber parts of brake chamber	Every 12 months: I Every 24 months: R									-
Rubber parts of wheel cylinder	Every 12 months: R									-
Resin parts of relay valve with double check valve	Every 24 months: R									-
TRANSMISSION/CLUTCH										
Transmission oil (MZW model)*3	I	R	I	R	I	R	I	R	or every 12 months: R	X
[SA] Smoother clutch oil	-	R	-	R	-	R	-	R	or every 12 months	X
Leak from, damage to, or loose connection of transmission fluid cooling system hose or pipe	Every 12 months: I									-
Transmission fluid cooling system hose	Every 48 months: R									-
Leak from, damage to, or loose connection of transfer cooling system hose or pipe (FSS model)	Every 12 months: I									-
Transfer cooling system hose (FSS model)	Every 48 months: R									-
Transfer gear case oil (FSS model)	I	R	I	R	I	R	I	R	or every 12 months	X
[M/T] Clutch fluid	I	R	I	R	I	R	I	R	or every 12 months: R	X
Clutch booster exhaust cover	I	I	I	I	I	I	I	I	or every 12 months	-

MFWS0BLF006901

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	20	40	60	80	100	120	140	160		
x1,000 miles	12	24	37	49	62	75	87	99		
Clutch hose	Every 48 months: R									-
Leaks from, damage to, or loose connection of clutch hose or pipe	Every 12 months: I									-
Rubber parts and gaskets of clutch booster	Every 48 months: R									-
Clutch system function	I	I	I	I	I	I	I	I	or every 12 months	-
DRIVELINE/AXLE/TIRE										
Differential gear oil (rear axle and/or front axle)	I	R	I	R	I	R	I	R	or every 12 months	X
Damaged or distorted axle case (front and rear)	-	-	I	-	-	I	-	-	or every 12 months	-
Propeller shaft universal joint and spline wear	-	I	-	I	-	I	-	I	or every 12 months	X
Loose propeller shaft joints, propeller shaft bearings, and other related components (both at the front and rear)	Every 12 months: I									-
Loose king pin	Every 12 months: I									-
Wheel nuts and wheel bolts	T	T	T	T	T	T	T	T	or every 12 months	-
Front and rear wheel hub bearing grease	-	-	R	-	-	R	-	-	or every 12 months	-
Loose front and rear wheel hub bearings	-	-	I	-	-	I	-	-	or every 12 months	-
Disc wheel damage	I	I	I	I	I	I	I	I	or every 12 months	-
Foreign object in wheels	I	I	I	I	I	I	I	I	or every 12 months	-
STEERING										
Leaks from, damage to, or loose connection of power steering hose or pipe	Every 12 months: I									-
Power steering fluid	I	R	I	R	I	R	I	R	or every 12 months: R	-
Power steering fluid filter	-	I	-	I	-	I	-	I	or every 12 months	-

MFWS0BLF007001

	Service interval								Odometer reading or months, whichever comes first	Severe*1
x1,000 km	20	40	60	80	100	120	140	160		
x1,000 miles	12	24	37	49	62	75	87	99		
Loose power steering system mounting	I	I	I	I	I	I	I	I	or every 12 months	-
Excessive play in power steering bearing	-	I	-	I	-	I	-	I	or every 12 months	-
Power steering hose	Every 48 months: R									-
Damage to loose or excessive play in power steering joints and tie rod	I	I	I	I	I	I	I	I	or every 12 months	X
SUSPENSION										
Shock absorber mounting looseness	I	I	I	I	I	I	I	I	or every 12 months	-
Loose or damaged air suspension main support member	-	I	-	I	-	I	-	I	or every 12 months	-
Loose or damaged leaf spring mounting	I	I	I	I	I	I	I	I	or every 12 months	-
Loose or damaged air suspension mounting	I	I	I	I	I	I	I	I	or every 12 months	-
Air suspension's beam bolt nuts	-	T	-	T	-	T	-	T	or every 12 months	X
Function of height sensor or leveling valve	-	I	-	I	-	I	-	I	or every 12 months	-
Leaf spring U-bolt nuts	-	T	-	T	-	T	-	T	or every 12 months	X
Loose or damaged V-rod	I	I	I	I	I	I	I	I	or every 12 months	-
Spring leaves for misalignment	I	I	I	I	I	I	I	I	or every 12 months	-
Uneven suspension due to leaf spring fatigue	-	I	-	I	-	I	-	I	or every 12 months	-
Oil leaks from or damage to shock absorbers	I	I	I	I	I	I	I	I	or every 12 months	-
Rear shock absorber pin nuts (only hendrickson air suspension)	T	T	T	T	T	T	T	T	or every 12 months	-
Loose or damaged torque rod and traverse rod	-	I	-	I	-	I	-	I	or every 12 months	-
Air leaks from air suspension	I	I	I	I	I	I	I	I	or every 12 months	-

MFWS0BLF007101

	Service interval								Odometer reading or months, whichever comes first	Severe*1
x1,000 km	20	40	60	80	100	120	140	160		
x1,000 miles	12	24	37	49	62	75	87	99		
AIR CONDITIONER										
Air conditioner blower filter	Every 12 months: I									-
OTHER										
Electro-hydraulic cab tilt pump oil	-	I	-	I	-	I	-	I	or every 12 months	-
Electro-hydraulic cab tilt pump oil	Every 24 months: R									-
Function of cab tilt system	-	-	I	-	-	I	-	-	or every 12 months	-

MFWS0BSF002701

Note:

- ***1 Your vehicle needs to be maintained more often if it is driven in severe conditions.**
- ***2 The illumination timing depends on the usage of the vehicle.**
- ***3 Change the transmission oil for the first time after driving initial 5,000 km (3,000 miles).**

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	20	40	60	80	100	120	140	160		
x1,000 miles	12	24	37	49	62	75	87	99		
Drag link (not required for types without grease fittings)	L	L	L	L	L	L	L	L	or every 12 months	-
Clutch booster joint pin	Every 5,000 km (3,000 miles): L									-
Propeller shaft universal joints and sliding sleeves	Every 5,000 km (3,000 miles): L									-
Steering shaft sliding sleeve	Every 5,000 km (3,000 miles): L									-
Front spring pins and shackles	Every 5,000 km (3,000 miles): L									-
Rear spring shackle pins or rear spring sliding shackles	Every 5,000 km (3,000 miles): L									-
King pin	Every 5,000 km (3,000 miles): L									-
Tie rod ends	Every 5,000 km (3,000 miles): L									-
Cab mounting	L	L	L	L	L	L	L	L	or every 12 months	-

MFWP00SF000401

2) When fuel consumption is less than 18.2 L/100 km (5.5 km/L or more)

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	30	60	90	120	150	180	210	240		
x1,000 miles	18	37	55	74	93	111	130	149		
ENGINE										
Valve clearance	Every 12 months: I									-
Engine oil	R	R	R	R	R	R	R	R	or every 12 months	X
Engine oil (main and partial) filter	R	R	R	R	R	R	R	R	or every 12 months	X
Fuel filter (engine-side and chassis-side)	R	R	R	R	R	R	R	R	or every 12 months	X
Air cleaner element	*2 When "air cleaner inspection indicator light" is displayed on the multi-information display: I									-
Damage to fan belt	Every 12 months: I									-
Engine coolant	Every 12 months: I Every 24 months: R (when Isuzu recommended coolant is used)									-
Radiator cap function, cooling circuit and radiator	Every 24 months: I									-
Oil separator element	R	R	R	R	R	R	R	R	or every 12 months	-
Fuel hose	Every 48 months: R									-
Leaks from, damage to, or loose connection of fuel hose or pipe	Every 12 months: I									-
Leaks from, damage to, or loose connection of radiator hose	Every 12 months: I									-
EXHAUST SYSTEM										
AdBlue® filter (4HK1-TCH engine model)	-	-	-	-	-	R	-	-	-	X
AdBlue® filter (4HK1-TCS engine model)	Every 270,000 km (167,000 miles): R									X
DPD exhaust pressure check or filter cleaning	-	-	-	I	-	-	-	I	or every 12 months	-
DPD differential pressure sensor rubber hose	I	I	I	I	I	I	I	I	or every 12 months	-

MFWS0BLF007201

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	30	60	90	120	150	180	210	240		
x1,000 miles	18	37	55	74	93	111	130	149		
PM sensor	Every 240,000 km (149,000 miles): R									-
Leaks from, damage to, or loose connection of SCR hose or tube	Every 12 months: I									-
Nitrogen oxides (NOx) sensor	Every 300,000 km (185,000 miles): R									-
BRAKE										
Brake fluid	I	R	I	R	I	R	I	R	or every 12 months	-
Brake drum wear or damage	-	I	-	I	-	I	-	I	or every 12 months	X
Leaks from, damage to, or loose connection of brake hose or pipe	I	I	I	I	I	I	I	I	or every 12 months	-
Function of parking brake control valve system	I	I	I	I	I	I	I	I	or every 12 months	-
Loose parking brake system mounting	I	I	I	I	I	I	I	I	or every 12 months	-
Rubber parts of brake valve, relay valve, parking brake valve, quick release valve, reducing valve, double check valve, multi-protection valve, AIR MASTER, TCV, HSA valve	Every 24 months: R									-
ABS modulator	Every 24 months: R									-
Brake booster exhaust cover	I	I	I	I	I	I	I	I	or every 12 months	-
Brake chamber piggy-bag	Every 36 months: R									-
Brake chamber rod stroke	I	I	I	I	I	I	I	I	or every 12 months	-
Brake expander	Every 12 months: I Every 36 months: overhaul									-
Brake hose	-	R	-	R	-	R	-	R	or every 48 months	-
Brake lining wear	I	I	I	I	I	I	I	I	or every 12 months	X
Brake valve, EPM-1ch, EPM-2ch	Every 10 years: R									-
Damaged or loosely connected rod or cable	I	I	I	I	I	I	I	I	or every 12 months	-

MFWS0BLF007301

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	30	60	90	120	150	180	210	240		
x1,000 miles	18	37	55	74	93	111	130	149		
Desiccant, filter and rubber parts of air dryer	-	-	R	-	-	R	-	-	or every 12 months	-
Electronic hydraulic control unit (EHCU)	Every 10 years: R									-
Function of brake chamber, brake valve and relay valve	-	I	-	I	-	I	-	I	or every 12 months	-
Proportional valve	Every 24 months: R									-
Rubber parts of brake chamber	Every 12 months: I Every 24 months: R									-
Rubber parts of wheel cylinder	Every 12 months: R									-
Resin parts of relay valve with double check valve	Every 24 months: R									-
TRANSMISSION/CLUTCH										
Transmission oil (MZW model)*3	I	R	I	R	I	R	I	R	or every 12 months: R	X
[SA] Smoother clutch oil	-	R	-	R	-	R	-	R	or every 12 months	X
Leak from, damage to, or loose connection of transmission fluid cooling system hose or pipe	Every 12 months: I									-
Transmission fluid cooling system hose	Every 48 months: R									-
Leak from, damage to, or loose connection of transfer cooling system hose or pipe (FSS model)	Every 12 months: I									-
Transfer cooling system hose (FSS model)	Every 48 months: R									-
Transfer gear case oil (FSS model)	I	R	I	R	I	R	I	R	or every 12 months	X
[M/T] Clutch fluid	I	R	I	R	I	R	I	R	or every 12 months: R	X
Clutch booster exhaust cover	I	I	I	I	I	I	I	I	or every 12 months	-
Clutch hose	Every 48 months: R									-
Leaks from, damage to, or loose connection of clutch hose or pipe	Every 12 months: I									-

MFWS0BLF007401

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	30	60	90	120	150	180	210	240		
x1,000 miles	18	37	55	74	93	111	130	149		
Rubber parts and gaskets of clutch booster	Every 48 months: R									-
Clutch system function	I	I	I	I	I	I	I	I	or every 12 months	-
DRIVELINE/AXLE/TIRE										
Differential gear oil (rear axle and/or front axle)	I	R	I	R	I	R	I	R	or every 12 months	X
Damaged or distorted axle case (front and rear)	-	I	-	I	-	I	-	I	or every 12 months	-
Propeller shaft universal joint and spline wear	-	I	-	I	-	I	-	I	or every 12 months	X
Loose propeller shaft joints, propeller shaft bearings, and other related components (both at the front and rear)	Every 12 months: I									-
Loose king pin	Every 12 months: I									-
Wheel nuts and wheel bolts	T	T	T	T	T	T	T	T	or every 12 months	-
Front and rear wheel hub bearing grease	-	R	-	R	-	R	-	R	or every 12 months	-
Loose front and rear wheel hub bearings	-	I	-	I	-	I	-	I	or every 12 months	-
Disc wheel damage	I	I	I	I	I	I	I	I	or every 12 months	-
Foreign object in wheels	I	I	I	I	I	I	I	I	or every 12 months	-
STEERING										
Leaks from, damage to, or loose connection of power steering hose or pipe	Every 12 months: I									-
Power steering fluid	I	R	I	R	I	R	I	R	or every 12 months: R	-
Power steering fluid filter	-	I	-	I	-	I	-	I	or every 12 months	-
Loose power steering system mounting	I	I	I	I	I	I	I	I	or every 12 months	-
Excessive play in power steering bearing	-	I	-	I	-	I	-	I	or every 12 months	-
Power steering hose	Every 48 months: R									-

MFWS0BLF007501

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	30	60	90	120	150	180	210	240		
x1,000 miles	18	37	55	74	93	111	130	149		
Damage to loose or excessive play in power steering joints and tie rod	I	I	I	I	I	I	I	I	or every 12 months	X
SUSPENSION										
Shock absorber mounting looseness	I	I	I	I	I	I	I	I	or every 12 months	-
Loose or damaged air suspension main support member	-	I	-	I	-	I	-	I	or every 12 months	-
Loose or damaged leaf spring mounting	I	I	I	I	I	I	I	I	or every 12 months	-
Loose or damaged air suspension mounting	I	I	I	I	I	I	I	I	or every 12 months	-
Air suspension's beam bolt nuts	-	T	-	T	-	T	-	T	or every 12 months	X
Function of height sensor or leveling valve	-	I	-	I	-	I	-	I	or every 12 months	-
Leaf spring U-bolt nuts	-	T	-	T	-	T	-	T	or every 12 months	X
Loose or damaged V-rod	I	I	I	I	I	I	I	I	or every 12 months	-
Spring leaves for misalignment	I	I	I	I	I	I	I	I	or every 12 months	-
Uneven suspension due to leaf spring fatigue	-	I	-	I	-	I	-	I	or every 12 months	-
Oil leaks from or damage to shock absorbers	I	I	I	I	I	I	I	I	or every 12 months	-
Rear shock absorber pin nuts (only hendrickson air suspension)	T	T	T	T	T	T	T	T	or every 12 months	-
Loose or damaged torque rod and traverse rod	-	I	-	I	-	I	-	I	or every 12 months	-
Air leaks from air suspension	I	I	I	I	I	I	I	I	or every 12 months	-
AIR CONDITIONER										
Air conditioner blower filter	Every 12 months: I									-

MFWS0BLF007601

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	30	60	90	120	150	180	210	240		
x1,000 miles	18	37	55	74	93	111	130	149		
OTHER										
Electro-hydraulic cab tilt pump oil	-	I	-	I	-	I	-	I	or every 12 months	-
Electro-hydraulic cab tilt pump oil	Every 24 months: R									-
Function of cab tilt system	-	I	-	I	-	I	-	I	or every 12 months	-

MFWS0BSF002801

Note:

- ***1 Your vehicle needs to be maintained more often if it is driven in severe conditions.**
- ***2 The illumination timing depends on the usage of the vehicle.**
- ***3 Change the transmission oil for the first time after driving initial 5,000 km (3,000 miles).**

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	30	60	90	120	150	180	210	240		
x1,000 miles	18	37	55	74	93	111	130	149		
Drag link (not required for types without grease fittings)	L	L	L	L	L	L	L	L	or every 12 months	-
Clutch booster joint pin	Every 5,000 km (3,000 miles): L									-
Propeller shaft universal joints and sliding sleeves	Every 5,000 km (3,000 miles): L									-
Steering shaft sliding sleeve	Every 5,000 km (3,000 miles): L									-
Front spring pins and shackles	Every 5,000 km (3,000 miles): L									-
Rear spring shackle pins or rear spring sliding shackles	Every 5,000 km (3,000 miles): L									-
King pin	Every 5,000 km (3,000 miles): L									-
Tie rod ends	Every 5,000 km (3,000 miles): L									-
Cab mounting	L	L	L	L	L	L	L	L	or every 12 months	-

MFWP00SF000501

3. For Australia and New Zealand (DB6A Engine Model)

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	25	50	75	100	125	150	175	200		
x1,000 miles	15	31	46	62	77	93	108	124		
ENGINE										
Valve clearance	-	I	-	I	-	I	-	I	or every 12 months	-
Air compressor, governor and unloader valve functions	I	I	I	I	I	I	I	I	or every 6 months	-
Engine oil	R	R	R	R	R	R	R	R	or every 6 months or every 1,000 hours	-
Engine oil filter	R	R	R	R	R	R	R	R	or every 6 months or every 1,000 hours	-
Fuel filter	R	R	R	R	R	R	R	R	or every 6 months or every 1,000 hours	-
Air cleaner element	Every 12 months or after 6th cleaning: R									-
Accessory drive belts	-	I	-	I	-	I	-	I	or every 12 months	-
Engine coolant	Every 12 months: I Every 24 months: R (when Isuzu recommended coolant is used)									-
Turbocharger to air duct connection and gasket	I	I	I	I	I	I	I	I	or every 6 months	-
Radiator cap function, cooling circuit and radiator	Every 24 months: I									-
Fuel hose	Every 48 months: R									-
Cooling fan belt tensioner	-	I	-	I	-	I	-	I	or every 12 months	-
Leaks from, damage to, or loose connection of fuel hose or pipe	Every 6 months: I									-
Leaks from, damage to, or loose connection of radiator hose	Every 12 months: I									-

MFWS0BLF007701

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	25	50	75	100	125	150	175	200		
x1,000 miles	15	31	46	62	77	93	108	124		
EXHAUST SYSTEM										
Damage to or looseness of the exhaust pipe, exhaust throttle, silencer, and their mountings	I	I	I	I	I	I	I	I	or every 6 months	X
Leaks from, damage to, or loose connection of SCR hose or tube	Every 6 months: I									-
AdBlue® filter	Every 175,000 km (108,000 miles):R									-
DPD differential pressure sensor rubber hose	I	I	I	I	I	I	I	I	or every 12 months	-
BRAKE										
Brake fluid	I	R	I	R	I	R	I	R	or every 6 months: I or every 12 months: R	-
Brake drum wear or damage	-	I	-	I	-	I	-	I	or every 12 months	X
Leaks from, damage to, or loose connection of brake hose or pipe	I	I	I	I	I	I	I	I	or every 6 months	-
Function of parking brake control valve system	I	I	I	I	I	I	I	I	or every 6 months	-
Rubber parts of brake valve, relay valve, parking brake valve, quick release valve, reducing valve, double check valve, multi-protection valve, AIR MASTER, TCV, HSA valve	Every 24 months: R									-
ABS modulator	Every 24 months: R									-
Brake booster exhaust cover	I	I	I	I	I	I	I	I	or every 12 months	-
Brake chamber piggy-bag	Every 36 months: R									-
Brake chamber (Disc brake type)	Every 36 months: R									-
Brake expander	Every 12 months: I Every 36 months: overhaul									-
Brake rotor for wear and damage	I	I	I	I	I	I	I	I	or every 6 months	X
Brake pad for wear	I	I	I	I	I	I	I	I	or every 6 months	X

MFWS0BLF007801

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	25	50	75	100	125	150	175	200		
x1,000 miles	15	31	46	62	77	93	108	124		
Brake hose	-	R	-	R	-	R	-	R	or every 24 months	-
Brake lining wear	I	I	I	I	I	I	I	I	or every 6 months	X
Brake valve, EPM-1ch, EPM-2ch	Every 10 years: R									-
Desiccant, filter and rubber parts of air dryer	-	-	-	R	-	-	-	R	or every 12 months	-
Function of brake chamber, brake valve and relay valve	-	I	-	I	-	I	-	I	or every 12 months	-
Rubber parts of brake chamber	Every 24 months: R									-
Rubber parts of wheel cylinder	Every 12 months: R									-
Resin parts of relay valve with double check valve	Every 24 months: R									-
Function and damage of brake disc caliper	I	I	I	I	I	I	I	I	or every 6 months	-
TRANSMISSION/CLUTCH										
[A/T][SA] Leak from, damage to, or loose connection of transmission fluid cooling system hose or pipe	Every 6 months: I									-
[A/T] Transmission fluid cooling system hose	Every 48 months: R									-
Transmission gear oil (MEB9 model)	-	R	-	R	-	R	-	R	or every 12 months	X
Transmission gear oil (ES-9306A model (oil spec; EATON PS-386))	Refer to the maintenance schedule of the ES-9306A model.									-
Transmission gear oil (ES-9306A model (oil spec; EATON PS-321))	Refer to the maintenance schedule of the ES-9306A model.									-
Transmission gear oil (ES-9306A model (oil spec; MTF Gear Oil API GL-4/ Engine Oil API-CD/ MIL-2104H/ CAT TO-4))	Refer to the maintenance schedule of the ES-9306A model.									-
[M/T] Clutch fluid	I	R	I	R	I	R	I	R	or every 6 months: I or every 12 months: R	X
Clutch booster exhaust cover	I	I	I	I	I	I	I	I	or every 6 months	-

MFWS0BLF007901

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	25	50	75	100	125	150	175	200		
x1,000 miles	15	31	46	62	77	93	108	124		
Clutch hose	Every 48 months: R									-
Leaks from, damage to, or loose connection of clutch hose or pipe	Every 6 months: I									-
Rubber parts and gaskets of clutch booster	Every 48 months: R									-
Transmission fluid (ALLISON2500 model (other than TES-295/668 licensed fluid))	Every 80,000 km (50,000 miles) or 2,000 hours or 24 months: R									X
Transmission fluid (ALLISON2500 model (TES-295/668 licensed fluid))	Every 240,000 km (150,000 miles) or 4,000 hours or 48 months: R									X
Transmission fluid (ALLISON3000/3500 models)	*2 When the service indicator is displayed on the shift selector display or every 60 months: R									-
Transmission internal filter (ALLISON2500 model)	Replace at overhaul.									-
Transmission internal filter (ALLISON3000/3500 models)	Replace at overhaul.									-
ATF filter (ALLISON2500 model (other than TES-295/668 licensed fluid))	Every 80,000 km (50,000 miles) or 2,000 hours or 24 months: R									X
ATF filter (ALLISON2500 model (TES-295/668 licensed fluid))	Every 80,000 km (50,000 miles) or 2,000 hours or 24 months: R									-
Transmission main filter (ALLISON3000/3500 models)	*2 When the service indicator is displayed on the shift selector display or every 60 months: R									-
Clutch system function	I	I	I	I	I	I	I	I	or every 6 months	-
Transmission Lube filter (ALLISON3000/3500 models)	*2 When the service indicator is displayed on the shift selector display or every 60 months: R									-
Transfer gear case oil (FTS model)	I	R	I	R	I	R	I	R	or every 6 months: I or every 12 months: R	X
DRIVELINE/AXLE/TIRE										
[ISZ] Differential gear oil (rear axle and/or front axle)	I	R	I	R	I	R	I	R	or every 6 months: I or every 12 months: R	X
[MER] Rear axle differential/Inter-differential gear oil	Refer to the maintenance schedule of the MS11/MP10/MR10 type axles.									-

MFWS0BLF008001

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	25	50	75	100	125	150	175	200		
x1,000 miles	15	31	46	62	77	93	108	124		
Damaged or distorted axle case (front and rear)	-	I	-	I	-	I	-	I	or every 12 months	-
Propeller shaft universal joint and spline wear	-	I	-	I	-	I	-	I	or every 12 months	X
Loose propeller shaft joints, propeller shaft bearings, and other related components (both at the front and rear)	Every 6 months: I									-
Knuckle-to-front axle clearance	-	I	-	I	-	I	-	I	or every 12 months	-
Wheel nuts and wheel bolts	T	T	T	T	T	T	T	T	or every 6 months	-
Wheel alignment	-	I	-	I	-	I	-	I	or every 12 months	-
Front and rear wheel hub bearing grease	-	R	-	R	-	R	-	R	or every 12 months	-
[MER] Front wheel hub bearing oil	Every 10,000 km (6,000 miles) or every 3 months: I Every 50,000 km (31,000 miles) or every 12 months: R *3									X
[MER] Rearward rear wheel hub bearing oil	Every 10,000 km (6,000 miles) or every 3 months: I Every 50,000 km (31,000 miles) or every 12 months: R *3									X
Loose front and rear wheel hub bearings	-	I	-	I	-	I	-	I	or every 12 months	-
Disc wheel damage	I	I	I	I	I	I	I	I	or every 6 months	-
Foreign object in wheels	I	I	I	I	I	I	I	I	or every 6 months	-
King pin-to-bearing clearance	-	I	-	I	-	I	-	I	or every 12 months	-
STEERING										
Leaks from, damage to, or loose connection of power steering hose or pipe	Every 6 months: I									-
Power steering fluid	I	R	I	R	I	R	I	R	or every 6 months: I or every 12 months: R	-
Power steering fluid filter	-	I	-	I	-	I	-	I	or every 12 months	-
Loose power steering system mounting	I	I	I	I	I	I	I	I	or every 6 months	-
Excessive play in power steering bearing	-	I	-	I	-	I	-	I	or every 12 months	-

MFWS0BLF008101

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	25	50	75	100	125	150	175	200		
x1,000 miles	15	31	46	62	77	93	108	124		
Power steering hose	Every 48 months: R									-
[ISZ] Damage to, loose or excessive play in power steering joints and tie rod	I	I	I	I	I	I	I	I	or every 6 months	X
[MER] Damage, loose or excessive play in tie rod ends	Refer to the maintenance schedule of the MFS73 type axle.									-
Steering angle range for right and left turns	-	I	-	I	-	I	-	I	or every 12 months	-
SUSPENSION										
Shock absorber mounting looseness	I	I	I	I	I	I	I	I	or every 6 months	-
Loose or damaged air suspension main support member	-	I	-	I	-	I	-	I	or every 12 months	-
Loose or damaged leaf spring mounting	I	I	I	I	I	I	I	I	or every 6 months	-
Loose or damaged air suspension mounting	I	I	I	I	I	I	I	I	or every 6 months	-
Air suspension's beam bolt nuts	-	T	-	T	-	T	-	T	or every 12 months	X
Function of height sensor or leveling valve	-	I	-	I	-	I	-	I	or every 12 months	-
Leaf spring U-bolt nuts	-	T	-	T	-	T	-	T	or every 12 months	X
Loose or damaged V-rod	I	I	I	I	I	I	I	I	or every 6 months	-
V-rod bush	Every 500,000 km (310,000 miles): R									-
Spring leaves for misalignment	I	I	I	I	I	I	I	I	or every 6 months	-
Uneven suspension due to leaf spring fatigue	-	I	-	I	-	I	-	I	or every 12 months	-
Oil leaks from or damage to shock absorbers	I	I	I	I	I	I	I	I	or every 6 months	-
Rear shock absorber pin nuts (only hendrickson air suspension)	T	T	T	T	T	T	T	T	or every 6 months	-
Loose or damaged torque rod and traverse rod	-	I	-	I	-	I	-	I	or every 12 months	-

MFWS0BLF008201

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	25	50	75	100	125	150	175	200		
x1,000 miles	15	31	46	62	77	93	108	124		
Looseness or damage to trunnion shaft rubber bushing and fixing (FVZ models, with leaf spring suspension)	-	I	-	I	-	I	-	I	or every 12 months	-
Air leaks from air suspension	I	I	I	I	I	I	I	I	or every 6 months	-
AIR CONDITIONER										
Air conditioner blower filter	Every 12 months: I									-
OTHER										
Electro-hydraulic cab tilt pump oil	-	I	-	I	-	I	-	I	or every 6 months	-
Electro-hydraulic cab tilt pump oil	Every 24 months: R									-
Function of cab tilt system	-	-	I	-	-	I	-	-	or every 12 months	-
Rear engine mount	Initial 500,000 km (310,000 miles) or 96 months: I Every 100,000 km (62,000 miles) or 12 months: I									-

MFWS0BMF003001

Note:

- ***1 Your vehicle needs to be maintained more often if it is driven in severe conditions.**
- ***2 The illumination timing depends on the usage of the vehicle.**
- ***3 Change the front/rear wheel hub bearing oil for the first time after driving initial 1,000 km (600 miles).**

Service interval									Odometer reading or months, whichever comes first
x1,000 km	25	50	75	100	125	150	175	200	
x1,000 miles	15	31	46	62	77	93	108	124	
Drag link (not required for types without grease fittings)	L	L	L	L	L	L	L	L	or every 6 months
Clutch shaft	Every 5,000 km (3,000 miles): L								
Clutch shift block	Every 5,000 km (3,000 miles): L								
Clutch booster joint pin	Every 5,000 km (3,000 miles): L								
Propeller shaft center bearing	-	L	-	L	-	L	-	L	or every 12 months
Propeller shaft universal joints and sliding sleeves	Every 5,000 km (3,000 miles): L								
Steering shaft sliding sleeve	Every 5,000 km (3,000 miles): L								
Front spring pins and shackles	Every 5,000 km (3,000 miles): L								
Rear spring shackle pins or rear spring sliding shackles	Every 5,000 km (3,000 miles): L								
[ISZ] King pins	Every 5,000 km (3,000 miles): L								
[MER] King pin and king pin bushing	Refer to page 8-33 for the maintenance schedule of the MFS73 type axle.								
[ISZ] Tie rod ends	L	L	L	L	L	L	L	L	or every 6 months
Rear spring pads (FVZ models, with leaf spring suspension)	Every 5,000 km (3,000 miles): L								
Cab mounting	L	L	L	L	L	L	L	L	or every 6 months

MFWS0BMF003201

2. Transmission Oil

1. Maintenance Schedule - ES-9306A Model Transmission

Carry out periodic maintenance on the transmission in order to maintain its original performance. It is particularly important to replace the transmission oil according to the Maintenance Schedule.
The Maintenance Schedule varies according to the type of oil used.

Oil Level Check

Service item	Stationary	Service interval
Check oil level and inspect for leakage	Line haul (on-highway)	Up to 20,000 km (12,000 miles)
	Vocational (off-highway)	50 hours
	Stationary	

Oil Change Interval

Product	GCW	Coolant Used	Service Interva	Lubricant Specification	SAE Viscosity Grade	Drain Interval
Manual Transmission	< 50 Ton	Yes/No	Extended	Eaton PS-386	N/A	400,000 km (248,000 miles)
			Standard	Eaton PS-321	N/A	120,000 km (74,000 miles)
				MTF Gear Oil API GL-4	SAE 80W90 SAE 75W90	100,000 km (62,000 miles)
				Engine Oil API-CD	SAE 50 SAE 40 SAE 30	
				MIL-2104H		

				CAT TO-4		

Note:

- **For a list of approved Extended Service Interval Lubricant Suppliers, visit www.Roadranger.com/Lubricants to download TCMT0020.**

3. Differential Oil

1. Maintenance Schedule for MS11/MP10/MR10/MFS73/RR4710 Type Axles

The differential gear of your vehicle can stay in good conditions through regular maintenance. Above all, make sure to replace the differential oil and filter element regularly in accordance with the specified maintenance schedule.

Check and replacement interval

Vocation or Vehicle Operation	Linehaul	City Delivery	Construction,Refuse, Yard Tractor,Logging, Heavy Haul, Mining, Oil Field, Rescue
Initial oil change	Initial oil change	Not required	Not required
Check Oil Level Add the correct type and amount of oil as required.	Every 40,000 km (25,000 miles) or the fleet maintenance interval, whichever comes first	Every 16,000 km (10,000 miles), once a month or the fleet maintenance interval, whichever comes first	Every 8,000 km (5,000 miles), once a month or the fleet maintenance interval, whichever comes first [1]
Petroleum-Based Oil Change on Axles	Every 160,000 km (100,000 miles) or annually, whichever comes first	Every 80,000 km (50,000 miles) or annually, whichever comes first	Every 40,000 km (25,000 miles) or annually, whichever comes first
Synthetic Oil Change on Axles [2]	Every 800,000 km (500,000 miles) or every 4 years, whichever comes first	Every 160,000 km (100,000 miles) or every 3 years, whichever comes first	Every 80,000 km (50,000 miles) or every 2 years, whichever comes first

[1] For continuous heavy-duty operation, check the oil level every 1,600 km (1,000 miles).

[2] These intervals apply to approved semi-synthetic and full-synthetic oils only.

Recommended oil

Type	API/MIL rating	SAE viscosity rating
Mineral oil (O-76A)	GL5/MIL-L-2105D	SAE 85W-140
Synthetic oil (O-76M)	GL5/MIL-L-2105D (if approved by the body anufacturer)	SAE 75W-140/75W-90

Wheel Hub Bearing Oil

Recommended oil

Meritor specification (Military)	Oil description	Outside temperature	
		Minimum	Maximum
O-76A gear oil (MIL-L-2105D)	GL-5, SAE 85W/140	-12°C (10°F)	None
O-76D gear oil (MIL-L-2105D)	GL-5, SAE 80W/90	-26°C (-15°F)	None
O-76E gear oil (MIL-L-2105D)	GL-5, SAE 75W/90	-40°C (-40°F)	None
O-76J gear oil (MIL-L-2105D)	GL-5, SAE 75W	-40°C (-40°F)	2°C (36°F)
	API -CD, -CE, -SF or -SG SAE 40 or 50	-12°C (10°F)	None

Heavy duty engine oil (MIL-L-2104-B, -C, -D or -E)			
Heavy duty engine oil (MIL-L-2104-B, -C, -D or -E)	API -CD, -CE, -SF or -SG SAE 30	-26°C (-15°F)	None

Front axle greasing

Check and replacement interval

Components	Intervals
King pin and king pin bushing	Every 80,000 km (50,000 miles) or every year

Recommended grease

Specifications	Meritor specifications	NLGI grade	Grease classification
Multipurpose type grease	0-617-A	1	6% lithium 12-hydroxyl stearic acid
	0-617-B	2	8% lithium 12-hydroxyl stearic acid

Tie rod ends

Vocational Groups

Group Number	Typical Vocations	Vehicle Build	Typical Operation Conditions
1. Light	On highway or turnpike, linehaul only	After July 1, 1996 Before July 1, 1996, use category 3	High mileage operation (more than 80,500 km (50,000 miles) per year) 95% on-highway/turnpike surface
2. Medium	Fire and rescue, city delivery, inner city coach, heavy haul, school bus, motor home, transit coach	After July 1, 1996 Before July 1, 1996, use category 3	Lower mileage operation (less than 80,500 km (50,000 miles) per year)
3. Harsh	Logging, oil field, construction, heavy haul, yard tractor (highway licensed), residential refuse	All	Low mileage operation (less than 40,250 km (25,000 miles) per year) Heavy duty service with substantial off - road operation
4. Severe	Mining, yard tractor (nonhighway licensed), and land fill refuse		Heavy-duty service
5. Very Severe	Mining, logging and construction		Severe duty 80 - 100% off highway

Inspection and Maintenance Schedule

Components		Service Intervals
Tie Rod Ends	Group 1 Vocations	Inspect every 80,500 km (50,000 miles) or 12 months
	Group 2 Vocations	Inspect every 32,200 km (20,000 miles)
	Group 3 Vocations	Inspect every 16,100 km (10,000 miles)
	Group 4 Vocations	Inspect every 8,050 km (5,000 miles) or 100 hours
	Group 5 Vocations	Inspect every 48 hours
	Group 1 Vocations	Inspect every 80,500 km (50,000 miles) or 12 months

Inspect the Tie Rod Assembly for Movement	Group 2 Vocations	Inspect every 32,200 km (20,000 miles)
	Group 3 Vocations	Inspect and lubricate every 16,100 km (10,000 miles)
	Group 4 Vocations	Inspect every 8,050 km (5,000 miles) or 100 hours
	Group 5 Vocations	Inspect every 48 hours

Note:

- **The type (characteristics) of the grease specified for use with a chassis component differs from that of the grease specified for use with another component. Be sure to use only the specified grease for each component and perform greasing according to the Maintenance Schedule.**
- **For points with the grease fittings, be sure to apply grease from the grease fittings.**
- **If mud, dust, or any other dirt adheres to the grease fittings, remove the dirt before lubricating.**

4. Maintenance Schedule for Severe-Condition

1. For Italy, Israel, Portugal, United Kingdom, Ireland (4HK1 Engine Model)

Driving condition
A: Operations involving frequent starts and stops
B: Driving on rough roads, mountain roads or uphill roads
C: Driving in dusty areas
D: Driving on snow-covered or seashore roads
E: Low travel distance high engine load (Ex. Concrete pump truck, electric power supply truck, fire truck)

Item	Distance covered	Condition
Engine oil	Replace every 10,000 km (6,000 miles)	C, A+D
	Replace every 500 hours	E
Engine oil (main and partial) filter	Replace every 10,000 km (6,000 miles)	C, A+D
	Replace every 500 hours	E
AdBlue® filter (4HK1-TCH engine model)	Replace every 4,000 hours	E
Brake drum wear or damage	Inspect every 20,000 km (12,000 miles)	A, B, C
Brake lining wear	Inspect every 2,500 km (1,500 miles)	A, B, C
Transmission oil (MZW models)	Replace every 20,000 km (12,000 miles)	B, C
[SA] Smoother clutch oil	Replace every 20,000 km (12,000 miles)	A, B, C
[M/T] Clutch fluid	Replace every 20,000 km (12,000 miles)	A
Rear axle differential gear oil	Replace every 30,000 km (18,000 miles)	B
Propeller shaft universal joint and spline wear	Inspect every 30,000 km (18,000 miles)	B
Damage to, loose or excessive play in power steering joints and tie rod	Inspect every 2,500 km (1,500 miles)	B
Air suspension's beam bolt nuts	Tighten every 20,000 km (12,000 miles)	B
Leaf spring U-bolt nuts	Tighten every 20,000 km (12,000 miles)	B

MFWP00MF000501

2. For Australia and New Zealand (4HK1 Engine Model)

1) When fuel consumption is 18.2 L/100 km or more (less than 5.5 km/L)

Driving condition
A: Operations involving frequent starts and stops
B: Driving on rough roads, mountain roads or uphill roads
C: Driving in dusty areas
D: Driving on snow-covered or seashore roads
E: Low travel distance high engine load (Ex. Concrete pump truck, electric power supply truck, fire truck)

Item	Distance covered	Condition
Engine oil	Replace every 10,000 km (6,000 miles)	C, A+D
	Replace every 500 hours	E
Engine oil (main and partial) filter	Replace every 10,000 km (6,000 miles)	C, A+D
	Replace every 1,000 hours	E
Fuel filter (engine-side and chassis-side)	Replace every 1,000 hours	E
AdBlue® filter (4HK1-TCH engine model)	Replace every 4,000 hours	E
AdBlue® filter (4HK1-TCS engine model)	Replace every 4,000 hours	E
Brake drum wear or damage	Inspect every 20,000 km (12,000 miles)	A, B, C
Brake lining wear	Inspect every 2,500 km (1,500 miles)	A, B, C
Transmission oil (MZW model)	Replace every 20,000 km (12,000 miles)	B, C
[SA] Smoother clutch oil	Replace every 20,000 km (12,000 miles)	A, B, C
Transfer gear case oil (FSS model)	Replace every 30,000 km (18,000 miles)	B
[M/T] Clutch fluid	Replace every 20,000 km (12,000 miles)	A
Differential gear oil (rear axle and/or front axle)	Replace every 30,000 km (18,000 miles)	B
Propeller shaft universal joint and spline wear	Inspect every 30,000 km (18,000 miles)	B

MFWS0BMF003301

Item	Distance covered	Condition
Damage to, loose or excessive play in power steering joints and tie rod	Inspect every 2,500 km (1,500 miles)	B
Air suspension's beam bolt nuts	Tighten every 20,000 km (12,000 miles)	B
Leaf spring U-bolt nuts	Tighten every 20,000 km (12,000 miles)	B

MFWS0BSF003001

2) When fuel consumption is less than 18.2 L/100 km (5.5 km/L or more)

Driving condition
A: Operations involving frequent starts and stops
B: Driving on rough roads, mountain roads or uphill roads
C: Driving in dusty areas
D: Driving on snow-covered or seashore roads
E: Low travel distance high engine load (Ex. Concrete pump truck, electric power supply truck, fire truck)

Item	Distance covered	Condition
Engine oil	Replace every 10,000 km (6,000 miles)	C, A+D
	Replace every 500 hours	E
Engine oil (main and partial) filter	Replace every 10,000 km (6,000 miles)	C, A+D
	Replace every 1,000 hours	E
Fuel filter (engine-side and chassis-side)	Replace every 1,000 hours	E
AdBlue® filter (4HK1-TCH engine model)	Replace every 4,000 hours	E
AdBlue® filter (4HK1-TCS engine model)	Replace every 4,000 hours	E
Brake drum wear or damage	Inspect every 20,000 km (12,000 miles)	A, B, C
Brake lining wear	Inspect every 2,500 km (1,500 miles)	A, B, C
Transmission oil (MZW model)	Replace every 20,000 km (12,000 miles)	B, C
[SA] Smoother clutch oil	Replace every 20,000 km (12,000 miles)	A, B, C,
Transfer gear case oil (FSS model)	Replace every 30,000 km (18,000 miles)	B
[M/T] Clutch fluid	Replace every 20,000 km (12,000 miles)	A
Differential gear oil (rear axle and/or front axle)	Replace every 30,000 km (18,000 miles)	B
Propeller shaft universal joint and spline wear	Inspect every 30,000 km (18,000 miles)	B
Damage to, loose or excessive play in power steering joints	Inspect every 2,500 km (1,500 miles)	B
Air suspension's beam bolt nuts	Tighten every 20,000 km (12,000 miles)	B

MFWS0BMF003401

Item	Distance covered	Condition
Leaf spring U-bolt nuts	Tighten every 20,000 km (12,000 miles)	B

MFWS0BSF003101

3. For Australia and New Zealand (DB6A Engine Model)

Driving condition
A: Operations involving frequent starts and stops
B: Driving on rough roads, mountain roads or uphill roads
C: Driving in dusty areas
D: Driving on snow-covered or seashore roads
E: Low travel distance high engine load (Ex. Concrete pump truck, electric power supply truck, fire truck)
F: Driving with a trailer

Item	Distance covered	Condition
Damage to or looseness of the exhaust pipe, exhaust throttle, silencer, and their mountings	Inspect every 10,000 km (6,000 miles)	A, B, D, F
Brake drum wear or damage	Inspect every 20,000 km (12,000 miles)	A, B, C, F
Brake lining wear	Inspect every 2,500 km (1,500 miles)	A, B, C, F
Brake rotor for wear and damage	Inspect every 20,000 km (12,000 miles)	A, B, C, F
Brake pad for wear	Inspect every 10,000 km(6,000 miles)	A, B, C, F
Transmission gear oil (MEB9 model)	Replace every 20,000 km (12,000 miles)	B, C, F
[M/T] Clutch fluid	Replace every 20,000 km (12,000 miles)	A
Transmission fluid (ALLISON2500 model (other than TES-295/668 licensed fluid))	Replace every 20,000 km (12,000 miles) or 500 hours or 6 months	A, B, F
Transmission fluid (ALLISON2500 model (TES-295/668 licensed fluid))	Replace every 120,000 km (75,000 miles) or 3,000 hours or 36 months	A, B, F
ATF filter (ALLISON2500 model (other than TES-295/668 licensed fluid))	Replace every 20,000 km (12,000 miles) or 500 hours or 6 months	A, B, F
Transfer gear case oil (FTS model)	Replace every 30,000 km (18,000 miles)	B, F
Differential gear oil (rear axle and/or front axle)	Replace every 30,000 km (18,000 miles)	B
Inter-differential gear oil (FVZ model)	Replace every 30,000 km (18,000 miles)	B
Propeller shaft universal joint and spline wear	Inspect every 30,000 km (18,000 miles)	B

MFWS0BMF003101

Item	Distance covered	Condition
[MER] Front wheel hub bearing oil	Replace every 20,000 km (12,000 miles)	B, F
[MER] Rearward rear wheel hub bearing oil	Replace every 20,000 km (12,000 miles)	B, F
[ISZ] Damage to, loose or excessive play in power steering joints and tie rod	Inspect every 2,500 km (1,500 miles)	B
Air suspension's beam bolt nuts	Tighten every 20,000 km (12,000 miles)	B
Leaf spring U-bolt nuts	Tighten every 20,000 km (12,000 miles)	B

MFWS0BSF002901

Copyright ISUZU MOTORS LIMITED. All rights reserved.