Maintenance Schedule

1. Maintenance Schedule

When inspecting the following items, also inspect regular inspection items.

Abbreviations used
I: Inspect then clean, adjust, repair, or replace as necessary.
A: Adjust.
R: Replace.
T: Tighten to the specified torque.
L: Lubricate.

[M/T]: Manual transmission model
[A/T]: Automatic transmission model
[HPS]: Hydraulic Power Steering
[4WD]: Four Wheel Drive

Except for Indonesia, Australia, Europe, Israel, Hong Kong, and Singapore

Service item	Service content	Service interval (Odometer reading or months (years), whichever comes first)
Engine oil (4JJ3 engine models)*	R	Every 20,000 km (12,000 miles) or 24 months
Engine oil (RZ4E-TC engine models)*	R	Every 20,000 km (12,000 miles) or 24 months
Engine oil* [If normally driving at altitudes below 2,000 m (6,562 ft)] (RZ4F-TC engine models without SCR)	R	Every 20,000 km (12,000 miles) or 24 months
Engine oil* [If normally driving at altitudes below 2,000 m (6,562 ft)] (RZ4F-TC engine models with SCR)	R	Every 15,000 km (9,000 miles) or 24 months
Engine oil [If normally driving at altitudes of 2,000 m (6,562 ft) or above] (RZ4F-TC engine models)	R	Every 5,000 km (3,000 miles) or 6 months
Engine oil filter (4JJ3 engine models)*	R	Every 20,000 km (12,000 miles) or 24 months
Engine oil filter (RZ4E-TC engine models)*	R	Every 20,000 km (12,000 miles) or 24 months
Engine oil filter* [If normally driving at altitudes below 2,000 m (6,562 ft)] (RZ4F-TC engine models without SCR)	R	Every 20,000 km (12,000 miles) or 24 months
Engine oil filter* [If normally driving at altitudes below 2,000 m (6,562 ft)] (RZ4F-TC engine models with SCR)	R	Every 15,000 km (9,000 miles) or 24 months
	R	Every 5,000 km (3,000 miles) or 6 months

Engine oil filter [If normally driving at altitudes of 2,000 m (6,562 ft) or above] (RZ4F-TC engine models)		
Engine oil leakage and contamination	I	Every 10,000 km (6,000 miles) or 12 months
Engine idling speed and acceleration	I	Every 10,000 km (6,000 miles) or 12 months
Fan belt tension and damage (4JJ3 engine models)	I	Every 10,000 km (6,000 miles) or 12 months
Accessory belt tension and damage (RZ4E engine models)	I	Every 10,000 km (6,000 miles) or 12 months
Accessory belt tension and damage (RZ4F engine models)	I	Every 10,000 km (6,000 miles) or 12 months
Exhaust system	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
All hoses and pipes in engine compartment for clog or damage	I	Every 10,000 km (6,000 miles) or 12 months
Valve clearance (4JJ3 engine models)	I	Every 40,000 km (24,000 miles) or 48 months
*Air cleaner element	I R	Every 10,000 km (6,000 miles) or 12 months Every 40,000 km (24,000 miles) or 48 months
Fuel filter	R	Replace the fuel filter when the fuel filter warning light comes on
Pre fuel filter	R	Replace the fuel filter when the fuel filter warning light comes on
Fuel tank	I	Every 20,000 km (12,000 miles) or 24 months
Fuel hoses and pipes for clog or damage	I	Every 10,000 km (6,000 miles) or 12 months
Draining of water separator	Drain the fuel filter when the water separator warning light comes on	
Engine coolant concentration	I	Every 10,000 km (6,000 miles) or 12 months
Engine coolant	R	Every 24 months (When Isuzu genuine or recommended coolant is used)
Cooling system for water leakage	I	Every 10,000 km (6,000 miles) or 12 months
Clutch pedal travel and play	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
* [M/T] Manual transmission oil and oil leakage	R I R	Initial 10,000 km (6,000 miles) or 12 months Every 20,000 km (12,000 miles) or 24 months Every 40,000 km (24,000 miles) or 48 months
* [4WD] Transfer case oil and oil leakage	I	Every 20,000 km (12,000 miles) or 24 months
Gear control mechanism for looseness	I	Every 20,000 km (12,000 miles) or 24 months
* [A/T] Automatic transmission fluid	I	Every 100,000 km (60,000 miles) or 60 months
	I	Every 10,000 km (6,000 miles) or 12 months

[A/T] Automatic transmission fluid leakage		
Propeller shaft loose connections	I	Every 10,000 km (6,000 miles) or 12 months
*Propeller shaft universal joints and splines for wear	I	Every 10,000 km (6,000 miles) or 12 months
[4WD] Propeller shaft universal joints and sliding sleeve	L	Every 10,000 km (6,000 miles) or 12 months
*Differential gear oil (Front and rear)	R I R	Initial 10,000 km (6,000 miles) or 12 months Every 20,000 km (12,000 miles) or 24 months Every 40,000 km (24,000 miles) or 48 months
Front axle shaft rubber boot for damage	I	Every 20,000 km (12,000 miles) or 24 months
[4WD] Shift on the fly system gear oil	I	Every 20,000 km (12,000 miles) or 24 months
Axle case for distortion or damage	I	Every 20,000 km (12,000 miles) or 24 months
[HPS] Power steering fluid	I R	Every 10,000 km (6,000 miles) or 12 months Every 40,000 km (24,000 miles) or 48 months
[HPS] Power steering fluid leakage	I	Every 10,000 km (6,000 miles) or 12 months
* Steering system for looseness or damage	I	Every 10,000 km (6,000 miles) or 12 months
[HPS] Power steering hose	I R	Every 10,000 km (6,000 miles) or 12 months Every 80,000 km (48,000 miles) or 96 months
Steering wheel play	I	Every 10,000 km (6,000 miles) or 12 months
Steering function	I	Every 10,000 km (6,000 miles) or 12 months
Wheel alignment	I	Every 20,000 km (12,000 miles) or 24 months
Steering joint ball for oil leakage or damage	I	Every 10,000 km (6,000 miles) or 12 months
Brake and clutch fluid	I R	Every 20,000 km (12,000 miles) or 24 months Every 40,000 km (24,000 miles) or 48 months
Brake system for fluid leakage	I	Every 10,000 km (6,000 miles) or 12 months
Brake function	I	Every 10,000 km (6,000 miles) or 12 months
*Front disc brake pad and disc wear	I	Every 10,000 km (6,000 miles) or 12 months
* Rear brake lining and drum wear	I	Every 10,000 km (6,000 miles) or 12 months
Brake pedal travel and play	I	Every 10,000 km (6,000 miles) or 12 months
Brake pipes and hoses for loose connections or damage	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Parking brake function	I	Every 10,000 km (6,000 miles) or 12 months
Parking brake lever travel	I	Every 10,000 km (6,000 miles) or 12 months
Parking brake cables for looseness or damage and guide for damage	I	Every 10,000 km (6,000 miles) or 12 months

Parking brake ratchet for wear or damage	I	Every 10,000 km (6,000 miles) or 12 months
Leaf/coil springs for damage	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Suspension mount for looseness or damage	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Shock absorbers for oil leakage	I	Every 10,000 km (6,000 miles) or 12 months
Shock absorbers mount for looseness	I	Every 10,000 km (6,000 miles) or 12 months
Rubber bushes of suspension wear or damage	I	Every 10,000 km (6,000 miles) or 12 months
Suspension joint ball rubber boot for damage	I	Every 10,000 km (6,000 miles) or 12 months
Wheel nuts	T	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Wheel disc for damage	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Front and rear hub bearing for looseness	I	Every 10,000 km (6,000 miles) or 12 months
Tire air pressure and damage	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Tire rotation	Rotate as required	
Other bolts and nuts on chassis and body	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Air conditioning filter	R	Every 15,000 km (9,000 miles) or 12 months

*Under severe driving conditions, additional maintenance is required. Refer to "Maintenance Schedule for Severe-condition Operations".

For Indonesia

Service item	Service content	Service interval (Odometer reading or months, whichever comes first)
* Engine oil	R	Every 20,000 km (12,000 miles) or 24 months
*Engine oil filter	R	Every 20,000 km (12,000 miles) or 24 months
Engine oil leakage and contamination	I	Every 10,000 km (6,000 miles) or 12 months
Engine idling speed and acceleration	I	Every 10,000 km (6,000 miles) or 12 months
Accessory belt tension and damage	I	Every 10,000 km (6,000 miles) or 12 months
Exhaust system	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
All hoses and pipes in engine compartment for clog or damage	I	Every 10,000 km (6,000 miles) or 12 months
*Air cleaner element		

	I I R	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months Every 40,000 km (24,000 miles) or 48 months
Fuel filter	R	Replace the fuel filter when the fuel filter warning light comes on
Pre fuel filter	R	Replace the fuel filter when the fuel filter warning light comes on
Fuel tank	I	Every 20,000 km (12,000 miles) or 24 months
Fuel hoses and pipes for clog or damage	I	Every 10,000 km (6,000 miles) or 12 months
Draining of water separator	Drain the fuel filter when the water separator warning light comes on	
Engine coolant concentration	I	Every 10,000 km (6,000 miles) or 12 months
Engine coolant	R	Every 24 months (When Isuzu genuine or recommended coolant is used)
Cooling system for water leakage	I	Every 10,000 km (6,000 miles) or 12 months
Clutch pedal travel and play	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
* [M/T] Manual transmission oil and oil leakage	R I R	Initial 10,000 km (6,000 miles) or 12 months Every 20,000 km (12,000 miles) or 24 months Every 40,000 km (24,000 miles) or 48 months
* [4WD] Transfer case oil and oil leakage	I	Every 20,000 km (12,000 miles) or 24 months
Gear control mechanism for looseness	I	Every 20,000 km (12,000 miles) or 24 months
* [A/T] Automatic transmission fluid	I	Every 100,000 km (60,000 miles) or 60 months
[A/T] Automatic transmission fluid leakage	I	Every 10,000 km (6,000 miles) or 12 months
Propeller shaft loose connections	I	Every 10,000 km (6,000 miles) or 12 months
*Propeller shaft universal joints and splines for wear	I	Every 10,000 km (6,000 miles) or 12 months
[4WD] Propeller shaft universal joints and sliding sleeve	L	Every 10,000 km (6,000 miles) or 12 months
*Differential gear oil (Front and rear)	R I R	Initial 10,000 km (6,000 miles) or 12 months Every 20,000 km (12,000 miles) or 24 months Every 40,000 km (24,000 miles) or 48 months
Front axle shaft rubber boot for damage	I	Every 20,000 km (12,000 miles) or 24 months
[4WD] Shift on the fly system gear oil	I	Every 20,000 km (12,000 miles) or 24 months
Axle case for distortion or damage	I	Every 20,000 km (12,000 miles) or 24 months
Power steering fluid	I I R	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months Every 40,000 km (24,000 miles) or 48 months
Power steering fluid leakage	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
	I	Every 10,000 km (6,000 miles) or 12 months

* Steering system for looseness or damage		
Power steering hose	I R	Every 10,000 km (6,000 miles) or 12 months Every 80,000 km (48,000 miles) or 96 months
Steering wheel play	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Steering function	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Wheel alignment	I	Every 20,000 km (12,000 miles) or 24 months
Steering joint ball for oil leakage or damage	I	Every 10,000 km (6,000 miles) or 12 months
Brake and clutch fluid	I R	Every 20,000 km (12,000 miles) or 24 months Every 40,000 km (24,000 miles) or 48 months
Brake system for fluid leakage	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Brake function	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
*Front disc brake pad and disc wear	I	Every 10,000 km (6,000 miles) or 12 months
* Rear brake lining and drum wear	I	Every 10,000 km (6,000 miles) or 12 months
Brake pedal travel and play	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Brake pipes and hoses for loose connections or damage	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Parking brake function	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Parking brake lever travel	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Parking brake cables for looseness or damage and guide for damage	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Parking brake ratchet for wear or damage	I	Every 10,000 km (6,000 miles) or 12 months
Leaf/coil springs for damage	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Suspension mount for looseness or damage	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Shock absorbers for oil leakage	I	Every 10,000 km (6,000 miles) or 12 months
Shock absorbers mount for looseness	I	Every 10,000 km (6,000 miles) or 12 months
Rubber bushes of suspension wear or damage	I	Every 10,000 km (6,000 miles) or 12 months
Suspension joint ball rubber boot for damage	I	Every 10,000 km (6,000 miles) or 12 months
Wheel nuts	T	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Wheel disc for damage	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
	I	Every 10,000 km (6,000 miles) or 12 months

Front and rear hub bearings for looseness		
Tire air pressure and damage	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Tire rotation	Rotate as required	
Other bolts and nuts on chassis and body	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Air conditioning filter	R	Every 15,000 km (9,000 miles) or 12 months

*Under severe driving conditions, additional maintenance is required. Refer to "Maintenance Schedule for Severe-condition Operations".

For Australia

Service item	Service content	Service interval (Odometer reading or months, whichever comes first)
* Engine oil	R	Every 15,000 km (9,000 miles) or 12 months
*Engine oil filter	R	Every 15,000 km (9,000 miles) or 12 months
Engine oil leakage and contamination	I	Every 15,000 km (9,000 miles) or 12 months
Engine idling speed and acceleration	I	Every 15,000 km (9,000 miles) or 12 months
Accessory belt tension and damage (RZ4F engine models)	I	Every 15,000 km (9,000 miles) or 12 months
Fan belt tension and damage (4JJ3 engine models)	I	Every 15,000 km (9,000 miles) or 12 months
Exhaust system	I	Every 15,000 km (9,000 miles) or 12 months
All hoses and pipes in engine compartment for clog or damage	I	Every 15,000 km (9,000 miles) or 12 months
Valve clearance (4JJ3 engine models)	I	Every 60,000 km (36,000 miles) or 48 months
*Air cleaner element	I R	Every 15,000 km (9,000 miles) or 12 months Every 45,000 km (27,000 miles) or 36 months
Fuel filter	R	Replace the fuel filter when the fuel filter warning light comes on
Fuel tank	I	Every 30,000 km (18,000 miles) or 24 months
Fuel hoses and pipes for clog or damage	I	Every 15,000 km (9,000 miles) or 12 months
Draining of water separator	Drain the fuel filter when the water separator warning light comes on	
Engine coolant concentration	I	Every 15,000 km (9,000 miles) or 12 months
Engine coolant	R	Initial 120,000 km (72,000 miles) or 96 months Every 120,000 km (72,000 miles) or 96 months (when BESCO (coolant) is used)** Every 24 months (when other coolant is used)
Cooling system for water leakage	I	Every 15,000 km (9,000 miles) or 12 months
* [4WD] Transfer case oil and oil leakage	I	Every 15,000 km (9,000 miles) or 12 months

* [A/T] Automatic transmission fluid	I	Every 105,000 km (63,000 miles) or 84 months
[A/T] Automatic transmission fluid leakage	I	Every 15,000 km (9,000 miles) or 12 months
Propeller shaft loose connections	I	Every 15,000 km (9,000 miles) or 12 months
*Propeller shaft universal joints and splines for wear	I	Every 15,000 km (9,000 miles) or 12 months
[4WD] Propeller shaft universal joints and sliding sleeve	L	Every 15,000 km (9,000 miles) or 12 months
*Differential gear oil (Front and rear)	R R	Initial 15,000 km (9,000 miles) or 12 months Every 60,000 km (36,000 miles) or 48 months
Front axle shaft rubber boot for damage	I	Every 30,000 km (18,000 miles) or 24 months
[4WD] Shift on the fly system gear oil	I	Every 30,000 km (18,000 miles) or 24 months
Axle case for distortion or damage	I	Every 30,000 km (18,000 miles) or 24 months
* Steering system for looseness or damage	I	Every 15,000 km (9,000 miles) or 12 months
Steering wheel play	I	Every 15,000 km (9,000 miles) or 12 months
Steering function	I	Every 15,000 km (9,000 miles) or 12 months
Wheel alignment	I	Every 30,000 km (18,000 miles) or 24 months
Steering joint ball for oil leakage or damage	I	Every 15,000 km (9,000 miles) or 12 months
Brake fluid	I R	Every 15,000 km (9,000 miles) or 12 months Every 45,000 km (27,000 miles) or 36 months
Brake system for fluid leakage	I	Every 15,000 km (9,000 miles) or 12 months
Brake function	I	Every 15,000 km (9,000 miles) or 12 months
*Front disc brake pad and disc wear	I	Every 15,000 km (9,000 miles) or 12 months
* Rear brake lining and drum wear	I	Every 15,000 km (9,000 miles) or 12 months
Brake pedal travel and play	I	Every 15,000 km (9,000 miles) or 12 months
Brake pipes and hoses for loose connections or damage	I	Every 15,000 km (9,000 miles) or 12 months
Parking brake function	I	Every 15,000 km (9,000 miles) or 12 months
Parking brake lever travel	I	Every 15,000 km (9,000 miles) or 12 months
Parking brake cables for looseness or damage and guide for damage	I	Every 15,000 km (9,000 miles) or 12 months
Parking brake ratchet for wear or damage	I	Every 15,000 km (9,000 miles) or 12 months
Leaf/coil springs for damage	I	Every 15,000 km (9,000 miles) or 12 months
Suspension mount for looseness or damage	I	Every 15,000 km (9,000 miles) or 12 months
	I	Every 15,000 km (9,000 miles) or 12 months

Shock absorbers for oil leakage		
Shock absorbers mount for looseness	I	Every 15,000 km (9,000 miles) or 12 months
Rubber bushes of suspension wear or damage	I	Every 15,000 km (9,000 miles) or 12 months
Suspension joint ball rubber boot for damage	I	Every 15,000 km (9,000 miles) or 12 months
Wheel nuts	T	Every 15,000 km (9,000 miles) or 12 months
Wheel disc for damage	I	Every 15,000 km (9,000 miles) or 12 months
Front and rear hub bearings for looseness	I	Every 15,000 km (9,000 miles) or 12 months
Tire air pressure and damage	I	Every 15,000 km (9,000 miles) or 12 months
Tire rotation	Rotate as required	
Other bolts and nuts on chassis and body	I	Every 15,000 km (9,000 miles) or 12 months
Air conditioning filter	R	Every 30,000 km (18,000 miles) or 24 months

*Under severe driving conditions, additional maintenance is required. Refer to "Maintenance Schedule for Severe-condition Operations".
**For details about BESCO (coolant), please refer to "Recommended Fluids, Lubricants and Diesel Fuels".

For Europe, Israel, Hong Kong, and Singapore

Service item	Service content	Service interval (Odometer reading or months, whichever comes first)
* Engine oil	R	Every 15,000 km (9,000 miles) or 24 months
*Engine oil filter	R	Every 15,000 km (9,000 miles) or 24 months
Engine oil leakage and contamination	I	Every 20,000 km (12,000 miles) or 24 months
Engine idling speed and acceleration	I	Every 20,000 km (12,000 miles) or 24 months
Accessory belt tension and damage	I	Every 20,000 km (12,000 miles) or 24 months
Exhaust system	I	Every 20,000 km (12,000 miles) or 24 months
All hoses and pipes in engine compartment for clog or damage	I	Every 20,000 km (12,000 miles) or 24 months
*Air cleaner element	I R	Every 20,000 km (12,000 miles) or 24 months Every 40,000 km (24,000 miles) or 48 months
Fuel filter	R	Replace the fuel filter when the fuel filter warning light comes on.
Fuel tank	I	Every 20,000 km (12,000 miles) or 24 months
Fuel hoses and pipes for clog or damage	I	Every 20,000 km (12,000 miles) or 24 months
Draining of water separator	Drain the fuel filter when the water separator warning light comes on	
Engine coolant concentration	I	Every 20,000 km (12,000 miles) or 24 months
Engine coolant	R	Initial 160,000 km (96,000 miles) or 96 months

		Every 160,000 km (96,000 miles) or 96 months (when Isuzu genuine coolant is used) Every 24 months (when Isuzu recommended coolant is used)
Cooling system for water leakage	I	Every 20,000 km (12,000 miles) or 24 months
Clutch pedal travel and play	I	Every 20,000 km (12,000 miles) or 24 months
[M/T] Manual transmission oil leakage	I	Every 20,000 km (12,000 miles) or 24 months
* [M/T] Manual transmission oil	R	Every 40,000 km (24,000 miles) or 48 months (When Isuzu recommended lubrication other than BESCO MTF is used)
* [4WD] Transfer case oil and oil leakage	I	Every 20,000 km (12,000 miles) or 24 months
Gear control mechanism for looseness	I	Every 20,000 km (12,000 miles) or 24 months
* [A/T] Automatic transmission fluid	I	Every 120,000 km (72,000 miles) or 72 months
[A/T] Automatic transmission fluid leakage	I	Every 20,000 km (12,000 miles) or 24 months
Propeller shaft loose connections	I	Every 20,000 km (12,000 miles) or 24 months
*Propeller shaft universal joints and splines for wear	I	Every 20,000 km (12,000 miles) or 24 months
[4WD] Propeller shaft universal joints and sliding sleeve	L	Every 20,000 km (12,000 miles) or 24 months
*Differential gear oil (Front and rear)	R R	Initial 20,000 km (12,000 miles) or 24 months Every 40,000 km (24,000 miles) or 48 months
Front axle shaft rubber boot for damage	I	Every 20,000 km (12,000 miles) or 24 months
[4WD] Shift on the fly system gear oil	I	Every 20,000 km (12,000 miles) or 24 months
Axle case for distortion or damage	I	Every 20,000 km (12,000 miles) or 24 months
[HPS] Power steering fluid	I R	Every 20,000 km (12,000 miles) or 24 months Every 180,000 km (108,000 miles) or 120 months
[HPS] Power steering fluid leakage	I	Every 20,000 km (12,000 miles) or 24 months
* Steering system for looseness or damage	I	Every 20,000 km (12,000 miles) or 24 months
[HPS] Power steering hose	I	Every 20,000 km (12,000 miles) or 24 months
Steering wheel play	I	Every 20,000 km (12,000 miles) or 24 months
Steering function	I	Every 20,000 km (12,000 miles) or 24 months
Wheel alignment	I	Every 20,000 km (12,000 miles) or 24 months
Steering joint ball for oil leakage or damage	I	Every 20,000 km (12,000 miles) or 24 months
Brake and clutch fluid	I R	Every 20,000 km (12,000 miles) or 24 months Every 40,000 km (24,000 miles) or 48 months
Brake system for fluid leakage	I	Every 20,000 km (12,000 miles) or 24 months

Brake function	I	Every 20,000 km (12,000 miles) or 24 months
*Front disc brake pad and disc wear	I	Every 20,000 km (12,000 miles) or 24 months
* Rear brake lining and drum wear	I	Every 20,000 km (12,000 miles) or 24 months
Brake pedal travel and play	I	Every 20,000 km (12,000 miles) or 24 months
Brake pipes and hoses for loose connections or damage	I	Every 20,000 km (12,000 miles) or 24 months
Parking brake function	I	Every 20,000 km (12,000 miles) or 24 months
Parking brake lever travel	I	Every 20,000 km (12,000 miles) or 24 months
Parking brake cables for looseness or damage and guide for damage	I	Every 20,000 km (12,000 miles) or 24 months
Parking brake ratchet for wear or damage	I	Every 20,000 km (12,000 miles) or 24 months
Leaf/coil springs for damage	I	Every 20,000 km (12,000 miles) or 24 months
Suspension mount for looseness or damage	I	Every 20,000 km (12,000 miles) or 24 months
Shock absorbers for oil leakage	I	Every 20,000 km (12,000 miles) or 24 months
Shock absorbers mount for looseness	I	Every 20,000 km (12,000 miles) or 24 months
Rubber bushes of suspension wear or damage	I	Every 20,000 km (12,000 miles) or 24 months
Suspension joint ball rubber boot for damage	I	Every 20,000 km (12,000 miles) or 24 months
Wheel nuts	T	Every 20,000 km (12,000 miles) or 24 months
Wheel disc for damage	I	Every 20,000 km (12,000 miles) or 24 months
Front and rear hub bearing for looseness	I	Every 20,000 km (12,000 miles) or 24 months
Tire air pressure and damage	I	Every 20,000 km (12,000 miles) or 24 months
Tire rotation	Rotate as required	
Other bolts and nuts on chassis and body	I	Every 20,000 km (12,000 miles) or 24 months
Air conditioning filter	R	Every 60,000 km (36,000 miles) or 24 months

*Under severe driving conditions, additional maintenance is required. Refer to "Maintenance Schedule for Severe-condition Operations".

2. Maintenance Schedule for Severe-Condition

Vehicles used under severe conditions need more frequent maintenance than those receiving ordinary use.

A: Repeated short trips
B: Driving on rough roads

C: Driving on dusty roads
D: Driving in extremely cold weather and/or on salted roads
E: Towing trailer or climbing mountain frequently
F: Continuous driving in low speed and/or with a low load
G: Frequently turning the engine off during DPD regeneration

Except for Australia, Europe, Israel, Turkey, Hong Kong, and Singapore
(Models without DPD)

Item	Distance range	Condition
Engine oil	Replace every 5,000 km (3,000 miles)	C, F, A + D
Engine oil filter	Replace every 5,000 km (3,000 miles)	C, F, A + D
Exhaust pipes and mounting	Inspect every 5,000 km (3,000 miles)	A, B, D
Air cleaner element	Inspect every 2,500 km (1,500 miles) Replace every 20,000 km (12,000 miles)	C
Steering system for looseness or damage	Inspect every 5,000 km (3,000 miles)	B
Universal joints and sleeves	Inspect for wear and lubricate every 5,000 km (3,000 miles)	B, C
Manual transmission oil	Replace every 20,000 km (12,000 miles) after replacing at initial 10,000 km (6,000 miles)	B
Automatic transmission fluid	Inspect every 40,000 km (24,000 miles) Replace every 80,000 km (48,000 miles)	B, E, A + D
Transfer case oil	Replace every 20,000 km (12,000 miles) after replacing at initial 10,000 km (6,000 miles)	B
Differential oil	Replace every 20,000 km (12,000 miles) after replacing at initial 10,000 km (6,000 miles)	B
Front disc brake pad and disc wear	Inspect every 5,000 km (3,000 miles)	A, B, C
Rear brake lining and drum wear	Inspect every 5,000 km (3,000 miles)	A, B, C

Except for Australia, Europe, Israel, Turkey, Hong Kong, and Singapore
(Models with DPD)

Item	Distance range	Condition
Engine oil	Replace every 5,000 km (3,000 miles)	A, C, D, F, G
Engine oil filter	Replace every 5,000 km (3,000 miles)	A, C, D, F, G
Exhaust pipes and mounting	Inspect every 5,000 km (3,000 miles)	A, B, D
Air cleaner element	Inspect every 2,500 km (1,500 miles) Replace every 20,000 km (12,000 miles)	C
Steering system for looseness or damage	Inspect every 5,000 km (3,000 miles)	B
Universal joints and sleeves	Inspect for wear and lubricate every 5,000 km (3,000 miles)	B, C
Manual transmission oil	Replace every 20,000 km (12,000 miles)	B

	after replacing at initial 10,000 km (6,000 miles)	
Automatic transmission fluid	Inspect every 40,000 km (24,000 miles) Replace every 80,000 km (48,000 miles)	B, E, A + D
Transfer case oil	Replace every 20,000 km (12,000 miles) after replacing at initial 10,000 km (6,000 miles)	B
Differential oil	Replace every 20,000 km (12,000 miles) after replacing at initial 10,000 km (6,000 miles)	B
Front disc brake pad and disc wear	Inspect every 5,000 km (3,000 miles)	A, B, C
Rear brake lining and drum wear	Inspect every 5,000 km (3,000 miles)	A, B, C

For Australia

Item	Distance range	Condition
Engine oil	Replace every 5,000 km (3,000 miles)	A, C, D, F, G
Engine oil filter	Replace every 5,000 km (3,000 miles)	A, C, D, F, G
Exhaust pipes and mounting	Replace every 5,000 km (3,000 miles)	A, B, D
Air cleaner element	Inspect every 5,000 km (3,000 miles) Replace every 20,000 km (12,000 miles)	C
Steering system for looseness or damage	Inspect every 5,000 km (3,000 miles)	B
Universal joints and sleeves	Inspect for wear and lubricate every 5,000 km (3,000 miles)	B, C
Automatic transmission fluid	Inspect every 40,000 km (24,000 miles) Replace every 80,000 km (48,000 miles)	B, E, A + D
Transfer case oil	Replace every 20,000 km (12,000 miles) after replacing at initial 10,000 km (6,000 miles)	B
Differential oil	Replace every 20,000 km (12,000 miles) after replacing at initial 10,000 km (6,000 miles)	B
Front disc brake pad and disc wear	Inspect every 5,000 km (3,000 miles)	A, B, C
Rear brake lining and drum wear	Inspect every 5,000 km (3,000 miles)	A, B, C

For Europe, Israel, Turkey, Hong Kong, and Singapore

Item	Distance range	Condition
Engine oil	Replace every 5,000 km (3,000 miles)	C, E, F, G, A+D
Engine oil filter	Replace every 10,000 km (6,000 miles)	C, E, F, G, A+D

Exhaust pipes and mounting	Inspect every 10,000 km (6,000 miles)	A, B, D
Air cleaner element	Inspect every 5,000 km (3,000 miles) Replace every 20,000 km (12,000 miles)	C
Steering system for looseness or damage	Inspect every 5,000 km (3,000 miles)	B
Universal joints and sleeves	Inspect for wear and lubricate every 5,000 km (3,000 miles)	B, C
Manual transmission oil	Replace every 20,000 km (12,000 miles) after replacing at initial 10,000 km (6,000 miles)	B
Automatic transmission fluid	Inspect every 40,000 km (24,000 miles) Replace every 80,000 km (48,000 miles)	B, E, A + D
Transfer case oil	Replace every 20,000 km (12,000 miles) after replacing at initial 10,000 km (6,000 miles)	B
Differential oil	Replace every 20,000 km (12,000 miles) after replacing at initial 10,000 km (6,000 miles)	B
Front disc brake pad and disc wear	Inspect every 5,000 km (3,000 miles)	A, B, C
Rear brake lining and drum wear	Inspect every 5,000 km (3,000 miles)	A, B, C

Copyright ISUZU MOTORS LIMITED. All rights reserved.