2013 TF series 4JK1 TB-50LS

Maintenance Schedule

Introduction Safety Information Reference

1.Maintenance Schedule

When inspecting the following items, also inspect regular inspection items.

Abbreviations used
I: Inspect, clean, or repair or replace as necessary.
A: Adjust.
R: Replace.
T: Tighten to the specified torque.
L: Add lubricant.

Service item	Service content	Service interval (Odometer reading or months (years), whichever comes first)
*Engine oil (Except models for Chile)	R	Every 20,000 km (12,000 miles) or 24 months
*Engine oil [If normally driving at altitudes below 2,000 m (6,562 ft)] (Models for Chile)	R	Every 10,000 km (6,000 miles) or 12 months
Engine oil [If normally driving at altitudes of 2,000 m (6,562 ft) or above] (Models for Chile)	R	Every 5,000 km (3,000 miles) or 6 months
*Engine oil filter	R	Every 20,000 km (12,000 miles) or 24 months
Engine oil leakage and contamination	I	Every 5,000 km (3,000 miles) or 6 months
Engine idling speed and acceleration	I	Every 5,000 km (3,000 miles) or 6 months
Fan belt tension and damage	I	Every 5,000 km (3,000 miles) or 6 months
Exhaust system	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
All hoses and pipes in engine compartment for clog of damage	I	Every 10,000 km (6,000 miles) or 12 months
Valve clearance	A	Every 40,000 km (24,000 miles) or 12 months
*Air cleaner element	I	Every 10,000 km (6,000 miles) or 12 months
	R	Every 40,000 km (24,000 miles) or 48 months
Fuel filter	R	Replace the fuel filter when the fuel filter indicator light comes on

Pre fuel filter	R	Replace the fuel filter when the fuel filter indicator light comes on
Fuel tank	I	Every 20,000 km (12,000 miles) or 24 months
Draining of water separator	Drain the fuel filter when the water separator indicator light comes on	
Engine coolant concentration	I	Every 10,000 km (6,000 miles) or 12 months
Engine coolant	R	Every 2 years (when Isuzu recommended coolant is used)
Cooling system for water leakage	I	Every 10,000 km (6,000 miles) or 12 months
Clutch fluid	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Clutch pedal travel and play	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
*Manual transmission oil	I	Every 20,000 km (12,000 miles) or 24 months
*Transfer case oil	I	Every 20,000 km (12,000 miles) or 24 months
Manual transmission and transfer case oil leakage	I	Every 10,000 km (6,000 miles) or 12 months
Gear control mechanism for looseness	I	Every 20,000 km (12,000 miles) or 24 months
*Automatic transmission fluid (AT)	I	Every 100,000 km (60,000 miles) or 60 months
*Transfer case oil (AT)	I	Every 20,000 km (12,000 miles) or 24 months
Automatic transmission and transfer oil leakage (AT)	I	Every 10,000 km (6,000 miles) or 12 months
Propeller shaft loose connections	I	Every 10,000 km (6,000 miles) or 12 months
*Propeller shaft universal joints and splines for wear	I	Every 10,000 km (6,000 miles) or 12 months
Propeller shaft universal joints and splines sleeve (4WD)	L	Every 10,000 km (6,000 miles) or 12 months
	R	Initial 10,000 km (6,000 miles) or 12 months
*Differential gear oil - Front and rear	I	Every 20,000 km (12,000 miles) or 24 months
	R	Every 40,000 km (24,000 miles) or 48 months
Front and rear axle oil leakage	I	Every 20,000 km (12,000 miles) or 24 months

Shift on the fly system gear oil	I	Every 20,000 km (12,000 miles) or 24 months
Front axle shaft rubber boot for damage	I	Every 20,000 km (12,000 miles) or 24 months
Axle case for distortion or damage	I	Every 20,000 km (12,000 miles) or 24 months
Axle shafts for distortion or damage	I	Every 20,000 km (12,000 miles) or 24 months
Power steering fluid	I	Every 10,000 km (6,000 miles) or 12 months
	R	Every 40,000 km (24,000 miles) or 48 months
Power steering oil leakage	I	Every 10,000 km (6,000 miles) or 12 months
*Steering system for looseness or damage	I	Every 10,000 km (6,000 miles) or 12 months
Power steering hose	I	Every 10,000 km (6,000 miles) or 12 months
	R	Every 80,000 km (48,000 miles) or 96 months
Steering wheel play	I	Every 10,000 km (6,000 miles) or 12 months
Steering function	I	Every 10,000 km (6,000 miles) or 12 months
Right and left turning radius	I	Every 20,000 km (12,000 miles) or 24 months
Wheel alignment	I	Every 20,000 km (12,000 miles) or 24 months
Steering joint ball for oil leakage or damage	I	Every 10,000 km (6,000 miles) or 12 months
Steering joint ball rubber boot for damage	I	Every 10,000 km (6,000 miles) or 12 months
Brake fluid	I	Every 20,000 km (12,000 miles) or 24 months
	R	Every 40,000 km (24,000 miles) or 48 months
Brake system for fluid leakage	I	Every 10,000 km (6,000 miles) or 12 months
Brake function	I	Every 10,000 km (6,000 miles) or 12 months
*Front disc brake pads and discs wear	I	Every 10,000 km (6,000 miles) or 12 months
*Rear brake lining and drum wear	I	Every 10,000 km (6,000 miles) or 12 months
Brake pedal travel and play	I	Every 10,000 km (6,000 miles) or 12 months
	I	Every 10,000 km (6,000 miles) or 12 months

Brake pipes and hoses for loose connections or damage		
Parking brake function	I	Every 10,000 km (6,000 miles) or 12 months
Parking brake lever travel	I	Every 10,000 km (6,000 miles) or 12 months
Parking brake cables for looseness or damage and guide for damage	I	Every 10,000 km (6,000 miles) or 12 months
Ratchet for wear or damage	I	Every 10,000 km (6,000 miles) or 12 months
Leaf/coil springs for damage	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Suspension mount for looseness or damage	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Shock absorbers for oil leakage	I	Every 10,000 km (6,000 miles) or 12 months
Shock absorbers mount for looseness	I	Every 10,000 km (6,000 miles) or 12 months
Rubber bushes of suspension wear or damage	I	Every 10,000 km (6,000 miles) or 12 months
Spring action for loss of balance due to weakening	I	Every 20,000 km (12,000 miles) or 24 months
Suspension joint ball rubber boot for damage	I	Every 10,000 km (6,000 miles) or 12 months
Wheel nuts	T	Every 10,000 km (6,000 miles) or 12 months
Wheel disc for damage	I	Every 10,000 km (6,000 miles) or 12 months
Front hub bearing grease	R	Every 30,000 km (18,000 miles) or 36 months
Front and rear hub bearing for looseness	I	Every 10,000 km (6,000 miles) or 12 months
Tire air pressure and damage	I	Every 10,000 km (6,000 miles) or 12 months
Tire rotation	-	Rotate as required
Other bolts and nuts on chassis and body	I	Initial 5,000 km (3,000 miles) or 6 months Every 10,000 km (6,000 miles) or 12 months
Air conditioning filter	R	Every 15,000 km (9,000 miles) or 12 months

* : Under severe driving conditions, additional maintenance is needed. Refer to "Maintenance Schedule for Severe-condition Operations".

2.Maintenance Schedule for Severe-Condition

Vehicles used under severe conditions need more frequent maintenance than ordinary use.

A: Operations involving frequent starts and stops
B: Driving on rough, mountain, or uphill roads
C: Driving in dusty areas
D: Driving on snowy or coast roads
E: Towing of a trailer or frequent climbing drive

Item	Distance covered	Condition					
		A	B	C	D	E	A+D
Engine oil	Change every 5,000 km (3,000 miles)			O			O
Engine oil filter	Change every 5,000 km (3,000 miles)			O			O
Air cleaner element	Inspection every 5,000 km (3,000 miles) Change every 20,000 km (12,000 miles)			O			
Damage to or looseness of the exhaust pipe and its installation	Inspection every 10,000 km (6,000 miles)	O	O		O		
Manual Transmission oil	Change every 20,000 km (12,000 miles) 1st time, change at 10,000 km (6,000 miles)		O				
Automatic transmission fluid	Inspection every 40,000 km (24,000 miles) Change every 80,000 km (48,000 miles)		O			O	O
Transfer case oil	Change every 20,000 km (12,000 miles) 1st time, change at 10,000 km (6,000 miles)		O				
Universal joint and sleeve	Inspection for wear, lubrication of grease every 5,000 km (3,000 miles)		O	O			
Differential gear oil	Change every 20,000 km (12,000 miles) 1st time, change at		O				

	10,000 km (6,000 miles)						
Looseness or damage of steering system installation	Inspection every 5,000 km (3,000 miles)		O				
Front brake pad and disc wear	Inspection every 5,000 km (3,000 miles)	O	O	O			
Rear brake lining and drum wear	Inspection every 5,000 km (3,000 miles)	O	O	O			