Maintenance Schedule

1. Maintenance Schedule

When checking the following items, also check regular inspection items.

Abbreviations used
I: Perform inspection, cleaning, or repair or replacement as necessary.
A: Make adjustments.
R: Make replacements.
T: Tighten the item using the specified torque.
L: Add lubricant.

NLR85/NLS85/NMR85/NNR85/NPR85 models No. 1

I : Inspect, clean, or repair or replace as required A : Adjust R : Replace T : Tighten to the specified torque L : Lubricate

Service Interval x1,000 km	1	5	10	15	20	25	30	35	40	45	50	55	60	65	70	75	80	85	90	95	100	105	Odometer reading or months, whichever comes first
x1,000 miles	0.6	3	6	9	12	15	18	21	24	27	31	34	37	40	43	46	49	52	55	59	62	65	
* Engine oil (models for Israel)	-	-	-	R	-	-	R	-	-	R	-	-	R	-	-	R	-	-	R	-	-	R	or every 12 months
* Engine oil (models without PTO and except models for Israel)	-	-	-	-	R	-	-	-	R	-	-	-	R	-	-	-	R	-	-	-	R	-	or every 12 months
* Engine oil (models with PTO and except models for Israel)	-	-	-	R	-	-	R	-	-	R	-	-	R	-	-	R	-	-	R	-	-	R	or every 12 months
* Engine oil filter (models for Israel)	-	-	-	R	-	-	R	-	-	R	-	-	R	-	-	R	-	-	R	-	-	R	or every 12 months
* Engine oil filter (models without PTO and except models for Israel)	-	-	-	-	R	-	-	-	R	-	-	-	R	-	-	-	R	-	-	-	R	-	or every 12 months
* Engine oil filter (models with PTO and except models for Israel)	-	-	-	R	-	-	R	-	-	R	-	-	R	-	-	R	-	-	R	-	-	R	or every 12 months
Fuel filter element	-	-	-	-	-	-	-	-	R	-	-	-	-	-	-	-	R	-	-	-	-	-	or every 12 months
Pre-fuel filter	-	-	-	-	-	-	-	-	R	-	-	-	-	-	-	-	R	-	-	-	-	-	or every 12 months
* Air cleaner element	-	-	I	-	I	-	I	-	R	-	I	-	I	-	I	-	R	-	I	-	I	-	or every 24 months
Idle speed and acceleration	-	-	-	-	I	-	-	-	I	-	-	-	I	-	-	-	I	-	-	-	I	-	or every 12 months
Valve clearance	-	-	-	-	-	-	-	-	A	-	-	-	-	-	-	-	A	-	-	-	-	-	or every 12 months
Looseness in or damage to fuel tank cap and fuel line	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	I	-	-	-	I	-	or every 24 months
Drive belt tension and damage	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 6 months
Engine coolant	Every 12 months:I Every 24 months: R (when Isuzu recommended coolant is used)																						
* Damage to or looseness in exhaust pipe, exhaust brake, exhaust throttle, and their mounting	-	-	-	-	-	-	I	-	-	-	-	-	I	-	-	-	-	-	I	-	-	-	or every 18 months
Cooling system	-	-	-	-	-	-	I	-	-	-	-	-	I	-	-	-	-	-	I	-	-	-	or every 12 months
Damage to air intake ducts and hoses	-	-	-	-	-	-	I	-	-	-	-	-	I	-	-	-	-	-	I	-	-	-	or every 12 months
Engine operating conditions	-	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	or every 9 months
Clutch fluid (Manual transmission model)	-	-	-	I	-	-	I	-	-	R	-	-	I	-	-	I	-	-	R	-	-	I	or every 27 months
Clutch pedal stroke and free play (Manual transmission model)	-	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	or every 3 months
* Transmission oil	-	-	-	I	-	-	I	-	-	R	-	-	I	-	-	I	-	-	R	-	-	I	or every 24 months
* Smoother clutch oil (Vehicle equipped with the Smoother system)	-	-	-	I	-	-	I	-	-	R	-	-	I	-	-	I	-	-	R	-	-	I	or every 24 months
Gear control mechanism looseness	-	-	-	-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	-	or every 36 months
Gear control cable	-	-	-	-	-	-	A	-	-	-	-	-	A	-	-	-	-	-	A	-	-	-	or every 18 months
* Transmission and transfer case oil (4WD model)	-	-	-	I	-	-	I	-	-	R	-	-	I	-	-	I	-	-	R	-	-	I	or every 24 months
* Propeller shaft, universal joints and sliding sleeves	-	-	-	L	-	-	L	-	-	-	-	-	L	-	-	-	-	-	L	-	-	-	or every 12 months
Loose propeller shaft joints	-	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	or every 6 months
Propeller shaft spline wear	-	-	-	-	-	-	I	-	-	-	-	-	I	-	-	-	-	-	I	-	-	-	or every 24 months
Looseness in propeller shaft bearings and related components	-	-	-	-	-	-	I	-	-	-	-	-	I	-	-	-	-	-	I	-	-	-	or every 24 months
Propeller shaft center bearing	-	-	-	L	-	-	L	-	-	-	-	-	L	-	-	-	-	-	L	-	-	-	or every 12 months
* Front propeller shaft, universal joints and sliding sleeves (4WD model)	-	-	-	L	-	-	L	-	-	L	-	-	L	-	-	L	-	-	L	-	-	L	or every 6 months
Looseness in front propeller shaft joints (4WD model)	-	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	or every 6 months
Front propeller shaft spline wear (4WD model)	-	-	-	-	-	-	I	-	-	-	-	-	I	-	-	-	-	-	I	-	-	-	or every 24 months
* Differential gear oil	-	-	-	I	-	-	I	-	-	R	-	-	I	-	-	I	-	-	R	-	-	I	or every 24 months

* : The vehicle needs to be maintained more often if it is driven in severe condition. Refer to "Maintenance Schedule for Severe-condition" in this section.

LNWF0BLF000401

NLR85/NLS85/NMR85/NNR85/NPR85 models No. 2

I : Inspect, clean, or repair or replace as required A : Adjust R : Replace T : Tighten to the specified torque L : Lubricate

Service Interval x1,000 km	1	5	10	15	20	25	30	35	40	45	50	55	60	65	70	75	80	85	90	95	100	105	Odometer reading or months, whichever comes first
x1,000 miles	0.6	3	6	9	12	15	18	21	24	27	31	34	37	40	43	46	49	52	55	59	62	65	
* Kingpin (model with rigid front suspension)	-	-	-	L	-	-	L	-	-	L	-	-	L	-	-	L	-	-	L	-	-	L	or every 12 months
* Front differential gear oil (4WD model)	-	-	-	I	-	-	I	-	-	R	-	-	I	-	-	I	-	-	R	-	-	I	or every 24 months
Oil leaks from power steering system	-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 6 months
Power steering fluid	-	-	-	-	-	-	-	-	R	-	-	-	-	-	-	-	R	-	-	-	-	-	or every 24 months
* Looseness in or damage to power steering system mounting	-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 6 months
Looseness in connection between knuckle and front axle	-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 6 months
Looseness in or damage to steering mechanism	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	I	-	-	-	-	-	or every 24 months
Steering wheel free play	-	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	or every 3 months
Steering mechanism functionality	-	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	or every 3 months
Wheel alignment	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	I	-	-	-	-	-	or every 24 months
Power steering hose	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	R	-	-	-	-	-	or every 48 months
Brake fluid	-	-	-	I	-	-	I	-	-	R	-	-	I	-	-	I	-	-	R	-	-	I	or every 27 months
Brake system oil leaks	-	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	or every 9 months
* Brake shoe lining and drum wear	-	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	or every 9 months
* Disc brake pad and disc wear	-	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	or every 9 months
Brake pedal stroke and free play	-	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	or every 9 months
Looseness in or damage to brake pipe and brake hose connections	-	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	or every 9 months
Parking brake cable	-	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	or every 9 months
Parking brake functionality	-	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	or every 9 months
Parking brake lever stroke	-	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	or every 9 months
Parking brake shoe lining wear	-	-	-	-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	-	or every 36 months
Wear of or damage to parking brake drum	-	-	-	-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	-	or every 36 months
Damage to parking brake ratchet mechanism	-	-	-	-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	-	or every 36 months
Leaf spring damage	-	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	or every 9 months
Looseness in or damage to suspension mounting	-	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	or every 9 months
Shock absorber oil leaks	-	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	or every 9 months
Shock absorber mounting looseness	-	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	or every 9 months
Wheel nuts and wheel bolts	T	-	-	T	-	-	T	-	-	T	-	-	T	-	-	T	-	-	T	-	-	T	or every 12 months
Disc wheel damage	-	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	or every 12 months
Wheel hub bearing grease	-	-	-	-	-	-	-	-	R	-	-	-	-	-	-	-	R	-	-	-	-	-	or every 24 months
Tire air pressure and damage	-	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	I	-	or every 6 months
Battery fluid specific gravity	-	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	or every 9 months
Exhaust pressure check or filter cleaning	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	I	or every 12 months
Differential pressure sensor rubber element	-	-	-	-	-	-	-	-	R	-	-	-	-	-	-	-	R	-	-	-	-	-	or every 12 months
AdBlue® filter (if so equipped)	Every 200,000km (124,000 miles): R																						
Inspection of lights, horn, windshield wiper and washer	-	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	-	-	I	or every 9 months
Damage to drive shaft dust boot (4WD model)	-	-	-	-	I	-	-	-	I	-	-	-	I	-	-	-	I	-	-	-	I	-	or every 12 months
Inspection of nuts and bolts on chassis and body	-	-	-	-	-	-	-	-	-	-	-	-	I	-	-	-	-	-	-	-	-	-	or every 36 months

* : The vehicle needs to be maintained more often if it is driven in severe condition. Refer to "Maintenance Schedule for Severe-condition" in this section.

LNWE0BLF003301

NPR75 model No. 1

I : Inspect, clean, or repair or replace as required A : Adjust R : Replace T : Tighten to the specified torque L : Lubricate

Service Interval	km	11,250	22,500	33,750	45,000	56,250	67,500	78,750	90,000	101,250	Odometer reading or months, whichever comes first
	miles	7,000	14,000	21,000	28,000	35,000	42,000	49,000	56,000	63,000	
• Engine oil		-	R	-	R	-	R	-	R	-	or every 14 months
• Engine oil filter		-	R	-	R	-	R	-	R	-	or every 14 months
Fuel filter element		-	-	-	R	-	-	-	R	-	or every 14 months
Pre-fuel filter (if so equipped)		-	-	-	R	-	-	-	R	-	or every 14 months
• Air cleaner element		I	I	I	R	I	I	I	R	I	or every 28 months
Idle speed and acceleration		-	I	-	I	-	I	-	I	-	or every 14 months
Valve clearance		-	-	-	A	-	-	-	A	-	or every 12 months
Looseness in or damage to fuel tank cap and fuel line		-	-	-	I	-	-	-	I	-	or every 28 months
Drive belt tension and damage		I	I	I	I	I	I	I	I	I	or every 7 months
Engine coolant		Every 12 months:I Every 24 months: R (when Isuzu recommended coolant is used)									
• Damage to or looseness in exhaust pipe, exhaust brake, exhaust throttle, and their mounting		-	I	-	I	-	I	-	I	-	or every 14 months
Cooling system		-	I	-	I	-	I	-	I	-	or every 12 months
Damage to air intake ducts and hoses		Every 30,000km (18,000miles) or 12 months: I									
Engine operating conditions		I	I	I	I	I	I	I	I	I	or every 7 months
Clutch fluid (Manual transmission model)		I	I	I	R	I	I	I	R	I	or every 28 months
Clutch pedal stroke and free play (Manual transmission model)		Every 5,000km (3,000miles) or 3 months: I									
• Transmission oil		I	I	I	R	I	I	I	R	I	or every 24 months
• Smoother clutch oil (Vehicle equipped with the Smoother system)		I	I	I	R	I	I	I	R	I	or every 24 months
Gear control mechanism looseness		-	-	-	I	-	-	-	I	-	or every 21 months
Gear control cable		-	A	-	A	-	A	-	A	-	or every 14 months
• Propeller shaft, universal joints and sliding sleeves		-	L	-	L	-	L	-	L	-	or every 14 months
Loose propeller shaft joints		I	I	I	I	I	I	I	I	I	or every 7 months
Propeller shaft spline wear		-	-	-	I	-	-	-	I	-	or every 28 months
Looseness in propeller shaft bearings and related components		-	-	-	I	-	-	-	I	-	or every 28 months
Propeller shaft center bearing		-	L	-	L	-	L	-	L	-	or every 14 months
• Differential gear oil		I	I	I	R	I	I	I	R	I	or every 28 months
• Kingpin (model with rigid front suspension)		L	L	L	L	L	L	L	L	L	or every 7 months
Oil leaks from power steering system		I	I	I	I	I	I	I	I	I	or every 7 months
• Looseness in or damage to power steering system mounting		I	I	I	I	I	I	I	I	I	or every 7 months
Power steering fluid		-	-	-	R	-	-	-	R	-	or every 28 months
Power steering hose		-	-	-	R	-	-	-	R	-	or every 28 months
Looseness in connection between knuckle and front axle		I	I	I	I	I	I	I	I	I	or every 7 months
Looseness in or damage to steering mechanism		-	-	-	I	-	-	-	I	-	or every 28 months

• : The vehicle needs to be maintained more often if it is driven in severe condition. Refer to "Maintenance Schedule for Severe-condition" in this section.

LNWE0BLF003201

NPR75 model No. 2

I : Inspect, clean, or repair or replace as required A : Adjust R : Replace T : Tighten to the specified torque L : Lubricate

Service Interval	km	11,250	22,500	33,750	45,000	56,250	67,500	78,750	90,000	101,250	Odometer reading or months, whichever comes first
	miles	7,000	14,000	21,000	28,000	35,000	42,000	49,000	56,000	63,000	
Steering wheel free play		I	I	I	I	I	I	I	I	I	or every 7 months
Steering mechanism functionality		I	I	I	I	I	I	I	I	I	or every 7 months
Wheel alignment		-	-	-	I	-	-	-	I	-	or every 28 months
Brake fluid		I	I	I	R	I	I	I	R	I	or every 28 months
Brake system oil leaks		I	I	I	I	I	I	I	I	I	or every 7 months
• Disc brake pad and disc wear		I	I	I	I	I	I	I	I	I	or every 7 months
Brake pedal stroke and free play		I	I	I	I	I	I	I	I	I	or every 7 months
Looseness in or damage to brake pipe and brake hose connections		I	I	I	I	I	I	I	I	I	or every 7 months
Parking brake cable		I	I	I	I	I	I	I	I	I	or every 7 months
Parking brake functionality		I	I	I	I	I	I	I	I	I	or every 7 months
Parking brake lever stroke		I	I	I	I	I	I	I	I	I	or every 7 months
Parking brake shoe lining wear		-	-	-	I	-	-	-	I	-	or every 28 months
Wear of or damage to parking brake drum		-	-	-	I	-	-	-	I	-	or every 28 months
Damage to parking brake ratchet mechanism		-	-	-	I	-	-	-	I	-	or every 28 months
Leaf spring damage		I	I	I	I	I	I	I	I	I	or every 7 months
Looseness in or damage to suspension mounting		I	I	I	I	I	I	I	I	I	or every 7 months
Shock absorber oil leaks		I	I	I	I	I	I	I	I	I	or every 7 months
Shock absorber mounting looseness		I	I	I	I	I	I	I	I	I	or every 7 months
Wheel nuts and wheel bolts		T	T	T	T	T	T	T	T	T	or every 7 months
Disc wheel damage		I	I	I	I	I	I	I	I	I	or every 7 months
Wheel hub bearing grease		-	-	-	R	-	-	-	R	-	or every 28 months
Tire air pressure and damage		I	I	I	I	I	I	I	I	I	or every 7 months
Battery fluid specific gravity		I	I	I	I	I	I	I	I	I	or every 7 months
Exhaust pressure check or filter cleaning		-	-	-	-	-	-	-	-	I	or every 12 months
Differential pressure sensor rubber element		Every 40,000km (24,000miles): R									or every 12 months
AdBlue® filter		Every 200,000km (124,000 miles): R									
Inspection of lights, horn, windshield wiper, and washer		I	I	I	I	I	I	I	I	I	or every 7 months
Inspection of nuts and bolts on chassis and body		-	-	-	I	-	-	-	I	-	or every 28 months

• : The vehicle needs to be maintained more often if it is driven in severe condition. Refer to "Maintenance Schedule for Severe-condition" in this section.

LNWE0BLF001101

2. Maintenance Schedule for Severe-Condition

Vehicles used under severe conditions need more frequent maintenance than those receiving ordinary use.

A: Operations involving frequent stop and go
B: Driving on rough, mountain, or uphill roads
C: Driving in dusty areas
D: Driving on snowy or coastal roads

Item		Distance covered	Condition				
			A	B	C	D	A+D
Engine oil	4JJ1 engine without PTO (Except Israel)	Replace. every 10,000 km (6,000 miles)			O		O
	4JJ1 engine with PTO (Except Israel)	Replace. every 7,500 km (4,500 miles)			O		O
	4JJ1 engine (Israel)	Replace. every 7,500 km (4,500 miles)			O		O
	4HK1 engine	Replace. every 10,000 km (6,000 miles)			O		O
Engine oil filter	4JJ1 engine without PTO (Except Israel)	Replace. every 10,000 km (6,000 miles)			O		O
					O		O

	4JJ1 engine with PTO (Except Israel)	Replace. every 7,500 km (4,500 miles)					
	4JJ1 engine (Israel)	Replace. every 7,500 km (4,500 miles)			O		O
	4HK1 engine	Replace. every 10,000 km (6,000 miles)			O		O
Air cleaner element		Inspect. every 5,000 km (3,000 miles) Replace. every 20,000 km (12,000 miles)			O		
Damage or looseness in exhaust pipe, exhaust brake, exhaust throttle, and their fittings		Inspect. every 10,000 km (6,000 miles)	O	O		O	
Transmission oil		Replace. every 20,000 km (12,000 miles)		O			
Smoother clutch oil (Vehicles with Smoother system)		Replace. every 20,000 km (12,000 miles)		O			
Propeller shaft universal joint and sliding sleeve		Grease every 10,000 km (6,000 miles)		O			
Differential gear oil		Replace. every 20,000 km (12,000 miles)		O			
Kingpin		Grease every 5,000 km (3,000 miles)		O	O	O	
Looseness or damage in power steering installation		Inspect. every 5,000 km (3,000 miles)		O			
Wear in brake shoe lining and drum		Inspect. every 10,000 km (6,000 miles)	O	O	O		
Wear in disc brake pad and disc		Inspect. every 5,000 km (3,000 miles)	O	O	O		

Copyright ISUZU MOTORS LIMITED. All rights reserved.