Maintenance Schedule

1. Maintenance Schedule

When inspecting the following items, also inspect regular inspection items.

I: Inspect then clean, adjust, repair, or replace as necessary
A: Adjust
R: Replace
T: Tighten to the specified torque
L: Lubricate

[V]: Market-/type-specific equipment (The vehicle may not have the equipment with this symbol.)
[M/T]: Manual transmission model
[A/T]: Automatic transmission model
[SA]: Vehicle equipped with the Smoother system
[DCT]: Vehicle equipped with the DCT system

NLR88/NMR88/NPR88 models (4JZ1 engine model)

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	20	40	60	80	100	120	140	160		
x1,000 miles	12	24	37	49	62	75	87	99		
ENGINE										
Engine oil	*2 When "engine oil and filter indicator light" is displayed on the multi-information display: R								or every 12 months	-
Engine oil filter	*2 When "engine oil and filter indicator light" is displayed on the multi-information display: R								or every 12 months	-
Fuel filter element	-	R	-	R	-	R	-	R	or every 12 months	X
Pre-fuel filter	-	R	-	R	-	R	-	R	or every 12 months	X
Fuel line system	-	I	-	I	-	I	-	I	or every 24 months	-
Air cleaner element	I	R	I	R	I	R	I	R	or every 24 months: R	X
Valve clearance	Every 12 months: I									-
Drive belt tension and damage	I	I	I	I	I	I	I	I	or every 12 months	-
Engine coolant	Every 12 months: I Every 24 months: R (when Isuzu recommended coolant is used)									-
Engine cooling system	Every 24 months: I									-
Starter (model with ecostop)	When "starter indicator light" is displayed on the multi-information display: R									-
EXHAUST SYSTEM										
Damage to or looseness of the exhaust system such as exhaust pipe, exhaust brake, exhaust throttle, silencer, and their mountings	I	I	I	I	I	I	I	I	or every 12 months	X
DPD exhaust pressure check or filter cleaning	-	-	-	-	I	-	-	-	or every 12 months	-
DPD differential pressure sensor rubber hose	-	I	-	I	-	I	-	I	or every 12 months	-

LNWS0BLF003601

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	20	40	60	80	100	120	140	160		
x1,000 miles	12	24	37	49	62	75	87	99		
PM sensor	Every 240,000 km (149,000 miles): R								or every 180 months	-
Nitrogen oxides (NOx) sensor	Every 280,000 km (174,000 miles): R								or every 180 months	-
O2 sensor	Every 240,000 km (149,000 miles): R								or every 180 months	-
BRAKE										
Brake fluid	-	R	-	R	-	R	-	R	or every 24 months	-
Brake fluid level and fluid leak in brake system	I	I	I	I	I	I	I	I	or every 12 months	X
Brake shoe lining and drum wear and damage (model with drum brakes)	I	I	I	I	I	I	I	I	or every 12 months	X
Brake pad for wear	I	I	I	I	I	I	I	I	-	X
Brake rotor for wear and damage	I	I	I	I	I	I	I	I	or every 12 months	-
Parking brake cable looseness and damage	I	I	I	I	I	I	I	I	or every 12 months	-
Wear of parking brake shoe lining and parking brake drum	-	I	-	I	-	I	-	I	or every 24 months	-
Brake pedal stroke and free play	I	I	I	I	I	I	I	I	or every 12 months	-
TRANSMISSION/CLUTCH										
Transmission oil (MYY model)	I	R	I	R	I	R	I	R	or every 24 months: R	X
Transmission oil (MYR model)	I	R	I	R	I	R	I	R	or every 24 months: R	X
Gear control cable	-	A	-	A	-	A	-	A	or every 12 months	-
Gear control mechanism looseness	-	I	-	I	-	I	-	I	or every 24 months	-
[M/T] Clutch system function	I	I	I	I	I	I	I	I	or every 12 months	-
[M/T] Clutch fluid	I	R	I	R	I	R	I	R	or every 12 months: I or every 24 months: R	-
[DCT] DCT clutch oil	I	R	I	R	I	R	I	R	or every 24 months: R	X
DRIVELINE/AXLE/TIRE										
Differential gear oil	I	R	I	R	I	R	I	R	or every 24 months: R	X

LNWR0BLF002201

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	20	40	60	80	100	120	140	160		
x1,000 miles	12	24	37	49	62	75	87	99		
Propeller shaft, propeller shaft center bearing, universal joints and sliding sleeves	L	L	L	L	L	L	L	L	or every 12 months	X
Propeller shaft spline wear	I	I	I	I	I	I	I	I	or every 24 months	-
Loose propeller shaft joints, propeller shaft bearings, and other related components	I	I	I	I	I	I	I	I	or every 12 months	-
King pin (model with rigid front suspension)	L	L	L	L	L	L	L	L	or every 12 months	X
Wheel nuts and wheel bolts	T	T	T	T	T	T	T	T	or every 12 months	-
Wheel alignment	-	I	-	I	-	I	-	I	or every 24 months	-
STEERING										
Power steering fluid	-	R	-	R	-	R	-	R	or every 24 months	-
Oil leaks from power steering system	I	I	I	I	I	I	I	I	or every 12 months	-
Power steering hose	-	-	-	R	-	-	-	R	or every 48 months	-
Steering mechanism functionality	I	I	I	I	I	I	I	I	or every 12 months	-
Looseness in or damage to power steering system mounting	I	I	I	I	I	I	I	I	or every 12 months	X
Looseness in or damage to steering mechanism	-	I	-	I	-	I	-	I	or every 24 months	-
SUSPENSION										
Leaf spring damage	I	I	I	I	I	I	I	I	or every 12 months	-
Shock absorber mounting looseness	I	I	I	I	I	I	I	I	or every 12 months	-
Looseness in or damage to suspension mounting	I	I	I	I	I	I	I	I	or every 12 months	-
AIR CONDITIONER										
Air conditioner blower filter	Every 12 months: I*3									-

LNWS0BLF003701

Note:

- ***1 Your vehicle needs to be maintained more often if it is driven in severe conditions.**
- ***2 The illumination timing depends on the usage of the vehicle (the light is illuminated when the mileage reaches a maximum of 40,000 km (24,000 miles)).**
- ***3 If the air conditioner blower filter is dirty, clean it as needed.**

NPR75 model (4HK1 engine model)

When "fuel filter indicator light" is displayed on the multi-information display: R

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	20	40	60	80	100	120	140	160		
x1,000 miles	12	24	37	49	62	75	87	99		
ENGINE										
Engine oil (except models for Israel)	-	R	-	R	-	R	-	R	or every 12 months	X
Engine oil (models for Israel)	Every 22,500 km (14,000 miles): R								or every 12 months	X
Engine oil filter (except models for Israel)	-	R	-	R	-	R	-	R	or every 12 months	X
Engine oil filter (models for Israel)	Every 22,500 km (14,000 miles): R								or every 12 months	X
Fuel filter element	-	R	-	R	-	R	-	R	or every 12 months	-
Pre-fuel filter	When "fuel filter indicator light" is displayed on the multi-information display: R									-
Fuel line system	-	-	I	-	-	I	-	-	or every 24 months	-
Air cleaner element	When "air cleaner inspection indicator light" is displayed on the multi-information display: I									-
Valve clearance	Every 12 months: I									-
Drive belt tension and damage	I	I	I	I	I	I	I	I	or every 12 months	-
Engine coolant	Every 12 months: I Every 24 months: R (when Isuzu recommended coolant is used)									-
Engine cooling system	Every 24 months: I									-
EXHAUST SYSTEM										
Damage to or looseness of the exhaust system such as exhaust pipe, exhaust brake, exhaust throttle, silencer, and their mountings	I	I	I	I	I	I	I	I	or every 12 months	X
DPD exhaust pressure check or filter cleaning	-	-	-	-	-	I	-	-	or every 12 months	-
DPD differential pressure sensor rubber hose	-	I	-	I	-	I	-	I	or every 12 months	-
AdBlue® filter	Every 200,000 km (124,000 miles): R									X
PM sensor	Every 240,000 km (149,000 miles): R								or every 180 months	-

LNWS0BLF004301

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	20	40	60	80	100	120	140	160		
x1,000 miles	12	24	37	49	62	75	87	99		
Nitrogen oxides (NOx) sensor	Every 280,000 km (174,000 miles): R								or every 180 months	-
BRAKE										
Brake fluid	-	R	-	R	-	R	-	R	or every 24 months	-
Brake fluid level and fluid leak in brake system	I	I	I	I	I	I	I	I	or every 12 months	X
Brake pad for wear	I	I	I	I	I	I	I	I	-	X
Brake rotor for wear and damage	I	I	I	I	I	I	I	I	or every 12 months	-
Parking brake cable looseness and damage	I	I	I	I	I	I	I	I	or every 12 months	-
Wear of parking brake shoe lining and parking brake drum	-	I	-	I	-	I	-	I	or every 24 months	-
Brake pedal stroke and free play	I	I	I	I	I	I	I	I	or every 12 months	-
TRANSMISSION/CLUTCH										
Transmission oil (MZZ model)	I	R	I	R	I	R	I	R	or every 24 months: R	X
Gear control cable	-	A	-	A	-	A	-	A	or every 12 months	-
Gear control mechanism looseness	-	I	-	I	-	I	-	I	or every 24 months	-
[M/T] Clutch system function	I	I	I	I	I	I	I	I	or every 12 months	-
[M/T] Clutch fluid	I	R	I	R	I	R	I	R	or every 12 months: I or every 24 months: R	-
[SA] Smoother clutch oil	I	R	I	R	I	R	I	R	or every 24 months: R	X
DRIVELINE/AXLE/TIRE										
Differential gear oil	I	R	I	R	I	R	I	R	or every 24 months: R	X
Propeller shaft, propeller shaft center bearing, universal joints and sliding sleeves	L	L	L	L	L	L	L	L	or every 12 months	X
Propeller shaft spline wear	-	I	-	I	-	I	-	I	or every 24 months	-

LNWS0BLF003901

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	20	40	60	80	100	120	140	160		
x1,000 miles	12	24	37	49	62	75	87	99		
Loose propeller shaft joints, propeller shaft bearings, and other related components	I	I	I	I	I	I	I	I	or every 12 months	-
King pin (model with rigid front suspension)	L	L	L	L	L	L	L	L	or every 12 months	X
Wheel nuts and wheel bolts	T	T	T	T	T	T	T	T	or every 12 months	-
Wheel alignment	-	I	-	I	-	I	-	I	or every 24 months	-
STEERING										
Power steering fluid	-	R	-	R	-	R	-	R	or every 24 months	-
Oil leaks from power steering system	I	I	I	I	I	I	I	I	or every 12 months	-
Power steering hose	-	-	-	R	-	-	-	R	or every 48 months	-
Steering mechanism functionality	I	I	I	I	I	I	I	I	or every 12 months	-
Looseness in or damage to power steering system mounting	I	I	I	I	I	I	I	I	or every 12 months	X
Looseness in or damage to steering mechanism	-	I	-	I	-	I	-	I	or every 24 months	-
SUSPENSION										
Leaf spring damage	I	I	I	I	I	I	I	I	or every 12 months	-
Shock absorber mounting looseness	I	I	I	I	I	I	I	I	or every 12 months	-
Looseness in or damage to suspension mounting	I	I	I	I	I	I	I	I	or every 12 months	-
AIR CONDITIONER										
Air conditioner blower filter	Every 12 months: I*2									-

LNWR0BLF002601

Note:

- ***1 Your vehicle needs to be maintained more often if it is driven in severe conditions.**
- ***2 If the air conditioner blower filter is dirty, clean it as needed.**

NLR87 model (RZ4E engine model)

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	20	40	60	80	100	120	140	160		
x1,000 miles	12	24	37	49	62	75	87	99		
ENGINE										
Engine oil*2	R	R	R	R	R	R	R	R	or every 12 months	X
Engine oil filter*2	R	R	R	R	R	R	R	R	or every 12 months	X
Fuel filter element	-	R	-	R	-	R	-	R	or every 12 months	-
Pre-fuel filter	-	R	-	R	-	R	-	R	or every 12 months	-
Fuel line system	-	I	-	I	-	I	-	I	or every 24 months	-
Air cleaner element	I	I	R	I	I	R	I	I	or every 24 months: R	X
Drive belt damage	I	I	I	I	I	I	I	I	or every 12 months	-
Engine coolant	Every 12 months: I Every 24 months: R (when Isuzu recommended coolant is used)									-
Engine cooling system	Every 24 months: I									-
Starter	When "starter indicator light" is displayed on the multi-information display: R									-
EXHAUST SYSTEM										
Damage to or looseness of the exhaust system such as exhaust pipe, exhaust brake, exhaust throttle, silencer, and their mountings	I	I	I	I	I	I	I	I	or every 12 months	X
DPD exhaust pressure check or filter cleaning	-	-	-	-	I	-	-	-	or every 12 months	-
DPD differential pressure sensor rubber hose	-	I	-	I	-	I	-	I	or every 12 months	-
PM sensor	Every 240,000 km (149,000 miles): R								or every 180 months	-
Nitrogen oxides (NOx) sensor	Every 300,000 km (186,000 miles): R								or every 180 months	-
O2 sensor	Every 240,000 km (149,000 miles): R								or every 120 months	-

LNWS0BLF004001

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	20	40	60	80	100	120	140	160		
x1,000 miles	12	24	37	49	62	75	87	99		
BRAKE										
Brake fluid	-	R	-	R	-	R	-	R	or every 24 months	-
Brake fluid level and fluid leak in brake system	I	I	I	I	I	I	I	I	or every 12 months	X
Brake shoe lining and drum wear and damage (model with drum brakes)	I	I	I	I	I	I	I	I	or every 12 months	X
Brake pad for wear	I	I	I	I	I	I	I	I	-	X
Brake rotor for wear and damage	I	I	I	I	I	I	I	I	or every 12 months	-
Parking brake cable looseness and damage	I	I	I	I	I	I	I	I	or every 12 months	-
Wear of parking brake shoe lining and parking brake drum	-	I	-	I	-	I	-	I	or every 24 months	-
Brake pedal stroke and free play	I	I	I	I	I	I	I	I	or every 12 months	-
TRANSMISSION/CLUTCH										
[M/T] Transmission oil (MVC model)	I	R	I	R	I	R	I	R	or every 24 months: R	X
[A/T] Automatic transmission fluid	Initial 60,000 km (37,000 miles): I Every 60,000 km (37,000 miles) after every replacement: I									X
[A/T] Automatic transmission fluid	-	-	-	-	R	-	-	-	or every 60months	X
[A/T] Automatic transmission fluid leakage	I	I	I	I	I	I	I	I	or every 12 months	-
Gear control cable	-	A	-	A	-	A	-	A	or every 12 months	-
Gear control mechanism looseness	-	I	-	I	-	I	-	I	or every 24 months	-
[M/T] Clutch system function	I	I	I	I	I	I	I	I	or every 12 months	-
[M/T] Clutch fluid	I	R	I	R	I	R	I	R	or every 12 months: I or every 24 months: R	-
DRIVELINE/AXLE/TIRE										
Differential gear oil	I	R	I	R	I	R	I	R	or every 24 months: R	X

LNWR0BLF002801

Service interval									Odometer reading or months, whichever comes first	Severe*1
x1,000 km	20	40	60	80	100	120	140	160		
x1,000 miles	12	24	37	49	62	75	87	99		
Propeller shaft, propeller shaft center bearing, universal joints and sliding sleeves	L	L	L	L	L	L	L	L	or every 12 months	X
Propeller shaft spline wear	-	I	-	I	-	I	-	I	or every 24 months	-
Loose propeller shaft joints, propeller shaft bearings, and other related components	I	I	I	I	I	I	I	I	or every 12 months	-
Rear wheel hub bearing grease (model with drum brakes and rear single tire)	-	R	-	R	-	R	-	R	or every 24 months	-
King pin (model with rigid front suspension)	L	L	L	L	L	L	L	L	or every 12 months	X
Wheel nuts and wheel bolts	T	T	T	T	T	T	T	T	or every 12 months	-
Wheel alignment	-	I	-	I	-	I	-	I	or every 24 months	-
STEERING										
Power steering fluid	-	R	-	R	-	R	-	R	or every 24 months	-
Oil leaks from power steering system	I	I	I	I	I	I	I	I	or every 12 months	-
Power steering hose	-	-	-	R	-	-	-	R	or every 48 months	-
Steering mechanism functionality	I	I	I	I	I	I	I	I	or every 12 months	-
Looseness in or damage to power steering system mounting	I	I	I	I	I	I	I	I	or every 12 months	X
Looseness in or damage to steering mechanism	-	I	-	I	-	I	-	I	or every 24 months	-
SUSPENSION										
Leaf spring damage	I	I	I	I	I	I	I	I	or every 12 months	-
Shock absorber mounting looseness	I	I	I	I	I	I	I	I	or every 12 months	-
Looseness in or damage to suspension mounting	I	I	I	I	I	I	I	I	or every 12 months	-
AIR CONDITIONER										
Air conditioner blower filter	Every 12 months: I*3									-

LNWS0BLF004101

Note:

- ***1 Your vehicle needs to be maintained more often if it is driven in severe conditions.**
- ***2 When "engine oil and filter maintenance alerts" is displayed on the multi-information display at less than 20,000 km (12,000 miles), perform maintenance according to the indicated interval.**
- ***3 If the air conditioner blower filter is dirty, clean it as needed.**

2. Maintenance Schedule for Severe-Condition

Driving condition
A: Operations involving frequent starts and stops
B: Driving on rough roads, mountain roads or uphill roads
C: Driving in dusty areas
D: Driving on snow-covered or seashore roads
E: Low travel distance high engine load (Ex. Concrete pump truck, electric power supply truck, fire truck)

NLR88/NMR88/NPR88 models (4JZ1 engine model)

Item	Distance covered or engine operation time	Condition
Fuel filter element	Replace every 1,000 hours	E
Pre-fuel filter	Replace every 1,000 hours	E
Air cleaner element	Inspect every 10,000 km (6,000 miles) Replace every 20,000 km (12,000 miles)	C
Damage to or looseness of the exhaust system such as exhaust pipe, exhaust brake, exhaust throttle, silencer, and their mountings	Inspect every 10,000 km (6,000 miles)	A, B, D
Brake fluid level and fluid leak in brake system	Inspect every 5,000 km (3,000 miles)	D
Brake shoe lining and drum wear and damage	Inspect every 10,000 km (6,000 miles)	A, B
Brake pad for wear	Inspect every 5,000 km (3,000 miles)	A, B
Transmission oil (MYY model)	Replace every 20,000 km (12,000 miles)	B, C
Transmission oil (MYR model)	Replace every 20,000 km (12,000 miles)	B, C
[DCT] DCT clutch oil	Replace every 20,000 km (12,000 miles)	B, C
Differential gear oil	Replace every 20,000 km (12,000 miles)	B
Propeller shaft, propeller shaft center bearing, universal joints and sliding sleeves	Grease every 10,000 km (6,000 miles)	B
King pin (model with rigid front suspension)	Grease every 10,000 km (6,000 miles)	B, C, D
Looseness in or damage to power steering system mounting	Inspect every 10,000 km (6,000 miles)	B

LNWR0BMF000601

NPR75 model (4HK1 engine model)

Item	Distance covered or engine operation time	Condition
Engine oil (except models for Israel)	Replace every 20,000 km (12,000 miles)	C, A+D
	Replace every 500 hours	E
Engine oil (models for Israel)	Replace every 10,000 km (6,000 miles)	C, A+D
	Replace every 500 hours	E
Engine oil filter (except models for Israel)	Replace every 20,000 km (12,000 miles)	C, A+D
	Replace every 1,000 hours	E
Engine oil filter (models for Israel)	Replace every 10,000 km (6,000 miles) or 500 hours	C, A+D
	Replace every 1,000 hours	E
Fuel filter element	Replace every 1,000 hours	E
Damage to or looseness of the exhaust system such as exhaust pipe, exhaust brake, exhaust throttle, silencer, and their mountings	Inspect every 10,000 km (6,000 miles)	A, B, D
AdBlue® filter	Replace every 4,000 hours	E
Brake fluid level and fluid leak in brake system	Inspect every 5,000 km (3,000 miles)	D
Brake pad for wear	Inspect every 5,000 km (3,000 miles)	A, B
Transmission oil (MZZ model)	Replace every 20,000 km (12,000 miles)	B, C
[SA] Smoother clutch oil	Replace every 20,000 km (12,000 miles)	B, C
Differential gear oil	Replace every 20,000 km (12,000 miles)	B
Propeller shaft, propeller shaft center bearing, universal joints and sliding sleeves	Grease every 10,000 km (6,000 miles)	B
King pin (model with rigid front suspension)	Grease every 10,000 km (6,000 miles)	B, C, D
Looseness in or damage to power steering system mounting	Inspect every 10,000 km (6,000 miles)	B

LNWS0BLF004201

NLR87 model (RZ4E engine model)

Item	Distance covered	Condition
Engine oil	Replace every 5,000 km (3,000 miles)	C, E, A+D
Engine oil filter	Replace every 5,000 km (3,000 miles)	C, E, A+D
Air cleaner element	Inspect every 5,000 km (3,000 miles) Replace every 20,000 km (12,000 miles)	C
Damage to or looseness of the exhaust system such as exhaust pipe, exhaust brake, exhaust throttle, silencer, and their mountings	Inspect every 10,000 km (6,000 miles)	A, B, D
Brake fluid level and fluid leak in brake system	Inspect every 5,000 km (3,000 miles)	D
Brake shoe lining and drum wear and damage	Inspect every 10,000 km (6,000 miles)	A, B
Brake pad for wear	Inspect every 5,000 km (3,000 miles)	A, B
[M/T] Transmission oil (MVC model)	Replace every 20,000 km (12,000 miles)	B, C
[A/T] Automatic transmission fluid	Inspect every 40,000 km (24,000 miles) Replace every 80,000 km (48,000 miles) or 60 months	B, C
Differential gear oil	Replace every 20,000 km (12,000 miles)	B
Propeller shaft, propeller shaft center bearing, universal joints and sliding sleeves	Grease every 10,000 km (6,000 miles)	B
King pin (model with rigid front suspension)	Grease every 10,000 km (6,000 miles)	B, C, D
Looseness in or damage to power steering system mounting	Inspect every 10,000 km (6,000 miles)	B

LNWR0BMF000801

Copyright ISUZU MOTORS LIMITED. All rights reserved.