



PERFORMER RPM CHRYSLER ALUMINUM CYLINDER HEADS
for Small-block Chrysler V8 Engines
CATALOG #60779 & #60179 (Complete),
CATALOG #60769 & #60199 (Bare)
GENERAL INSTRUCTIONS

PLEASE study these instructions carefully before installing your new cylinder heads. If you have any questions or problems, do not hesitate to contact our **Technical Hotline at: 1-800-416-8628**, 7am-5pm, Monday through Friday **or e-mail us at Edelbrock@Edelbrock.com**. **PLEASE** complete and mail your warranty card. Be sure to write the model number of this product in the "Part # ____" space. **THANK YOU.**

- **DESCRIPTION:** Designed for non-emissions 1967-1991 Chrysler 318-340-360 c.i.d. engines, these heads feature a 65cc combustion chamber along with a 171cc intake port and an 77cc exhaust port volume. Other outstanding features include phosphor-bronze valve guides, interlocking, ductile iron valve seats and premium one-piece, stainless steel, high-flow 2.02" and 1.60" intake and exhaust valves. Heat treated, machined steel retainers and valve locks along with heavy duty valve springs work with cams having valve lifts up to .575". These powerful heads use the stock location for intake and exhaust bolt holes and flanges, rocker shafts, spark plugs and valve cover rails, for compatibility with original equipment and aftermarket parts. These heads are assembled with the following components: Stainless steel, one-piece, swirl-polished intake and exhaust valves with under-cut stems for increased flow; 2-ring positive oil control seals; Edelbrock Sure-Seat Valve Springs #5767, retainers #9736, and valve keepers #9611. Complete cylinder heads are assembled and prepared for installation right out of the box. Bare cylinder heads will have valve guides and seats installed, but will require final sizing and a valve job to match the valves you will be using.

- **IMPORTANT NOTES: READ THIS BEFORE BEGINNING INSTALLATION!**

For a successful installation, the Edelbrock Performer RPM Cylinder Heads require some components other than original equipment replacement parts.

To complete your installation, you will need the following items:

- ☐ Head gaskets; Fel-Pro #1008 (see installation instructions)
- ☐ Intake manifold gaskets; Fel-Pro #1213 or equivalent
- ☐ Exhaust gaskets; Fel-Pro #1413 or equivalent
- ☐ Edelbrock Head Bolt Kit #8555; (see instructions below)
- ☐ Adjustable rocker arm assembly

NOTE: These heads are designed to accommodate stock stamped steel rocker arm assemblies, and stock-like aftermarket setups. Ductile iron adjustable arms may require special clearancing of the rocker arm body in order to clear valve spring retainers. Also, non-stock spec, aftermarket rocker arms may require special modifications.

- ☐ Pushrods compatible with adjustable rocker arm assembly (stock length- 7.375")
- ☐ 14mm x 3/4" reach gasketed spark plugs; Champion RC-12YC or equivalent

Checking Piston-to-Valve, Piston-to-Bore and Piston-to-Head Clearances

Prior to installation, it is highly recommended that valve-to-piston clearances are checked and corrected to minimum specs, if necessary. These heads have larger-than-stock valve sizes and may not work with the valve pockets in stock pistons, especially if a high lift cam is used. The use of aftermarket pistons and/or custom machining to your pistons may be required. Actual valve-to-piston clearance should be specified by your camshaft manufacturer.

If these heads are used on small bore engines, valve-to-bore clearance should also be checked, and the top of the bore notched for clearance if necessary.

Special Note: Use P/N 60179 for high compression 340 engines with negative piston deck height (Pistons protrude above the deck on the block). **In all cases, you must make sure that there is at least .035" clearance between the piston and any part of the cylinder heads.**

- **ACCESSORIES**

Although Edelbrock Cylinder Heads will accept OEM components (valve covers, intake manifold, etc.), we highly recommend that premium quality hardware be used with your new heads.

HEAD BOLTS or STUDS: High quality head studs or head bolts with hardened washers must be used to prevent galling of the aluminum bolt bosses. Edelbrock Head Bolt Kit #8555 includes two longer-than-stock bolts which must be used with these cylinder heads. If you use any other head



AIR/FUEL RATIO MONITOR

Catalog #6593

INSTALLATION INSTRUCTIONS

PLEASE study these instructions carefully before beginning this installation. Most installations can be accomplished with common tools and procedures. However, you should be familiar with and comfortable working on your vehicle. If you do not feel comfortable performing this installation, it is recommended to have the installation completed by a qualified mechanic. If you have any questions, please call our **Technical Hotline at: 1-800-416-8628**, 7:00 am - 5:00 pm, Pacific Standard Time, Monday through Friday or e-mail us at edelbrock@edelbrock.com.

NOTE: Proper installation is the responsibility of the installer. Improper installation may result in poor performance and engine or vehicle damage.

PLEASE complete and mail your warranty card. Be sure to write the model number of this product in the "Part # ____" space. **THANK YOU.**

DESCRIPTION: These instructions are for installation of the Edelbrock Air/Fuel Ratio Monitor, an electronic device that measures oxygen content of exhaust gas to determine Air/Fuel ratio.

KIT CONTENTS:

- | | | |
|---|---|--|
| ☐ 1 - Air/Fuel Monitor | ☐ 1 - Weld Bung for Exhaust Pipe | ☐ 1 - Rubber Grommet, 5/16" |
| ☐ 1 - O2 Sensor Assembly | ☐ 2 - Velcro Mounting Strips | ☐ 1 - Warranty Card |

INSTALLATION INSTRUCTIONS

1. The exhaust weld bung should be welded to a 3/4-inch hole in the exhaust system located as close as practical to the exhaust manifold/header coupling flange. Your local muffler shop should be able to perform this task at a reasonable cost. Be sure to allow clearance for the sensor and its wire harness.
2. Screw the O2 sensor assembly into the weld bung using a 7/8" wrench. A small amount of anti-seize compound is on the threads of the sensor. Should this be wiped off, we recommend reapplying anti-seize to the threads.
3. Disconnect the battery prior to any electrical work. Always disconnect the ground terminal first to reduce the possibility of shorting a wrench from the +12V side of the battery to ground.
4. Select a mounting location for the Air/Fuel Ratio Monitor display that may be viewed easily, but in reach of the supplied harness. Install the Air/Fuel display using the supplied velcro strips.
5. Locate a place in the firewall to feed the three wires through to the engine compartment. Usually there are existing through holes that may be used. A rubber grommet is provided and should be used if required. **NOTE: Use care in routing wires near or around hot exhaust components. Shorting the O2 sensor signal to ground may permanently damage the sensor.**
6. Insert the three-pin Weather Pack connector pins into the supplied connector body. **Refer to Figure 1.**
7. Route the wires to the mating connector attached to the O2 sensor and plug the cable together. **NOTE: To prevent catastrophic failure of unit, avoid routing wires near spark plug wires.** Be especially careful to avoid running wires parallel to plug wires. Allow even more clearance with high energy ignitions.
8. Locate and connect the Red wire to a source of +12 volt power that is on when the engine is running.
9. Connect the Black wire to the rear of a cylinder head or a manifold bolt. Make sure the bolt hole is free of paint or other non-conducting material. **DO NOT USE VEHICLE SHEET METAL AS A SYSTEM GROUND.** Use an Ohm meter to check resistance along the path between the ground location and the O2 sensor bung. It should read less than 1 Ohm.
10. Re-connect the battery (positive terminal first), and start the engine.
11. The Air/Fuel Ratio Monitor is now ready for use. Indications begin after the exhaust temperature reaches about 600°F (after approximately 60 seconds).

USING THE AIR/FUEL RATIO MONITOR

- You can use the A/F Monitor to properly adjust all of your carburetion circuits including idle, cruise, and power. The seven indicator lights on your A/F Monitor include (from left to right) two yellow, four green, and one red light. These span a range of Air/Fuel ratios from 12:1 to 15:1. The stoichiometric (chemically ideal) ratio is 14.6:1, and this is usually a very good ratio to strive for during cruise and mild acceleration. Wide Open Throttle (WOT) typically requires a richer mixture, usually around 12 or 13:1. 15:1 ratios and higher are on the verge of lean misfire, and may result in pinging and excessive heat buildup. After initial warm-up (about 60 seconds), the A/F Monitor will begin to give

accurate readings. Notice that the very rapid response time of the monitor will often produce a quickly changing pattern of indicator light movement. This indicates that the actual A/F ratio is unstable, which is not uncommon. Bear in mind, it is always necessary to ensure that your engine is in proper operating condition in order to achieve best results. Factors such as ignition timing, spark plug condition, spark plug wire condition, compression, and manifold vacuum will all influence the efficiency of your engine and must be checked to verify that they are not the source of unusual readings.