



Installation Instructions

Chrysler Flexplates

Part Nos. 10230, 10231, 10234, 10235, 10236,
10237, 10238, 10239, 10241, and 10242

©1991, 1999, 2001 by B&M Racing and Performance Products

CAUTION: Please read the following information before installing your **B&M** flexplate.

Engine to transmission alignment is normally not a problem in low to medium performance applications with original equipment engines. However in applications where the crankshaft to block dowel pins dimension has changed because of line boring, serious problems can develop. **B&M** flexplates are designed primarily for high performance applications and will perform satisfactorily as long as the engine to transmission alignment is within .008" Total Indicator Reading (TIR). Installations which exceed this amount of runout can result in a worn converter hub bushing, leaking front seal and cracks in the flex plate. If you are installing this (or any other) flexplate on anything other than an original factory

installation we strongly recommend that you check the engine to transmission alignment.

Since the Torqueflite has a wrap around bellhousing aligning the block to transmission must be done with the transmission case empty. Rigidly attach indicator to crankshaft and indicate on the oil pump bore in the case. Alternatively you can use a manual transmission bellhousing to indicate runout. The TIR is a relative measure of crankshaft to transmission centerline eccentricity.

A Total Indicator Reading exceeding .008" can be corrected with offset dowel pins. An offset dowel pin will produce a TIR change that is double the dowel pin's eccentricity. To correct a particular case; select a pair of offset dowel pins that are nearest to one half of the TIR. Install both dowel pins with their slots parallel to each other and

aligned in the proper direction to correct the eccentricity.

Offset dowel pins are available from Mopar Performance dealers in three different offset ranges:

Offset	Chrysler P/N
.007"	P4120383
.014"	P4120383
.021"	P4120383

For Total Indicator Readings from:

.009 thru .020 use .007 dowel
.021 thru .034 use .014 dowel
.035 thru .050 use .021 dowel

NOTE: All dimensions given are in inches.

Once you are sure the engine and transmission are properly aligned install flexplate and torque bolts to the factory specification for your particular engine.



Installation Instructions

Pro Ratchet Shifter

Part Number 80840 & 80842

©2000 by B&M Racing and Performance Products

The **B&M Pro Ratchet Shifter** is a full ratchet shifter that is equally at home on the strip and on the street. It will work with most two speed, three speed or four speed automatic transmissions. It has a positive ratchet design so that you will not miss a shift, either up or down. It works with both standard and reverse pattern valve bodies. It has a unique "one hand" reverse lockout feature that meets NHRA and IHRA requirements. You don't need to use two hands to shift into Reverse.

Part #80840 is for use only with aluminum Powerglide transmissions. **The supplied B&M Powerglide Pro-Lever is for use with full manual valve bodies or transbrakes applications only.** Part #80842 is for use with three speed automatic transmissions such as the GM TH-400, TH-350, TH-250 and TH-200; the Ford C-4 and C-6; and the Chrysler 1966 and later Torqueflite A-727 and A-904, or four speed automatic transmissions such as the GM TH-200 4R, TH-700 R4, 4L60, 4L60E and 4L80E; the Ford AOD; and the Chrysler A-500 and A-518. To use the **B&M Pro Ratchet Shifter** with the Ford AOD transmissions you will need the optional accessory kit #40496.

Your **B&M Pro Ratchet Shifter** comes equipped with a neutral safety switch, a backup light switch, transmission brackets, levers and a five foot shift cable. Optional shifter cables in 2 ft. (#80830), 3 ft. (#80831), 4 ft. (#80832), 8 ft. (#80834), 10 ft. (#80835) and 12 ft. (#80836) are also available.

Please read the instructions and review the illustrations thoroughly before beginning the installation.

The mechanical components of this shifter are precision made and assembled at our factory. Any modification or disassembly of

these parts can cause the shifter to malfunction and will void the warranty. You should disassemble only those items outlined in the instructions.

The vehicle should be about 2 feet off the ground for ease of installation. Use jack stands, wheel ramps or a vehicle lift. Make sure the vehicle is firmly supported before attempting to work on it.

IMPORTANT: If your vehicle is equipped with a locking steering column. Securing the column lock lever in the engine compartment in the full up position will allow the steering wheel to be locked and unlocked and the ignition key to be removed.

WARNING: This allows the steering wheel to be locked **WHENEVER** the ignition key is turned to the "lock" position **WHILE THE VEHICLE IS MOVING, OR AT ANY OTHER TIME.** Securing the steering column lock lever in any other position will both **PREVENT** the steering wheel from locking and removal of the ignition key.

INSTALLATION

NOTE: If you are installing this shifter with a GM four speed automatic transmission, you must remove the three speed limiter blocker pin and the e-clips indicated in **Figure 1.** Removing this blocker pin gives the shifter four forward positions rather than three. For Ford AOD four speed automatic transmissions and Chrysler A-500 and A-518 four speed automatic transmissions do **not** remove this blocker pin, since these transmissions have only three forward positions. Also do **not** remove the blocker pin and the e-clips for any three speed automatic transmissions. (The three speed limiter blocker pin goes in the upper of the two holes at the rear of the shifter and the two speed limiter

blocker pin goes in the lower hole).

If you are installing this shifter with a Ford or Chrysler three or four speed automatic transmission you must install the Park limiter blocker pin and the e-clips as also indicated in **Figure 1.** This limiter limits the shifter travel into the Park position, so that it does not stretch the cable since Ford and Chrysler transmissions have less travel between Reverse and Park than GM transmissions do.

STEP 1. Remove the stock shift linkage;

Column Shifters: Remove all rods, levers or cables from the column and the transmission. Place the column shift lever in the Park position. Remove the pin holding the shift lever in the column and remove the lever assembly. If your vehicle is equipped with a locking steering column, secure the column lock lever in the full up position. **WARNING:** This allows the steering wheel to be locked and the ignition key removed **WHENEVER** the ignition key is turned to the "lock" position **WHILE THE VEHICLE IS MOVING, OR AT ANY OTHER TIME.**

Console Shifters: Remove the shifter mechanism from the console. Disconnect the rod or the cable from the transmission. Remove the cable bracket if equipped. If there is a cable or linkage from the console shifter or transmission to the steering column lock, it must be blocked in the Park position as described above.

NOTE: Installation of the shifter may require console modification or complete console removal depending on the space available in your vehicle.

STEP 2. Pull the carpet, if any, away from the floorboard where the shifter is to be mounted. If the vehicle has a bench type seat, move the seat to the full forward position. Place the shifter on the floor with the stick shifted to the



2005 Limited Warranty Guide

B&M Warranty Information

This warranty covers the **original purchasing consumer**. This warranty is limited to repair or replacement by B&M of any B&M part that fails because of a defect in materials or workmanship. **Implied warranty:** Any warranties implied by law are limited to the duration of this warranty, (except in those states where prohibited by law).

B&M Product Warranty Coverage

Limited Lifetime Warranty - All currently cataloged automatic and manual shifters (except cables) are covered by a limited lifetime warranty.

1 Year Limited Warranty - All other B&M products (except racing products) are covered for one year from the date of retail purchase to be free of defects in material and workmanship to the original purchaser (not warranted against normal wear, misuse or abuse).

90 Day Limited Warranty - B&M transmissions are covered for a period of 90 days from the date of retail purchase to the original retail purchaser.

What Is Not Covered

Failure of a B&M product due to misapplication, improper installation or maintenance, failure to provide adequate cooling or maintain proper fluid level, misuse, abuse, unauthorized repairs, accidents, or modifications to the original design.

Removal or replacement costs, transmission oil.

Damage to related components.

Costs incurred due to downtime of vehicle, towing costs or transportation costs.

Normal wear and tear.

Products used for racing - except shifters.

Melted shifter cables.

Transmissions and High Stall Converters damaged by overheating. These must be protected by a supplementary transmission oil cooler (in addition to the stock radiator-type cooler).

Shipping costs.