



INSTALLATION INSTRUCTIONS

MSD Pro-Billet Chrysler V8 Distributor

PN 8534 - 273, 318, 360

PN 8543 - 331/354 Early Hemi

PN 8544 - 392 Early Hemi

Important: Read these Instructions before attempting the installation.

Note: An MSD Ignition Control is required to use these distributors.

Parts Included:

- | | |
|-------------------------------------|---|
| 1 - Pro-Billet Distributor | 1 - Advance Kit |
| 1 - Rotor, PN 8467 | 1 - O-Ring |
| 1 - Distributor Cap, PN 8433 | 1 - Vacuum Advance Lock-Out Kit
(Hemis Only) |
| 1 - Wire Retainer | |
| 2 - 1.5" Self Tapping Screws | |
| 2 - 10-32 x 3/4" Socket Head Screws | |

WARNING: Before installing the MSD Distributor, disconnect the battery cables. When disconnecting the battery cables, always remove the Negative (-) cable first and install it last.

Note: The terminals of this Distributor require spark plug style terminals. You may need to change the terminals and boots of your wires. MSD offers two kits, PN 8849 or PN 8848 that are supplied with nine boots and terminals.

TIMING FUNCTIONS

Before continuing with the installation, here are a few definitions you should be aware of:

Initial Timing: This is the base timing (also referred to as idle timing) of the engine before the centrifugal advance begins.

Centrifugal Advance: The centrifugal (or mechanical) advance mechanism is made up of weights, springs, advance cams, and an advance stop bushing. The amount and rate of advance that your distributor is capable of is determined by the centrifugal timing. If you ever wish to lock out the centrifugal advance, refer to the centrifugal advance section.

Total Timing: This is the total of the initial timing plus the centrifugal advance added together. Example: 10° Initial + 25° centrifugal = 35° Total Timing. (When checking Total timing, disconnect the vacuum canister and plug the vacuum source.)

Vacuum Advance (Hemi's Only): The vacuum advance will advance the timing up to 10° during partial throttle driving (with 15 lbs of vacuum). The vacuum line should be routed to a ported vacuum outlet above the throttle plates.

Note: MSD Distributors are supplied with the heavy (slow) advance springs installed. This is to prevent detonation in certain applications. Review the information on pages 2-4 to determine the best advance curve for your application.



INSTALLATION INSTRUCTIONS

MSD 6 Series Installation Instructions 6A, 6AL, 6T, 6BTM, 6TN, 6ALN

Parts Included:

1 - MSD 6 Series Ignition
1 - Harness, PN 8860
1 - Harness, PN 8861
1 - 18" Ground Wire
1 - White Jumper
1 - Red Jumper
4 - 45° Faston Terminals
4 - #8 x 3/4" Screws
2 - 10-32 x 1/2" Screws
4 - 10-32 Hex Nuts
6 - #10 Lock Washers

1 - 100V/1A Diode
4 - Wire Splicers
2 - Wire Ties
1 - Faston Receptacle
2 - Faston Straight Terminals

6T, 6TN, 6AL 6ALN, 6BTM, 6-Offroad Only:

4 - Vibration Mounts and Hardware

6AL, 6ALN, 6BTM Only:

4 - RPM Modules, 3,000, 6,000, 7,000, 8,000

WARNING: During installation, disconnect the battery cables. When disconnecting the battery always remove the Negative cable first and install it last.

Note: Solid Core spark plug wires **cannot** be used with an MSD Ignition.

Note: An MSD 6 Series **cannot** be used with distributorless ignition systems (DIS).

THEORY OF 6 SERIES IGNITION

CAPACITIVE DISCHARGE

The MSD 6 Series Ignitions feature a capacitive discharge ignition design. The majority of stock ignition systems are inductive ignitions. In an inductive ignition, the coil must store and step up the voltage to maximum strength in between each firing. At higher rpm, since there is less time to charge the coil to full capacity, the voltage falls short of reaching maximum energy which results in a loss of power or top end miss.

The MSD Ignition features a capacitor which is quickly charged (within one millisecond) with 460 - 480 volts and stores it until the ignition is triggered. With the CD design, the voltage sent to the coil is always at full power even at high rpm.

MULTIPLE SPARKS

The MSD 6 Series produces full power multiple sparks for each firing of a plug. The number of multiple sparks that occur decreases as rpm increases, however the spark series always lasts for 20° of crankshaft rotation. Above 3,000 rpm there is simply not enough "time" to fire the spark plug more than once, so there is only one powerful spark.

REV LIMITER

6AL, 6ALN, 6BTM: These ignitions are equipped with built-in Adjustable Soft Touch Rev Controls. MSD Rev Limiters are adjustable with plug-in modules which are available in 100 rpm increments. The Soft Touch circuitry provides a smooth and accurate rev limit by dropping the spark to individual cylinders. The Soft Touch produces a load-free rev limit that is within 1% of the selected rpm.



COIL COMPATIBILITY LIST

This chart lists the compatibility of various coils with MSD Ignition Controls. It is impossible to list every coil combination and it is recommended to check with the coil manufacturer before installation.

★ - Indicates preferred coils for model indicated. YES - Coil is compatible with the model indicated. NO - Coil is NOT compatible. Do not use.	MSD-5/ BLASTER	MSD-6/SCI SERIES	7AL-2, 7AL-3 SERIES	DIGITAL-7 SERIES
MSD Blaster II Coil PN 8200 Chrome	★	★	YES	NO
MSD Pro Power Coil PN 8201 (Drag Race Only)	NO	NO	★	NO
MSD Blaster II Coil PN 8202 Red	★	★	YES	NO
MSD Blaster II Coil PN 8203 w/hardware	★	★	YES	NO
MSD Blaster II Coil PN 8205 (Ford style Nail Head)	★	★	YES	NO
MSD Blaster II High Vibration Coil PN 8222	★	★	YES	NO
MSD Blaster III Power Tower Coil PN 8223	★	★	YES	NO
MSD GM HEI High Output Coil PN 8225	YES	YES	YES	NO
MSD GM Dual Connector Blaster Coil PN 8226	YES	YES	YES	NO
MSD GM Single Connector Blaster Coil PN 8231	YES	YES	YES	NO
MSD Dodge Late Model PN 8228	YES	YES	YES	NO
MSD Ford TFI Blaster Coil PN 8227	YES	YES	YES	NO
MSD Blaster SS Coil PN 8207	YES	YES	YES	NO
MSD HVC Blaster Coil PN 8252	YES	★	YES	NO
MSD HVC Pro Power Coil PN 8251	YES	NO	★	★
MSD 6 HVC Coil PN 8250	Use only with PN 6600 Ignition			
MSD 6 HVC II Coil PN 8260	Use only with PN 6600 Ignition			
MSD HVC II Blaster Coil PN 8253	YES	★	YES	YES
MSD HVC II Pro Power Coil PN 8261	NO	NO	★	★
MSD 10-PLUS Coil PN 8208 (Use only with MSD 10 PLUS, PN 7502)	NO	NO	NO	NO
Accel HEI Super Coils 140003, 140005	NO	YES	YES	NO
Accel Super Coil 140098, 140001	YES	YES	NO	NO
ON 14005	YES	YES	YES	NO
ON 140207	YES	YES	YES	NO
140305	YES	YES	YES	NO
Accel 140306	NO	NO	NO	NO
Accel 8140, 8140C	YES	YES	YES	NO
Bosch (Blue Coil)	NO	YES	YES	NO
Bosch (Red Coil)	YES	YES	YES	NO
Bosch 0221 121001	NO	NO	YES	NO
Chrysler 2875004	NO	NO	NO	NO
Chrysler 3690560	NO	NO	NO	NO
Chrysler E12495531	YES	YES	YES	NO
Chrysler OEM12V Coil*	YES	YES	YES	NO
Crane PS-20, PS-40	YES	YES	NO	NO
Crane PS-91	YES	YES	NO	NO
Crane PS-92	NO	NO	NO	NO
Crane LX-91	YES	YES	NO	NO
Crane LX-92	NO	NO	YES	NO
Crane LX-93	NO	NO	NO	NO
Crane PS-20	YES	YES	NO	NO
Crane PS-40	YES	YES	NO	NO
Crane PS-60	NO	YES	YES	NO
Delco 190-12V	YES	YES	YES	NO
Delco 202	YES	YES	YES	NO
Ford D5TE	YES	YES	YES	NO
Ford D6VE-AA	NO	YES	YES	NO
Ford D7VE-AA	NO	YES	YES	NO
Ford D7AE-1209AA	YES	YES	YES	NO
Ford TFI Coil	YES	YES	YES	NO
Ford OEM 12V Coil*	YES	YES	YES	NO