Parallel Port Configuration

32-bit MATLAB on 64-bit Windows XP, Vista, 7

Files in the Folder:

inpout32a.dll

io32.mexw32

config_io_32.m

inp_32.m

outp_32.m

Instructions:

1. Log in your account as a user with Administrator privileges.
2. . Disable UAC (User Account Control). You can leave this part.An easy way to do this in Windows Vista is to: Start-Run-MSCONFIG. Select the Tools tab, scroll down to the option for "Disable UAC" and select it. Next, press the "Launch" button. You must then RESTART the system for this change to take effect.
3. Download and copy the inpout32a.dll file to the C:\windows\sysWOW64 directory.
4. Download or Copy Paste files, the io32.mexw32, config_io_32.m, inp_32.m and outp_32,m files to a working directory of your choice. This directory will be added to your MATLAB path in step-6 below.
5. Start MATLAB in "Run as Administrator" mode (Right-click icon and select "Run as Administrator").
6. Add the directory containing the downloaded m-files to your MATLAB path via the File, Set Path, Add with Subfiles... menu command. I preferred using ‘addpath’ command.
7. Run "config_io_32.m" from the MATLAB command window. If there's no error message at this point, you've successfully installed the software. . For successful driver installation, you will get message:

64-bit Windows
Driver is open

Optional: If you need to re-enable UAC (User Account Control), follow the instructions in step-2 but select "Enable UAC" instead of "Disable UAC".

Reference:

http://apps.usd.edu/coglab/psyc770/IO32on64.html

Important Information:

1. Once you run the file config_io.m , after that don't run **clear all** command because the driver installation somehow gets cancelled.
2. If you are following the instructions from the reference link, then save the files in two different locations because even though files have same name for 64 bit MATLAB or 32 bit MATLAB but they are different. Don't over write.

Function Files:

inp_32.m `[byte] = inp_32(address)`

The function receives the Byte and the address is given in decimal number.

outp_32.m `outp_32(address,byte)`

Address and Byte are in decimal numbers.
Convert the Hexa-decimal address into Decimal first.

Example:

```
outp_32(888,bin2dec(code));
outp_32(12288,arrow_trigger);
```

Make sure to check the address for the Parallel Port. Sometimes it changes in the laptop when you insert the device again.