

Description:

Instructions for spare parts manual

**Ordering spare parts****Order for spare parts must include the following data:**

- Machine type
- Machine serial number
- Figure and drawing number
- Part number

Warning

- In this spare parts book, are indicated all the parts that compose the TECPORT machine.
- The items "right" and "left", "front" and "rear", indicated in the parts denomination, refer to the running direction of the machine.

Use the spare parts manual as follow:

1. Identify the **"SYSTEM"** of the machine you need to check
2. Identify the **"CHAPTER"** of the system
3. Go to **"INDICE"**
4. Identify the **"DESCRIPTION"** of the component you need to locate.
Verify the **"Drawing number"** and **"Page"**
5. Go to **"PAGE"**

TRANSMISION GEARBOX CAIXA DE VELOCIDADE	06
EJE FRONTAL FRONT AXLE EIXO DE TRANSMISSÃO DIANTEIRO	07
1 SISTEMA DE FRENOS BRAKE SYSTEM SISTEMA DE TRAVAGEM	2 08

4	Drawing: N° 08.XXX Rev:	3	Description: INDICE	
#	DRAWING	DESCRIPTION		PAG.
1	08.001	BRAKE PUMP ASSY		8.03
2	08.002	BRAKE PEDAL ASSEMBLY		8.05

6. Verify the “DESCRIPTION” , “Drawing number” and “PAGE”
7. Locate the position (“Pos”) of spare part you required in the “drawing page”
8. In next page, “part list”, you will find the spare part number (“Part-No”) of the part you need and the quantity (“Quantity”) installed in the machine.

Drawing:

N° 08.001

Rev: 00.0724

Description:

BRAKE PUMP ASSY

Tecport

254.803.53.29

Tecport TRS4531

Page 8.03

Drawing:

N° 08.001

Rev: 00.0724

Description:

BRAKE PUMP ASSY

Tecport

Pos.	Part-No.	Designation	Quantity	replaced by	Remarks
1	08.01.540369159	o-ring 84x2,5-FKM80	1		
2	08.01.546948798	clutch ANSI 16/3219Z-16/329Z	1		
3	08.01.540189597	gear pump	1		
4	08.01.984959993	socket-head screw ISO 4762M10x25-8.8-A2C	2		

