

VEHICLE ERROR CODES LIST

Fault Code	Fault Description	TECPORT Description	Error level
1101	Air Filtler is clog 空气滤器堵塞	Check the Air Filtler ! 检查空气过滤器!	Message
1102	ALTERNATOR NOT CHARGING 发电机不充电	Check Alternator circuit or the Alternator 请检查电路或发电机	Warning
1103	ALTERNATOR BROKEN, high voltage 发电机损坏, 电压过高	ALTERNATOR REGULATOR BROKEN, CHECK! 发电机调节器损坏	Warning
1104	BATTERY FLAT 蓄电池电压低	BATTERY OUTPUT voltage LOW, CHECK THE BATTERY 电池输出电压低, 请检查电池	Warning
1105	FUEL LEVEL SENSOR ERROR 燃油液位传感器错误	CHECK THE SENSOR AND CALL SERVICE 检查传感器并请求服务	Warning
1201	PRESS AT A-LIFT CYL PRESSURE DIFFERENCE A腔压力偏差过大	Check A-LIFT PRESSURE SENSOR OR HYDRAULIC CIRCUIT 请检查A腔压力传感器或油路	Critical
1202	PRESS AT A-LIFT CYL ERROR A腔压力错误	Check A-LIFT PRESSURE SENSOR OR HYDRAULIC CIRCUIT 请检查A腔压力传感器或油路	Critical
1203	PRESS AT A-LIFT CYL ALARM A腔压力超范围报警	Check A-LIFT PRESSURE SENSOR OR HYDRAULIC CIRCUIT 请检查A腔压力传感器或油路	Critical
1204	PRESS AT B-LIFT CYL ALARM B腔压力超范围报警	Check B-LIFT PRESSURE SENSOR OR HYDRAULIC CIRCUIT 请检查B腔压力传感器或油路	Critical
1205	PRESS AT B-LIFT CYL ERROR B腔压力错误	Check B-LIFT PRESSURE SENSOR OR HYDRAULIC CIRCUIT 请检查B腔压力传感器或油路	Critical
1206	LS PRESSURE SENSOR ERROR LS 压力传感器错误	CHECK THE SENSOR AND CALL SERVICE 检查传感器并请求服务	Alarm
1207	HYDR. TEMP SENSOR ERROR 液压油温度传感器错误	CHECK THE SENSOR AND CALL SERVICE 检查传感器并请求服务	Alarm
1208	PUMP PRESSURE SENSOR ERROR 主泵压力传感器错误	CHECK THE SENSOR AND CALL SERVICE 检查传感器并请求服务	Alarm
1209	PILOT PRESSURE SENSOR ERROR 先导压力传感器错误	CHECK THE SENSOR AND CALL SERVICE 检查传感器并请求服务	Alarm
1301	Spreader WDO 吊具出错	Spreader sensor fault or Operation error 吊具传感器故障或操作错误	Alarm
1401	Brake Temp Low 刹车油温度低	Brake Temp Below -30° 刹车油温度低于-30°	Alarm
1402	Brake Temp High 刹车温度高	Brake Temp above 90° , STOP AND CHECK BRAKE COOLER 刹车油温度高于90° , 停车并检查刹车油散热系统	Alarm
1403	MAIN BRAKE PRESSURE LOW 主刹车压力低	STOP AND CALL SERVICE 停车并请求服务	Alarm
1404	BRAKE FILTE WARNING 刹车滤清器警告	BRAKE FITLER ELEMENT IS BLOCKED. 刹车滤清器堵塞	Warning
1405	SERVICE BRAKE PRESSURE HIGH 行车制动压力高	STOP AND CALL SERVICE 停车并请求服务	Alarm
1406	SERVICE BRAKE PRESSURE LOW 行车制动压力低	STOP AND CALL SERVICE 停车并请求服务	Alarm
1407	brake sensor can not back to 0 踏板角度传感器不回零	brake sensor need re adjust 踏板角度传感器不回零, 需重新调整	Message
1408	BRAKE PEDALSenor ERROR 刹车踏板角度传感器错误	CHECK THE SENSOR AND CALL SERVICE 检查传感器并请求服务	Alarm
1409	Main Brake Press SENSOR ERROR 主制动压力错误	CHECK THE SENSOR AND CALL SERVICE 检查传感器并请求服务	Alarm
1410	Service Brake Press SENSOR ERROR 行车制动压力错误	CHECK THE SENSOR AND CALL SERVICE 检查传感器并请求服务	Alarm
1411	BRAKE TEMP SENSOR ERROR 刹车油温度传感器错误	CHECK THE SENSOR AND CALL SERVICE 检查传感器并请求服务	Alarm
1412	HYDR. TEMP HIGH 液压油温度高(>100°)	CHECK THE cooler or have a rest 清洁液压冷却器或车辆休息一下	warning
1501	Drive pedal differential errors. 油门踏板双电位计不匹配	Drive pedals are out of phase-check and calibrate the drive pedal 重新标定油门踏板.	Alarm
1502	Drive pedal electrical error 油门踏板电气错误	Drive pedals are out of phase-check and calibrate the drive pedal. 重新标定油门踏板	Alarm
1601	GHOST MOVEMENT ANGLE SENSOR when joystick in middle 手柄回中后大臂角度系统值变动过大	STOP AND CHECK Electrical OR Hydraulic Circuit 停车并检查电气或液压系统	Critical
1602	BOOM ANGLE DIFFERENCE 大臂角度偏差过大	STOP AND CHECK THE ANGLE SENSOR 停车并检查角度传感器	Critical
1603	BOOM ANGLE ERROR 大臂角度传感器错误	STOP AND CHECK THE ANGLE SENSOR 停车并检查角度传感器	Critical
1604	GHOST MOVEMENT LENGTH SENSOR when joystick in middle 手柄回中后长度传感器系统值变动过大	STOP AND CHECK Electrical OR Hydraulic Circuit 停车并检查电气或液压系统	Critical
1605	BOOM LENGTH DIFFERENCE 大臂长度偏差太大	STOP AND CHECK THE LENGTH SENSOR 停车并检查长度传感器	Critical

1606	BOOM LENGTH ERROR 大臂长度传感器错误	STOP AND CHECK THE LENGTH SENSOR 停车并检查长度传感器	Critical
1607	JOYSTICK1 X-ERROR 手柄横轴错误	STOP AND CHECK JOYSTICK1-X SINGAL OR CIRCUIT 停车并检查手柄X轴信号及电路	Critical
1608	JOYSTICK1 Y-ERROR 手柄纵轴错误	STOP AND CHECK JOYSTICK1-Y SINGAL OR CIRCUIT 停车并检查手柄Y轴信号及电路	Critical
1609	BOOM EXTENT OUTPUT OPEN LOAD 大臂延伸输出电路开路	STOP AND CHECK Electrical Circuit or Solenoid 停车并检查电路或电磁阀	Critical
1610	BOOM RETRACT OUTPUT OPEN LOAD 大臂缩回输出电路开路	STOP AND CHECK Electrical Circuit or Solenoid 停车并检查电路或电磁阀	Critical
1611	BOOM EXTENT OUTPUT OVERLOAD 大臂延伸输出电路短路或过载	STOP AND CHECK Electrical Circuit or Solenoid 停车并检查电路或电磁阀	Critical
1612	BOOM RETRACT OUTPUT OVERLOAD 大臂缩回输出电路短路或过载	STOP AND CHECK Electrical Circuit or Solenoid 停车并检查电路或电磁阀	Critical
1613	BOOM LIFT OUTPUT OPEN LOAD 大臂提升输出电路开路	STOP AND CHECK Electrical Circuit or Solenoid 停车并检查电路或电磁阀	Critical
1614	BOOM LOW OUTPUT OPEN LOAD 大臂下降输出电路开路	STOP AND CHECK Electrical Circuit or Solenoid 停车并检查电路或电磁阀	Critical
1615	BOOM LIFT OUTPUT OVERLOAD 大臂提升输出电路短路或过载	STOP AND CHECK Electrical Circuit or Solenoid 停车并检查电路或电磁阀	Critical
1616	BOOM LOW OUTPUT OVERLOAD 大臂下降输出电路短路或过载	STOP AND CHECK Electrical Circuit or Solenoid 停车并检查电路或电磁阀	Critical
1617	Boom length sensor stuck ! 大臂长度传感器卡住 !	Boom length sensor stuck or broken, stop and check it ! 大臂传感器卡住或损坏, 请停车检查确认!	Critical
1701	XS2-A0 no contact(cab) 驾驶室XS2模块没有联接	CHECK THE NETWORK OR THE MODULE POWER 检查网络联接或模块电源	Alarm
1702	XS2-A1 no contact(right chassis) 车架右侧XS2模块没有联接	CHECK THE NETWORK OR THE MODULE POWER 检查网络联接或模块电源	Alarm
1703	XA2-A0 no contact(left chassis) 车架左侧XA2模块没有联接	CHECK THE NETWORK OR THE MODULE POWER 检查网络联接或模块电源	Alarm
1704	ECU no contact (engine) 发动机ECU没有联接	CHECK THE NETWORK OR THE MODULE POWER 检查网络联接或模块电源	Alarm
1705	TCU no contact (gearbox) 变速箱TCU没有联接	CHECK THE NETWORK OR THE MODULE POWER 检查网络联接或模块电源	Alarm
1706	Remote module no contact 远程监控模块没有联接	CHECK THE NETWORK OR THE MODULE POWER 检查网络联接或模块电源	Alarm
1707	length encoder no contact 长度编码器没有联接	CHECK THE NETWORK OR THE MODULE POWER 检查网络联接或模块电源	Alarm
1801	WEAE BLOCK NEED ADJUST(2000h) 耐磨块需要调整 (2000h)	beam WEAR BLOCK INTERVAL NEED ADJUST(CHECK beam SHAKING) 大臂耐磨块间隙需要调整 (检查大臂晃动量)	Critical
1802	WEAE BLOCK NEED ADJUST OR CHANGE(4000h) 耐磨块需要调整或更换 (4000h)	beam WEAR BLOCK INTERVAL NEED ADJUST OR CHANGE(CHECK beam SHAKING) 大臂耐磨块间隙需要调整或更换 (检查大臂晃动量)	Critical