
[Radio]

- If ATU (eg. ICOM AH-4) control function is disabled, Select Alex. If enabled, Select Apollo.




[Receive]

• If AK4951 Speaker output is enabled, Select Random.




[Transmit]

- Select Mic In.
- If Mic Boost is needed, Select Mic Boost .




[PA Calibration]

- Set 38.8dB (all band).




[CW]

• Refer to https://github.com/ji1udd/Hermes-Lite/blob/6M/audiocodec/docs/Keyer_Sequece_and_setting.pdf



[Open Collector Output]

• No need to set. But it is preferable to set the following assuming the case of installing official gateware.



[ANT]

- Cooling Fan control
- Refer to https://github.com/ji1udd/Hermes-Lite2/tree/CompactTRX

