

Church lighting

Lightkey and Booth Check on the MacBook: how to start, how to finish, and what to do if something's wrong.

Leave everything plugged in: the charger, and the USB cable from the MacBook to the blue ENTTEC Open DMX box.

Start

1 Open the MacBook and press the power button.

2 Type the password.

It's written on the MacBook.

3 Wait, and don't touch anything.

A big sign says so while Booth Check finds the DMX box and opens Lightkey. If it says to unplug and replug, it means the USB cable in the blue box: pull it out and plug it back in.

4 Tap Authenticate on the Touch Bar, and type the password again.

The sign moves to the bottom of the screen when it's time. If Lightkey shows its list of projects instead, click the newest

`BackupChurch_modular`.

5 Test: press House 10% on the Stream Deck, then press it again.

The lights come up, then go off.

✓ **Ready for the service.**

Something not working?

The Booth Check icon (top right) shows a triangle or a cross

Click it. Each item says what to do.

Stream Deck keys do nothing, then all fire at once

Stop pressing: the Mac had put the Stream Deck app to sleep. Click the Stream Deck app once.

A key is lit but its cue isn't on, or the other way round

Press any key on the page you're looking at. Lightkey's own panel is always right.

The Stream Deck does nothing at all

Pick the newest "Lightkey ... Service Panel" profile. Still nothing: quit and reopen the Stream Deck app.

Cues change in Lightkey, but no lights come on

Reseat the DMX USB cable at both ends, then quit and reopen Lightkey.

Old cues, wrong looks or missing buttons

File → Open Recent → the newest

`BackupChurch_modular`.

The screen is black, or the Mac went to sleep

Plug the charger in, then press a key.

Anything else

Restart the MacBook (Apple menu → Restart) and follow Start from step 2. Still stuck? Take a photo of the screen, write down what you tried, and send Fynn a message.

Finish

1 Click the Booth Check icon at the top right of the screen, then Shut down the booth.

Can't see it? Move the pointer to the very top of the screen. A 10-second countdown comes first (Not yet stops it). If Lightkey asks about saving, click Don't Save.

2 Close the lid.

Leave everything plugged in.

If the lights run away

Unplug the Stream Deck's USB cable and don't press anything else. If one press changes lots of cues, or Lightkey freezes, this stops it at once.

Run the rest of the service from Lightkey's own panel with the mouse, and send Fynn a message afterwards.