

Networking > Networking Software > ... >

MFT Supported Configurations and Parameters

## MFT Supported Configurations and Parameters

The list of MFT Supported Configurations and Parameters is available by running the “`mlxconfig -d <device> show_confs`” command.

Before setting the number of VFs in SR-IOV, make sure your system can support that number of VFs. If your hardware and software cannot support that number, this may cause your system to cease working. Therefore, `mlxconfig` protects the user by making sure that when setting SR-IOV parameters, for ConnectX-3 and ConnectX-3 Pro, the value of `NUM_OF_VFS*PCI_BAR_SIZE(1)` must not exceed 512. For 5th generation devices (Group II devices), however, the value is dependent on the firmware. Also, `NUM_OF_VFS` must not exceed the limit defined by the firmware (127 VFs upper bound). The same calculation applies to BAR size settings.

<sup>(1)</sup>. `PCI_BAR_SIZE` refers to the PCI BAR size per function, either physical or virtual.

In case there were no server booting after enabling SR-IOV, please refer to [Troubleshooting](#).

Support was added to set some of the parameters in mlxconfig in textual values in addition to the numerical values that are still supported. For example: LINK\_TYPE\_P1 can be set as follows: LINK\_TYPE\_P1=ETH, instead of: LINK\_TYPE\_P1=2

Note that the textual values are case insensitive (either “True” or “true” are accepted).

Last updated: January 24, 2021



[Previous page](#)  
[mlxconfig Commands](#)

[Next page](#)



[flint – Firmware Burning Tool](#)

 Use with AI 



[Privacy Policy](#)  
[Your Privacy Choices](#)  
[Terms of Service](#)  
[Accessibility](#)  
[Corporate Policies](#)  
[Product Security](#)  
[Contact](#)

Copyright © 2026 • Powered by Scroll Sites & Atlassian Confluence