

Querying the Firmware Image

To query the FW image on a device, use the following command line:

```
# flint -d <device> q
```

To query the FW image in a file, use the following command line:

```
# flint -i <image file> q
```

where:



device	Device on which the query is run.
image file	Image file on which the query is run.

Examples:

- Query the FW on the device.

```
# flint -d /dev/mst/mt4099_pci_cr0 query
```
- Query the FW image file.

```
# flint -i 25408-2_42_5000-MCX354A-FCB_A2.bin query
```
- Security Attributes field in Query output:
This field lists the security attributes of the device’s firmware, where:
 - Secure-fw: This attribute indicates that this binary/device supports secure-firmware-updates. It means that only officially signed binaries can be loaded to the device from the host, and that the current binary is signed.
 - Signed-fw: This attribute indicates that that this binary is signed and that the device can verify digital signatures of new updates. However, unlike, secure-fw, there might still be methods to upload unsigned binaries to the device from the host.
 - debug: This attribute indicate that this binary is (or this device runs) a debug-version. Debug versions are custom made for specific data-centers or labs, and can only be installed after a corresponding debug-fw token is pushed to the device. The debug-fw-token, which is digitally signed, includes a list of the target devices MAC addresses.

(test) key.

- Default Update Method" field in Query Full output:{This field reflect the method which flint will use in order to update the device. The user can enforce a different method using the --no_fw_ctrl or the --ocr flags.The default methods are:
 - Legacy: flint will use the low level flash access registers.
 - fw_ctrl: flint will operate the 'firmware component update' state machine.
- Secure-boot attributes
 - Secure-boot : This attribute indicates if the device supports secure-boot
 - Life-cycle : This attribute indicates the current status of secure-boot
 - Security-version:
 - For query on image: This attribute indicates the security-version of the image.
 - For query on device:
 - "EFUSE security version": Indicates the security version of the device
 - "Image security version": Indicates the security version of the image on the flash
 - Programming method: Indicates when the boot will program the "EFUSE security version" to be aligned with the "image security version".

Last updated: June 17, 2021



Previous page

[Burning a Firmware Image](#)

Next page

[Verifying the Firmware Image](#)



🔗 Use with AI ▾



[Privacy Policy](#)

[Your Privacy Choices](#)

[Terms of Service](#)

[Accessibility](#)

[Corporate Policies](#)

[Product Security](#)

[Contact](#)

Copyright © 2026 • Powered by Scroll Sites & Atlassian Confluence