

Networking > Networking Software > ... > Setting the VSD

Setting the VSD

To set the vsd for the given image/device (4th generation/Group I), use the sv command with -vsd flag.

Example:

```

1  # flint -d /dev/mst/mt4099_pci_cr0 -vsd "MELLANOX" sv
2  Setting the VSD      - OK
3  Restoring signature - OK
4
5  # flint -d /dev/mst/mt4099_pci_cr0 q
6  Image type:         FS2
7  FW Version:         2.31.5050
8  FW Release Date:    4.5.2014
9  Device ID:          4099
10 Description:         Node          Port1          Port2          Sys imag
11 GUIDs:               f45214030001b8a0 f45214030001b8a1 f45214030001b8a2 f4521403
12 MACs:                00300abadaba    00300abadabb
13 VSD:                  MELLANOX
14 PSID:                 MT_1090120019

```

Last updated: September 18, 2019


[Previous page](#)
[Setting GUIDs and MACs](#)

[Next page](#)

[Disabling/Enabling Access to](#)
[the Hardware](#)

 Use with AI

