Reference Manuals Errata

Hardware Reference Manual – ch 2 – p 17-19. (6 places)

the Gp lines are assigned to the hardware 'Y' channel, the Gp lines are assigned to the hardware 'Y' channel

should read

the Gp lines are assigned to the hardware 'Y' channel, and the Gs lines are assigned to the hardware 'Z' channel

NTNMR Reference Manual – ch 8 – p 142.

This is the default mode for S.A. Dimension = 1.

should read

This is the default mode for S.A. Dimension = 0.

NTNMR Reference Manual – ch 9 – p 196 and following.

objectname.SetData *array*

should read

objectname.SetData *numPoints*, *array*

Example:
Data.SetData myArray

should read

Example:
Data.SetData 512, myArray

Also note that the parameter *numPoints* is the total number of points to be passed, not the number of complex points.

NTNMR Reference Manual – ch 9 – p 158 and following.

SetData	yes	array	variant (array)	-

should read

SetData	yes	numPoints, array	long, variant (array)	-

Also note that the parameter *numPoints* is the total number of points to be passed, not the number of complex points.