

蜂鸟M芯片 GPIO 功能说明			
序号	管脚名	功能	说明
1	USBDM	UART1RXD/SPI2DOB/I2C SDA A	升级口
2	USBDP	UART1TXD/SPI2CLKB/I2C_SCL_A/ADC12	升级口
3	PA_0	AMUXOL/TouchO/CLKOUTO/UART1TXC/PWMOH	
4	PA_1	AMUXOR/Touch1/ADC0/UART1RXC/PWM0L	
5	PB_1	ADC5/TMR2/UART1RXA	
6	PB_5	PWM3/CAP1/UARTOTXC/UATORXC or Charge Power 5V	用于控制功放MUTE脚
7	PB_8	AMUX1R/SD0DAT0B/SPI2DIA/ADC8/CLKOUT1	
8	PB_9	AMUX2L/SDOCLKB/SPI2CLKA/CAPO/UART2TXC/PWM3H	作为串口对外通信使用
9	PB_10	AMUX2R/SD0CMB/SPI2D0A/ADC9/UART2RXC/PWM3L	作为串口对外通信使用
10	PB_11	SDC Power Gate	
11	PC_7	MIC BIAS	









