



USB PWR



ST-LINK



TX

RX



SWD

GND



GND



IOREF

RESET

3V3

5V

GND

GND

VIN

POWER

A0

A1

A2

A3

A4

A5

AIN



5V

5V

5V



5V

5V



SCL

SDA

AWTD

GND

SCK/D13

MISO/D12

PWM/MOSI/D11

PWM/CS/D10

PWM/D9

D8

D7

PWM/D6

PWM/D5

D4

PWM/D3

D2

TX/D1

RX/D0

