765th VIRTUAL STRIKEFIGHTER SQUADRON DOCUMENT NO. 132-765-F18C-500

BY ORDER OF THE COMMANDER 132nd VIRTUAL WING



June 2, 2018 POCKET CHECKLIST - F/A-18C HORNET

DRAFT / WORK IN PROGRESS / UNOFFICIAL DOCUMENT

POCKET CHECKLIST - F/A-18C HORNET



NORMALPROCEDURES

INTERIORCHECKS	DDI, HI/MPCD and HUDON
Left Console	Comm 1, 2 and ADF AS DESIRED
Communications PanelSET	Warning and Caution Lights TEST
Volume Panel SET	INS ENTER WAYPOINTS
External Tank Switches NORM	
Dump Switch OFF	All Starts
Internal Wing Switch NORM	Battery Switch ON
External Lights SET	Fire Warning A and B TEST BOTH
Throttles OFF	
Parking Brake SET	If APU Start
Landing/Taxi Switch OFF	APU ACCUM Caution Light OFF
Anti-Skid Switch(LAND)	APU Switch ON - READY light within 30
Anti-Skid Switch(SEA) OFF	seconds
Flap Switch	
Selective Jettison Knob	If External Air Start
Landing Gear Handle DOWN	Bleed Air Knob OFF
Canopy Jettison Handle FORWARD	
	All Starts
Instrument Panel	Engine Crank Switch R
Master Arm SwitchSAFE	RIGHT Throttle IDLE (Min. 15 % RPM)
Altitude SourceSELECT	GPWS Voice Alerts CHECK
Attitude SourceAUTO	DDI, HI/MPCD, HUD and UFCON
ClockCHECK AND SET	EMI/IFEICHECK
IR Coolant Switch OFF	LDDI FCS PAGE
	RDDIBIT PAGE
Right Console	
Hook handleUP	Ground Idle
Wing Fold Handle SAME AS WING POS	DESC
Radar Altimeter OFF	N2 63 - 70 %
Generator Switches NORM	EGT190 - 590°C
Battery Switch OFF	Fuel Flow420 - 900 pph
ECS SystemSET	Nozzle
Interior Lights AS DESIRED	Oil Pressure 45 - 110 psi
Sensors OFF	
KY-58 Panel SET	If APU or Crossbleed Start
	Bleed Air Knob CYCLE 360° TO NORM
ENGINE START	The blood of shortest colors decises
	The bleed air shutoff valves close during
Battery StatusCHECK	the fire warning test and the bleed air knob
	must be cycled thru OFF to NORM with AC
With External Power	power on to reset the valves
External Power Switch	Wannin n and Oasti 1111
Switch 1, 2 and 4 B - ON (HOLD 3 SEC)	Warning and Caution Lights TEST

DDI, HI/MPCD and HUD
All Starts ON Battery Switch ON Fire Warning A and B TEST BOTH
If APU Start APU ACCUM Caution LightOFF APU SwitchON - READY light within 30 seconds
If External Air Start Bleed Air KnobOFF
All Starts Engine Crank Switch R RIGHT Throttle IDLE (Min. 15 % RPM) GPWS Voice Alerts CHECK DDI, HI/MPCD, HUD and UFC ON EMI/IFEI CHECK LDDI FCS PAGE RDDI BIT PAGE
Ground Idle DESC SET N2 63 - 70 % EGT 190 - 590°C Fuel Flow 420 - 900 pph Nozzle 73 - 84 % Oil Pressure 45 - 110 psi
If APU or Crossbleed Start Bleed Air Knob CYCLE 360° TO NORM
The bleed air shutoff valves close during the fire warning test and the bleed air knob must be cycled thru OFF to NORM with AC power on to reset the valves

For a crossbleed start, insure APU switch	Ejection SeatARM
is OFF and a minimum of 80 % rpm and 1,900 pph fuel flow	BEFORE TAKEOFF Canopy
Engine Crank Switch L LEFT Throttle IDLE (Min. 15 % RPM) Engine Crank Switch CHECK OFF	IFF
If External Air Start	
Bleed Air Knob RETURN TO NORMAL	AFTER TAKEOFF
All Starts CHECK External Power DISCONNECT	When AirborneUP Landing GearUP FlapsAUTO
	10,000 FEET
BEFORE TAXI	Cockpit Altimeter CHECK Fuel Transfer CHECK
Radar OPR INS CV, GND or IFA	Radar Low Altitude Warning CHECK/SET
OBOGS Control Switch ON	DESCENT/PENETRATION
OXY Flow Knob ON Wingfold SPREAD AND LOCK/CHECK	Engine Anti-Ice AS DESIRED Pitot HeatAUTO
FCS RESET button PUSH	Defog Handle
If wings are folded, verify aileron Xs are	Windshield Anti-Ice/Rain SwitchAS DESIRED
present	Altimeter Settings
If no most	Radar Altimeter SET AND CHECK HUD NAV MASTER MODE
If no reset	1185
T.O. trim button	Compare with STBY Flight Instruments and STBY Compass
Lift FCS BIT consent switch [Y] and push	NAVAIDS CROSS CHECK ILS ON AND CHANNEL SET
FCS RESET button simultaneously	IFF AS DIRECTED
APUVERIFY OFF	Weapons/SensorsAS REQUIRED
Hook Bypass FIELD/CARRIER Fuel BIT/SET BINGO	
Attitude Source STBY	AFTER LANDING
Altitude Source AUTO GPWS BOXED	When Clear of Active Runway SAFE
Mission Data ENTER	FlapsAUTO
Standby Attitude Indicator UNCAGE Radar Altimeter ON	T.O. Trim button PUSH
Weapons/SensorsAS REQUIRED	Canopy either full up or full down during taxi

SPECIAL PROCEDURES

AIR REFUELING
Before Plug-In
For Night Air Refueling Exterior Lights
Parking Brake ON Nosewheel Steering OFF Left Throttle OFF Throttle Friction MAX Avionics AS DESIRED
CV ALIGNMENTS
INS CV ALIGNMENTS (RF or CBL)(SINS) Parking BrakeSET

ATT Select SwitchAUTO OR INS INS mode selector knobCV
After Alignment Complete INS mode selector knob NAV
INS CV ALIGNMENT (MANUAL)
Parking Brake SET ATT Select Switch AUTO OR INS INS mode selector knob CV HI/MPCD PRESS MAN
On the UFC
After Alignment CompleteNS mode selector knobNAV

CASE 1 - CARRIER RECOVERY

INBOUND - 10 NM COMM1 or COMM2 ... CONTACT CATCC Join Port Holding Pattern as instructed **HOLDING PATTERN - 5 NM CIRCLE** Altitude AS INSRUCTED (Min. 2000 ft) Airspeed 250 KIAS Anti-Skid Switch OFF Hook BypassSEA Depart Holding Pattern 30° opposite BRC heading (210° from BRC) - AFT of ship's beam Initials - 3 NM AFT Altitude 800 FT Airspeed 350 KIAS HookCHECK DOWN **Break** Speed Brake EXTEND FULLY Altitude KEEP 800 FT

Rule of Thumb: Match Gs according to 1/100 of Airspeed during deceleration in order to arrive at On-Speed AOA on roll-out

(350 KIAS => 3.5 G)

Flaps	AOA
Below 250 KIAS Landing Gear DOWN AND LOC Flaps	
Landing Gear DOWN AND LOC Flaps	·VEF
Flaps	·VEC
Target and approximatly 140 KIAS	
Target speed approximatly 140 KIAS	
Turn to final	
Position ABEAM LSO PLATE	
Angle of Bank	
Speed	
Aft (90) - 3/4 NM	
Altitude45	50 F1
Rate of Decent500) fpm
Maintain optimum AOA, and a 30° AOI	В
IN THE GROOVE	
AOACH	IECK
	IECH
Rate of DecentCH	
Rate of DecentCH Ball Call CALLSIGN TYPE FUELS	TATE

Five"