

Bindings ▾

ABB/Busch-free@home Smart Home

Adorne

aha Waste Collection

Air Quality

air-Q

AirGradient

AirParif

AirVisual Node

Alarm Decoder

Amazon Dash Button

Amazon Echo Control

Amber Electric

Ambient Weather

AmpliPi

Android Debug Bridge

AndroidTV

Anel NET-PwrCtrl

Anthem

Pentair Binding

This is an openHAB binding for a Pentair Pool System.

It is based on combined efforts of many on the Internet in reverse-engineering the proprietary

Pentair protocol (see References section). The binding

was developed and tested on a system with a Pentair

EasyTouch controller, but will also operate with the

Pentair IntelliTouch/SunTouch controllers. Note that with the Pentair IntelliCenter controllers,

the functionality will be limited since that utilizes a different protocol which has not yet been implemented. Further, if there is interest to improve functionality or address issues with any

of the Pentair controllers, please reach out to the binding author.



Hardware Setup

REQUISITE DISCLAIMER: CONNECTING 3RD PARTY DEVICES TO THE PENTAIR SYSTEM BUS COULD CAUSE SERIOUS DAMAGE TO THE SYSTEM SHOULD SOMETHING MALFUNCTION. IT IS NOT ENDORSED BY PENTAIR AND COULD VOID WARRENTY. IF YOU DECIDE TO USE THIS BINDING TO INTERFACE TO A PENTAIR CONTROLLER, THE AUTHOR(S) CAN NOT BE HELD RESPONSIBLE.

This binding requires an adapter to interface to the Pentair system bus. This bus/wire runs

Bindings ▾

ABB/Busch-free@home Smart Home

Adorne

aha Waste Collection

Air Quality

air-Q

AirGradient

AirParif

AirVisual Node

Alarm Decoder

Amazon Dash Button

Amazon Echo Control

Amber Electric

Ambient Weather

AmpliPi

Android Debug Bridge

AndroidTV

Anel NET-PwrCtrl

Anthem

between the Pentair control system, indoor control panels, IntelliFlo pumps, etc. It is a standard RS-485 bus running at 9600,8N1 so any RS-485 adapter should work and you should be able to buy one for under \$30. Pentair does not publish any information on the protocol so this binding was developed using the great reverse-engineering efforts of others made available on the internet. I have cited several of those in the References section below.

Connecting adapter to your system

A USB or serial RS-485 interface or IP based interface can be used to interface to the Pentair system bus. The binding includes 2 different Bridges depending on which type of interface you use, `serial_bridge` or `ip_bridge`.

If your openHAB system is physically located far from your Pentair equipment or indoor control panel, you can use a Raspberry Pi or other computer to redirect USB/serial port traffic over the internet using a program called `ser2sock` (see Reference section). An example setup would run the following command: `"ser2sock -p 10000 -s /dev/ttyUSB1 -b 9600 -d"`.

Note: This is the setup utilized for the majority of my testing of this binding.

Once you have the interface connected to your system, it is best to test basic connectivity. Note the protocol is a binary protocol (not ASCII text based) and in order to view the communication packets, one must use a program capable of a binary/HEX mode. If connected properly, you will see a periodic traffic with packets starting with `FF00FFA5`. This is the preamble for Pentair's communication packet.

After you see this traffic, you can proceed to configuring the Pentair binding in openHAB.

Bindings ▾

ABB/Busch-free@home Smart Home

Adorne

aha Waste Collection

Air Quality

air-Q

AirGradient

AirParif

AirVisual Node

Alarm Decoder

Amazon Dash Button

Amazon Echo Control

Amber Electric

Ambient Weather

AmpliPi

Android Debug Bridge

AndroidTV

Anel NET-PwrCtrl

Anthem

Note: Many adapters use A and B to represent Data+ and Data-. There is no reliable standard for determining which is Data+ and Data-. If you connect the system in reverse, you will still see serial data, however it will be corrupted. Look at your data coming from your device and look for a repeated "FFa5". If you don't see that preamble reliably, you may try switching your data lines."

USB/Serial interface

For a USB/Serial interface, you can use most terminal emulators. For Linux, you can use minicom with the following options: `minicom -H -D /dev/ttyUSB1 -b 9600`

IP interface

For an IP based interface (or utilizing ser2sock) on a Linux system, you can use nc command with the following options: `nc localhost 10000 | xxd`

Pentair Controller panel configuration

In order for the Pentair controller to receive commands from this binding, you may need to enable "Spa-side" remote on the controller itself.

Supported Things

This binding supports the following thing types:

Bindings ▾

ABB/Busch-free@home Smart Home

Adorne

aha Waste Collection

Air Quality

air-Q

AirGradient

AirParif

AirVisual Node

Alarm Decoder

Amazon Dash Button

Amazon Echo Control

Amber Electric

Ambient Weather

AmpliPi

Android Debug Bridge

AndroidTV

Anel NET-PwrCtrl

Anthem

ThingType UID	Thing Type	Description
ip_bridge	Bridge	A TCP network RS-485 bridge device.
serial_bridge	Bridge	A USB or serial RS-485 device.
controller	Thing	Pentair EasyTouch, SunTouch, or IntelliTouch pool controller.
intelliflo	Thing	Pentair IntelliFlo variable speed pump.
intellichlor	Thing	Pentair IntelliChlor chlorinator.
intellichem	Thing	Pentair IntelliChem.

Binding Configuration

There are no overall binding configurations that need to be set up as all configuration is done at the "Bridge/Thing" level.

Bridge Configuration

A Bridge item must first be configured to gain access to the Pentair bus. This can be done via the interactive setup pages in openHAB or manually through a .thing configuration file. The following table shows the parameters for each Bridge.

Bindings ▾

ABB/Busch-free@home Smart Home

Adorne

aha Waste Collection

Air Quality

air-Q

AirGradient

AirParif

AirVisual Node

Alarm Decoder

Amazon Dash Button

Amazon Echo Control

Amber Electric

Ambient Weather

AmpliPi

Android Debug Bridge

AndroidTV

Anel NET-PwrCtrl

Anthem

Thing	Configuration Parameters
ip_bridge	address - IP address for the RS-485 adapter - Required.
	port - TCP port for the RS-485 adapter - Not Required - default = 10000.
	id - ID to use when communicating on Pentair control bus - default = 34.
serial_bridge	serialPort - Serial port for the IT-100s bridge - Required.
	baud - Baud rate of the IT-100 bridge - Not Required - default = 9600.
	pollPeriod - Period of time in minutes between the poll command being sent to the IT-100 bridge - Not Required - default=1.
	id - ID to use when communicating on Pentair control bus - default = 34.

```
Bridge pentair:ip_bridge:1 [ address="192.168.1.202", port=10001 ] {  
    controller main [ id=16 ]  
    intelliflo pump1 [ id=96 ]  
    intellichlor ic40  
    intellichem chem  
}
```

java

For a serial bridge you would use a configuration similar to this, again saved as 'pentair.things':

Bindings ▾

ABB/Busch-free@home Smart Home

Adorne

aha Waste Collection

Air Quality

air-Q

AirGradient

AirParif

AirVisual Node

Alarm Decoder

Amazon Dash Button

Amazon Echo Control

Amber Electric

Ambient Weather

AmpliPi

Android Debug Bridge

AndroidTV

Anel NET-PwrCtrl

Anthem

```
Bridge pentair:serial_bridge:1 [ serialPort="/dev/ttyUSB0" ] {  
    controller main [ id=16 ]  
    intelliflo pump1 [ id=96 ]  
    intellichlor ic40  
    intellichem chem  
}
```

java

Things & Channels

Thing: Controller

Represents and interfaces with a Pentair pool controller in the system. This binding should work for both Intellitouch and EasyTouch systems. Feature availability is dependent on the version of hardware and firmware versions of your specific controller.

Synchronize Time

This configuration setting will instruct the binding to automatically update the controller's clock every 24 hours with the value from the openHAB server. This is useful to keep the pool system clock set correct and automatically adjust for daylight savings time.

Channel Group	Channel	Type		Description
---------------	---------	------	--	-------------

Bindings ▾

ABB/Busch-free@home Smart Home

Adorne

aha Waste Collection

Air Quality

air-Q

AirGradient

AirParif

AirVisual Node

Alarm Decoder

Amazon Dash Button

Amazon Echo Control

Amber Electric

Ambient Weather

AmpliPi

Android Debug Bridge

AndroidTV

Anel NET-PwrCtrl

Anthem

Channel Group	Channel	Type		Description
pool, spa, aux[1-8], feature[1-8]	switch	Switch	RW	Indicates the particular circuit or feature is on or off.
"	name	String	R	Name of circuit
"	feature	String	R	Feature of circuit
poolheat, spaheat	setpoint	Number:Temperature	RW	Temperature setpoint
"	temperature	Number:Temperature	R	Current water temperature. Note, the temperature is only valid while either pool or spa is in heat mode.
"	heatmode	String	R	Heat mode configured. Values: NONE, HEATER, SOLARPREFERRED, SOLAR
schedule[1-9]	schedule	String	RW	Summary string of schedule.

Bindings ▼

ABB/Busch-free@home Smart Home

Adorne

aha Waste Collection

Air Quality

air-Q

AirGradient

AirParif

AirVisual Node

Alarm Decoder

Amazon Dash Button

Amazon Echo Control

Amber Electric

Ambient Weather

AmpliPi

Android Debug Bridge

AndroidTV

Anel NET-PwrCtrl

Anthem

Channel Group	Channel	Type		Description
"	type	String	RW	Type of schedule. Note, to actually write the program to the controller this channel must be written to with the same value times within 5 seconds. Values: NONE, NORMAL, EGGTIMER, ONCE ONLY
"	start	Number:Time	RW	Time of day to start schedule expressed in minutes.
"	end	Number:Time	RW	Time of day to end schedule expressed in minutes. In the case of EGGTIMER, this should be the duration.
"	circuit	Number	RW	Circuit/Feature to schedule will control.

Bindings ▼

ABB/Busch-free@home Smart Home

Adorne

aha Waste Collection

Air Quality

air-Q

AirGradient

AirParif

AirVisual Node

Alarm Decoder

Amazon Dash Button

Amazon Echo Control

Amber Electric

Ambient Weather

AmpliPi

Android Debug Bridge

AndroidTV

Anel NET-PwrCtrl

Anthem

Channel Group	Channel	Type		Description
"	days	String	RW	The days the schedule will run S=Sunday, M=Monday, T=Tuesday, W=Wednesday, R=Thursday, F=Friday, Y=Saturday
status	lightmode	String	RW	Light mode. Values: OFF, ON, COLORSYNC, COLORSWIM, COLORSET, PAR ROMANCE, CARIBBEAN, AMERICAN, SUNSET, ROYAL BLUE, GREEN, RIVER WHITE, MAGENTA
"	solartemperature	Number:Temperature	R	Solar temperature sensor reading
"	airtemperature	Number:Temperature	R	Air temperature sensor reading
"	servicemode	Switch	R	Indicates whether

Bindings ▾

ABB/Busch-free@home Smart Home

Adorne

aha Waste Collection

Air Quality

air-Q

AirGradient

AirParif

AirVisual Node

Alarm Decoder

Amazon Dash Button

Amazon Echo Control

Amber Electric

Ambient Weather

AmpliPi

Android Debug Bridge

AndroidTV

Anel NET-PwrCtrl

Anthem

Channel Group	Channel	Type		Description
				controller is in service mode.
"	solaron	Switch	R	Indicates wheth solar heat is or
"	heateron	Switch	R	Indicates wheth heater is on.

Working with schedules

This binding allows both reading and writing of schedules and supports up to 9 schedules. Programming of a schedule can be accomplished either by using the discrete channels linked to items (i.e. type, start, end, circuit, days) or you can concatenate those and use the `schedule` channel saved as a comma delimited string. To prevent erroneous writes to the schedules though, one must write to the `type` channel the same value twice within 5 sec.

Thing: IntelliChlor

Represents an Intellichlor module connected in your system. Currently, the values here are readonly.

Channel	Type		Description
saltOutput	Number:Dimensionless	R	Current salt output %.

Bindings ▾

ABB/Busch-free@home Smart Home

Adorne

aha Waste Collection

Air Quality

air-Q

AirGradient

AirParif

AirVisual Node

Alarm Decoder

Amazon Dash Button

Amazon Echo Control

Amber Electric

Ambient Weather

AmpliPi

Android Debug Bridge

AndroidTV

Anel NET-PwrCtrl

Anthem

Channel	Type		Description
salinity	Number:Dimensionless	R	Salinity (ppm).
ok	Switch	R	System is operating normally.
lowFlow	Switch	R	Water flow rate is low.
lowSalt	Switch	R	Low salt level.
veryLowSalt	Switch	R	Very low salt level.
highCurrent	Switch	R	High current level.
cleanCell	Switch	R	Clean cell.
lowVoltage	Switch	R	Low voltage.
lowWaterTemp	Switch	R	Water temperature is too low for chlorine generation.
commError	Switch	R	Communication error.

Thing: IntelliFlo

Represents and interfaces to an Intelliflo pump. When a controller is active in the system all pump values are read only since the pump can only have one master at a time. If no controller is present or the controller is in service mode, the pump can be controlled directly from OpenHab.

Bindings ▾

ABB/Busch-free@home Smart Home

Adorne

aha Waste Collection

Air Quality

air-Q

AirGradient

AirParif

AirVisual Node

Alarm Decoder

Amazon Dash Button

Amazon Echo Control

Amber Electric

Ambient Weather

AmpliPi

Android Debug Bridge

AndroidTV

Anel NET-PwrCtrl

Anthem

Channel	Type		Description
run	Switch	RW	Indicates whether the pump is running.
rpm	Number	RW	Pump RPM
gpm	Number:VolumetricFlowRate	R	Pump GPM (only valid for VF pumps)
power	Number:Power	R	Pump power (Watt)
status1	Number	R	Pump status1. (not reversed engineered)
status2	Number	R	Pump status2. (not reversed engineered)
runProgram	Number	RW	Run program (0 to stop, # to run)

Thing: IntelliChem

Represents and interfaces to an IntelliChem unit. This is for monitoring of values only and IntelliChem cannot be directly controlled through this binding. Note: This has limited testing since I don't own an IntelliChem

Channel	Type		Description
phReading	Number	R	Current PH

Bindings ▼

ABB/Busch-free@home Smart Home

Adorne

aha Waste Collection

Air Quality

air-Q

AirGradient

AirParif

AirVisual Node

Alarm Decoder

Amazon Dash Button

Amazon Echo Control

Amber Electric

Ambient Weather

AmpliPi

Android Debug Bridge

AndroidTV

Anel NET-PwrCtrl

Anthem

Channel	Type		Description
			reading.
orpReading	Number	R	Current Oxidation Reduction Potential (ORP) reading.
phSetPoint	Number	R	Current PH set point.
orpSetPoint	Number	R	Oxidation Reduction Potential (ORP) set point.
tank1Level	Number	R	Tank 1 level (1-7).
tank2Level	Number	R	Tank 2 level (1-7).
calciumHardness	Number:Dimensionless	R	Calcium hardness PPM (mg/L).
cyaReading	Number	R	Cyanuric acid reading.
alkalinity	Number	R	Alkalinity reading.
phDoserType	String	R	The doser type for PH (None, CO2, Acid).

Bindings ▾

ABB/Busch-free@home Smart Home
Adorne
aha Waste Collection
Air Quality
air-Q
AirGradient
AirParif
AirVisual Node
Alarm Decoder
Amazon Dash Button
Amazon Echo Control
Amber Electric
Ambient Weather
AmpliPi
Android Debug Bridge
AndroidTV
Anel NET-PwrCtrl
Anthem

Channel	Type		Description
orpDOserType	String	R	The doser type for ORP (None, ORP).
phDoserStatus	Switch	R	Whether the chemical is currently dosing.
orpDoserStatus	Switch	R	Whether the chemical is currently dosing.
phDoseTime	Number:Time	R	The time a particular chemical has been dosing.
orpdoseTime	Number:Time	R	The time a particular chemical has been dosing.
Isi	Number	R	Langelier Saturation Index.
saltLevel	Number:Dimensionless	R	Current salt content reading of the water (PPM).
temperature	Number:Temperature	R	Current

Bindings ▼

ABB/Busch-free@home Smart Home

Adorne

aha Waste Collection

Air Quality

air-Q

AirGradient

AirParif

AirVisual Node

Alarm Decoder

Amazon Dash Button

Amazon Echo Control

Amber Electric

Ambient Weather

AmpliPi

Android Debug Bridge

AndroidTV

Anel NET-PwrCtrl

Anthem

Channel	Type		Description
			temperature.
alarmWaterFlow	Switch	R	Water flow alarm (on = no water flow).
alarmPh	Switch	R	PH alarm reported.
alarmOrp	Switch	R	ORP alarm reported.
alarmPhTank	Switch	R	PH tank alarm reported.
alarmOrpTank	Switch	R	ORP tank alarm reported.
alarmProbeFault	Switch	R	Probe fault alarm reported.
warningPhLockout	Switch	R	Unit is in PH Lockout.
warningPhDailyLimitReached	Switch	R	Daily limit of PH dosing has been reached.
warningOrpDailLimitReached	Switch	R	Daily limit of ORP dosing has been reached.

Bindings ▾

ABB/Busch-free@home Smart Home

Adorne

aha Waste Collection

Air Quality

air-Q

AirGradient

AirParif

AirVisual Node

Alarm Decoder

Amazon Dash Button

Amazon Echo Control

Amber Electric

Ambient Weather

AmpliPi

Android Debug Bridge

AndroidTV

Anel NET-PwrCtrl

Anthem

Channel	Type		Description
warningInvalidSetup	Switch	R	Invalid setup for the unit.
warningChlorinatorCommError	Switch	R	Error in communicating with the Chlorinator.

Example setup

pentair.items

```
Group gPool (All)

Number:Temperature Pool_Temp "Pool Temperature" <temperature>
(gPool) { channel = "pentair:controller:1:main:poolheat#temperature" }

Number:Temperature Spa_Temp "Spa Temperature " <temperature>
(gPool) { channel = "pentair:controller:1:main:spaheat#temperature" }

Number:Temperature Air_Temp "Air Temperature" <temperature>
(gPool) { channel = "pentair:controller:1:main:status#airtemperature" }

Number:Temperature Solar_Temp "Solar Temperature" <temperature>
(gPool) { channel = "pentair:controller:1:main:status#solartemperature" }

String PoolHeatMode "Pool Heat Mode [%s]"
(gPool) { channel="pentair:controller:1:main:poolheat#heatmode" }

String SpaHeatMode "Spa Heat Mode [%s]"
(gPool) { channel="pentair:controller:1:main:spaheat#heatmode" }
```


Bindings ▾

ABB/Busch-free@home Smart Home

Adorne

aha Waste Collection

Air Quality

air-Q

AirGradient

AirParif

AirVisual Node

Alarm Decoder

Amazon Dash Button

Amazon Echo Control

Amber Electric

Ambient Weather

AmpliPi

Android Debug Bridge

AndroidTV

Anel NET-PwrCtrl

Anthem

```
Number:Temperature PoolSetPoint "Pool Set Point"
(gPool) { channel="pentair:controller:1:main:poolheat#setpoint" }

Number:Temperature SpaSetPoint "Spa Set Point"
(gPool) { channel="pentair:controller:1:main:spaheat#setpoint" }

String PoolLightMode "Light Mode"
(gPool) { channel="pentair:controller:1:main:status#lightmode" }

Number PoolHeatEnable "Pool Heat Enable [%d]"
(gPool) { channel="pentair:controller:1:main:poolheatenable" }

Number SpaHeatEnable "Spa Heat Enable [%d]"
(gPool) { channel="pentair:controller:1:main:spaheatenable" }

Switch Mode_Pool "Pool Mode"
(gPool) { channel = "pentair:controller:1:main:pool#switch" }

Switch Mode_Spa "Spa"
(gPool) { channel = "pentair:controller:1:main:spa#switch" }

Switch Mode_PoolLight "Pool Light"
(gPool) { channel = "pentair:controller:1:main:aux1#switch" }

Switch Mode_SpaLight "Spa Light"
(gPool) { channel = "pentair:controller:1:main:aux2#switch" }

Switch Mode_Jets "Jets"
(gPool) { channel = "pentair:controller:1:main:aux3#switch" }

Switch Mode_Boost "Boost Mode"
(gPool) { channel = "pentair:controller:1:main:aux4#switch" }

Switch Mode_Aux5 "Aux5 Mode"
(gPool) { channel = "pentair:controller:1:main:aux5#switch" }

Switch Mode_Aux6 "Aux6 Mode"
(gPool) { channel = "pentair:controller:1:main:aux6#switch" }

Switch Mode_Aux7 "Aux7 Mode"
(gPool) { channel = "pentair:controller:1:main:aux7#switch" }
```

Bindings ▾

ABB/Busch-free@home Smart Home

Adorne

aha Waste Collection

Air Quality

air-Q

AirGradient

AirParif

AirVisual Node

Alarm Decoder

Amazon Dash Button

Amazon Echo Control

Amber Electric

Ambient Weather

AmpliPi

Android Debug Bridge

AndroidTV

Anel NET-PwrCtrl

Anthem

```
String ModeName_Pool          "Pool Name [%s]"
(gPool) { channel = "pentair:controller:1:main:pool#name" }

String ModeFunc_Pool          "Pool Func [%s]"
(gPool) { channel = "pentair:controller:1:main:pool#function" }

String ModeName_Spa           "Spa Name [%s]"
(gPool) { channel = "pentair:controller:1:main:spa#name" }

String ModeFunc_Spa           "Spa Func [%s]"
(gPool) { channel = "pentair:controller:1:main:spa#function" }

Switch Delay                  "Heater Delay"
(gPool) { channel = "pentair:controller:1:main:status#heaterdelay" }

Number Salt_Output            "Salt Output [%d%]"
(gPool) { channel = "pentair:intellichlor:1:ic40:salt_output" }

Number Salinity                "Salinity [%d ppm]"
(gPool) { channel = "pentair:intellichlor:1:ic40:salinity" }

Switch Pump_Run                "Pump run"
(gPool) { channel = "pentair:intelliflo:1:pump1:run" }

Number Pump_RPM                "Pump RPM [%d]"
(gPool) { channel = "pentair:intelliflo:1:pump1:rpm" }

Number Pump_GPM                "Pump GPM [%d]"
(gPool) { channel = "pentair:intelliflo:1:pump1:gpm" }

Number Pump_Power              "Pump Power [%d W]"
(gPool) { channel = "pentair:intelliflo:1:pump1:power" }

Number Pump_Error              "Pump Error [%d]"
(gPool) { channel = "pentair:intelliflo:1:pump1:error" }

Number Pump_Status1            "Pump Status 1 [%d]"
(gPool) { channel = "pentair:intelliflo:1:pump1:status1" }
```

Bindings ▾

ABB/Busch-free@home Smart Home

Adorne

aha Waste Collection

Air Quality

air-Q

AirGradient

AirParif

AirVisual Node

Alarm Decoder

Amazon Dash Button

Amazon Echo Control

Amber Electric

Ambient Weather

AmpliPi

Android Debug Bridge

AndroidTV

Anel NET-PwrCtrl

Anthem

```
Number Pump_Status2          "Pump Status 2 [%d]"
(gPool) { channel = "pentair:intelliflo:1:pump1:status2" }

Number Schedule1_Start       "Schedule 1 start"
(gPool) { channel = "pentair:controller:1:main:schedule1#start" }
Number Schedule1_End         "Schedule 1 end"
(gPool) { channel = "pentair:controller:1:main:schedule1#end" }
Number Schedule1_Type         "Schedule 1 type"
(gPool) { channel = "pentair:controller:1:main:schedule1#type" }
String Schedule1_String      "Schedule 1 string"
(gPool) { channel = "pentair:controller:1:main:schedule1#schedule" }
Number Schedule1_Circuit      "Schedule 1 circuit"
(gPool) { channel = "pentair:controller:1:main:schedule1#circuit" }
String Schedule1_Days         "Schedule 1 days"
(gPool) { channel = "pentair:controller:1:main:schedule1#days" }
```

sitemap

```
sitemap pool label="Pool stuff" {
  Frame label="Pool" {
    Switch item=Mode_Pool
    Switch item=Mode_PoolLight
    Text item=Pool_Temp valuecolor=[>82="red",>77="orange",<=77="blue"]
    Setpoint item=PoolSetPoint minValue=85 maxValue=103 step=1.0
    Default item=PoolLightMode
    Group item=gPool label="Advanced"
  }
  Frame label="Spa" {
    Switch item=Mode_Spa
```

Bindings ▾

ABB/Busch-free@home Smart Home

Adorne

aha Waste Collection

Air Quality

air-Q

AirGradient

AirParif

AirVisual Node

Alarm Decoder

Amazon Dash Button

Amazon Echo Control

Amber Electric

Ambient Weather

AmpliPi

Android Debug Bridge

AndroidTV

Anel NET-PwrCtrl

Anthem

```
Switch item=Mode_SpaLight
Switch item=Mode_Jets
Text item=Spa_Temp valuecolor=[>82="red",>77="orange",<=77="blue"]
Setpoint item=SpaSetPoint minValue=85 maxValue=103 step=1.0
}
}
```

References

Setting up RS485 and basic protocol - <https://www.sdyoung.com/home/decoding-the-pentair-easytouch-rs-485-protocol/> [↗](#) ser2sock GitHub - <https://github.com/nutechsoftware/ser2sock> [↗](#) nodejs-poolController - <https://github.com/tagyoureit/nodejs-poolController> [↗](#)

Copyright © 2026 by the openHAB Community and the openHAB Foundation e.V.