Reuse Water System – Quick Card

Keep this card next to the washing machine. The Reuse Water System (Spanish: *Sistema de Reúso de Agua*) reuses rinse water from your last wash to fill the next one.

The screen, the app and the phone alerts use the language chosen in the app (**Settings** → **Language**). Spanish is the default. This card gives the English text, with the Spanish screen text beside it.

When you switch it on

A dog chases a butterfly across the screen for about 4 seconds. Then the screen shows `REUSE WATER` / System ready (Spanish: `REUSO DE AGUA` / Sistema listo) for 2 seconds, then `READY`. Pressing START skips the dog.

Every wash

1. **Check the controller's screen** shows `READY` and *Start washer › Press START* (Spanish: `LISTO`, *Inicie lavadora › y pulse START*).
2. **Start the washing machine program** as usual.
3. **Press the button labelled START** on the controller and let go (screen: `REUSAR Y GUARDAR` › *Suelte e inicia*), or **Reuse and save** in the app.
   To use tank water but not keep the rinse water: hold START for **2 seconds** until the screen shows `SOLO REUSAR`, then let go; or **Reuse only** in the app. Step 4 then shows `DESAGUE 4 DE 4`.
4. **Let it run.** The top line shows the step, `WASH 1 OF 4` to `SAVE 4 OF 4` (Spanish: `LAVADO 1 DE 4` to `AHORRO 4 DE 4`). After the first wash the screen also says about how many minutes are left.
5. **Done** when the screen shows `DONE` (Spanish: `TERMINADO`) with the litres it reused and saved.

To cancel at any time, press the button labelled **STOP**, or **Stop cycle** in the app.

What the screen tells you

The top line says the step; the message below says what is happening now. A longer message comes in two short parts that change every 3 seconds (shown here with ›).

Screen	In Spanish	Meaning
A dog chasing a butterfly	(same)	The controller has just been switched on
Start washer › Press START	Inicie lavadora › y pulse START	Ready for a wash
Waiting to fill	Esperando agua	The washing machine has not started taking water yet
Reusing water	Reusando agua	The machine is filling with water saved in the tank
Using tap water	Agua de la llave	The machine is filling from the tap
Tank low › Using tap water	Tanque bajo › Agua de la llave	Not enough water in the tank, so the tap is used
Washing... / Rinsing...	Lavando... / Enjuagando...	The machine has filled and is working
25 min left	Faltan 25 min	About how long the wash still needs (learnt from earlier washes)
Draining › soapy water	Desaguando › agua jabonosa	Soapy water goes down the drain, not into the tank
Filling tank › Ends in 18:42	Agua al tanque › Fin en 18:42	Rinse water is stored for your next wash; the clock shows when the system finishes
Tank full › Ends in 18:42	Tanque lleno › Fin en 18:42	The tank is full; the rest goes down the drain
Low flow › To the drain	Flujo bajo › Al desague	Only a trickle is left, so it goes down the drain; saving starts again if the machine pumps out again
DONE: Reused 26 L › Saved 30 L	TERMINADO: Reusados 26 L › Guardados 30 L	Done: tank water used this wash, and rinse water stored for the next one
STOPPED: Cycle cancelled	DETENIDO: Ciclo cancelado	STOP was pressed

The small box at the top right of the screen shows how full the tank is: empty, half or full.

When something needs you

Screen	In Spanish	What to do
No water flow › Check washer › Call installer	Sin flujo › Revise lavadora › Pida ayuda	Check that the washing machine is running. If it is, press STOP and call your technician

Screen	In Spanish	What to do
INTERRUPTED: Check washer › Resume in app	INTERRUMPIDO: Revise lavadora › Reanude en app	The power went off during a wash. Check the machine. Then, within 30 minutes, open the app and tap **Reanudar ciclo** to continue where it stopped, or **No reanudar** and start again if needed
WASH STOPPED: Check tank › Call installer	LAVADO DETENIDO: Revise tanque › Pida ayuda	A tank wash stopped early. Call your technician
App: Check float switches	App: Revise los flotadores	The tank's float switches disagree, so tap water is used and nothing is saved. Call your technician
Blank screen	—	Check the power. If it stays blank, call your technician; the system keeps working without the screen

The app

On a phone connected to the home Wi-Fi, open **reusewater.local**. (Until firmware 3.1 it was *greywater.local*: update old bookmarks.)

- **Sign in once:** the first time, enter the password and leave **Recordar este dispositivo** on. The phone is not asked again. The door icon at the top signs out.
- **Overview:** what is happening now, Start and Stop, the tank, and Wash tank.
- **Water use:** how much water you have reused this month.
- **Refresh:** use it if the page looks stuck.
- **Settings → Language:** Español or English, for the app, the screen and the alerts.
- **View only:** if you signed in as **viewer**, you see only Overview and Water use and cannot change anything. Use the buttons on the controller, or ask the person with the admin sign-in.
- **Settings → Screen font:** four letter styles for the controller screen: Hyperlegible (default), Plain sans, Terminal bold, Schoolbook bold. Save, look at the screen, and keep the one you read best.

Phone alerts start with *Reuse Water:* (Spanish: *Reúso de Agua:*).

Technician: _____ Phone: _____

Installer commissioning checklist (firmware 3.11)

Firmware 3.0 has run correctly on the installed system. Firmware 3.1 adds the Spanish texts and the language setting. Firmware 3.2 renames the app to Reuse Water System, adds the start-up animation and a clearer screen font, and moves the optional buzzer from D12 to D1, on the same control logic. Firmware 3.3 makes the screen messages explain themselves in short pages and makes phone alerts more reliable. Complete these checks when installing or replacing a controller.

Hardware

- [ ] **Tap flow sensor position:** fitted on the machine's inlet, *after* the tap and tank lines join. The tank-water fill and the pump cut-off depend on it seeing the pump's water.
- [ ] **Flow sensor wiring:** Schottky diode (cathode to the sensor) and 10 kΩ pull-up to 3V3 on D2 and D3; no resistor divider.
- [ ] **Noise check:** with no water moving, the Service tab's pulse counts stay still for 2 minutes.
- [ ] **Signal level:** at D3 while turning the impeller, at least 2.8 V high and at most 0.5 V low.
- [ ] **Pump protection:** pressure switch or bypass to the tank fitted.
- [ ] **Tank-wash valve:** on D0, with a 10 kΩ resistor from D0 to GND.
- [ ] **Buzzer (optional):** active buzzer module, signal on **D1 (TX0)**, VCC on 3V3, GND on GND (it was on D12 until 3.1); switched on in Settings. A short chirp at power-on is normal.

First start

- [ ] **Start-up screen:** the dog chases the butterfly (about 4 s), then `REUSO DE AGUA` / Sistema listo for 2 s, then `LISTO`. START during the dog skips it.
- [ ] **Readability:** the bold messages can be read from where the household stands.
- [ ] **App address:** the app opens at **reusewater.local**; Service shows firmware 3.11.0.

First cycle (watch the Service tab)

- [ ] Screen shows `WASH 1 OF 4` with *Waiting to fill*, then *Reusing water* or *Using tap water*, then *Washing...*.
- [ ] The pump turns on when the machine draws water and off within about 0.3 s after it stops (*Recent events*: "Pump stopped: machine closed its inlet").
- [ ] Step 1 ends only when the wash drain starts, not before (*Machine filled* appears first).

- [ ] Step 4 saves water (*Filling tank › Ends in …*); the fill valve is on and the drain valve off in *Valves and pump*. When the pump-out ends, the screen shows *Low flow › To the drain* and the fill valve turns off within about 3 s.
- [ ] `DONE` shows the litres reused and saved; *Water use* shows the wash. With the buzzer on: two short beeps.

Firmware features (3.0 to 3.11)

- [ ] **Passwords:** the app asked for new passwords on first use, and both were changed.
- [ ] **Sign in once:** on the household's phones, sign in with *Recordar este dispositivo* on; close the browser and open the app again: it opens straight to Overview, with no password.
- [ ] **View-only user (if the household wants one):** Settings → Security → View-only user on, with its own password. In a private browser window, sign in as `viewer`: only Overview and Water use, with no Start, Stop or Wash tank.
- [ ] **Power cut and resume:** switch the controller off during step 1, after the machine has filled, and on again (leave the washer on). Expect the start-up animation, then `INTERRUMPIDO` › *Reanude en app*, an alert, and in the app the popup *¿Reanudar el ciclo interrumpido?*. Tap **Reanudar ciclo**: `REANUDADO`, step 1 continues and ends when the washer drains.
- [ ] **Updates:** during a cycle, *Wireless updates* reads Blocked; when Ready, Allowed now. The IDE lists the port as `reusewater`.
- [ ] **Alerts:** a private topic created, the phone subscribed, and the test alert received with the title *Reúso de Agua: …* (or *Reuse Water: …*). The topic uses only letters, numbers, - and _; tapping the alert opens the app.
- [ ] **Time zone:** chosen from the list; the clock on the badge is correct.
- [ ] **History backup:** *Download history file* saves a file.
- [ ] **Wi-Fi setup key:** hold STOP for 5 s at `READY`. The screen shows `ReuseWater-Setup` and a key like `gw-a1b2c3`, unique to this board; it is also printed over USB. Join the network with that key. The old shared password `greywater` works only if the screen is missing.
- [ ] **Screen messages:** during a wash the message changes every 3 seconds (for example *Draining › soapy water*); every part is readable and nothing is cut off. From the second wash a *min left* part appears.
- [ ] **Float switches:** with the low float down, hold the high float up for 5 s. Expect the alert *check level switches* and *Check float switches* in the app (and three long beeps with the buzzer on).
- [ ] **START press and hold:** a short press shows `REUSAR Y GUARDAR` and starts on release; held 2 s the screen changes to `SOLO REUSAR`. Put the label *START: pulse = Reusar y*

guardar · *mantenga 2 s* = *Solo reusar* on the panel.

- [ ] **Reuse only:** with water in the tank, start a wash with **Reuse only** in the app (or hold START 2 s). Step 4 shows `DESAGUE 4 DE 4` and *Sin guardar*, and Service shows the fill valve off; `TERMINADO` shows only the litres reused.
- [ ] **Screen font:** each of the four styles in Settings → Screen font changes the screen after Save; in each style every message has the same letter size and nothing is cut off; the household's choice is set before handover (after an upgrade from 3.5 the screen starts in Hyperlegible).
- [ ] **Language:** Settings → Language switches the app, the screen and the alerts; the household's language is set before handover.
- [ ] **Test alert:** the app reports *Test alert delivered* (or the reason it failed).

Accessibility

- [ ] Use the app with VoiceOver (iPhone) or TalkBack (Android): start a cycle, hear the step changes, stop it.

Checked by: _____ Date: _____