Reuse Water System – Quick Card

Keep this card next to the washing machine. The Reuse Water System (Spanish: *Sistema de Reúso de Agua*) reuses rinse water from your last wash to fill the next one.

The screen, the app and the phone alerts use the language chosen in the app (**Settings → Language**). Spanish is the default. This card gives the English text, with the Spanish screen text beside it.

When you switch it on

A dog chases a butterfly across the screen for about 4 seconds. Then the screen shows `REUSE WATER` / System ready (Spanish: `REUSO DE AGUA` / Sistema listo) for 2 seconds, then `READY`. Pressing START skips the dog.

Every wash

1. **Check the controller's screen** shows `READY` and *Start washer, › Press START* (Spanish: `LISTO`, *Inicie lavadora › y pulse START*).
2. **Start the washing machine program** as usual.
3. **Press the button labelled START** on the controller, or Start cycle in the app.
4. **Let it run.** The top line shows the step, `WASH 1 OF 4` to `SAVE 4 OF 4` (Spanish: `LAVADO 1 DE 4` to `AHORRO 4 DE 4`). After the first wash the screen also says about how many minutes are left.
5. **Done** when the screen shows `DONE` / *Wash finished* (Spanish: `TERMINADO` / *Lavado listo*) and the litres it reused and saved.

To cancel at any time, press the button labelled **STOP**, or Stop cycle in the app.

What the screen tells you

The screen has room for a few words, so a message comes in short parts that change every 3 seconds (shown here with ›). Wait for the next part to read the rest.

Screen	In Spanish	Meaning
A dog chasing a butterfly	(same)	The controller has just been switched on

Screen	In Spanish	Meaning
Start washer, › Press START › Tank: low / half / full	Inicie lavadora › y pulse START › Tanque: bajo / medio / lleno	Ready for a wash; how much water is saved in the tank
Waiting for › washer to fill	Esperando que › llene la lavadora	The washing machine has not started taking water yet
Reusing water › from the tank	Reusando agua › del tanque	The machine is filling with water saved in the tank
Filling washer › with tap water	Llenando con › agua de la llave	The machine is filling from the tap
Tank is low › Using tap water	Tanque bajo › Agua de la llave	Not enough water in the tank, so the tap is used
Washing... / Rinsing...	Lavando ropa / Enjuagando	The machine has filled and is working
25 min left	Faltan 25 min	About how long the wash still needs (learnt from earlier washes)
Soapy water › is not saved	Agua jabonosa › no se guarda	Soapy water goes down the drain, not into the tank
Saving rinse › water in tank › Ends in 18:42	Ahorrando agua › en el tanque › Fin en 18:42	Rinse water is stored for your next wash; the clock shows when the system finishes
Tank is full › Rest to drain	Tanque lleno › Ya no se guarda	The tank is full; the rest goes down the drain
Wash finished › Reused 26 L › Saved 30 L	Lavado listo › Reusados 26 L › Guardados 30 L	Done: tank water used this wash, and rinse water stored for the next one

The small box at the top right of the screen shows how full the tank is: empty, half or full.

When something needs you

Screen	In Spanish	What to do
No water flow › Is washer on? › If so: STOP › Call installer	Sin flujo › Revise lavadora › Si funciona, › pulse STOP y › pida ayuda	Check that the washing machine is running. If it is, press STOP and call your technician
INTERRUPTED / Wash cut short › Check washer › Start again	INTERRUMPIDO / Ciclo cortado › Revise lavadora › Inicie de nuevo	The power went off during a wash. Check the machine, then start again if needed
WASH STOPPED / Check the tank › Call installer	LAVADO DETENIDO / Revise tanque › Pida ayuda	A tank wash stopped early. Call your technician

Screen	In Spanish	What to do
App: Check float switches	App: Revise los flotadores	The tank's float switches disagree, so tap water is used and nothing is saved. Call your technician
Blank screen	—	Check the power. If it stays blank, call your technician; the system keeps working without the screen

The app

On a phone connected to the home Wi-Fi, open **reusewater.local**. (Until firmware 3.1 it was *greywater.local*: update old bookmarks.)

- **Overview:** what is happening now, Start and Stop, the tank, and Wash tank.
- **Water use:** how much water you have reused this month.
- **Refresh:** use it if the page looks stuck.
- **Settings → Language:** Español or English, for the app, the screen and the alerts.

Phone alerts start with *Reuse Water:* (Spanish: *Reúso de Agua:*).

Technician: _____ Phone: _____

Installer commissioning checklist (firmware 3.3)

Firmware 3.0 has run correctly on the installed system. Firmware 3.1 adds the Spanish texts and the language setting. Firmware 3.2 renames the app to Reuse Water System, adds the start-up animation and a clearer screen font, and moves the optional buzzer from D12 to D1, on the same control logic. Firmware 3.3 makes the screen messages explain themselves in short pages and makes phone alerts more reliable. Complete these checks when installing or replacing a controller.

Hardware

- [ ] **Tap flow sensor position:** fitted on the machine's inlet, *after* the tap and tank lines join. The tank-water fill and the pump cut-off depend on it seeing the pump's water.
- [ ] **Flow sensor wiring:** Schottky diode (cathode to the sensor) and 10 kΩ pull-up to 3V3 on D2 and D3; no resistor divider.
- [ ] **Noise check:** with no water moving, the Service tab's pulse counts stay still for 2 minutes.
- [ ] **Signal level:** at D3 while turning the impeller, at least 2.8 V high and at most 0.5 V low.
- [ ] **Pump protection:** pressure switch or bypass to the tank fitted.
- [ ] **Tank-wash valve:** on D0, with a 10 kΩ resistor from D0 to GND.
- [ ] **Buzzer (optional):** active buzzer module, signal on **D1 (TX0)**, VCC on 3V3, GND on GND (it was on D12 until 3.1); switched on in Settings. A short chirp at power-on is normal.

First start

- [ ] **Start-up screen:** the dog chases the butterfly (about 4 s), then `REUSO DE AGUA` / Sistema listo for 2 s, then `LISTO`. START during the dog skips it.
- [ ] **Readability:** the bold messages can be read from where the household stands.
- [ ] **App address:** the app opens at **reusewater.local**; Service shows firmware 3.3.1.

First cycle (watch the Service tab)

- [ ] Screen shows `WASH 1 OF 4` with *Waiting for › washer to fill*, then *Reusing water › from the tank* or *Filling washer › with tap water*, then *Washing…*.
- [ ] The pump turns on when the machine draws water and off within about 0.3 s after it stops (*Recent events*: "Pump stopped: machine closed its inlet").
- [ ] Step 1 ends only when the wash drain starts, not before (*Machine filled* appears first).

- [ ] Step 4 saves water (*Saving rinse › water in tank › Ends in …*); the fill valve is on and the drain valve off in *Valves and pump*.
- [ ] `DONE` shows *Wash finished* and the litres reused and saved; *Water use* shows the wash. With the buzzer on: two short beeps.

Firmware features (3.0 to 3.3)

- [ ] **Passwords:** the app asked for new passwords on first use, and both were changed.
- [ ] **Power cut:** switch the controller off during step 1 and on again. Expect the start-up animation, then `INTERRUPTED` on the screen, an alert, and the notice on Overview.
- [ ] **Updates:** during a cycle, *Wireless updates* reads Blocked; when Ready, Allowed now. The IDE lists the port as `reusewater`.
- [ ] **Alerts:** a private topic created, the phone subscribed, and the test alert received with the title *Reúso de Agua: …* (or *Reuse Water: …*). The topic uses only letters, numbers, - and _; tapping the alert opens the app.
- [ ] **Time zone:** chosen from the list; the clock on the badge is correct.
- [ ] **History backup:** *Download history file* saves a file.
- [ ] **Wi-Fi setup key:** hold STOP for 5 s at `READY`. The screen shows `ReuseWater-Setup` and a key like `gw-a1b2c3`, unique to this board; it is also printed over USB. Join the network with that key. The old shared password `greywater` works only if the screen is missing.
- [ ] **Screen messages:** during a wash the message changes every 3 seconds (for example *Reusing water › from the tank*); every part is readable and nothing is cut off. From the second wash a *min left* part appears.
- [ ] **Float switches:** with the low float down, hold the high float up for 5 s. Expect the alert *check level switches* and *Check float switches* in the app (and three long beeps with the buzzer on).
- [ ] **Language:** Settings → Language switches the app, the screen and the alerts; the household's language is set before handover.
- [ ] **Test alert:** the app reports *Test alert delivered* (or the reason it failed).

Accessibility

- [ ] Use the app with VoiceOver (iPhone) or TalkBack (Android): start a cycle, hear the step changes, stop it.

Checked by: _____ Date: _____