

AeroMorse — Keycode Reference

Every valid `Keycode.NAME` for `morse_map.py` · from `adafruit_hid` (CircuitPython 9.x)

Names are case-sensitive — `PAGE_UP` works, `Page_Up` does not. The AeroMorse validator warns on any name not listed here.

```
# one key
g1[3][0b101] = Keycode.K
# a chord (Ctrl+C) — use a tuple
g2[4][0b0001] = (Keycode.LEFT_CONTROL, Keycode.C)
# to TYPE a character, use a string instead of a Keycode
g3[2][0b01] = "hello"
```

Letters

A	B	C	D	E	F	G	H
I	J	K	L	M	N	O	P
Q	R	S	T	U	V	W	X
Y	Z						

Number keys (words, not digits)

ONE	TWO	THREE	FOUR
FIVE	SIX	SEVEN	EIGHT
NINE	ZERO		

`ONE` presses the “1” key. To type “1”, use the string “1”.

Whitespace & editing

ENTER	RETURN	ESCAPE
BACKSPACE	TAB	SPACEBAR
SPACE	DELETE	INSERT
CAPS_LOCK		

Navigation

UP_ARROW	DOWN_ARROW	
LEFT_ARROW	RIGHT_ARROW	
HOME	END	PAGE_UP
PAGE_DOWN		

Punctuation keys

MINUS	-
EQUALS	=
LEFT_BRACKET	[
RIGHT_BRACKET	]
BACKSLASH	\
SEMICOLON	;
QUOTE	'
GRAVE_ACCENT	`
COMMA	,
PERIOD	.
FORWARD_SLASH	/
POUND	# (non-US)

Locks & system

CAPS_LOCK	SCROLL_LOCK
PRINT_SCREEN	PAUSE
APPLICATION	(menu key)
POWER	

Function keys

F1	F2	F3	F4	F5	F6
F7	F8	F9	F10	F11	
F12	F13	F14	F15	F16	
F17	F18	F19	F20	F21	
F22	F23	F24			

Group 4 uses F1–F12. F13–F24 exist but most PCs ignore them.

Number-pad (keypad)

KEYPAD_NUMLOCK	KEYPAD_ONE
KEYPAD_TWO	KEYPAD_THREE
KEYPAD_FOUR	KEYPAD_FIVE
KEYPAD_SIX	KEYPAD_SEVEN
KEYPAD_EIGHT	KEYPAD_NINE
KEYPAD_ZERO	KEYPAD_PERIOD
KEYPAD_PLUS	KEYPAD_MINUS
KEYPAD_ASTERISK	
KEYPAD_FORWARD_SLASH	
KEYPAD_ENTER	
KEYPAD_EQUALS	
KEYPAD_BACKSLASH	

Modifiers (for chords)

- LEFT_CONTROL = CONTROL
- RIGHT_CONTROL
- LEFT_SHIFT = SHIFT
- RIGHT_SHIFT
- LEFT_ALT = ALT = OPTION
- RIGHT_ALT
- LEFT_GUI = GUI = WINDOWS =
- COMMAND
- RIGHT_GUI

GUI = the  Windows key (
Command on Mac).

Shifted symbols have no Keycode of their own. Characters like : { } " ? < > + _ ! @ # aren't separate keys — they're **Shift + another key**. So there is no COLON or LEFT_BRACE — nothing is missing. Easiest fix: just **type the character as a string** (= ":") and code.py presses Shift for you. Or use a Shift chord, e.g. (Keycode.LEFT_SHIFT, Keycode.SEMICOLON) for :.

Symbol	Shift +	Symbol	Shift +	Symbol	Shift +
:	SEMICOLON	_	MINUS	!	ONE
"	QUOTE	+	EQUALS	@	TWO
{	LEFT_BRACKET		BACKSLASH	#	THREE
}	RIGHT_BRACKET	~	GRAVE_ACCENT	\$	FOUR
<	COMMA	?	FORWARD_SLASH	%	FIVE
>	PERIOD	^	SIX	&	SEVEN
*	EIGHT	(	NINE	)	ZERO

Gotchas

- The space key is SPACEBAR (SPACE also works).
- Number keys are words: ONE ... ZERO , never Keycode.1 .
- ENTER = RETURN ; the modifier aliases above are the same key.
- Case-sensitive and all-caps: it's LEFT_CONTROL , never Left_Control .
- To type text (letters, digits, words, passwords) use a **string** value — Keycodes are for pressing keys (Enter, arrows, F-keys, chords).

Source: adafruit_hid/keycode.py — CircuitPython 9.x bundle, the version on the AeroMorse devices. Regenerate if you upgrade adafruit_hid .