TRANSFER (VF3AM) SST (Special Service Tools)

PP1ZO-02

09223-15020	Oil Seal & Bearing Replacer	Planetary gear outer bearing
09304-12012	Input Shaft Front Bearing Replacer	Shift fork shaft oil seal
09316-6001 1	Transmission & Transfer Bearing Replacer	
(09316-00011)	Replacer Pipe	Output shaft radial ball bearing Front case oil seal
(09316-00071)	Replacer "F"	Output shaft radial ball bearing
09330-00021	Companion Flange Holding Tool	Companion flange
09515-30010	Rear Wheel Bearing Replacer	Planetary gear outer bearing
09554-22010	Differential Oil Seal Replacer	Extension housing oil seal
09554-3001 1	Differential Oil Seal Replacer	Planetary gear outer bearing
09555-55010	Differential Drive Pinion Bearing Replacer	Driven sprocket rear bearing Planetary gear outer bearing
09612-65014	Steering Worm Bearing Puller	
(09612-01030)	Claw "C"	Planetary gear inner bearing

2002 4RUNNER (RM887U)

Author: Date: 80

	(09612-01050)	Hanger Pin with Nut	Planetary gear inner bearing
	09950-00020	Bearing Remover	Output shaft radial ball bearing
	09950-00030	Bearing Remover Attachment	Output shaft radial ball bearing
	09950-4001 1	Puller B Set	
	(09951-04020)	Hanger 200	Companion flange
	(09952-04010)	Slide Arm	Companion flange
	(09953-04030)	Center Bolt 200	Companion flange
	(09954-04010)	Arm 25	Companion flange
	(09955-04051)	Claw No.5	Companion flange
٨	(09957-04010)	Attachment	Companion flange Output shaft radial ball bearing
	(09958-04011)	Holder	Companion flange
	09950-60010	Replacer Set	
9	(09951-00220)	Replacer 22	Companion flange oil seal

2002 4RUNNER (RM887U)

Author: Date: 81

9	(09951-00350)	Replacer 35	Companion flange oil seal
6	(09951-00570)	Replacer 57	Planetary gear inner bearing
6	(09951-00590)	Replacer 59	Case cover oil seal
	(09952-06010)	Adapter	Companion flange oil seal
	09950-70010	Handle Set	
	(09951-07100)	Handle 100	Case cover oil seal Planetary gear outer bearing Planetary gear inner bearing Companion flange oil seal

Author: Date: 82