GENERATOR

COMPONENTS

CH00F-03

Generator Connector

Generator Wire

Adjusting Bolt

Pivot Bolt

Lock Nut

Drive Belt

Generator

S02091

Retainer

Rear Bearing

Drive End Frame (Starter)

Pulley

Front Bearing

Bearing Cover (inside)

Rotor

Bearing Cover (outside)

Rear End Cover

Brush

Voltage Regulator

Rubber Insulator x4

Spring

Brush Holder Cover

Generator Washer

Rectifier Holder

Brush Holder

Rectifier End Frame

Terminal Insulator

S05685