J	L
Jack	Lane Tracing Assist (LTA) 270
Positioning the jack459	Language (multi-
Vehicle-equipped jack544	information display) 107, 124
Jack handle544	LATCH anchors 69
Jam protection function	Lever
Moon roof184	Auxiliary catch lever 457
Panoramic moon roof 188	Hood lock release lever 457
Power window180	Internal trunk release lever 158
	Shift lever217
K	Tilt and telescopic steering
Keyless entry	lock release lever 173
Smart key system 147, 156	Turn signal lever223
Wireless remote	Wiper lever 240
control148, 157	License plate lights
Keys140	Light switch231
Battery-saving function 163	Replacing light bulbs 512
Electronic key140	Light bulbs
Engine switch209, 211	Replacing502
If the electronic key does	Wattage 589
not operate properly559	Lights
If you lose your keys144	Automatic High Beam
Key number plate140	Headlight switch
Keyless entry141	Illuminated entry system 408
Mechanical key142	Interior lights
Replacing the battery494	Interior lights list
Warning buzzer162	Personal lights
Wireless remote control 141	Replacing light bulbs 502
Knee airbags36	Trunk light
	Turn signal lever
	Vanity lights
	Wattage
	Load capacity 206 Lock steering column
	LTA (Lane Tracing Assist) 270
	LIA (Lane Hacing Assist) 210

^{*:} Refer to the "NAVIGATION AND MULTIMEDIA SYSTEM OWNER'S MANUAL".