■When the moon roof does not close normally

Perform the following procedure:

●If the moon roof closes but then re-opens slightly

1 Stop the vehicle.

2 Press and hold the "CLOSE" switch.[1]
The moon roof will close, reopen and pause for approximately 10 seconds.[2] Then it will close again, tilt up and pause for approximately 1 second. Finally, it will tilt down, open and close.

3 Check to make sure that the moon roof is completely closed and then release the switch.

●If the moon roof tilts down but then tilts back up

1 Stop the vehicle.

2 Press and hold the "UP" switch[1] until the moon roof moves into the tilt up position and stops.

3 Release the "UP" switch once and then press and hold the "UP" switch again.[1]

The moon roof will pause for approximately 10 seconds in the tilt up position.[2] Then it will adjust slightly and pause for approximately 1 second. Finally, it will tilt down, open and close.

4 Check to make sure that the moon roof is completely closed and then release the switch.

[1]: If the switch is released at the incorrect time, the procedure will have to be performed again from the beginning.

[2]: If the switch is released after the above mentioned 10 second pause, automatic operation will be disabled. In that case, press and hold the "CLOSE" or "UP" switch, and the moon roof will tilt up and pause for approximately 1 second. Then it will tilt down, open and close. Check to make sure that the moon roof is completely closed and then release the switch.

If the moon roof does not fully close even after performing the above procedure correctly, have the vehicle inspected by your Toyota dealer.

■Alarm
The alarm may be triggered if the alarm is set and the moon roof is closed using the door lock linked moon roof operation function. (→P. 83)

■Moon roof open warning buzzer
A buzzer sounds and a message is shown on the multi-information display in the instrument cluster when the engine switch is turned off and the driver's door is opened with the moon roof open.

■Customization
Some functions can be customized. (→P. 606)

3

Operation of each component